

## Benz\_V01.15 Diag Function List (Note:For reference only)

**NOTES:**

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Chassis	Model year	System Name	EcuInfo.	ReadCodes	EraseCode	LiveData
A-Class	168	ALL	ECM-Engine control monolith	●	●	●	●
A-Class	168	ALL	ACS-Automatic clutch system	●	●	●	●
A-Class	168	ALL	FTC-Front transmission control	●	●	●	●
A-Class	168	ALL	FTC2 -Front transmission control2	●	●	●	●
A-Class	168	ALL	GRM-Gear recognition module	●	●	●	●
A-Class	168	ALL	CDI-Common Rail Diesel Injection	●	●	●	●
A-Class	168	ALL	ESP-Electronic stability program	●	●	●	●
A-Class	168	ALL	ESP-Electronic stability program	●	●	●	●
A-Class	168	ALL	AB-Airbag	●	●	●	●
A-Class	168	ALL	AB-Airbag	●	●	●	●
A-Class	168	ALL	RFL-Radio frequency locking/electric central locking	●	●	●	●
A-Class	168	ALL	LCP-Lower control panel	●	●	●	●
A-Class	168	ALL	ATA-Anti-theft alarm system	●	●	●	●
A-Class	168	ALL	APS-Auto pilot system	●	●	●	●
A-Class	168	ALL	HB-Heater booster	●	●	●	●
A-Class	168	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
A-Class	168	ALL	AUDIO	●	●	●	●
A-Class	168	ALL	CTEL- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
A-Class	168	ALL	CDC-CD changer	●	●	●	●
A-Class	168	ALL	PTS-Parktronic system	●	●	●	●
A-Class	168	ALL	DCM-FL-Door control module front left	●	●	●	●
A-Class	168	ALL	DCM-FR-Door control module front right	●	●	●	●
A-Class	168	ALL	DCM-RL-Door control module rear left	●	●	●	●
A-Class	168	ALL	DCM-RR-Door control module rear right	●	●	●	●
A-Class	168	ALL	STH-Stationary heater	●	●	●	●
A-Class	168	ALL	TAC-Automatic temperature control	●	●	●	●
A-Class	169	Up to 11/2005	ESM-Electronic selector module	●	●	●	●
A-Class	169	Up to 11/2005	FCVT-Continuously variable automatic transmission	●	●	●	●
A-Class	169	Up to 11/2005	ME-SFI-Gasoline engine control	●	●	●	●
A-Class	169	Up to 11/2005	CDI-Common Rail Diesel Injection	●	●	●	●
A-Class	169	Up to 11/2005	ES-Electrical power steering	●	●	●	●
A-Class	169	Up to 11/2005	ESP-Electronic stability program	●	●	●	●
A-Class	169	Up to 11/2005	CGW-Central gateway	●	●	●	●
A-Class	169	Up to 11/2005	EZS-Electronic ignition switch	●	●	●	●
A-Class	169	Up to 11/2005	AB-Airbag	●	●	●	●
A-Class	169	Up to 11/2005	OCP-Overhead control panel	●	●	●	●

A-Class	169	Up to 11/2005	ATA-Anti-theft alarm system	●	●	●	●
A-Class	169	Up to 11/2005	SAM-Signal acquisition and actuation module	●	●	●	●
A-Class	169	Up to 11/2005	AHE-Trailer recognition	●	●	●	●
A-Class	169	Up to 11/2005	MSS-Special vehicle multifunction control module	●	●	●	●
A-Class	169	Up to 11/2005	MSS-Special vehicle multifunction control module	●	●	●	●
A-Class	169	Up to 11/2005	HRA-FR-Front right headlamp range control	●	●	●	●
A-Class	169	Up to 11/2005	HRA-FL-Front left headlamp range control	●	●	●	●
A-Class	169	Up to 11/2005	System diagnosis (CAN)	●	●	●	●
A-Class	169	Up to 11/2005	SCM [MRM]-Steering column module	●	●	●	●
A-Class	169	Up to 11/2005	PTS-Parktronic system	●	●	●	●
A-Class	169	Up to 11/2005	IC-Instrument cluster	●	●	●	●
A-Class	169	Up to 11/2005	ASSYST-Active Service System	●	●	●	●
A-Class	169	Up to 11/2005	ASSYST PLUS-PLUS Active Service System	●	●	●	●
A-Class	169	Up to 11/2005	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
A-Class	169	Up to 11/2005	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
A-Class	169	Up to 11/2005	AGW-Audio gateway or Audio 20 with CD drive	●	●	●	●
A-Class	169	Up to 11/2005	AUDIO	●	●	●	●
A-Class	169	Up to 11/2005	COMAND or AUDIO	●	●	●	●
A-Class	169	Up to 11/2005	CTEL-Mobile phone adapter with universal interface	●	●	●	●
A-Class	169	Up to 11/2005	CDC-CD changer	●	●	●	●
A-Class	169	Up to 11/2005	VCS-Voice control system	●	●	●	●
A-Class	169	Up to 11/2005	SOUND- Sound system	●	●	●	●
A-Class	169	Up to 11/2005	CTEL-Cellular telephone	●	●	●	●
A-Class	169	Up to 11/2005	DCM-FL-Door control module front left	●	●	●	●
A-Class	169	Up to 11/2005	DCM-FR-Door control module front right	●	●	●	●
A-Class	169	Up to 11/2005	DCM-RL-Door control module rear left	●	●	●	●
A-Class	169	Up to 11/2005	DCM-RR-Door control module rear right	●	●	●	●
A-Class	169	Up to 11/2005	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●
A-Class	169	As of 12/2005	ESM-Electronic selector module	●	●	●	●
A-Class	169	As of 12/2005	FCVT-Continuously variable automatic transmission	●	●	●	●

A-Class	169	As of 12/2005	ME-SFI-Gasoline engine control	●	●	●	●
A-Class	169	As of 12/2005	TV-TV tuner	●	●	●	●
A-Class	169	As of 12/2005	CDI-Common Rail Diesel Injection	●	●	●	●
A-Class	169	As of 12/2005	CDI-Common Rail Diesel Injection	●	●	●	●
A-Class	169	As of 12/2005	N93/4 (Vehicle gateway control unit)	●	●	●	●
A-Class	169	As of 12/2005	ES-Electrical power steering	●	●	●	●
A-Class	169	As of 12/2005	ESP-Electronic stability program	●	●	●	●
A-Class	169	As of 12/2005	CGW-Central gateway	●	●	●	●
A-Class	169	As of 12/2005	EZS-Electronic ignition switch	●	●	●	●
A-Class	169	As of 12/2005	AB-Airbag	●	●	●	●
A-Class	169	As of 12/2005	OCP-Overhead control panel	●	●	●	●
A-Class	169	As of 12/2005	ATA-Anti-theft alarm system	●	●	●	●
A-Class	169	As of 12/2005	SAM-Signal acquisition and actuation module	●	●	●	●
A-Class	169	As of 12/2005	AHE-Trailer recognition	●	●	●	●
A-Class	169	As of 12/2005	MSS-Special vehicle multifunction control module	●	●	●	●
A-Class	169	As of 12/2005	MSS-Special vehicle multifunction control module	●	●	●	●
A-Class	169	As of 12/2005	HRA-FR-Front right headlamp range control	●	●	●	●
A-Class	169	As of 12/2005	HRA-FL-Front left headlamp range control	●	●	●	●
A-Class	169	As of 12/2005	System diagnosis (CAN)	●	●	●	●
A-Class	169	As of 12/2005	SCM [MRM]-Steering column module	●	●	●	●
A-Class	169	As of 12/2005	PTS-Parktronic system	●	●	●	●
A-Class	169	As of 12/2005	IC-Instrument cluster	●	●	●	●
A-Class	169	As of 12/2005	ASSYST-Active Service System	●	●	●	●
A-Class	169	As of 12/2005	ASSYST PLUS-PLUS Active Service System	●	●	●	●
A-Class	169	As of 12/2005	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
A-Class	169	As of 12/2005	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
A-Class	169	As of 12/2005	AGW-Audio gateway or Audio 20 with CD drive	●	●	●	●
A-Class	169	As of 12/2005	AUDIO	●	●	●	●
A-Class	169	As of 12/2005	COMAND or AUDIO	●	●	●	●
A-Class	169	As of 12/2005	CTEL-Mobile phone adapter with universal interface	●	●	●	●

A-Class	169	As of 12/2005	CDC-CD changer	●	●	●	●
A-Class	169	As of 12/2005	VCS-Voice control system	●	●	●	●
A-Class	169	As of 12/2005	SOUND- Sound system	●	●	●	●
A-Class	169	As of 12/2005	CTEL-Cellular telephone	●	●	●	●
A-Class	169	As of 12/2005	PTS-Parktronic system	●	●	●	●
A-Class	169	As of 12/2005	COMAND or AUDIO	●	●	●	●
A-Class	169	As of 12/2005	Sound system (Main amplifier)	●	●	●	●
A-Class	169	As of 12/2005	UCI-Media interface	●	●	●	●
A-Class	169	As of 12/2005	DAB-Digital radio	●	●	●	●
A-Class	169	As of 12/2005	SDAR-Satellite radio(Valid for USA)	●	●	●	●
A-Class	169	As of 12/2005	CTEL-Cellular telephone (JAPAN)	●	●	●	●
A-Class	169	As of 12/2005	DCM-FL-Door control module front left	●	●	●	●
A-Class	169	As of 12/2005	DCM-FR-Door control module front right	●	●	●	●
A-Class	169	As of 12/2005	DCM-RL-Door control module rear left	●	●	●	●
A-Class	169	As of 12/2005	DCM-RR-Door control module rear right	●	●	●	●
A-Class	169	As of 12/2005	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●
A-Class	169	As of 12/2005	EKMK-Electric refrigerant compressor (A9/5)	●	●	●	●
A-Class	169	As of 12/2005	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●
A-Class	176	ALL	PTCU-Common powertrain controller (N127)	●	●	●	●
A-Class	176	ALL	PTCU-Common powertrain controller (N127)	●	●	●	●
A-Class	176	ALL	ME-Motor electronics 'MED40' for combustion engine' M270' (N3/10)	●	●	●	●
A-Class	176	ALL	ME-Motor electronics 'MED40AMG' for combustion engine' M133' (N3/10)	●	●	●	●
A-Class	176	ALL	FSCU-Fuel pump	●	●	●	●
A-Class	176	ALL	FSCU-Fuel pump	●	●	●	●
A-Class	176	ALL	mbrace-mbrace (N123/4)	●	●	●	●
A-Class	176	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
A-Class	176	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
A-Class	176	ALL	CDI-Motor electronics 'CRR1' for combustion engine' OM607' (N3/9)	●	●	●	●
A-Class	176	ALL	ES-Electrical power steering (N68)	●	●	●	●
A-Class	176	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
A-Class	176	ALL	EFB-Electronic parking break (N128)	●	●	●	●
A-Class	176	ALL	DTR-DISTRONIC (A89)	●	●	●	●
A-Class	176	ALL	DTR-DISTRONIC (A89)	●	●	●	●
A-Class	176	ALL	TPM-Tire pressure monitor	●	●	●	●

A-Class	176	ALL	EZS-Electronic ignition switch	●	●	●	●
A-Class	176	ALL	SAM-Signal acquisition and actuation module (N10)	●	●	●	●
A-Class	176	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
A-Class	176	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
A-Class	176	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
A-Class	176	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
A-Class	176	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
A-Class	176	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
A-Class	176	ALL	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
A-Class	176	ALL	SCM-Steering column module(N80)	●	●	●	●
A-Class	176	ALL	Trailer recognition module-Trailer recognition (N28/1)	●	●	●	●
A-Class	176	ALL	PSD-Control module 'Panoramic sliding roof (A98)'	●	●	●	●
A-Class	176	ALL	ATA-ATA[EDW]/tow-away protection/interiorprotection (N26/6)	●	●	●	●
A-Class	176	ALL	IC-Instrument cluster (A1)	●	●	●	●
A-Class	176	ALL	IC-Instrument cluster (A1)	●	●	●	●
A-Class	176	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
A-Class	176	ALL	COU [ZBE]-Central operating unit	●	●	●	●
A-Class	176	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
A-Class	176	ALL	DAB-Digital radio	●	●	●	●
A-Class	176	ALL	DKG-Electronic transmission control for double-plateclutch transmission (N15/13)	●	●	●	●
A-Class	176	ALL	ZAN-Central display	●	●	●	●
A-Class	176	ALL	DSI-DIRECT SELECT interface (N150)	●	●	●	●
A-Class	176	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
A-Class	176	ALL	MFK-Multifunction camera	●	●	●	●
A-Class	176	ALL	NAV-Navigation module (A2/30)	●	●	●	●
A-Class	176	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
A-Class	176	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
A-Class	176	ALL	SOUND - Sound system(N40/3)	●	●	●	●
A-Class	176	ALL	Sound system (Main amplifier)	●	●	●	●
A-Class	176	ALL	TV-TV tuner (AGW)	●	●	●	●
A-Class	176	ALL	UCI-Media interface	●	●	●	●
A-Class	176	ALL	Audio-Audio 5 USB (A2)	●	●	●	●
A-Class	176	ALL	DCU-LF-Left front door (N69/1)	●	●	●	●
A-Class	176	ALL	DCU-RF-Right front door (N69/2)	●	●	●	●
A-Class	176	ALL	ESA 'Driver'-Electrical seat adjustment 'Driver' withmemory function (N32/1)	●	●	●	●
A-Class	176	ALL	ESA' Front passenger'-Electric seat adjustment 'Frontpassenger' with memory function (N32/2)	●	●	●	●
A-Class	176	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
A-Class	176	ALL	STH-Stationary heater (A6n1)	●	●	●	●
A-Class	176	ALL	UCP-Upper control panel (N72/1)	●	●	●	●

A-Class	176	ALL	BSN-Battery sensor (B95)	●	●	●	●
A-Class	176	ALL	AISP-Dimming inside rearview mirror (A67)	●	●	●	●
A-Class	176	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
A-Class	176	ALL	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	●	●	●	●
A-Class	176	ALL	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	●	●	●	●
A-Class	176	ALL	RGLS-Rain/light sensor (B38/2)	●	●	●	●
A-Class	176	ALL	OCP-Control unit 'Overhead control panel' (N70)	●	●	●	●
A-Class	176	ALL	AS-Alarm siren(H3/1)	●	●	●	●
AMG	190	ALL	EZS-Electronic ignition lock	●	●	●	●
AMG	190	ALL	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●
AMG	190	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
AMG	190	ALL	SG-SW-Control unit 'Headlamp'	●	●	●	●
AMG	190	ALL	KG-Keyless Go	●	●	●	●
AMG	190	ALL	SCM-Steering column module	●	●	●	●
AMG	190	ALL	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●
AMG	190	ALL	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●
AMG	190	ALL	PTCU-Common powertrain controller	●	●	●	●
AMG	190	ALL	AC-Air conditioning	●	●	●	●
AMG	190	ALL	FSCU-Fuel pump	●	●	●	●
AMG	190	ALL	ECM-Engine control monolith	●	●	●	●
AMG	190	ALL	ADS-Adaptive damping system	●	●	●	●
AMG	190	ALL	EFB-Electronic parking brake	●	●	●	●
AMG	190	ALL	ESP-Electronic stability program	●	●	●	●
AMG	190	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
AMG	190	ALL	PTS-PARKTRONIC	●	●	●	●
AMG	190	ALL	MFK-Multifunction camera	●	●	●	●
AMG	190	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
AMG	190	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem	●	●	●	●
AMG	190	ALL	DTR-DISTRONIC	●	●	●	●
AMG	190	ALL	IC-Instrument cluster	●	●	●	●
AMG	190	ALL	SRS-Supplemental restraint system	●	●	●	●
AMG	190	ALL	mbrace-mbrace	●	●	●	●
AMG	190	ALL	COU [ZBE]-Central operating unit	●	●	●	●
AMG	190	ALL	DAB-Digital radio	●	●	●	●
AMG	190	ALL	ZAN-Central display	●	●	●	●
AMG	190	ALL	TV-TV tuner(AGW)	●	●	●	●
AMG	190	ALL	TPAD-Touchpad	●	●	●	●
AMG	190	ALL	DCU-LF-Left front door	●	●	●	●
AMG	190	ALL	DCU-RF-Right front door	●	●	●	●
AMG	190	ALL	ESA 'Driver'-Electric seat adjustment 'Driver'	●	●	●	●
AMG	190	ALL	ESA' Front passenger'-Electric seat adjustment 'Frontpassenger'	●	●	●	●
B-Class	245	Up to 11/2005	ESM-Electronic selector module	●	●	●	●

B-Class	245	Up to 11/2005	FCVT-Continuously variable automatic transmission	●	●	●	●
B-Class	245	Up to 11/2005	ME-SFI-Gasoline engine control	●	●	●	●
B-Class	245	Up to 11/2005	CDI-Common Rail Diesel Injection	●	●	●	●
B-Class	245	Up to 11/2005	ES-Electrical power steering	●	●	●	●
B-Class	245	Up to 11/2005	ESP-Electronic stability program	●	●	●	●
B-Class	245	Up to 11/2005	CGW-Central gateway	●	●	●	●
B-Class	245	Up to 11/2005	EZS-Electronic ignition switch	●	●	●	●
B-Class	245	Up to 11/2005	AB-Airbag	●	●	●	●
B-Class	245	Up to 11/2005	OCP-Overhead control panel	●	●	●	●
B-Class	245	Up to 11/2005	ATA-Anti-theft alarm system	●	●	●	●
B-Class	245	Up to 11/2005	SAM-Signal acquisition and actuation module	●	●	●	●
B-Class	245	Up to 11/2005	AHE-Trailer recognition	●	●	●	●
B-Class	245	Up to 11/2005	MSS-Special vehicle multifunction control module	●	●	●	●
B-Class	245	Up to 11/2005	MSS-Special vehicle multifunction control module	●	●	●	●
B-Class	245	Up to 11/2005	XALWA-L-Xenon headlamp, left	●	●	●	●
B-Class	245	Up to 11/2005	XALWA-R-Xenon headlamp, right	●	●	●	●
B-Class	245	Up to 11/2005	System diagnosis (CAN)	●	●	●	●
B-Class	245	Up to 11/2005	SCM [MRM]-Steering column module	●	●	●	●
B-Class	245	Up to 11/2005	CM-Compass module	●	●	●	●
B-Class	245	Up to 11/2005	PTS-Parktronic system	●	●	●	●
B-Class	245	Up to 11/2005	IC-Instrument cluster	●	●	●	●
B-Class	245	Up to 11/2005	ASSYST-Active Service System	●	●	●	●
B-Class	245	Up to 11/2005	ASSYST PLUS-PLUS Active Service System	●	●	●	●
B-Class	245	Up to 11/2005	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
B-Class	245	Up to 11/2005	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
B-Class	245	Up to 11/2005	AGW-Audio gateway or Audio 20 with CD drive	●	●	●	●
B-Class	245	Up to 11/2005	AUDIO	●	●	●	●
B-Class	245	Up to 11/2005	COMAND or AUDIO	●	●	●	●
B-Class	245	Up to 11/2005	CTEL-Mobile phone adapter with universal interface	●	●	●	●
B-Class	245	Up to 11/2005	CDC-CD changer	●	●	●	●

B-Class	245	Up to 11/2005	VCS-Voice control system	●	●	●	●
B-Class	245	Up to 11/2005	SOUND- Sound system	●	●	●	●
B-Class	245	Up to 11/2005	SDAR-Satellite radio	●	●	●	●
B-Class	245	Up to 11/2005	NAVI-Navigation system	●	●	●	●
B-Class	245	Up to 11/2005	CTEL-Cellular telephone	●	●	●	●
B-Class	245	Up to 11/2005	TELE AID-Control unit	●	●	●	●
B-Class	245	Up to 11/2005	TELE AID-Telematic services Emergency call	●	●	●	●
B-Class	245	Up to 11/2005	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
B-Class	245	Up to 11/2005	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
B-Class	245	Up to 11/2005	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
B-Class	245	Up to 11/2005	DCM-FL-Door control module front left	●	●	●	●
B-Class	245	Up to 11/2005	DCM-FR-Door control module front right	●	●	●	●
B-Class	245	Up to 11/2005	DCM-RL-Door control module rear left	●	●	●	●
B-Class	245	Up to 11/2005	DCM-RR-Door control module rear right	●	●	●	●
B-Class	245	Up to 11/2005	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●
B-Class	245	As of 12/2005	ESM-Electronic selector module	●	●	●	●
B-Class	245	As of 12/2005	FCVT-Continuously variable automatic transmission	●	●	●	●
B-Class	245	As of 12/2005	ME-SFI-Gasoline engine control	●	●	●	●
B-Class	245	As of 12/2005	ME-SFI-Motor electronics	●	●	●	●
B-Class	245	As of 12/2005	ME-SFI-CNG compressed natural gas	●	●	●	●
B-Class	245	As of 12/2005	BSA-Belt-driven starter/alternator	●	●	●	●
B-Class	245	As of 12/2005	TV-TV tuner	●	●	●	●
B-Class	245	As of 12/2005	CDI-Common Rail Diesel Injection	●	●	●	●
B-Class	245	As of 12/2005	CDI-Common Rail Diesel Injection	●	●	●	●
B-Class	245	As of 12/2005	N93/4 (Vehicle gateway control unit)	●	●	●	●
B-Class	245	As of 12/2005	ES-Electrical power steering	●	●	●	●
B-Class	245	As of 12/2005	ESP-Electronic stability program	●	●	●	●
B-Class	245	As of 12/2005	VP-Vacuum pump brake booster	●	●	●	●
B-Class	245	As of 12/2005	TPC-Tire pressure monitor	●	●	●	●
B-Class	245	As of 12/2005	CGW-Central gateway	●	●	●	●



B-Class	245	As of 12/2005	EZS-Electronic ignition switch	●	●	●	●
B-Class	245	As of 12/2005	AB-Airbag	●	●	●	●
B-Class	245	As of 12/2005	OCP-Overhead control panel	●	●	●	●
B-Class	245	As of 12/2005	ATA-Anti-theft alarm system	●	●	●	●
B-Class	245	As of 12/2005	SAM-Signal acquisition and actuation module	●	●	●	●
B-Class	245	As of 12/2005	AHE-Trailer recognition	●	●	●	●
B-Class	245	As of 12/2005	MSS-Special vehicle multifunction control module	●	●	●	●
B-Class	245	As of 12/2005	MSS-Special vehicle multifunction control module	●	●	●	●
B-Class	245	As of 12/2005	XALWA-L-Xenon headlamp, left	●	●	●	●
B-Class	245	As of 12/2005	XALWA-R-Xenon headlamp, right	●	●	●	●
B-Class	245	As of 12/2005	System diagnosis (CAN)	●	●	●	●
B-Class	245	As of 12/2005	WSS-Weight sensing system	●	●	●	●
B-Class	245	As of 12/2005	SCM [MRM]-Steering column module	●	●	●	●
B-Class	245	As of 12/2005	CM-Compass module	●	●	●	●
B-Class	245	As of 12/2005	PTS-Parktronic system	●	●	●	●
B-Class	245	As of 12/2005	PTS-Parktronic system	●	●	●	●
B-Class	245	As of 12/2005	IC-Instrument cluster	●	●	●	●
B-Class	245	As of 12/2005	ASSYST-Active Service System	●	●	●	●
B-Class	245	As of 12/2005	ASSYST PLUS-PLUS Active Service System	●	●	●	●
B-Class	245	As of 12/2005	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
B-Class	245	As of 12/2005	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
B-Class	245	As of 12/2005	AGW-Audio gateway or Audio 20 with CD drive	●	●	●	●
B-Class	245	As of 12/2005	AUDIO	●	●	●	●
B-Class	245	As of 12/2005	COMAND or AUDIO	●	●	●	●
B-Class	245	As of 12/2005	CTEL-Mobile phone adapter with universal interface	●	●	●	●
B-Class	245	As of 12/2005	CDC-CD changer	●	●	●	●
B-Class	245	As of 12/2005	VCS-Voice control system	●	●	●	●
B-Class	245	As of 12/2005	SOUND- Sound system	●	●	●	●
B-Class	245	As of 12/2005	SDAR-Satellite radio	●	●	●	●
B-Class	245	As of 12/2005	NAVI-Navigation system	●	●	●	●

B-Class	245	As of 12/2005	CTEL-Cellular telephone	●	●	●	●
B-Class	245	As of 12/2005	TELE AID-Control unit	●	●	●	●
B-Class	245	As of 12/2005	TELE AID-Telematic services Emergency call	●	●	●	●
B-Class	245	As of 12/2005	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
B-Class	245	As of 12/2005	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
B-Class	245	As of 12/2005	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●
B-Class	245	As of 12/2005	COMAND or AUDIO	●	●	●	●
B-Class	245	As of 12/2005	Sound system (Main amplifier)	●	●	●	●
B-Class	245	As of 12/2005	UCI-Media interface	●	●	●	●
B-Class	245	As of 12/2005	DAB-Digital radio	●	●	●	●
B-Class	245	As of 12/2005	SDAR-Satellite radio (Valid for USA)	●	●	●	●
B-Class	245	As of 12/2005	CTEL-Cellular telephone (JAPAN)	●	●	●	●
B-Class	245	As of 12/2005	DCM-FL-Door control module front left	●	●	●	●
B-Class	245	As of 12/2005	DCM-FR-Door control module front right	●	●	●	●
B-Class	245	As of 12/2005	DCM-RL-Door control module rear left	●	●	●	●
B-Class	245	As of 12/2005	DCM-RR-Door control module rear right	●	●	●	●
B-Class	245	As of 12/2005	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●
B-Class	245	As of 12/2005	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●
B-Class	245	As of 12/2005	EKMK-Electric refrigerant compressor (A9/5)	●	●	●	●
B-Class	246	ALL	PTCU-Common powertrain controller (N127)	●	●	●	●
B-Class	246	ALL	PTCU-Common powertrain controller (N127)	●	●	●	●
B-Class	246	ALL	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	●	●	●	●
B-Class	246	ALL	ME-Motor electronics 'MED40CNG' for combustion engine 'M274' (N3/10)	●	●	●	●
B-Class	246	ALL	FSCU-Fuel pump	●	●	●	●
B-Class	246	ALL	FSCU-Fuel pump	●	●	●	●
B-Class	246	ALL	mbrace-mbrace (N123/4)	●	●	●	●
B-Class	246	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
B-Class	246	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
B-Class	246	ALL	CDI-Motor electronics 'CRR1' for combustion engine 'OM607' (N3/9)	●	●	●	●
B-Class	246	ALL	ES-Electrical power steering (N68)	●	●	●	●
B-Class	246	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
B-Class	246	ALL	EFB-Electronic parking break (N128)	●	●	●	●
B-Class	246	ALL	DTR-DISTRONIC (A89)	●	●	●	●

B-Class	246	ALL	DTR-DISTRONIC (A89)	●	●	●	●
B-Class	246	ALL	TPM-Tire pressure monitor	●	●	●	●
B-Class	246	ALL	EZS-Electronic ignition switch	●	●	●	●
B-Class	246	ALL	SAM-Signal acquisition and actuation module (N10)	●	●	●	●
B-Class	246	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
B-Class	246	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
B-Class	246	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
B-Class	246	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
B-Class	246	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
B-Class	246	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
B-Class	246	ALL	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
B-Class	246	ALL	SCM-Steering column module(N80)	●	●	●	●
B-Class	246	ALL	Trailer recognition module-Trailer recognition(N28/1)	●	●	●	●
B-Class	246	ALL	ATA-ATA[EDW]/tow-away protection/interiorprotection(N26/6)	●	●	●	●
B-Class	246	ALL	COU [ZBE]-Central operating unit	●	●	●	●
B-Class	246	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
B-Class	246	ALL	DAB-Digital radio	●	●	●	●
B-Class	246	ALL	DKG-Electronic transmission control for double-plateclutch transmission (N15/13)	●	●	●	●
B-Class	246	ALL	ZAN-Central display	●	●	●	●
B-Class	246	ALL	IC-Instrument cluster (A1)	●	●	●	●
B-Class	246	ALL	IC-Instrument cluster (A1)	●	●	●	●
B-Class	246	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
B-Class	246	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
B-Class	246	ALL	MFK-Multifunction camera	●	●	●	●
B-Class	246	ALL	NAV-Navigation module (A2/30)	●	●	●	●
B-Class	246	ALL	PTS-Parktronic	●	●	●	●
B-Class	246	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
B-Class	246	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
B-Class	246	ALL	Sound system (Main amplifier)	●	●	●	●
B-Class	246	ALL	TV-TV tuner(AGW)	●	●	●	●
B-Class	246	ALL	UCI-Media interface	●	●	●	●
B-Class	246	ALL	Audio-Audio 5 USB (A2)	●	●	●	●
B-Class	246	ALL	DCU-LF-Left front door (N69/1)	●	●	●	●
B-Class	246	ALL	DCU-RF-Right front door (N69/2)	●	●	●	●
B-Class	246	ALL	ESA 'Driver'-Electrical seat adjustment 'Driver' withmemory function(N32/1)	●	●	●	●
B-Class	246	ALL	ESA' Front passenger'-Electric seat adjustment 'Frontpassenger' with memory function(N32/2)	●	●	●	●
B-Class	246	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
B-Class	246	ALL	STH-Stationary heater (A6n1)	●	●	●	●
B-Class	246	ALL	UCP-Upper control panel (N72/1)	●	●	●	●

B-Class	246	ALL	AISP-Dimming inside rearview mirror (A67)	●	●	●	●
B-Class	246	ALL	BSN-Battery sensor (B95)	●	●	●	●
B-Class	246	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
B-Class	246	ALL	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	●	●	●	●
B-Class	246	ALL	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	●	●	●	●
B-Class	246	ALL	RGLS-Rain/light sensor (B38/2)	●	●	●	●
B-Class	246	ALL	OCP-Control unit 'Overhead control panel' (N70)	●	●	●	●
B-Class	246	ALL	AS-Alarm siren(H3/1)	●	●	●	●
C-Class	203	Up to 08/2003	ETC-Electronic transmission control	●	●	●	●
C-Class	203	Up to 08/2003	ETC-Electronic transmission control	●	●	●	●
C-Class	203	Up to 08/2003	SEQ-Sequentronic automated manual transmission	●	●	●	●
C-Class	203	Up to 08/2003	ESM-Electronic selector module	●	●	●	●
C-Class	203	Up to 08/2003	ME-SFI-Motor electronics	●	●	●	●
C-Class	203	Up to 08/2003	DTR-Distronic	●	●	●	●
C-Class	203	Up to 08/2003	ME-SFI-Motor electronics	●	●	●	●
C-Class	203	Up to 08/2003	ME-SFI-Motor electronics	●	●	●	●
C-Class	203	Up to 08/2003	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
C-Class	203	Up to 08/2003	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
C-Class	203	Up to 08/2003	CDI 2-Common Rail Diesel Injection	●	●	●	●
C-Class	203	Up to 08/2003	CDI 3-Common Rail Diesel Injection3	●	●	●	●
C-Class	203	Up to 08/2003	CDI 2-Common Rail Diesel Injection	●	●	●	●
C-Class	203	Up to 08/2003	ETC-Electronic transmission control	●	●	●	●
C-Class	203	Up to 08/2003	ESP-Electronic stability program	●	●	●	●
C-Class	203	Up to 08/2003	ESP-Electronic stability program	●	●	●	●
C-Class	203	Up to 08/2003	BAS-Brake assist	●	●	●	●
C-Class	203	Up to 08/2003	VP-Vacuum pump brake booster	●	●	●	●
C-Class	203	Up to 08/2003	ESP-Electronic stability program	●	●	●	●
C-Class	203	Up to 08/2003	EZS-Electronic ignition switch	●	●	●	●
C-Class	203	Up to 08/2003	EZS-Electronic ignition switch	●	●	●	●
C-Class	203	Up to 08/2003	AB-Airbag	●	●	●	●
C-Class	203	Up to 08/2003	OCP-Overhead control panel	●	●	●	●
C-Class	203	Up to 08/2003	LCP-Lower control panel	●	●	●	●
C-Class	203	Up to 08/2003	UCP-Upper control panel	●	●	●	●

C-Class	203	Up to 08/2003	SAM-F-Signal acquisition and actuation module front	●	●	●	●
C-Class	203	Up to 08/2003	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
C-Class	203	Up to 08/2003	AHE-Trailer recognition	●	●	●	●
C-Class	203	Up to 08/2003	MSS-Special vehicle multifunction control module	●	●	●	●
C-Class	203	Up to 08/2003	HRA-FR-Front right headlamp range control	●	●	●	●
C-Class	203	Up to 08/2003	HRA-FL-Front left headlamp range control	●	●	●	●
C-Class	203	Up to 08/2003	CGW-Central gateway	●	●	●	●
C-Class	203	Up to 08/2003	AB-Airbag	●	●	●	●
C-Class	203	Up to 08/2003	WSS-Weight sensing system	●	●	●	●
C-Class	203	Up to 08/2003	AHE-Trailer recognition	●	●	●	●
C-Class	203	Up to 08/2003	System diagnosis (CAN)	●	●	●	●
C-Class	203	Up to 08/2003	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
C-Class	203	Up to 08/2003	PTS-Parktronic system	●	●	●	●
C-Class	203	Up to 08/2003	SCM [MRM]-Steering column module	●	●	●	●
C-Class	203	Up to 08/2003	TV-TV tuner	●	●	●	●
C-Class	203	Up to 08/2003	E-call [Japan]-Emergency call system	●	●	●	●
C-Class	203	Up to 08/2003	E-call [Japan]-Telematic system	●	●	●	●
C-Class	203	Up to 08/2003	E-call [USA]-Telematic system	●	●	●	●
C-Class	203	Up to 08/2003	TELE AID-Telematic system	●	●	●	●
C-Class	203	Up to 08/2003	CTEL over K-wire-Telematic system	●	●	●	●
C-Class	203	Up to 08/2003	D2B-COMAND, MCS or AUDIO	●	●	●	●
C-Class	203	Up to 08/2003	AUDIO	●	●	●	●
C-Class	203	Up to 08/2003	COMAND	●	●	●	●
C-Class	203	Up to 08/2003	CDC-CD changer	●	●	●	●
C-Class	203	Up to 08/2003	VCS-Voice control system	●	●	●	●
C-Class	203	Up to 08/2003	SOUND- Sound system	●	●	●	●
C-Class	203	Up to 08/2003	CTEL- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
C-Class	203	Up to 08/2003	UHI- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
C-Class	203	Up to 08/2003	SDAR-Satellite radio	●	●	●	●
C-Class	203	Up to 08/2003	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
C-Class	203	Up to 08/2003	SCM [MRM]-Steering column module	●	●	●	●

C-Class	203	Up to 08/2003	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
C-Class	203	Up to 08/2003	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
C-Class	203	Up to 08/2003	AUDIO	●	●	●	●
C-Class	203	Up to 08/2003	COMAND or AUDIO	●	●	●	●
C-Class	203	Up to 08/2003	CTEL-Mobile phone adapter with universal interface	●	●	●	●
C-Class	203	Up to 08/2003	CDC-CD changer	●	●	●	●
C-Class	203	Up to 08/2003	VCS-Voice control system	●	●	●	●
C-Class	203	Up to 08/2003	SOUND- Sound system	●	●	●	●
C-Class	203	Up to 08/2003	TV-TV tuner	●	●	●	●
C-Class	203	Up to 08/2003	SDAR-Satellite radio	●	●	●	●
C-Class	203	Up to 08/2003	NAVI-Navigation system	●	●	●	●
C-Class	203	Up to 08/2003	TELE AID-Control unit	●	●	●	●
C-Class	203	Up to 08/2003	TELE AID-Telematic services Emergency call	●	●	●	●
C-Class	203	Up to 08/2003	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
C-Class	203	Up to 08/2003	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
C-Class	203	Up to 08/2003	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
C-Class	203	Up to 08/2003	CTEL-Cellular telephone	●	●	●	●
C-Class	203	Up to 08/2003	DCM-FL-Door control module front left	●	●	●	●
C-Class	203	Up to 08/2003	DCM-FR-Door control module front right	●	●	●	●
C-Class	203	Up to 08/2003	DCM-RL-Door control module rear left	●	●	●	●
C-Class	203	Up to 08/2003	DCM-RR-Door control module rear right	●	●	●	●
C-Class	203	Up to 08/2003	ESA passenger-Electric seat adjustment passenger	●	●	●	●
C-Class	203	Up to 08/2003	ESA passenger-Electric seat adjustment passenger	●	●	●	●
C-Class	203	Up to 08/2003	ESA passenger-Electric seat adjustment passenger	●	●	●	●
C-Class	203	Up to 08/2003	ESA driver-Electric seat adjustment driver	●	●	●	●
C-Class	203	Up to 08/2003	ESA driver-Electric seat adjustment driver	●	●	●	●
C-Class	203	Up to 08/2003	ESA driver-Electric seat adjustment driver (with	●	●	●	●
C-Class	203	Up to 08/2003	AAC-Automatic air conditioning	●	●	●	●
C-Class	203	Up to 08/2003	STH-Stationary heater	●	●	●	●
C-Class	203	Up to 08/2003	STH-Stationary heater	●	●	●	●

C-Class	203	From 09/2003 to12/2007	ETC-Electronic transmission control	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ETC-Electronic transmission control	●	●	●	●
C-Class	203	From 09/2003 to12/2007	SEQ-Sequentronic automated manual transmission	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ESM-Electronic selector module	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ME-SFI-Motor electronics	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ME-SFI-Motor electronics	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ME 9.7-Motor electronics 9.7	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
C-Class	203	From 09/2003 to12/2007	CDI 3-Common Rail Diesel Injection3	●	●	●	●
C-Class	203	From 09/2003 to12/2007	CDI 2-Common Rail Diesel Injection	●	●	●	●
C-Class	203	From 09/2003 to12/2007	CDI 2-Common Rail Diesel Injection	●	●	●	●
C-Class	203	From 09/2003 to12/2007	CDI 4-Common Rail Diesel Injection	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ESP-Electronic stability program	●	●	●	●
C-Class	203	From 09/2003 to12/2007	CGW-Central gateway	●	●	●	●
C-Class	203	From 09/2003 to12/2007	EZS-Electronic ignition switch	●	●	●	●
C-Class	203	From 09/2003 to12/2007	AB-Airbag	●	●	●	●
C-Class	203	From 09/2003 to12/2007	OCP-Overhead control panel	●	●	●	●
C-Class	203	From 09/2003 to12/2007	WSS-Weight sensing system	●	●	●	●
C-Class	203	From 09/2003 to12/2007	LCP-Lower control panel	●	●	●	●
C-Class	203	From 09/2003 to12/2007	UCP-Upper control panel	●	●	●	●
C-Class	203	From 09/2003 to12/2007	SAM-F-Signal acquisition and actuation module front	●	●	●	●
C-Class	203	From 09/2003 to12/2007	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
C-Class	203	From 09/2003 to12/2007	AHE-Trailer recognition	●	●	●	●
C-Class	203	From 09/2003 to12/2007	AHE-Trailer recognition	●	●	●	●
C-Class	203	From 09/2003 to12/2007	MSS-Special vehicle multifunction control module	●	●	●	●
C-Class	203	From 09/2003 to12/2007	HRA-FR-Front right headlamp range control	●	●	●	●
C-Class	203	From 09/2003 to12/2007	HRA-FL-Front left headlamp range control	●	●	●	●
C-Class	203	From 09/2003 to12/2007	System diagnosis (CAN)	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●

C-Class	203	From 09/2003 to12/2007	PTS-Parktronic system	●	●	●	●
C-Class	203	From 09/2003 to12/2007	SCM [MRM]-Steering column module	●	●	●	●
C-Class	203	From 09/2003 to12/2007	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
C-Class	203	From 09/2003 to12/2007	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
C-Class	203	From 09/2003 to12/2007	AUDIO	●	●	●	●
C-Class	203	From 09/2003 to12/2007	COMAND or AUDIO	●	●	●	●
C-Class	203	From 09/2003 to12/2007	CTEL-Mobile phone adapter with universal interface	●	●	●	●
C-Class	203	From 09/2003 to12/2007	CDC-CD changer	●	●	●	●
C-Class	203	From 09/2003 to12/2007	VCS-Voice control system	●	●	●	●
C-Class	203	From 09/2003 to12/2007	SOUND- Sound system	●	●	●	●
C-Class	203	From 09/2003 to12/2007	TV-TV tuner	●	●	●	●
C-Class	203	From 09/2003 to12/2007	SDAR-Satellite radio	●	●	●	●
C-Class	203	From 09/2003 to12/2007	NAVI-Navigation system	●	●	●	●
C-Class	203	From 09/2003 to12/2007	TELE AID-Control unit	●	●	●	●
C-Class	203	From 09/2003 to12/2007	TELE AID-Telematic services Emergency call	●	●	●	●
C-Class	203	From 09/2003 to12/2007	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
C-Class	203	From 09/2003 to12/2007	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
C-Class	203	From 09/2003 to12/2007	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
C-Class	203	From 09/2003 to12/2007	CTEL-Cellular telephone	●	●	●	●
C-Class	203	From 09/2003 to12/2007	DCM-FL-Door control module front left	●	●	●	●
C-Class	203	From 09/2003 to12/2007	DCM-FR-Door control module front right	●	●	●	●
C-Class	203	From 09/2003 to12/2007	DCM-RL-Door control module rear left	●	●	●	●
C-Class	203	From 09/2003 to12/2007	DCM-RR-Door control module rear right	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ESA passenger-Electric seat adjustment passenger	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ESA passenger-Electric seat adjustment passenger	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ESA passenger-Electric seat adjustment passenger	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ESA driver-Electric seat adjustment driver	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ESA driver-Electric seat adjustment driver	●	●	●	●
C-Class	203	From 09/2003 to12/2007	ESA driver-Electric seat adjustment driver (withmemory)	●	●	●	●



C-Class	203	From 09/2003 to12/2007	AAC-Automatic air conditioning	●	●	●	●
C-Class	203	From 09/2003 to12/2007	STH-Stationary heater	●	●	●	●
C-Class	204	ALL	ETC-Electronic transmission control	●	●	●	●
C-Class	204	ALL	ETC-Electronic transmission control	●	●	●	●
C-Class	204	ALL	ME - Motor electronics 'SIM271DE20' for combustionengine 'M271EVO' (N3/10)	●	●	●	●
C-Class	204	ALL	ME-SFI-Motor electronics	●	●	●	●
C-Class	204	ALL	FSCU-Fuel pump	●	●	●	●
C-Class	204	ALL	FSCU-Fuel pump	●	●	●	●
C-Class	204	ALL	FSCU-Fuel pump	●	●	●	●
C-Class	204	ALL	ESM-Electronic selector module	●	●	●	●
C-Class	204	ALL	ME 9.7-Motor electronics 9.7	●	●	●	●
C-Class	204	ALL	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
C-Class	204	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
C-Class	204	ALL	ME-Motor electronics 'MED40' for combustion engine'M270' (N3/10)	●	●	●	●
C-Class	204	ALL	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●
C-Class	204	ALL	FSCU Left-Control unit 'left fuel	●	●	●	●
C-Class	204	ALL	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●
C-Class	204	ALL	DTR-Distronic	●	●	●	●
C-Class	204	ALL	PTCU-Common powertrain controller(N127)	●	●	●	●
C-Class	204	ALL	ISM-Shift module (A80)	●	●	●	●
C-Class	204	ALL	mbrace-mbrace (N123/4)	●	●	●	●
C-Class	204	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
C-Class	204	ALL	FSCU-Fuel pump	●	●	●	●
C-Class	204	ALL	CDID-Common Rail Diesel Injection	●	●	●	●
C-Class	204	ALL	CDID-Common Rail Diesel Injection	●	●	●	●
C-Class	204	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
C-Class	204	ALL	ESM-Electronic selector module	●	●	●	●
C-Class	204	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
C-Class	204	ALL	CDI 60LS-Common Rail Diesel Injection	●	●	●	●
C-Class	204	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
C-Class	204	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
C-Class	204	ALL	ABR-Adaptive Brake	●	●	●	●
C-Class	204	ALL	TPC-Tire pressure monitor	●	●	●	●
C-Class	204	ALL	TPM - Tire pressure monitor(N88)	●	●	●	●
C-Class	204	ALL	AIRMATIC-AIRMATIC	●	●	●	●
C-Class	204	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
C-Class	204	ALL	EHPS-Electrohydraulic Power Steering	●	●	●	●
C-Class	204	ALL	ES-Electrical power steering (N68)	●	●	●	●
C-Class	204	ALL	ESP-Electronic stability program	●	●	●	●
C-Class	204	ALL	ESP-Regenerative braking system (N30/6)	●	●	●	●
C-Class	204	ALL	CGW-Central gateway	●	●	●	●
C-Class	204	ALL	CGW[ZGW]-Central gateway (CGW[ZGW])	●	●	●	●
C-Class	204	ALL	CGW-Central gateway	●	●	●	●
C-Class	204	ALL	EZS-Electronic ignition switch	●	●	●	●

C-Class	204	ALL	KG-Keyless Go	●	●	●	●
C-Class	204	ALL	KG-KEYLESS GO (N69/5)	●	●	●	●
C-Class	204	ALL	Trailer recognition module	●	●	●	●
C-Class	204	ALL	AB-Airbag	●	●	●	●
C-Class	204	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
C-Class	204	ALL	SRS-Supplemental restraint system	●	●	●	●
C-Class	204	ALL	WSS-Weight sensing system	●	●	●	●
C-Class	204	ALL	OCP-Overhead control panel	●	●	●	●
C-Class	204	ALL	PSD-Control module 'Panoramic sliding roof' (A98)	●	●	●	●
C-Class	204	ALL	PSD-Control module 'Panoramic sliding roof' (A98)	●	●	●	●
C-Class	204	ALL	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
C-Class	204	ALL	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●
C-Class	204	ALL	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●
C-Class	204	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
C-Class	204	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
C-Class	204	ALL	AHE-Trailer recognition	●	●	●	●
C-Class	204	ALL	MSS-Special vehicle multifunction control module	●	●	●	●
C-Class	204	ALL	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●
C-Class	204	ALL	RevETR-LF-Left front reversible emergency tensioning retractor (A76)	●	●	●	●
C-Class	204	ALL	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●
C-Class	204	ALL	RevETR-RF-Right front reversible emergency tensioning retractor (A76/1)	●	●	●	●
C-Class	204	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
C-Class	204	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
C-Class	204	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
C-Class	204	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
C-Class	204	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
C-Class	204	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
C-Class	204	ALL	Multifunction control unit-Multifunction control unit (N26/14)	●	●	●	●
C-Class	204	ALL	EZS-Electronic ignition lock	●	●	●	●
C-Class	204	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
C-Class	204	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
C-Class	204	ALL	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	●	●	●	●
C-Class	204	ALL	SGR-Radar sensors control unit	●	●	●	●
C-Class	204	ALL	RFK-Backup camera (B84/3)	●	●	●	●
C-Class	204	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
C-Class	204	ALL	SCM-Steering column module (N80)	●	●	●	●
C-Class	204	ALL	SGR-Radar sensors control unit	●	●	●	●
C-Class	204	ALL	ES-Electrical power steering	●	●	●	●
C-Class	204	ALL	ICM-Instrument cluster with maintenance interval display	●	●	●	●

C-Class	204	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
C-Class	204	ALL	IC-Instrument cluster (A1)	●	●	●	●
C-Class	204	ALL	IC-Instrument cluster (A1)	●	●	●	●
C-Class	204	ALL	ICI-InCar Internet (N125/3)	●	●	●	●
C-Class	204	ALL	PTS-Parktronic	●	●	●	●
C-Class	204	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
C-Class	204	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
C-Class	204	ALL	RFK-Backup camera (B84/3)	●	●	●	●
C-Class	204	ALL	SCM [MRM]-Steering column module	●	●	●	●
C-Class	204	ALL	SCCM-Steering column module (N80)	●	●	●	●
C-Class	204	ALL	COMAND or AUDIO	●	●	●	●
C-Class	204	ALL	COMAND or AUDIO	●	●	●	●
C-Class	204	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
C-Class	204	ALL	COU [ZBE]-Central operating unit	●	●	●	●
C-Class	204	ALL	ZBE-Audio/COMAND operating unit (A40/9)	●	●	●	●
C-Class	204	ALL	ZAN-Central display	●	●	●	●
C-Class	204	ALL	TV-TV tuner	●	●	●	●
C-Class	204	ALL	TV-TV tuner (AGW)	●	●	●	●
C-Class	204	ALL	CTEL-Cellular telephone (JAPAN)	●	●	●	●
C-Class	204	ALL	DAB-Digital radio	●	●	●	●
C-Class	204	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
C-Class	204	ALL	Sound system (Main amplifier)	●	●	●	●
C-Class	204	ALL	SDAR-Satellite radio (Valid for USA)	●	●	●	●
C-Class	204	ALL	UCI-Media interface	●	●	●	●
C-Class	204	ALL	AVE-H-Rear audio video unit	●	●	●	●
C-Class	204	ALL	Left rear screen	●	●	●	●
C-Class	204	ALL	Right rear screen	●	●	●	●
C-Class	204	ALL	TELE AID-Control unit	●	●	●	●
C-Class	204	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
C-Class	204	ALL	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
C-Class	204	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
C-Class	204	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
C-Class	204	ALL	AMG PM-AMG Performance Media (N125/2)	●	●	●	●
C-Class	204	ALL	AMG DRVU-AMG DRIVE UNIT (N145)	●	●	●	●
C-Class	204	ALL	Drive-side SAM-Front signal acquisition and actuationmodule (N10/1)	●	●	●	●
C-Class	204	ALL	MFK-Multifunction camera	●	●	●	●
C-Class	204	ALL	NAV-Navigation module (A2/30)	●	●	●	●
C-Class	204	ALL	360° camera-360° camera (N148)	●	●	●	●
C-Class	204	ALL	NAVI20 - Navigation (N125/2)	●	●	●	●
C-Class	204	ALL	DCM-FL-Door control module front left	●	●	●	●
C-Class	204	ALL	DCU-LF-Left front door	●	●	●	●
C-Class	204	ALL	DCM-FR-Door control module front right	●	●	●	●
C-Class	204	ALL	DCU-RF-Right front door	●	●	●	●
C-Class	204	ALL	DCM-RL-Door control module rear left	●	●	●	●
C-Class	204	ALL	DCU-LR-Left rear door	●	●	●	●

C-Class	204	ALL	DCM-RR-Door control module rear right	●	●	●	●
C-Class	204	ALL	DCU-RR-Right rear door	●	●	●	●
C-Class	204	ALL	HKS-Tailgate control (N121/1)	●	●	●	●
C-Class	204	ALL	ESA driver	●	●	●	●
C-Class	204	ALL	ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)	●	●	●	●
C-Class	204	ALL	ESA passenger	●	●	●	●
C-Class	204	ALL	ESA-Electirc seat adjustment 'Front passenger' (N32/2)	●	●	●	●
C-Class	204	ALL	ESA' Front passenger'-Electric seat adjustment 'Frontpassenger' with memory function (N32/2)	●	●	●	●
C-Class	204	ALL	Stationary heater	●	●	●	●
C-Class	204	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
C-Class	204	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
C-Class	204	ALL	EKMK-Electric refrigerant compressor (A9/5)	●	●	●	●
C-Class	204	ALL	LCP-Lower control panel (S77)	●	●	●	●
C-Class	204	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
C-Class	204	ALL	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	●	●	●	●
C-Class	204	ALL	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	●	●	●	●
C-Class	205	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
C-Class	205	ALL	IRS-HLA - Outer left rear intelligent radar sensorsystem	●	●	●	●
C-Class	205	ALL	360° camera-360° camera (N148)	●	●	●	●
C-Class	205	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
C-Class	205	ALL	EZS-Electronic ignition switch	●	●	●	●
C-Class	205	ALL	Driver-side SAM-Driver signal acquisition andactuation module	●	●	●	●
C-Class	205	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
C-Class	205	ALL	AHE-Trailer recognition	●	●	●	●
C-Class	205	ALL	DCU-LF-Left front door (N69/1)	●	●	●	●
C-Class	205	ALL	DCU-LR-Left rear door (N69/1)	●	●	●	●
C-Class	205	ALL	DCU-RF-Right front door (N69/2)	●	●	●	●
C-Class	205	ALL	DCU-RR-Right rear door (N69/2)	●	●	●	●
C-Class	205	ALL	ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)	●	●	●	●
C-Class	205	ALL	ESA-Electirc seat adjustment 'Front passenger' (N32/2)	●	●	●	●
C-Class	205	ALL	HKS-Tailgate control (N121/1)	●	●	●	●
C-Class	205	ALL	KG-Keyless Go	●	●	●	●
C-Class	205	ALL	SCM-Steering column module (N80)	●	●	●	●
C-Class	205	ALL	PSD-Control mudule 'Panoramic sliding roof' (A98)	●	●	●	●
C-Class	205	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
C-Class	205	ALL	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
C-Class	205	ALL	SG-FOND-Rear control unit (N22/6)	●	●	●	●
C-Class	205	ALL	BMS-Battery management system	●	●	●	●
C-Class	205	ALL	ATA-Interior motion sensor	●	●	●	●
C-Class	205	ALL	SD-Control mudule sliding roof	●	●	●	●

C-Class	205	ALL	SG-LG-Charger	●	●	●	●
C-Class	205	ALL	SG-SOGE-E-Sound generator for electric vehicle	●	●	●	●
C-Class	205	ALL	AC-Air conditioning	●	●	●	●
C-Class	205	ALL	PTCU-Common powertrain controller (N127)	●	●	●	●
C-Class	205	ALL	SG-EM-Power electronics (N129/1)	●	●	●	●
C-Class	205	ALL	FSCU-Fuel pump	●	●	●	●
C-Class	205	ALL	ISM-Shift module (A80)	●	●	●	●
C-Class	205	ALL	ADS-Adaptive damping system	●	●	●	●
C-Class	205	ALL	EFB-Electronic parking break (N128)	●	●	●	●
C-Class	205	ALL	ES-Electrical power steering	●	●	●	●
C-Class	205	ALL	ESP-Electronic stability program	●	●	●	●
C-Class	205	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
C-Class	205	ALL	ECM-Engine control monolith	●	●	●	●
C-Class	205	ALL	IC-Instrument cluster	●	●	●	●
C-Class	205	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
C-Class	205	ALL	PTS-Parktronic system	●	●	●	●
C-Class	205	ALL	RFK-Backup camera (B84/3)	●	●	●	●
C-Class	205	ALL	SGR-Radar sensors control unit	●	●	●	●
C-Class	205	ALL	TPM - Tire pressure monitor (N88)	●	●	●	●
C-Class	205	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
C-Class	205	ALL	KAB-Control unit 'Camera cover' (N42)	●	●	●	●
C-Class	205	ALL	MFK-Multifunction camera	●	●	●	●
C-Class	205	ALL	DTR-DISTRONIC (A89)	●	●	●	●
C-Class	205	ALL	mbrace-mbrace (N123/4)	●	●	●	●
C-Class	205	ALL	COU [ZBE]-Central operating unit	●	●	●	●
C-Class	205	ALL	DAB-Digital radio	●	●	●	●
C-Class	205	ALL	ZAN-Central display	●	●	●	●
C-Class	205	ALL	TV-TV tuner	●	●	●	●
C-Class	205	ALL	TPAD-Touchpad	●	●	●	●
CL	215	Up to 08/2002	ETC-Electronic transmission control	●	●	●	●
CL	215	Up to 08/2002	ETC-Electronic transmission control	●	●	●	●
CL	215	Up to 08/2002	ESM-Electronic selector module	●	●	●	●
CL	215	Up to 08/2002	DTR-Distronic	●	●	●	●
CL	215	Up to 08/2002	ME-SFI 2.0-Motor electronics 2.0	●	●	●	●
CL	215	Up to 08/2002	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CL	215	Up to 08/2002	ME-SFI 2.0-Motor electronics 2.0	●	●	●	●
CL	215	Up to 08/2002	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CL	215	Up to 08/2002	ME-SFI 2.7-Motor electronics 2.7	●	●	●	●
CL	215	Up to 08/2002	ESP-Electronic stability program	●	●	●	●
CL	215	Up to 08/2002	ABC-ABC active body control	●	●	●	●
CL	215	Up to 08/2002	TPM - Tire pressure monitor (N88)	●	●	●	●

CL	215	Up to 08/2002	AB-Airbag	●	●	●	●
CL	215	Up to 08/2002	EZS-Electronic ignition switch	●	●	●	●
CL	215	Up to 08/2002	EZS-Electronic ignition switch	●	●	●	●
CL	215	Up to 08/2002	SAM-FL-Front left signal acquisition and actuationmodule	●	●	●	●
CL	215	Up to 08/2002	SAM-FR-Front right signal acquisition and actuationmodule	●	●	●	●
CL	215	Up to 08/2002	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
CL	215	Up to 08/2002	AHE-Trailer recognition	●	●	●	●
CL	215	Up to 08/2002	OCP-Overhead control panel	●	●	●	●
CL	215	Up to 08/2002	PSE-Pneumatic system equipment	●	●	●	●
CL	215	Up to 08/2002	UCP-Upper control panel	●	●	●	●
CL	215	Up to 08/2002	KG-Keyless Go	●	●	●	●
CL	215	Up to 08/2002	MSS-Special vehicle multifunction control module	●	●	●	●
CL	215	Up to 08/2002	HRA-Headlamp range adjustment	●	●	●	●
CL	215	Up to 08/2002	PTS-Parktronic system	●	●	●	●
CL	215	Up to 08/2002	SCM [MRM]-Steering column module	●	●	●	●
CL	215	Up to 08/2002	TSTH-Radio remote control of stationary heater	●	●	●	●
CL	215	Up to 08/2002	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
CL	215	Up to 08/2002	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
CL	215	Up to 08/2002	COMAND	●	●	●	●
CL	215	Up to 08/2002	AUDIO	●	●	●	●
CL	215	Up to 08/2002	CDC-CD changer	●	●	●	●
CL	215	Up to 08/2002	CTEL- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
CL	215	Up to 08/2002	UHI- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
CL	215	Up to 08/2002	SOUND- Sound system	●	●	●	●
CL	215	Up to 08/2002	VCS-Voice control system	●	●	●	●
CL	215	Up to 08/2002	TV-TV tuner	●	●	●	●
CL	215	Up to 08/2002	E-call [Japan]-Emergency call system	●	●	●	●
CL	215	Up to 08/2002	E-call [Japan]-Telematic system	●	●	●	●
CL	215	Up to 08/2002	E-call [USA]-Emergency call system	●	●	●	●
CL	215	Up to 08/2002	TELE AID-Emergency call system	●	●	●	●
CL	215	Up to 08/2002	E-call [USA]-Telematic system	●	●	●	●

CL	215	Up to 08/2002	TELE AID-Telematic system	●	●	●	●
CL	215	Up to 08/2002	CTEL over K-wire-Telematic system	●	●	●	●
CL	215	Up to 08/2002	DN-Dynamic navigation by means of CTEL	●	●	●	●
CL	215	Up to 08/2002	DCM-FL-Door control module front left	●	●	●	●
CL	215	Up to 08/2002	DCM-FR-Door control module front right	●	●	●	●
CL	215	Up to 08/2002	RCM-Rear control module	●	●	●	●
CL	215	Up to 08/2002	ESA-FL-Electric seat adjustment front left	●	●	●	●
CL	215	Up to 08/2002	ESA-FR-Electric seat adjustment front right	●	●	●	●
CL	215	Up to 08/2002	OSB-FL-Multicontour backrest front left	●	●	●	●
CL	215	Up to 08/2002	OSB-FR-Multicontour backrest front right	●	●	●	●
CL	215	Up to 08/2002	AAC-Automatic air conditioning	●	●	●	●
CL	215	Up to 08/2002	STH-Stationary heater	●	●	●	●
CL	215	Up to 08/2002	HSW-Heated steering wheel	●	●	●	●
CL	215	Up to 08/2002	STH-Stationary heater	●	●	●	●
CL	215	As of 09/2002	ETC-Electronic transmission control	●	●	●	●
CL	215	As of 09/2002	ETC-Electronic transmission control	●	●	●	●
CL	215	As of 09/2002	ESM-Electronic selector module	●	●	●	●
CL	215	As of 09/2002	DTR-Distronic	●	●	●	●
CL	215	As of 09/2002	DTR-Distronic	●	●	●	●
CL	215	As of 09/2002	ME-SFI 2.0-Motor electronics 2.0	●	●	●	●
CL	215	As of 09/2002	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CL	215	As of 09/2002	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CL	215	As of 09/2002	ME-SFI 2.7.1-Motor electronics 2.7.1	●	●	●	●
CL	215	As of 09/2002	ESP-Electronic stability program	●	●	●	●
CL	215	As of 09/2002	ABC-ABC active body control	●	●	●	●
CL	215	As of 09/2002	TPM - Tire pressure monitor(N88)	●	●	●	●
CL	215	As of 09/2002	EZS-Electronic ignition switch	●	●	●	●
CL	215	As of 09/2002	PSE-Pneumatic system equipment	●	●	●	●
CL	215	As of 09/2002	SAM-FL-Front left signal acquisition and actuationmodule	●	●	●	●
CL	215	As of 09/2002	SAM-FR-Front right signal acquisition and actuationmodule	●	●	●	●
CL	215	As of 09/2002	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●

CL	215	As of 09/2002	AHE-Trailer recognition	●	●	●	●
CL	215	As of 09/2002	KG-Keyless Go	●	●	●	●
CL	215	As of 09/2002	MSS-Special vehicle multifunction control module	●	●	●	●
CL	215	As of 09/2002	HRA-FR-Front right headlamp range control	●	●	●	●
CL	215	As of 09/2002	HRA-FL-Front left headlamp range control	●	●	●	●
CL	215	As of 09/2002	CGW-Central gateway	●	●	●	●
CL	215	As of 09/2002	AB-Airbag	●	●	●	●
CL	215	As of 09/2002	OCP-Overhead control panel	●	●	●	●
CL	215	As of 09/2002	UCP-Upper control panel	●	●	●	●
CL	215	As of 09/2002	System diagnosis (CAN)	●	●	●	●
CL	215	As of 09/2002	PTS-Parktronic system	●	●	●	●
CL	215	As of 09/2002	SCM [MRM]-Steering column module	●	●	●	●
CL	215	As of 09/2002	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
CL	215	As of 09/2002	COMAND	●	●	●	●
CL	215	As of 09/2002	AUDIO	●	●	●	●
CL	215	As of 09/2002	CDC-CD changer	●	●	●	●
CL	215	As of 09/2002	CTEL- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
CL	215	As of 09/2002	UHI- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
CL	215	As of 09/2002	SOUND- Sound system	●	●	●	●
CL	215	As of 09/2002	VCS-Voice control system	●	●	●	●
CL	215	As of 09/2002	SDAR-Satellite radio	●	●	●	●
CL	215	As of 09/2002	TV-TV tuner	●	●	●	●
CL	215	As of 09/2002	E-call [Japan]-Telematic system	●	●	●	●
CL	215	As of 09/2002	E-call [USA]-Telematic system	●	●	●	●
CL	215	As of 09/2002	TELE AID-Telematic system	●	●	●	●
CL	215	As of 09/2002	CTEL over K-wire-Telematic system	●	●	●	●
CL	215	As of 09/2002	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
CL	215	As of 09/2002	CTEL-Telecommunication for telematics services	●	●	●	●
CL	215	As of 09/2002	Telephone adapter for portable CTCL- Telecommunicationfor telematics services	●	●	●	●
CL	215	As of 09/2002	AUDIO	●	●	●	●



CL	215	As of 09/2002	COMAND or AUDIO	●	●	●	●
CL	215	As of 09/2002	CTEL-Mobile phone adapter with universal interface	●	●	●	●
CL	215	As of 09/2002	NAVI-Navigation system	●	●	●	●
CL	215	As of 09/2002	CDC-CD changer	●	●	●	●
CL	215	As of 09/2002	VCS-Voice control system	●	●	●	●
CL	215	As of 09/2002	SOUND-Bose sound system	●	●	●	●
CL	215	As of 09/2002	TV-TV tuner	●	●	●	●
CL	215	As of 09/2002	TV-TV tuner (AGW)	●	●	●	●
CL	215	As of 09/2002	SDAR-Satellite radio	●	●	●	●
CL	215	As of 09/2002	GPS box	●	●	●	●
CL	215	As of 09/2002	TELE AID-Control unit	●	●	●	●
CL	215	As of 09/2002	TELE AID-Telematic services Emergency call	●	●	●	●
CL	215	As of 09/2002	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
CL	215	As of 09/2002	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
CL	215	As of 09/2002	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
CL	215	As of 09/2002	DCM-FL-Door control module front left	●	●	●	●
CL	215	As of 09/2002	DCM-FR-Door control module front right	●	●	●	●
CL	215	As of 09/2002	RCM-Rear control module	●	●	●	●
CL	215	As of 09/2002	ESA-FL-Electric seat adjustment front left	●	●	●	●
CL	215	As of 09/2002	ESA-FR-Electric seat adjustment front right	●	●	●	●
CL	215	As of 09/2002	OSB-FL-Multicontour backrest front left	●	●	●	●
CL	215	As of 09/2002	OSB-FR-Multicontour backrest front right	●	●	●	●
CL	215	As of 09/2002	AAC-Automatic air conditioning	●	●	●	●
CL	215	As of 09/2002	REAR AC- Rear air conditioning	●	●	●	●
CL	215	As of 09/2002	HSW-Heated steering wheel	●	●	●	●
CL	215	As of 09/2002	STH-Stationary heater	●	●	●	●
CL	216	ALL	ISM-Intelligent servo module	●	●	●	●
CL	216	ALL	ISM-Shift module (A80)	●	●	●	●
CL	216	ALL	ETC-Electronic transmission control	●	●	●	●
CL	216	ALL	ETC-Electronic transmission control	●	●	●	●
CL	216	ALL	ME 9.7-Motor electronics 9.7	●	●	●	●
CL	216	ALL	DTR-Distronic	●	●	●	●
CL	216	ALL	DTR-Distronic	●	●	●	●
CL	216	ALL	FSCU-Fuel pump	●	●	●	●

CL	216	ALL	FSCU-Fuel pump	●	●	●	●
CL	216	ALL	FSCU-Fuel pump	●	●	●	●
CL	216	ALL	SGR-Radar sensors control unit	●	●	●	●
CL	216	ALL	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
CL	216	ALL	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
CL	216	ALL	FSCU-Fuel pump AMG	●	●	●	●
CL	216	ALL	FSCU-Fuel pump	●	●	●	●
CL	216	ALL	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
CL	216	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
CL	216	ALL	ABR-Adaptive Brake	●	●	●	●
CL	216	ALL	ABR-Adaptive Brake	●	●	●	●
CL	216	ALL	AIRmatic	●	●	●	●
CL	216	ALL	ABC-ABC active body control	●	●	●	●
CL	216	ALL	Electronic parking brake-Electric parking brake	●	●	●	●
CL	216	ALL	TPC-Tire pressure monitor	●	●	●	●
CL	216	ALL	TPM - Tire pressure monitor (N88)	●	●	●	●
CL	216	ALL	EHPS-Electrohydraulic Power Steering	●	●	●	●
CL	216	ALL	CGW-Central gateway	●	●	●	●
CL	216	ALL	EZS-Electronic ignition switch	●	●	●	●
CL	216	ALL	EZS-Electronic ignition switch	●	●	●	●
CL	216	ALL	SGR-Radar sensors control unit	●	●	●	●
CL	216	ALL	KG-Keyless Go	●	●	●	●
CL	216	ALL	KG-KEYLESS GO	●	●	●	●
CL	216	ALL	AB-Airbag	●	●	●	●
CL	216	ALL	WSS-Weight sensing system	●	●	●	●
CL	216	ALL	OCP-Overhead control panel	●	●	●	●
CL	216	ALL	UCP-Upper control panel	●	●	●	●
CL	216	ALL	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
CL	216	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
CL	216	ALL	BNS-Vehicle power supply control module	●	●	●	●
CL	216	ALL	AHE-Trailer recognition	●	●	●	●
CL	216	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
CL	216	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
CL	216	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
CL	216	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
CL	216	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
CL	216	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
CL	216	ALL	System diagnosis (CAN)	●	●	●	●
CL	216	ALL	COU [ZBE]-Central operating unit	●	●	●	●
CL	216	ALL	NSA-Night View Assist	●	●	●	●
CL	216	ALL	SCM [MRM]-Steering column module	●	●	●	●
CL	216	ALL	IC-Instrument cluster	●	●	●	●
CL	216	ALL	ASSYST-Active Service System	●	●	●	●
CL	216	ALL	ASSYST PLUS	●	●	●	●
CL	216	ALL	PTS-Parktronic	●	●	●	●
CL	216	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
CL	216	ALL	RFK-Backup camera (B84/3)	●	●	●	●

CL	216	ALL	MFK-Multifunction camera	●	●	●	●
CL	216	ALL	COMAND	●	●	●	●
CL	216	ALL	COMAND	●	●	●	●
CL	216	ALL	Tuner-Standard tuner	●	●	●	●
CL	216	ALL	Tuner-Tuner sound	●	●	●	●
CL	216	ALL	Tuner-Tuner sound	●	●	●	●
CL	216	ALL	VCS-Voice control	●	●	●	●
CL	216	ALL	CTEL-Mobile phone adapter with universal interface	●	●	●	●
CL	216	ALL	TV-TV tuner (AGW)	●	●	●	●
CL	216	ALL	DAB-Digital radio	●	●	●	●
CL	216	ALL	SDAR-Satellite radio (Valid for USA)	●	●	●	●
CL	216	ALL	ZAN-Central display	●	●	●	●
CL	216	ALL	UCI-Media interface	●	●	●	●
CL	216	ALL	TELE AID-Control unit	●	●	●	●
CL	216	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
CL	216	ALL	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
CL	216	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
CL	216	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
CL	216	ALL	ICI-InCar Internet (N125/3)	●	●	●	●
CL	216	ALL	DS-LF-Left front dynamic seat	●	●	●	●
CL	216	ALL	DS-RF-Right front dynamic seat	●	●	●	●
CL	216	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●
CL	216	ALL	DCM-FL-Door control module front left	●	●	●	●
CL	216	ALL	DCM-FR-Door control module front right	●	●	●	●
CL	216	ALL	RCM-Rear control module	●	●	●	●
CL	216	ALL	ESA-FL-Electric seat adjustment front left	●	●	●	●
CL	216	ALL	ESA-FR-Electric seat adjustment front right	●	●	●	●
CL	216	ALL	TLC-Trunk lid control	●	●	●	●
CL	216	ALL	TLC-Trunk lid control	●	●	●	●
CL	216	ALL	AAC-Automatic air conditioning	●	●	●	●
CL	216	ALL	STH-Stationary heater with remote control	●	●	●	●
CLA	117	ALL	PTCU-Common powertrain controller (N127)	●	●	●	●
CLA	117	ALL	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	●	●	●	●
CLA	117	ALL	ME-Motor electronics 'MED40AMG' for combustion engine 'M133' (N3/10)	●	●	●	●
CLA	117	ALL	FSCU-Fuel pump	●	●	●	●
CLA	117	ALL	FSCU-Fuel pump	●	●	●	●
CLA	117	ALL	mbrace-mbrace (N123/4)	●	●	●	●
CLA	117	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
CLA	117	ALL	PTCU-Common powertrain controller (N127)	●	●	●	●
CLA	117	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
CLA	117	ALL	CDI-Motor electronics 'CRR1' for combustion engine 'OM607' (N3/9)	●	●	●	●
CLA	117	ALL	ES-Electrical power steering (N68)	●	●	●	●

CLA	117	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
CLA	117	ALL	TPM-Tire pressure monitor	●	●	●	●
CLA	117	ALL	EFB-Electronic parking break (N128)	●	●	●	●
CLA	117	ALL	DTR-DISTRONIC (A89)	●	●	●	●
CLA	117	ALL	DTR-DISTRONIC (A89)	●	●	●	●
CLA	117	ALL	EZS-Electronic ignition switch	●	●	●	●
CLA	117	ALL	SAM-Signal acquisition and actuation module (N10)	●	●	●	●
CLA	117	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
CLA	117	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
CLA	117	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
CLA	117	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
CLA	117	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
CLA	117	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
CLA	117	ALL	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
CLA	117	ALL	SCM-Steering column module(N80)	●	●	●	●
CLA	117	ALL	Trailer recognition module-Trailer recognition(N28/1)	●	●	●	●
CLA	117	ALL	PSD-Control module 'Panoramic sliding roof (A98)'	●	●	●	●
CLA	117	ALL	ATA-ATA[EDW]/tow-away protection/interiorprotection(N26/6)	●	●	●	●
CLA	117	ALL	KAB-Control unit 'Camera cover' (N42)	●	●	●	●
CLA	117	ALL	COU [ZBE]-Central operating unit	●	●	●	●
CLA	117	ALL	IC-Instrument cluster (A1)	●	●	●	●
CLA	117	ALL	IC-Instrument cluster (A1)	●	●	●	●
CLA	117	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
CLA	117	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
CLA	117	ALL	DAB-Digital radio	●	●	●	●
CLA	117	ALL	DKG-Electronic transmission control for double-plateclutch transmission (N15/13)	●	●	●	●
CLA	117	ALL	ZAN-Central display	●	●	●	●
CLA	117	ALL	DSI-DIRECT SELECT interface (N150)	●	●	●	●
CLA	117	ALL	MFK-Multifunction camera	●	●	●	●
CLA	117	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
CLA	117	ALL	NAV-Navigation module (A2/30)	●	●	●	●
CLA	117	ALL	PTS-Parktronic	●	●	●	●
CLA	117	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
CLA	117	ALL	SOUND - Sound system(N40/3)	●	●	●	●
CLA	117	ALL	Sound system (Main amplifier)	●	●	●	●
CLA	117	ALL	TV-TV tuner(AGW)	●	●	●	●
CLA	117	ALL	UCI-Media interface	●	●	●	●
CLA	117	ALL	Audio-Audio 5 USB(A2)	●	●	●	●
CLA	117	ALL	DCU-LF-Left front door (N69/1)	●	●	●	●
CLA	117	ALL	DCU-RF-Right front door (N69/2)	●	●	●	●

CLA	117	ALL	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function (N32/1)	●	●	●	●
CLA	117	ALL	ESA' Front passenger'-Electric seat adjustment 'Frontpassenger' with memory function (N32/2)	●	●	●	●
CLA	117	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
CLA	117	ALL	STH-Stationary heater (A6n1)	●	●	●	●
CLA	117	ALL	AISP-Dimming inside rearview mirror (A67)	●	●	●	●
CLA	117	ALL	UCP-Upper control panel (N72/1)	●	●	●	●
CLA	117	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
CLA	117	ALL	BSN-Battery sensor (B95)	●	●	●	●
CLA	117	ALL	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	●	●	●	●
CLA	117	ALL	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	●	●	●	●
CLA	117	ALL	RGLS-Rain/light sensor (B38/2)	●	●	●	●
CLA	117	ALL	OCP-Control unit 'Overhead control panel' (N70)	●	●	●	●
CLA	117	ALL	AS-Alarm siren (H3/1)	●	●	●	●
CLC	203	ALL	ETC-Electronic transmission control	●	●	●	●
CLC	203	ALL	ETC-Electronic transmission control	●	●	●	●
CLC	203	ALL	ETC-Electronic transmission control	●	●	●	●
CLC	203	ALL	ESM-Electronic selector module	●	●	●	●
CLC	203	ALL	ME-SFI-Motor electronics	●	●	●	●
CLC	203	ALL	ME 9.7-Motor electronics 9.7	●	●	●	●
CLC	203	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
CLC	203	ALL	ESP-Electronic stability program	●	●	●	●
CLC	203	ALL	EZS-Electronic ignition switch	●	●	●	●
CLC	203	ALL	AB-Airbag	●	●	●	●
CLC	203	ALL	OCP-Overhead control panel	●	●	●	●
CLC	203	ALL	LCP-Lower control panel	●	●	●	●
CLC	203	ALL	UCP-Upper control panel	●	●	●	●
CLC	203	ALL	SAM-F-Signal acquisition and actuation module front	●	●	●	●
CLC	203	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
CLC	203	ALL	MSS-Special vehicle multifunction control module	●	●	●	●
CLC	203	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
CLC	203	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
CLC	203	ALL	ICM-Instrument cluster with maintenance interval display	●	●	●	●
CLC	203	ALL	PTS-Parktronic system	●	●	●	●
CLC	203	ALL	SCM [MRM]-Steering column module	●	●	●	●
CLC	203	ALL	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
CLC	203	ALL	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
CLC	203	ALL	AUDIO	●	●	●	●
CLC	203	ALL	COMAND or AUDIO	●	●	●	●
CLC	203	ALL	CTEL-Mobile phone adapter with universal interface	●	●	●	●

CLC	203	ALL	CDC-CD changer	●	●	●	●
CLC	203	ALL	VCS-Voice control system	●	●	●	●
CLC	203	ALL	SOUND- Sound system	●	●	●	●
CLC	203	ALL	SDAR-Satellite radio	●	●	●	●
CLC	203	ALL	NAVI-Navigation system	●	●	●	●
CLC	203	ALL	COMAND or AUDIO	●	●	●	●
CLC	203	ALL	Sound system (Main amplifier)	●	●	●	●
CLC	203	ALL	UCI-Media interface	●	●	●	●
CLC	203	ALL	DAB-Digital radio	●	●	●	●
CLC	203	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
CLC	203	ALL	CTEL-Cellular telephone (JAPAN)	●	●	●	●
CLC	203	ALL	DCM-FL-Door control module front left	●	●	●	●
CLC	203	ALL	DCM-FR-Door control module front right	●	●	●	●
CLC	203	ALL	ESA passenger-Electric seat adjustment passenger	●	●	●	●
CLC	203	ALL	ESA driver-Electric seat adjustment driver (with	●	●	●	●
CLC	203	ALL	AAC-Automatic air conditioning	●	●	●	●
CLC	203	ALL	STH-Stationary heater	●	●	●	●
CLK	209	Up to 03/2004	ETC-Electronic transmission control	●	●	●	●
CLK	209	Up to 03/2004	ETC-Electronic transmission control	●	●	●	●
CLK	209	Up to 03/2004	SEQ-Sequentronic automated manual transmission	●	●	●	●
CLK	209	Up to 03/2004	ETC-Electronic transmission control	●	●	●	●
CLK	209	Up to 03/2004	ESM-Electronic selector module	●	●	●	●
CLK	209	Up to 03/2004	ME-SFI-Motor electronics	●	●	●	●
CLK	209	Up to 03/2004	ME-SFI-Motor electronics	●	●	●	●
CLK	209	Up to 03/2004	DTR-Distronic	●	●	●	●
CLK	209	Up to 03/2004	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CLK	209	Up to 03/2004	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CLK	209	Up to 03/2004	CDI 2-Common Rail Diesel Injection	●	●	●	●
CLK	209	Up to 03/2004	ESP-Electronic stability program	●	●	●	●
CLK	209	Up to 03/2004	EZS-Electronic ignition switch	●	●	●	●
CLK	209	Up to 03/2004	AB-Airbag	●	●	●	●
CLK	209	Up to 03/2004	OCP-Overhead control panel	●	●	●	●
CLK	209	Up to 03/2004	LCP-Lower control panel	●	●	●	●
CLK	209	Up to 03/2004	UCP-Upper control panel	●	●	●	●
CLK	209	Up to 03/2004	SAM-F-Signal acquisition and actuation module front	●	●	●	●
CLK	209	Up to 03/2004	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
CLK	209	Up to 03/2004	AHE-Trailer recognition	●	●	●	●

CLK	209	Up to 03/2004	MSS-Special vehicle multifunction control module	●	●	●	●
CLK	209	Up to 03/2004	RVC-Rollover bar soft top control module	●	●	●	●
CLK	209	Up to 03/2004	HRA-FR-Front right headlamp range control	●	●	●	●
CLK	209	Up to 03/2004	HRA-FL-Front left headlamp range control	●	●	●	●
CLK	209	Up to 03/2004	ICM-Instrument cluster with maintenance interval display	●	●	●	●
CLK	209	Up to 03/2004	PTS-Parktronic system	●	●	●	●
CLK	209	Up to 03/2004	SCM [MRM]-Steering column module	●	●	●	●
CLK	209	Up to 03/2004	TV-TV tuner	●	●	●	●
CLK	209	Up to 03/2004	E-call [Japan]-Telematic system	●	●	●	●
CLK	209	Up to 03/2004	E-call [USA]-Telematic system	●	●	●	●
CLK	209	Up to 03/2004	TELE AID-Telematic system	●	●	●	●
CLK	209	Up to 03/2004	CTEL over K-wire-Telematic system	●	●	●	●
CLK	209	Up to 03/2004	TELE AID-Control unit	●	●	●	●
CLK	209	Up to 03/2004	TELE AID-Telematic services Emergency call	●	●	●	●
CLK	209	Up to 03/2004	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
CLK	209	Up to 03/2004	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
CLK	209	Up to 03/2004	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●
CLK	209	Up to 03/2004	D2B-COMAND, MCS or AUDIO	●	●	●	●
CLK	209	Up to 03/2004	AUDIO	●	●	●	●
CLK	209	Up to 03/2004	COMAND	●	●	●	●
CLK	209	Up to 03/2004	CDC-CD changer	●	●	●	●
CLK	209	Up to 03/2004	VCS-Voice control system	●	●	●	●
CLK	209	Up to 03/2004	SOUND- Sound system	●	●	●	●
CLK	209	Up to 03/2004	SDAR-Satellite radio	●	●	●	●
CLK	209	Up to 03/2004	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●
CLK	209	Up to 03/2004	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●
CLK	209	Up to 03/2004	ESA passenger-Electric seat adjustment passenger	●	●	●	●
CLK	209	Up to 03/2004	ESA passenger-Electric seat adjustment passenger	●	●	●	●
CLK	209	Up to 03/2004	ESA driver-Electric seat adjustment driver	●	●	●	●
CLK	209	Up to 03/2004	ESA driver-Electric seat adjustment driver (with	●	●	●	●
CLK	209	Up to 03/2004	DCM-L-Door control module left	●	●	●	●

CLK	209	Up to 03/2004	DCM-R-Door control module right	●	●	●	●
CLK	209	Up to 03/2004	TLC-Trunk lid control	●	●	●	●
CLK	209	Up to 03/2004	RCM-Rear control module	●	●	●	●
CLK	209	Up to 03/2004	AAC-Automatic air conditioning	●	●	●	●
CLK	209	Up to 03/2004	STH-Stationary heater	●	●	●	●
CLK	209	As of 04/2004	ETC-Electronic transmission control	●	●	●	●
CLK	209	As of 04/2004	ETC-Electronic transmission control	●	●	●	●
CLK	209	As of 04/2004	SEQ-Sequentronic automated manual transmission	●	●	●	●
CLK	209	As of 04/2004	ETC-Electronic transmission control	●	●	●	●
CLK	209	As of 04/2004	ESM-Electronic selector module	●	●	●	●
CLK	209	As of 04/2004	DTR-Distrionic	●	●	●	●
CLK	209	As of 04/2004	ME-SFI-Motor electronics	●	●	●	●
CLK	209	As of 04/2004	ME-SFI-Motor electronics	●	●	●	●
CLK	209	As of 04/2004	ME 9.7-Motor electronics 9.7	●	●	●	●
CLK	209	As of 04/2004	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CLK	209	As of 04/2004	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CLK	209	As of 04/2004	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
CLK	209	As of 04/2004	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●
CLK	209	As of 04/2004	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●
CLK	209	As of 04/2004	CDI 4-Common Rail Diesel Injection	●	●	●	●
CLK	209	As of 04/2004	CDI 3-Common Rail Diesel Injection3	●	●	●	●
CLK	209	As of 04/2004	CDI 3-Common Rail Diesel Injection3	●	●	●	●
CLK	209	As of 04/2004	CDI 2-Common Rail Diesel Injection	●	●	●	●
CLK	209	As of 04/2004	ESP-Electronic stability program	●	●	●	●
CLK	209	As of 04/2004	TPC-Tire pressure monitor	●	●	●	●
CLK	209	As of 04/2004	EZS-Electronic ignition switch	●	●	●	●
CLK	209	As of 04/2004	AB-Airbag	●	●	●	●
CLK	209	As of 04/2004	OCP-Overhead control panel	●	●	●	●
CLK	209	As of 04/2004	WSS-Weight sensing system	●	●	●	●
CLK	209	As of 04/2004	LCP-Lower control panel	●	●	●	●
CLK	209	As of 04/2004	UCP-Upper control panel	●	●	●	●



CLK	209	As of 04/2004	SAM-F-Signal acquisition and actuation module front	●	●	●	●
CLK	209	As of 04/2004	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
CLK	209	As of 04/2004	AHE-Trailer recognition	●	●	●	●
CLK	209	As of 04/2004	AHE-Trailer recognition	●	●	●	●
CLK	209	As of 04/2004	MSS-Special vehicle multifunction control module	●	●	●	●
CLK	209	As of 04/2004	RVC-Rollover bar soft top control module	●	●	●	●
CLK	209	As of 04/2004	HRA-Automatic headlamp range adjustment and headlampcontrol	●	●	●	●
CLK	209	As of 04/2004	HRA-FR-Front right headlamp range control	●	●	●	●
CLK	209	As of 04/2004	HRA-FL-Front left headlamp range control	●	●	●	●
CLK	209	As of 04/2004	On board electrical system(voltage supply)	●	●	●	●
CLK	209	As of 04/2004	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
CLK	209	As of 04/2004	PTS-Parktronic system	●	●	●	●
CLK	209	As of 04/2004	SCM [MRM]-Steering column module	●	●	●	●
CLK	209	As of 04/2004	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
CLK	209	As of 04/2004	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
CLK	209	As of 04/2004	AUDIO	●	●	●	●
CLK	209	As of 04/2004	COMAND or AUDIO	●	●	●	●
CLK	209	As of 04/2004	CTEL-Mobile phone adapter with universal interface	●	●	●	●
CLK	209	As of 04/2004	CDC-CD changer	●	●	●	●
CLK	209	As of 04/2004	VCS-Voice control system	●	●	●	●
CLK	209	As of 04/2004	SOUND- Sound system	●	●	●	●
CLK	209	As of 04/2004	TV-TV tuner	●	●	●	●
CLK	209	As of 04/2004	TV-TV tuner(AGW)	●	●	●	●
CLK	209	As of 04/2004	SDAR-Satellite radio	●	●	●	●
CLK	209	As of 04/2004	NAVI-Navigation system	●	●	●	●
CLK	209	As of 04/2004	TELE AID-Control unit	●	●	●	●
CLK	209	As of 04/2004	TELE AID-Telematic services Emergency call	●	●	●	●
CLK	209	As of 04/2004	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
CLK	209	As of 04/2004	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
CLK	209	As of 04/2004	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●

CLK	209	As of 04/2004	ESA passenger-Electric seat adjustment passenger	●	●	●	●
CLK	209	As of 04/2004	ESA passenger-Electric seat adjustment passenger	●	●	●	●
CLK	209	As of 04/2004	ESA driver-Electric seat adjustment driver	●	●	●	●
CLK	209	As of 04/2004	ESA driver-Electric seat adjustment driver (with	●	●	●	●
CLK	209	As of 04/2004	DCM-L-Door control module left	●	●	●	●
CLK	209	As of 04/2004	DCM-R-Door control module right	●	●	●	●
CLK	209	As of 04/2004	TLC-Trunk lid control	●	●	●	●
CLK	209	As of 04/2004	RCM-Rear control module	●	●	●	●
CLK	209	As of 04/2004	AAC-Automatic air conditioning	●	●	●	●
CLK	209	As of 04/2004	STH-Stationary heater	●	●	●	●
CLS	218	ALL	DTR-Distronic	●	●	●	●
CLS	218	ALL	ME 9.7-Motor electronics 9.7	●	●	●	●
CLS	218	ALL	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
CLS	218	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
CLS	218	ALL	ME-Motor electronics 'MED40' for combustion engine'M270' (N3/10)	●	●	●	●
CLS	218	ALL	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●
CLS	218	ALL	ISM-Shift module (A80)	●	●	●	●
CLS	218	ALL	FSCU-Fuel pump	●	●	●	●
CLS	218	ALL	FSCU-Fuel pump	●	●	●	●
CLS	218	ALL	mbrace-mbrace (N123/4)	●	●	●	●
CLS	218	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
CLS	218	ALL	ESM-Electronic selector module	●	●	●	●
CLS	218	ALL	FSCU-Fuel pump	●	●	●	●
CLS	218	ALL	ETC-Electronic transmission control	●	●	●	●
CLS	218	ALL	CDI-Motor electronics 'CR42' for combustion engine'OM607' (N3/9)	●	●	●	●
CLS	218	ALL	CDI-Motor electronics 'CR43' for combustion engine'OM651' (N3/9)	●	●	●	●
CLS	218	ALL	CDI 60LS-Common Rail Diesel Injection	●	●	●	●
CLS	218	ALL	CDI-Motor electronics 'CDI61' for combustion engine'OM642' (N3/9)	●	●	●	●
CLS	218	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
CLS	218	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
CLS	218	ALL	ES-Electrical power steering (N68)	●	●	●	●
CLS	218	ALL	ESP-Electronic stability program	●	●	●	●
CLS	218	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
CLS	218	ALL	FWGW-Chassis gateway (N97/7)	●	●	●	●
CLS	218	ALL	TPM - Tire pressure monitor(N88)	●	●	●	●
CLS	218	ALL	CGW[ZGW]-Central gateway (CGW[ZGW])	●	●	●	●
CLS	218	ALL	CGW-Central gateway	●	●	●	●
CLS	218	ALL	CGW-Central gateway	●	●	●	●
CLS	218	ALL	EZS-Electronic ignition lock	●	●	●	●

CLS	218	ALL	EZS-Electronic ignition lock (N73)	●	●	●	●
CLS	218	ALL	XALWA-L-Left xenon headlamp(E1n1)	●	●	●	●
CLS	218	ALL	XALWA-R-Right xenon headlamp(E2n1)	●	●	●	●
CLS	218	ALL	SGR-Radar sensors control unit	●	●	●	●
CLS	218	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
CLS	218	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
CLS	218	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
CLS	218	ALL	KG-KEYLESS GO (N69/5)	●	●	●	●
CLS	218	ALL	KG-Keyless Go	●	●	●	●
CLS	218	ALL	WSS-Weight sensing system	●	●	●	●
CLS	218	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
CLS	218	ALL	SRS-Supplemental restraint system	●	●	●	●
CLS	218	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
CLS	218	ALL	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
CLS	218	ALL	RFK-Backup camera (B84/3)	●	●	●	●
CLS	218	ALL	Driver-side SAM-Driver signal acquisition andactuation module	●	●	●	●
CLS	218	ALL	Dr-side SAM-Driver signal acquisition and actuationmodule	●	●	●	●
CLS	218	ALL	Driver-side SAM-Driver signal acquisition andactuation module	●	●	●	●
CLS	218	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
CLS	218	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
CLS	218	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
CLS	218	ALL	SCM-Steering column module(N80)	●	●	●	●
CLS	218	ALL	Trailer recognition module	●	●	●	●
CLS	218	ALL	PSD-Control mudule 'Panoramic sliding roof' (A98)	●	●	●	●
CLS	218	ALL	SGR-Radar sensors control unit	●	●	●	●
CLS	218	ALL	ES-Electrical power steering	●	●	●	●
CLS	218	ALL	IC-Instrument cluster (A1)	●	●	●	●
CLS	218	ALL	IC-Instrument cluster (A1)	●	●	●	●
CLS	218	ALL	ICI-InCar Internet (N125/3)	●	●	●	●
CLS	218	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
CLS	218	ALL	COU [ZBE]-Central operating unit	●	●	●	●
CLS	218	ALL	DAB-Digital Audio Broadcating (N87/3)	●	●	●	●
CLS	218	ALL	DAB-Digital radio	●	●	●	●
CLS	218	ALL	ZAN-Central display	●	●	●	●
CLS	218	ALL	Left rear screen	●	●	●	●
CLS	218	ALL	Right rear screen	●	●	●	●
CLS	218	ALL	RFK-Backup camera(B84/3)	●	●	●	●
CLS	218	ALL	AMG DRVU-AMG DRIVE UNIT (N145)	●	●	●	●
CLS	218	ALL	DSI-DIRECT SELECT interface (N150)	●	●	●	●
CLS	218	ALL	AVE-H-Rear audio video unit	●	●	●	●
CLS	218	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
CLS	218	ALL	COMAND or AUDIO	●	●	●	●

CLS	218	ALL	MFK-Multifunction camera	●	●	●	●
CLS	218	ALL	NSA-Night View Assist	●	●	●	●
CLS	218	ALL	NSA-Night View Assist (N101)	●	●	●	●
CLS	218	ALL	PTS-Parktronic	●	●	●	●
CLS	218	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
CLS	218	ALL	SCCM-Steering column module (N80)	●	●	●	●
CLS	218	ALL	SDAR-Satellite radio (Valid for USA)	●	●	●	●
CLS	218	ALL	Sound system (Main amplifier)	●	●	●	●
CLS	218	ALL	Sound system (Main amplifier)	●	●	●	●
CLS	218	ALL	Sound system (Bass amplifier)	●	●	●	●
CLS	218	ALL	360° camera-360° camera (N148)	●	●	●	●
CLS	218	ALL	CTEL-Cellular telephone (JAPAN)	●	●	●	●
CLS	218	ALL	TV-TV tuner (AGW)	●	●	●	●
CLS	218	ALL	UCI-Media interface	●	●	●	●
CLS	218	ALL	NAVI20 - Navigation (N125/2)	●	●	●	●
CLS	218	ALL	TELE AID-Control unit	●	●	●	●
CLS	218	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
CLS	218	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
CLS	218	ALL	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
CLS	218	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
CLS	218	ALL	DCU-LF-Left front door	●	●	●	●
CLS	218	ALL	DCU-RF-Right front door	●	●	●	●
CLS	218	ALL	DCU-LR-Left rear door	●	●	●	●
CLS	218	ALL	DCU-RR-Right rear door	●	●	●	●
CLS	218	ALL	SIH-FOND-Rear passenger compartment seat heater	●	●	●	●
CLS	218	ALL	AMKS-LF-Active multicontour seat (N32/19)	●	●	●	●
CLS	218	ALL	AMKS-RF-Active multicontour seat (N32/22)	●	●	●	●
CLS	218	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●
CLS	218	ALL	HKS-Tailgate control (N121/1)	●	●	●	●
CLS	218	ALL	ESA 'Driver' -Electric seat adjustment 'Driver' (N32/1)	●	●	●	●
CLS	218	ALL	ESA driver	●	●	●	●
CLS	218	ALL	ESA 'Front passenger' -Electric seat adjustment 'Frontpassenger' with memory function (N32/2)	●	●	●	●
CLS	218	ALL	ESA passenger	●	●	●	●
CLS	218	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
CLS	218	ALL	Stationary heater	●	●	●	●
CLS	218	ALL	AU-Analog clock (A70/1)	●	●	●	●
CLS	218	ALL	LCP-Lower control panel (S77)	●	●	●	●
CLS	218	ALL	AISP-Dimming inside rearview mirror (A67)	●	●	●	●
CLS	218	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
CLS	218	ALL	AMLAB-L 2-Actuation module 2, LED exterior lighting, left front (E1n8)	●	●	●	●
CLS	218	ALL	AMLAB-R 2-Actuation module 2, LED exterior lighting, right front (E2n8)	●	●	●	●

CLS	218	ALL	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	●	●	●	●
CLS	218	ALL	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	●	●	●	●
CLS	219	Up to 05/2005	ETC-Electronic transmission control	●	●	●	●
CLS	219	Up to 05/2005	SEQ-Sequentronic automated manual transmission	●	●	●	●
CLS	219	Up to 05/2005	ETC-Electronic transmission control	●	●	●	●
CLS	219	Up to 05/2005	ME 9.7-Motor electronics 9.7	●	●	●	●
CLS	219	Up to 05/2005	DTR-Distronic	●	●	●	●
CLS	219	Up to 05/2005	ESM-Electronic selector module	●	●	●	●
CLS	219	Up to 05/2005	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●
CLS	219	Up to 05/2005	FSCU-Fuel pump	●	●	●	●
CLS	219	Up to 05/2005	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CLS	219	Up to 05/2005	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CLS	219	Up to 05/2005	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
CLS	219	Up to 05/2005	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●
CLS	219	Up to 05/2005	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●
CLS	219	Up to 05/2005	CDI 4-Common Rail Diesel Injection	●	●	●	●
CLS	219	Up to 05/2005	SBC-Sensotronic Brake Control	●	●	●	●
CLS	219	Up to 05/2005	ESP-Electronic stability program	●	●	●	●
CLS	219	Up to 05/2005	AIRmatic	●	●	●	●
CLS	219	Up to 05/2005	TPC-Tire pressure monitor	●	●	●	●
CLS	219	Up to 05/2005	TPC-Tire pressure monitor	●	●	●	●
CLS	219	Up to 05/2005	CGW-Central gateway	●	●	●	●
CLS	219	Up to 05/2005	EZS-Electronic ignition switch	●	●	●	●
CLS	219	Up to 05/2005	AB-Airbag	●	●	●	●
CLS	219	Up to 05/2005	WSS-Weight sensing system	●	●	●	●
CLS	219	Up to 05/2005	BCM-Battery control module	●	●	●	●
CLS	219	Up to 05/2005	System diagnosis (CAN)	●	●	●	●
CLS	219	Up to 05/2005	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
CLS	219	Up to 05/2005	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●
CLS	219	Up to 05/2005	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
CLS	219	Up to 05/2005	LCP-Lower control panel	●	●	●	●

CLS	219	Up to 05/2005	UCP-Upper control panel	●	●	●	●
CLS	219	Up to 05/2005	OCP-Overhead control panel	●	●	●	●
CLS	219	Up to 05/2005	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●
CLS	219	Up to 05/2005	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●
CLS	219	Up to 05/2005	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●
CLS	219	Up to 05/2005	On board electrical system (voltage supply)	●	●	●	●
CLS	219	Up to 05/2005	PTS-Parktronic system	●	●	●	●
CLS	219	Up to 05/2005	SCM [MRM]-Steering column module	●	●	●	●
CLS	219	Up to 05/2005	IC-Instrument cluster	●	●	●	●
CLS	219	Up to 05/2005	ASSYST-Active Service System	●	●	●	●
CLS	219	Up to 05/2005	ASSYST PLUS-PLUS Active Service System	●	●	●	●
CLS	219	Up to 05/2005	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
CLS	219	Up to 05/2005	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
CLS	219	Up to 05/2005	AUDIO	●	●	●	●
CLS	219	Up to 05/2005	COMAND or AUDIO	●	●	●	●
CLS	219	Up to 05/2005	CTEL-Mobile phone adapter with universal interface	●	●	●	●
CLS	219	Up to 05/2005	NAVI-Navigation system	●	●	●	●
CLS	219	Up to 05/2005	CDC-CD changer	●	●	●	●
CLS	219	Up to 05/2005	VCS-Voice control system	●	●	●	●
CLS	219	Up to 05/2005	TV-TV tuner	●	●	●	●
CLS	219	Up to 05/2005	TV-TV tuner (AGW)	●	●	●	●
CLS	219	Up to 05/2005	SDAR-Satellite radio	●	●	●	●
CLS	219	Up to 05/2005	GPS box	●	●	●	●
CLS	219	Up to 05/2005	TELE AID-Control unit	●	●	●	●
CLS	219	Up to 05/2005	TELE AID-Telematic services Emergency call	●	●	●	●
CLS	219	Up to 05/2005	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
CLS	219	Up to 05/2005	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
CLS	219	Up to 05/2005	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●
CLS	219	Up to 05/2005	ESA driver-Electric seat adjustment driver (with	●	●	●	●
CLS	219	Up to 05/2005	ESA passenger-Electric seat adjustment passenger	●	●	●	●

CLS	219	Up to 05/2005	DS-LF-Left front dynamic seat	●	●	●	●
CLS	219	Up to 05/2005	DS-RF-Right front dynamic seat	●	●	●	●
CLS	219	Up to 05/2005	DSP-Pneumatic pump for dynamic seat	●	●	●	●
CLS	219	Up to 05/2005	HS-Seat heater	●	●	●	●
CLS	219	Up to 05/2005	DCM-FL-Door control module front left	●	●	●	●
CLS	219	Up to 05/2005	DCM-FR-Door control module front right	●	●	●	●
CLS	219	Up to 05/2005	DCM-RL-Door control module rear left	●	●	●	●
CLS	219	Up to 05/2005	DCM-RR-Door control module rear right	●	●	●	●
CLS	219	Up to 05/2005	TLC-Trunk lid control	●	●	●	●
CLS	219	Up to 05/2005	LAE [LAA]-Loading floor automatically extendable	●	●	●	●
CLS	219	Up to 05/2005	RWT-Rear-end door control module	●	●	●	●
CLS	219	Up to 05/2005	AAC-Automatic air conditioning	●	●	●	●
CLS	219	Up to 05/2005	HSW-Heated steering wheel	●	●	●	●
CLS	219	Up to 05/2005	STH-Stationary heater	●	●	●	●
CLS	219	From 06/2005 to 05/2006	ETC-Electronic transmission control	●	●	●	●
CLS	219	From 06/2005 to 05/2006	SEQ-Sequentronic automated manual transmission	●	●	●	●
CLS	219	From 06/2005 to 05/2006	ETC-Electronic transmission control	●	●	●	●
CLS	219	From 06/2005 to 05/2006	ME 9.7-Motor electronics 9.7	●	●	●	●
CLS	219	From 06/2005 to 05/2006	DTR-Distronic	●	●	●	●
CLS	219	From 06/2005 to 05/2006	ESM-Electronic selector module	●	●	●	●
CLS	219	From 06/2005 to 05/2006	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●
CLS	219	From 06/2005 to 05/2006	FSCU-Fuel pump	●	●	●	●
CLS	219	From 06/2005 to 05/2006	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CLS	219	From 06/2005 to 05/2006	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CLS	219	From 06/2005 to 05/2006	ME 9.7 (AMG) -Motor electronics 9.7 (AMG)	●	●	●	●
CLS	219	From 06/2005 to 05/2006	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●
CLS	219	From 06/2005 to 05/2006	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●
CLS	219	From 06/2005 to 05/2006	CDI 4-Common Rail Diesel Injection	●	●	●	●
CLS	219	From 06/2005 to 05/2006	SBC-Sensotronic Brake Control	●	●	●	●
CLS	219	From 06/2005 to 05/2006	ESP-Electronic stability program	●	●	●	●
CLS	219	From 06/2005 to 05/2006	AIRmatic	●	●	●	●

CLS	219	From 06/2005 to05/2006	TPC-Tire pressure monitor	●	●	●	●
CLS	219	From 06/2005 to05/2006	CGW-Central gateway	●	●	●	●
CLS	219	From 06/2005 to05/2006	EZS-Electronic ignition switch	●	●	●	●
CLS	219	From 06/2005 to05/2006	AB-Airbag	●	●	●	●
CLS	219	From 06/2005 to05/2006	WSS-Weight sensing system	●	●	●	●
CLS	219	From 06/2005 to05/2006	BCM-Battery control module	●	●	●	●
CLS	219	From 06/2005 to05/2006	System diagnosis (CAN)	●	●	●	●
CLS	219	From 06/2005 to05/2006	Dr-side SAM-Driver signal acquisition and actuationmodule	●	●	●	●
CLS	219	From 06/2005 to05/2006	Pass-side SAM-Passenger-side signal acquisition andactuation module	●	●	●	●
CLS	219	From 06/2005 to05/2006	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
CLS	219	From 06/2005 to05/2006	LCP-Lower control panel	●	●	●	●
CLS	219	From 06/2005 to05/2006	UCP-Upper control panel	●	●	●	●
CLS	219	From 06/2005 to05/2006	OCP-Overhead control panel	●	●	●	●
CLS	219	From 06/2005 to05/2006	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
CLS	219	From 06/2005 to05/2006	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
CLS	219	From 06/2005 to05/2006	HRA-Automatic headlamp range adjustment and headlampcontrol	●	●	●	●
CLS	219	From 06/2005 to05/2006	On board electrical system(voltage supply)	●	●	●	●
CLS	219	From 06/2005 to05/2006	PTS-Parktronic system	●	●	●	●
CLS	219	From 06/2005 to05/2006	SCM [MRM]-Steering column module	●	●	●	●
CLS	219	From 06/2005 to05/2006	IC-Instrument cluster	●	●	●	●
CLS	219	From 06/2005 to05/2006	ASSYST-Active Service System	●	●	●	●
CLS	219	From 06/2005 to05/2006	ASSYST PLUS-PLUS Active Service System	●	●	●	●
CLS	219	From 06/2005 to05/2006	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
CLS	219	From 06/2005 to05/2006	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
CLS	219	From 06/2005 to05/2006	AUDIO	●	●	●	●
CLS	219	From 06/2005 to05/2006	COMAND or AUDIO	●	●	●	●
CLS	219	From 06/2005 to05/2006	CTEL-Mobile phone adapter with universal interface	●	●	●	●
CLS	219	From 06/2005 to05/2006	NAVI-Navigation system	●	●	●	●
CLS	219	From 06/2005 to05/2006	CDC-CD changer	●	●	●	●



CLS	219	From 06/2005 to05/2006	VCS-Voice control system	●	●	●	●
CLS	219	From 06/2005 to05/2006	TV-TV tuner	●	●	●	●
CLS	219	From 06/2005 to05/2006	TV-TV tuner(AGW)	●	●	●	●
CLS	219	From 06/2005 to05/2006	SDAR-Satellite radio	●	●	●	●
CLS	219	From 06/2005 to05/2006	GPS box	●	●	●	●
CLS	219	From 06/2005 to05/2006	TELE AID-Control unit	●	●	●	●
CLS	219	From 06/2005 to05/2006	TELE AID-Telematic services Emergency call	●	●	●	●
CLS	219	From 06/2005 to05/2006	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
CLS	219	From 06/2005 to05/2006	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
CLS	219	From 06/2005 to05/2006	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
CLS	219	From 06/2005 to05/2006	ESA driver-Electric seat adjustment driver (withmemory)	●	●	●	●
CLS	219	From 06/2005 to05/2006	ESA passenger-Electric seat adjustment passenger	●	●	●	●
CLS	219	From 06/2005 to05/2006	DS-LF-Left front dynamic seat	●	●	●	●
CLS	219	From 06/2005 to05/2006	DS-RF-Right front dynamic seat	●	●	●	●
CLS	219	From 06/2005 to05/2006	DSP-Pneumatic pump for dynamic seat	●	●	●	●
CLS	219	From 06/2005 to05/2006	HS-Seat heater	●	●	●	●
CLS	219	From 06/2005 to05/2006	DCM-FL-Door control module front left	●	●	●	●
CLS	219	From 06/2005 to05/2006	DCM-FR-Door control module front right	●	●	●	●
CLS	219	From 06/2005 to05/2006	DCM-RL-Door control module rear left	●	●	●	●
CLS	219	From 06/2005 to05/2006	DCM-RR-Door control module rear right	●	●	●	●
CLS	219	From 06/2005 to05/2006	TLC-Trunk lid control	●	●	●	●
CLS	219	From 06/2005 to05/2006	LAE [LAA]-Loading floor automatically extendable	●	●	●	●
CLS	219	From 06/2005 to05/2006	RWT-Rear-end door control module	●	●	●	●
CLS	219	From 06/2005 to05/2006	AAC-Automatic air conditioning	●	●	●	●
CLS	219	From 06/2005 to05/2006	HSW-Heated steering wheel	●	●	●	●
CLS	219	From 06/2005 to05/2006	STH-Stationary heater	●	●	●	●
CLS	219	As of 06/2006	ETC-Electronic transmission control	●	●	●	●
CLS	219	As of 06/2006	SEQ-Sequentronic automated manual transmission	●	●	●	●
CLS	219	As of 06/2006	ETC-Electronic transmission control	●	●	●	●
CLS	219	As of 06/2006	ME 9.7-Motor electronics 9.7	●	●	●	●

CLS	219	As of 06/2006	DTR-Distronic	●	●	●	●
CLS	219	As of 06/2006	ESM-Electronic selector module	●	●	●	●
CLS	219	As of 06/2006	TV-TV tuner	●	●	●	●
CLS	219	As of 06/2006	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●
CLS	219	As of 06/2006	FSCU-Fuel pump	●	●	●	●
CLS	219	As of 06/2006	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CLS	219	As of 06/2006	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
CLS	219	As of 06/2006	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
CLS	219	As of 06/2006	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●
CLS	219	As of 06/2006	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●
CLS	219	As of 06/2006	CDI 4-Common Rail Diesel Injection	●	●	●	●
CLS	219	As of 06/2006	ABR-Adaptive Brake	●	●	●	●
CLS	219	As of 06/2006	AIRmatic	●	●	●	●
CLS	219	As of 06/2006	TPC-Tire pressure monitor	●	●	●	●
CLS	219	As of 06/2006	CGW-Central gateway	●	●	●	●
CLS	219	As of 06/2006	EZS-Electronic ignition switch	●	●	●	●
CLS	219	As of 06/2006	AB-Airbag	●	●	●	●
CLS	219	As of 06/2006	WSS-Weight sensing system	●	●	●	●
CLS	219	As of 06/2006	System diagnosis (CAN)	●	●	●	●
CLS	219	As of 06/2006	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
CLS	219	As of 06/2006	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●
CLS	219	As of 06/2006	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
CLS	219	As of 06/2006	LCP-Lower control panel	●	●	●	●
CLS	219	As of 06/2006	UCP-Upper control panel	●	●	●	●
CLS	219	As of 06/2006	OCP-Overhead control panel	●	●	●	●
CLS	219	As of 06/2006	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●
CLS	219	As of 06/2006	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●
CLS	219	As of 06/2006	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●
CLS	219	As of 06/2006	PTS-Parktronic system	●	●	●	●
CLS	219	As of 06/2006	PTS-Parktronic system	●	●	●	●
CLS	219	As of 06/2006	SCM [MRM]-Steering column module	●	●	●	●

CLS	219	As of 06/2006	IC-Instrument cluster	●	●	●	●
CLS	219	As of 06/2006	ASSYST-Active Service System	●	●	●	●
CLS	219	As of 06/2006	ASSYST PLUS-PLUS Active Service System	●	●	●	●
CLS	219	As of 06/2006	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
CLS	219	As of 06/2006	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
CLS	219	As of 06/2006	AUDIO	●	●	●	●
CLS	219	As of 06/2006	COMAND or AUDIO	●	●	●	●
CLS	219	As of 06/2006	CTEL-Mobile phone adapter with universal interface	●	●	●	●
CLS	219	As of 06/2006	NAVI-Navigation system	●	●	●	●
CLS	219	As of 06/2006	CDC-CD changer	●	●	●	●
CLS	219	As of 06/2006	VCS-Voice control system	●	●	●	●
CLS	219	As of 06/2006	TV-TV tuner	●	●	●	●
CLS	219	As of 06/2006	TV-TV tuner(AGW)	●	●	●	●
CLS	219	As of 06/2006	SDAR-Satellite radio	●	●	●	●
CLS	219	As of 06/2006	GPS box	●	●	●	●
CLS	219	As of 06/2006	TELE AID-Control unit	●	●	●	●
CLS	219	As of 06/2006	TELE AID-Telematic services Emergency call	●	●	●	●
CLS	219	As of 06/2006	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
CLS	219	As of 06/2006	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
CLS	219	As of 06/2006	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
CLS	219	As of 06/2006	COMAND or AUDIO	●	●	●	●
CLS	219	As of 06/2006	Sound system (Main amplifier)	●	●	●	●
CLS	219	As of 06/2006	UCI-Media interface	●	●	●	●
CLS	219	As of 06/2006	DAB-Digital radio	●	●	●	●
CLS	219	As of 06/2006	SDAR-Satellite radio(Valid for USA)	●	●	●	●
CLS	219	As of 06/2006	TV-TV tuner	●	●	●	●
CLS	219	As of 06/2006	CTEL-Cellular telephone (JAPAN)	●	●	●	●
CLS	219	As of 06/2006	ESA driver-Electric seat adjustment driver (with	●	●	●	●
CLS	219	As of 06/2006	ESA passenger-Electric seat adjustment passenger	●	●	●	●
CLS	219	As of 06/2006	DS-LF-Left front dynamic seat	●	●	●	●

CLS	219	As of 06/2006	DS-RF-Right front dynamic seat	●	●	●	●
CLS	219	As of 06/2006	DSP-Pneumatic pump for dynamic seat	●	●	●	●
CLS	219	As of 06/2006	HS-Seat heater	●	●	●	●
CLS	219	As of 06/2006	DCM-FL-Door control module front left	●	●	●	●
CLS	219	As of 06/2006	DCM-FR-Door control module front right	●	●	●	●
CLS	219	As of 06/2006	DCM-RL-Door control module rear left	●	●	●	●
CLS	219	As of 06/2006	DCM-RR-Door control module rear right	●	●	●	●
CLS	219	As of 06/2006	TLC-Trunk lid control	●	●	●	●
CLS	219	As of 06/2006	LAE [LAA]-Loading floor automatically extendable	●	●	●	●
CLS	219	As of 06/2006	RWT-Rear-end door control module	●	●	●	●
CLS	219	As of 06/2006	AAC-Automatic air conditioning	●	●	●	●
CLS	219	As of 06/2006	HSW-Heated steering wheel	●	●	●	●
CLS	219	As of 06/2006	STH-Stationary heater	●	●	●	●
E-Class	207	ALL	ETC-Electronic transmission control	●	●	●	●
E-Class	207	ALL	ETC-Electronic transmission control	●	●	●	●
E-Class	207	ALL	ME 9.7-Motor electronics 9.7	●	●	●	●
E-Class	207	ALL	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
E-Class	207	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
E-Class	207	ALL	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●
E-Class	207	ALL	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	●	●	●	●
E-Class	207	ALL	ME-Motor electronics 'MED40CNG' for combustion engine 'M274' (N3/10)	●	●	●	●
E-Class	207	ALL	ME - Motor electronics 'SIM271DE20' for combustionengine 'M271EVO' (N3/10)	●	●	●	●
E-Class	207	ALL	FSCU-Fuel pump	●	●	●	●
E-Class	207	ALL	FSCU-Fuel pump	●	●	●	●
E-Class	207	ALL	DTR-Distronic	●	●	●	●
E-Class	207	ALL	ESM-Electronic selector module	●	●	●	●
E-Class	207	ALL	ISM-Shift module (A80)	●	●	●	●
E-Class	207	ALL	mbrace-mbrace (N123/4)	●	●	●	●
E-Class	207	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
E-Class	207	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
E-Class	207	ALL	CDI 60LS-Common Rail Diesel Injection	●	●	●	●
E-Class	207	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
E-Class	207	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
E-Class	207	ALL	CDID-Common Rail Diesel Injection	●	●	●	●
E-Class	207	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
E-Class	207	ALL	CDI-Motor electronics 'CR42' for combustion engine 'OM607' (N3/9)	●	●	●	●
E-Class	207	ALL	CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9)	●	●	●	●

E-Class	207	ALL	CDI-Motor electronics 'CDI61' for combustion engine'OM642' (N3/9)	●	●	●	●
E-Class	207	ALL	ESP-Electronic stability program	●	●	●	●
E-Class	207	ALL	ES-Electrical power steering (N68)	●	●	●	●
E-Class	207	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
E-Class	207	ALL	TPM - Tire pressure monitor(N88)	●	●	●	●
E-Class	207	ALL	AIRMATIC-AIRMATIC	●	●	●	●
E-Class	207	ALL	AIRSCARF-AIRSCARF system (N25/7)	●	●	●	●
E-Class	207	ALL	FWGW-Chassis gateway (N97/7)	●	●	●	●
E-Class	207	ALL	CGW-Central gateway	●	●	●	●
E-Class	207	ALL	CGW[ZGW]-Central gateway (CGW[ZGW])	●	●	●	●
E-Class	207	ALL	CGW-Central gateway	●	●	●	●
E-Class	207	ALL	EZS-Electronic ignition switch	●	●	●	●
E-Class	207	ALL	EZS-Electronic ignition lock (N73)	●	●	●	●
E-Class	207	ALL	KG-Keyless Go	●	●	●	●
E-Class	207	ALL	KG-KEYLESS GO(N69/5)	●	●	●	●
E-Class	207	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
E-Class	207	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
E-Class	207	ALL	SRS-Supplemental restraint system	●	●	●	●
E-Class	207	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
E-Class	207	ALL	WSS-Weight sensing system	●	●	●	●
E-Class	207	ALL	OCP-Overhead control panel	●	●	●	●
E-Class	207	ALL	PSD-Control mudule 'Panoramic sliding roof' (A98)	●	●	●	●
E-Class	207	ALL	SGR-Radar sensors control unit	●	●	●	●
E-Class	207	ALL	SGR-Radar sensors control unit	●	●	●	●
E-Class	207	ALL	Dr-side SAM-Driver signal acquisition and actuationmodule	●	●	●	●
E-Class	207	ALL	Driver-side SAM-Driver signal acquisition andactuation module	●	●	●	●
E-Class	207	ALL	Driver-side SAM-Driver signal acquisition andactuation module	●	●	●	●
E-Class	207	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
E-Class	207	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
E-Class	207	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
E-Class	207	ALL	Trailer recognition module	●	●	●	●
E-Class	207	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
E-Class	207	ALL	RevETR-LF-Left front reversible emergency tensioningretractor (A76)	●	●	●	●
E-Class	207	ALL	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
E-Class	207	ALL	RevETR-RF-Right front reversible emergency tensioningretractor (A76/1)	●	●	●	●
E-Class	207	ALL	XALWA-L-Left xenon headlamp(E1n1)	●	●	●	●
E-Class	207	ALL	XALWA-R-Right xenon headlamp(E2n1)	●	●	●	●
E-Class	207	ALL	BMS-Battery management system (N82/2)	●	●	●	●
E-Class	207	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
E-Class	207	ALL	KG-KEYLESS GO (N69/5)	●	●	●	●

E-Class	207	ALL	SG-EM-Power electronics (N129/1)	●	●	●	●
E-Class	207	ALL	RFK-Backup camera (B84/3)	●	●	●	●
E-Class	207	ALL	SCM-Steering column module(N80)	●	●	●	●
E-Class	207	ALL	ES-Electrical power steering	●	●	●	●
E-Class	207	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
E-Class	207	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
E-Class	207	ALL	IC-Instrument cluster (A1)	●	●	●	●
E-Class	207	ALL	IC-Instrument cluster (A1)	●	●	●	●
E-Class	207	ALL	ICI-InCar Internet (N125/3)	●	●	●	●
E-Class	207	ALL	PTS-PARKTRONIC(N62)	●	●	●	●
E-Class	207	ALL	RFK-Backup camera(B84/3)	●	●	●	●
E-Class	207	ALL	SCCM-Steering column module(N80)	●	●	●	●
E-Class	207	ALL	COMAND or AUDIO	●	●	●	●
E-Class	207	ALL	COMAND or AUDIO	●	●	●	●
E-Class	207	ALL	COU [ZBE]-Central operating unit	●	●	●	●
E-Class	207	ALL	ZBE-Audio/COMAND operating unit(A40/9)	●	●	●	●
E-Class	207	ALL	ZAN-Central display	●	●	●	●
E-Class	207	ALL	TV-TV tuner(AGW)	●	●	●	●
E-Class	207	ALL	CTEL-Cellular telephone(JAPAN)	●	●	●	●
E-Class	207	ALL	DAB-Digital radio	●	●	●	●
E-Class	207	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
E-Class	207	ALL	Sound system (Main amplifier)	●	●	●	●
E-Class	207	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
E-Class	207	ALL	UCI-Media interface	●	●	●	●
E-Class	207	ALL	TELE AID-Control unit	●	●	●	●
E-Class	207	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
E-Class	207	ALL	TELE AID-Telematic services MB Info, Roadsideassistance(USA, Canada), Tele diagnosis(ECE)	●	●	●	●
E-Class	207	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
E-Class	207	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
E-Class	207	ALL	SG-FOND-Rear control unit (N22/6)	●	●	●	●
E-Class	207	ALL	MFK-Multifunction camera	●	●	●	●
E-Class	207	ALL	Left rear screen	●	●	●	●
E-Class	207	ALL	Right rear screen	●	●	●	●
E-Class	207	ALL	AMG DRVU-AMG DRIVE UNIT (N145)	●	●	●	●
E-Class	207	ALL	DSI-DIRECT SELECT interface (N150)	●	●	●	●
E-Class	207	ALL	Drive-side SAM-Front signal acquisition and actuationmodule (N10/1)	●	●	●	●
E-Class	207	ALL	AVE-H-Rear audio video unit	●	●	●	●
E-Class	207	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
E-Class	207	ALL	NAV-Navigation module (A2/30)	●	●	●	●
E-Class	207	ALL	NSA-Night View Assist(N101)	●	●	●	●
E-Class	207	ALL	PTS-Parktronic	●	●	●	●
E-Class	207	ALL	Sound system (Main amplifier)	●	●	●	●
E-Class	207	ALL	Sound system (Bass amplifier)	●	●	●	●
E-Class	207	ALL	360° camera-360° camera(N148)	●	●	●	●
E-Class	207	ALL	360° camera-360° camera(N148)	●	●	●	●

E-Class	207	ALL	NAVI20 - Navigation(N125/2)	●	●	●	●
E-Class	207	ALL	DCU-LF-Left front door	●	●	●	●
E-Class	207	ALL	DCU-RF-Right front door	●	●	●	●
E-Class	207	ALL	ESA 'Driver' -Electric seat adjustment 'Driver' (N32/1)	●	●	●	●
E-Class	207	ALL	ESA driver	●	●	●	●
E-Class	207	ALL	ESA' Front passenger' -Electric seat adjustment 'Frontpassenger' with memory function (N32/2)	●	●	●	●
E-Class	207	ALL	ESA passenger	●	●	●	●
E-Class	207	ALL	ESA-Electirc seat adjustment 'Front passenger' (N32/2)	●	●	●	●
E-Class	207	ALL	SIH-FOND-Rear passenger compartment seat heater	●	●	●	●
E-Class	207	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●
E-Class	207	ALL	HKS-Tailgate control (N121/1)	●	●	●	●
E-Class	207	ALL	Stationary heater	●	●	●	●
E-Class	207	ALL	AAC-Air conditiioning	●	●	●	●
E-Class	207	ALL	EKMK-Electric refrigerant compressor (A9/5)	●	●	●	●
E-Class	207	ALL	LCP-Lower control panel (S77)	●	●	●	●
E-Class	207	ALL	AU-Analog clock (A70/1)	●	●	●	●
E-Class	207	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
E-Class	211	Up to 05/2005	ETC-Electronic transmission control	●	●	●	●
E-Class	211	Up to 05/2005	SEQ-Sequentronic automated manual transmission	●	●	●	●
E-Class	211	Up to 05/2005	ETC-Electronic transmission control	●	●	●	●
E-Class	211	Up to 05/2005	DTR-Distronic	●	●	●	●
E-Class	211	Up to 05/2005	DTR-Distronic	●	●	●	●
E-Class	211	Up to 05/2005	ME-SFI-Motor electronics	●	●	●	●
E-Class	211	Up to 05/2005	ME-SFI-Motor electronics	●	●	●	●
E-Class	211	Up to 05/2005	ME-SFI-Motor electronics	●	●	●	●
E-Class	211	Up to 05/2005	ESM-Electronic selector module	●	●	●	●
E-Class	211	Up to 05/2005	ME 9.7-Motor electronics 9.7	●	●	●	●
E-Class	211	Up to 05/2005	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
E-Class	211	Up to 05/2005	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
E-Class	211	Up to 05/2005	CDI 3-Common Rail Diesel Injection3	●	●	●	●
E-Class	211	Up to 05/2005	CDI 3-Common Rail Diesel Injection3	●	●	●	●
E-Class	211	Up to 05/2005	ETC-Electronic transmission control	●	●	●	●
E-Class	211	Up to 05/2005	CDID-Common Rail Diesel Injection	●	●	●	●
E-Class	211	Up to 05/2005	TV-TV tuner	●	●	●	●
E-Class	211	Up to 05/2005	CDI-V-Common Rail Diesel Injection	●	●	●	●

E-Class	211	Up to 05/2005	SBC-Sensotronic Brake Control	●	●	●	●
E-Class	211	Up to 05/2005	SBC-Sensotronic Brake Control	●	●	●	●
E-Class	211	Up to 05/2005	ESP-Electronic stability program	●	●	●	●
E-Class	211	Up to 05/2005	ESP-Electronic stability program	●	●	●	●
E-Class	211	Up to 05/2005	AIRmatic	●	●	●	●
E-Class	211	Up to 05/2005	Suspension	●	●	●	●
E-Class	211	Up to 05/2005	TPC-Tire pressure monitor	●	●	●	●
E-Class	211	Up to 05/2005	TPC-Tire pressure monitor	●	●	●	●
E-Class	211	Up to 05/2005	ABR-Adaptive Brake	●	●	●	●
E-Class	211	Up to 05/2005	CGW-Central gateway	●	●	●	●
E-Class	211	Up to 05/2005	EZS-Electronic ignition switch	●	●	●	●
E-Class	211	Up to 05/2005	AB-Airbag	●	●	●	●
E-Class	211	Up to 05/2005	WSS-Weight sensing system	●	●	●	●
E-Class	211	Up to 05/2005	BCM-Battery control module	●	●	●	●
E-Class	211	Up to 05/2005	On board electrical system(voltage supply)	●	●	●	●
E-Class	211	Up to 05/2005	System diagnosis (CAN)	●	●	●	●
E-Class	211	Up to 05/2005	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
E-Class	211	Up to 05/2005	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●
E-Class	211	Up to 05/2005	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
E-Class	211	Up to 05/2005	AHE-Trailer recognition	●	●	●	●
E-Class	211	Up to 05/2005	MSS-Special vehicle multifunction control module	●	●	●	●
E-Class	211	Up to 05/2005	LCP-Lower control panel	●	●	●	●
E-Class	211	Up to 05/2005	UCP-Upper control panel	●	●	●	●
E-Class	211	Up to 05/2005	OCP-Overhead control panel	●	●	●	●
E-Class	211	Up to 05/2005	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●
E-Class	211	Up to 05/2005	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●
E-Class	211	Up to 05/2005	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●
E-Class	211	Up to 05/2005	On board electrical system(voltage supply)	●	●	●	●
E-Class	211	Up to 05/2005	XALWA-L-Xenon headlamp, left	●	●	●	●
E-Class	211	Up to 05/2005	XALWA-R-Xenon headlamp, right	●	●	●	●
E-Class	211	Up to 05/2005	PTS-Parktronic system	●	●	●	●



E-Class	211	Up to 05/2005	SCM [MRM]-Steering column module	●	●	●	●
E-Class	211	Up to 05/2005	SCM [MRM]-Steering column module	●	●	●	●
E-Class	211	Up to 05/2005	IC-Instrument cluster	●	●	●	●
E-Class	211	Up to 05/2005	ASSYST-Active Service System	●	●	●	●
E-Class	211	Up to 05/2005	ASSYST PLUS-PLUS Active Service System	●	●	●	●
E-Class	211	Up to 05/2005	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
E-Class	211	Up to 05/2005	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
E-Class	211	Up to 05/2005	CTEL-Telecommunication for telematics services	●	●	●	●
E-Class	211	Up to 05/2005	Telephone adapter for portable CTET-Telecommunication for telematics services	●	●	●	●
E-Class	211	Up to 05/2005	CTEL-Mobile phone adapter with universal interface	●	●	●	●
E-Class	211	Up to 05/2005	AUDIO	●	●	●	●
E-Class	211	Up to 05/2005	COMAND or AUDIO	●	●	●	●
E-Class	211	Up to 05/2005	NAVI-Navigation system	●	●	●	●
E-Class	211	Up to 05/2005	CDC-CD changer	●	●	●	●
E-Class	211	Up to 05/2005	VCS-Voice control system	●	●	●	●
E-Class	211	Up to 05/2005	TV-TV tuner	●	●	●	●
E-Class	211	Up to 05/2005	TV-TV tuner (AGW)	●	●	●	●
E-Class	211	Up to 05/2005	SDAR-Satellite radio	●	●	●	●
E-Class	211	Up to 05/2005	GPS box	●	●	●	●
E-Class	211	Up to 05/2005	TELE AID-Control unit	●	●	●	●
E-Class	211	Up to 05/2005	TELE AID-Telematic services Emergency call	●	●	●	●
E-Class	211	Up to 05/2005	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
E-Class	211	Up to 05/2005	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
E-Class	211	Up to 05/2005	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●
E-Class	211	Up to 05/2005	PTS-Parktronic system	●	●	●	●
E-Class	211	Up to 05/2005	COMAND or AUDIO	●	●	●	●
E-Class	211	Up to 05/2005	Sound system (Main amplifier)	●	●	●	●
E-Class	211	Up to 05/2005	UCI-Media interface	●	●	●	●
E-Class	211	Up to 05/2005	DAB-Digital radio	●	●	●	●

E-Class	211	Up to 05/2005	SDAR-Satellite radio(Valid for USA)	●	●	●	●
E-Class	211	Up to 05/2005	TV-TV tuner	●	●	●	●
E-Class	211	Up to 05/2005	CTEL-Cellular telephone (JAPAN)	●	●	●	●
E-Class	211	Up to 05/2005	ESA driver-Electric seat adjustment driver	●	●	●	●
E-Class	211	Up to 05/2005	ESA driver-Electric seat adjustment driver (with	●	●	●	●
E-Class	211	Up to 05/2005	ESA passenger-Electric seat adjustment passenger	●	●	●	●
E-Class	211	Up to 05/2005	ESA passenger-Electric seat adjustment passenger	●	●	●	●
E-Class	211	Up to 05/2005	DS-LF-Left front dynamic seat	●	●	●	●
E-Class	211	Up to 05/2005	DS-RF-Right front dynamic seat	●	●	●	●
E-Class	211	Up to 05/2005	DSP-Pneumatic pump for dynamic seat	●	●	●	●
E-Class	211	Up to 05/2005	HS-Seat heater	●	●	●	●
E-Class	211	Up to 05/2005	HS-Seat heater	●	●	●	●
E-Class	211	Up to 05/2005	DCM-FL-Door control module front left	●	●	●	●
E-Class	211	Up to 05/2005	DCM-FR-Door control module front right	●	●	●	●
E-Class	211	Up to 05/2005	DCM-RL-Door control module rear left	●	●	●	●
E-Class	211	Up to 05/2005	DCM-RR-Door control module rear right	●	●	●	●
E-Class	211	Up to 05/2005	TLC-Trunk lid control	●	●	●	●
E-Class	211	Up to 05/2005	LAE [LAA]-Loading floor automatically extendable	●	●	●	●
E-Class	211	Up to 05/2005	RWT-Rear-end door control module	●	●	●	●
E-Class	211	Up to 05/2005	TLC-Trunk lid control	●	●	●	●
E-Class	211	Up to 05/2005	AAC-Automatic air conditioning	●	●	●	●
E-Class	211	Up to 05/2005	HSW-Heated steering wheel	●	●	●	●
E-Class	211	Up to 05/2005	HSW-Heated steering wheel	●	●	●	●
E-Class	211	Up to 05/2005	STH-Stationary heater	●	●	●	●
E-Class	211	From 06/2005 to 05/2006	ETC-Electronic transmission control	●	●	●	●
E-Class	211	From 06/2005 to 05/2006	SEQ-Sequentronic automated manual transmission	●	●	●	●
E-Class	211	From 06/2005 to 05/2006	ETC-Electronic transmission control	●	●	●	●
E-Class	211	From 06/2005 to 05/2006	DTR-Distronic	●	●	●	●
E-Class	211	From 06/2005 to 05/2006	ME-SFI-Motor electronics	●	●	●	●
E-Class	211	From 06/2005 to 05/2006	ME-SFI-Motor electronics	●	●	●	●
E-Class	211	From 06/2005 to 05/2006	ME-SFI-Motor electronics	●	●	●	●

E-Class	211	From 06/2005 to05/2006	ESM-Electronic selector module	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ME 9.7-Motor electronics 9.7	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
E-Class	211	From 06/2005 to05/2006	CDI 3-Common Rail Diesel Injection3	●	●	●	●
E-Class	211	From 06/2005 to05/2006	CDI 3-Common Rail Diesel Injection3	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ETC-Electronic transmission control	●	●	●	●
E-Class	211	From 06/2005 to05/2006	CDI 4-Common Rail Diesel Injection	●	●	●	●
E-Class	211	From 06/2005 to05/2006	CDI5-Common Rail Diesel Injection(USA)	●	●	●	●
E-Class	211	From 06/2005 to05/2006	CDI 5-Common Rail Diesel Injection	●	●	●	●
E-Class	211	From 06/2005 to05/2006	SBC-Sensotronic Brake Control	●	●	●	●
E-Class	211	From 06/2005 to05/2006	SBC-Sensotronic Brake Control	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ESP-Electronic stability program	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ESP-Electronic stability program	●	●	●	●
E-Class	211	From 06/2005 to05/2006	AIRmatic	●	●	●	●
E-Class	211	From 06/2005 to05/2006	Suspension	●	●	●	●
E-Class	211	From 06/2005 to05/2006	TPC-Tire pressure monitor	●	●	●	●
E-Class	211	From 06/2005 to05/2006	CGW-Central gateway	●	●	●	●
E-Class	211	From 06/2005 to05/2006	EZS-Electronic ignition switch	●	●	●	●
E-Class	211	From 06/2005 to05/2006	AB-Airbag	●	●	●	●
E-Class	211	From 06/2005 to05/2006	WSS-Weight sensing system	●	●	●	●
E-Class	211	From 06/2005 to05/2006	BCM-Battery control module	●	●	●	●
E-Class	211	From 06/2005 to05/2006	On board electrical system(voltage supply)	●	●	●	●
E-Class	211	From 06/2005 to05/2006	System diagnosis (CAN)	●	●	●	●
E-Class	211	From 06/2005 to05/2006	Dr-side SAM-Driver signal acquisition and actuationmodule	●	●	●	●
E-Class	211	From 06/2005 to05/2006	Pass-side SAM-Passenger-side signal acquisition andactuation module	●	●	●	●
E-Class	211	From 06/2005 to05/2006	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
E-Class	211	From 06/2005 to05/2006	AHE-Trailer recognition	●	●	●	●
E-Class	211	From 06/2005 to05/2006	MSS-Special vehicle multifunction control module	●	●	●	●
E-Class	211	From 06/2005 to05/2006	LCP-Lower control panel	●	●	●	●

E-Class	211	From 06/2005 to05/2006	UCP-Upper control panel	●	●	●	●
E-Class	211	From 06/2005 to05/2006	OCP-Overhead control panel	●	●	●	●
E-Class	211	From 06/2005 to05/2006	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
E-Class	211	From 06/2005 to05/2006	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
E-Class	211	From 06/2005 to05/2006	HRA-Automatic headlamp range adjustment and headlampcontrol	●	●	●	●
E-Class	211	From 06/2005 to05/2006	On board electrical system(voltage supply)	●	●	●	●
E-Class	211	From 06/2005 to05/2006	PTS-Parktronic system	●	●	●	●
E-Class	211	From 06/2005 to05/2006	SCM [MRM]-Steering column module	●	●	●	●
E-Class	211	From 06/2005 to05/2006	SCM [MRM]-Steering column module	●	●	●	●
E-Class	211	From 06/2005 to05/2006	IC-Instrument cluster	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ASSYST-Active Service System	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ASSYST PLUS-PLUS Active Service System	●	●	●	●
E-Class	211	From 06/2005 to05/2006	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
E-Class	211	From 06/2005 to05/2006	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
E-Class	211	From 06/2005 to05/2006	CTEL-Telecommunication for telematics services	●	●	●	●
E-Class	211	From 06/2005 to05/2006	Telephone adapter for portable CTET-Telecommunicationfor telematics services	●	●	●	●
E-Class	211	From 06/2005 to05/2006	CTEL-Mobile phone adapter with universal interface	●	●	●	●
E-Class	211	From 06/2005 to05/2006	AUDIO	●	●	●	●
E-Class	211	From 06/2005 to05/2006	COMAND or AUDIO	●	●	●	●
E-Class	211	From 06/2005 to05/2006	NAVI-Navigation system	●	●	●	●
E-Class	211	From 06/2005 to05/2006	CDC-CD changer	●	●	●	●
E-Class	211	From 06/2005 to05/2006	VCS-Voice control system	●	●	●	●
E-Class	211	From 06/2005 to05/2006	TV-TV tuner	●	●	●	●
E-Class	211	From 06/2005 to05/2006	TV-TV tuner (AGW)	●	●	●	●
E-Class	211	From 06/2005 to05/2006	SDAR-Satellite radio	●	●	●	●
E-Class	211	From 06/2005 to05/2006	GPS box	●	●	●	●
E-Class	211	From 06/2005 to05/2006	TELE AID-Control unit	●	●	●	●
E-Class	211	From 06/2005 to05/2006	TELE AID-Telematic services Emergency call	●	●	●	●

E-Class	211	From 06/2005 to05/2006	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
E-Class	211	From 06/2005 to05/2006	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
E-Class	211	From 06/2005 to05/2006	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ESA driver-Electric seat adjustment driver	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ESA driver-Electric seat adjustment driver (withmemory)	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ESA passenger-Electric seat adjustment passenger	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ESA passenger-Electric seat adjustment passenger	●	●	●	●
E-Class	211	From 06/2005 to05/2006	DS-LF-Left front dynamic seat	●	●	●	●
E-Class	211	From 06/2005 to05/2006	DS-RF-Right front dynamic seat	●	●	●	●
E-Class	211	From 06/2005 to05/2006	DSP-Pneumatic pump for dynamic seat	●	●	●	●
E-Class	211	From 06/2005 to05/2006	HS-Seat heater	●	●	●	●
E-Class	211	From 06/2005 to05/2006	HS-Seat heater	●	●	●	●
E-Class	211	From 06/2005 to05/2006	DCM-FL-Door control module front left	●	●	●	●
E-Class	211	From 06/2005 to05/2006	DCM-FR-Door control module front right	●	●	●	●
E-Class	211	From 06/2005 to05/2006	DCM-RL-Door control module rear left	●	●	●	●
E-Class	211	From 06/2005 to05/2006	DCM-RR-Door control module rear right	●	●	●	●
E-Class	211	From 06/2005 to05/2006	TLC-Trunk lid control	●	●	●	●
E-Class	211	From 06/2005 to05/2006	LAE [LAA]-Loading floor automatically extendable	●	●	●	●
E-Class	211	From 06/2005 to05/2006	RWT-Rear-end door control module	●	●	●	●
E-Class	211	From 06/2005 to05/2006	TLC-Trunk lid control	●	●	●	●
E-Class	211	From 06/2005 to05/2006	ARWT-Automatic rear-end door	●	●	●	●
E-Class	211	From 06/2005 to05/2006	AAC-Automatic air conditioning	●	●	●	●
E-Class	211	From 06/2005 to05/2006	HSW-Heated steering wheel	●	●	●	●
E-Class	211	From 06/2005 to05/2006	HSW-Heated steering wheel	●	●	●	●
E-Class	211	From 06/2005 to05/2006	STH-Stationary heater	●	●	●	●
E-Class	211	As of 06/2006	ETC-Electronic transmission control	●	●	●	●
E-Class	211	As of 06/2006	ETC-Electronic transmission control	●	●	●	●
E-Class	211	As of 06/2006	SEQ-Sequentronic automated manual transmission	●	●	●	●
E-Class	211	As of 06/2006	ETC-Electronic transmission control	●	●	●	●
E-Class	211	As of 06/2006	DTR-Distrionic	●	●	●	●

E-Class	211	As of 06/2006	ME-SFI-Motor electronics	●	●	●	●
E-Class	211	As of 06/2006	ME-SFI-Motor electronics	●	●	●	●
E-Class	211	As of 06/2006	ME-SFI-Motor electronics	●	●	●	●
E-Class	211	As of 06/2006	ME-SFI-Motor electronics	●	●	●	●
E-Class	211	As of 06/2006	ESM-Electronic selector module	●	●	●	●
E-Class	211	As of 06/2006	TV-TV tuner	●	●	●	●
E-Class	211	As of 06/2006	ME 9.7-Motor electronics 9.7	●	●	●	●
E-Class	211	As of 06/2006	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
E-Class	211	As of 06/2006	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●
E-Class	211	As of 06/2006	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●
E-Class	211	As of 06/2006	CDID-Common Rail Diesel Injection	●	●	●	●
E-Class	211	As of 06/2006	CDI 4-Common Rail Diesel Injection	●	●	●	●
E-Class	211	As of 06/2006	CDI5-Common Rail Diesel Injection(USA)	●	●	●	●
E-Class	211	As of 06/2006	CDI 5-Common Rail Diesel Injection	●	●	●	●
E-Class	211	As of 06/2006	ABR-Adaptive Brake	●	●	●	●
E-Class	211	As of 06/2006	AIRmatic	●	●	●	●
E-Class	211	As of 06/2006	Suspension	●	●	●	●
E-Class	211	As of 06/2006	TPC-Tire pressure monitor	●	●	●	●
E-Class	211	As of 06/2006	CGW-Central gateway	●	●	●	●
E-Class	211	As of 06/2006	EZS-Electronic ignition switch	●	●	●	●
E-Class	211	As of 06/2006	AB-Airbag	●	●	●	●
E-Class	211	As of 06/2006	WSS-Weight sensing system	●	●	●	●
E-Class	211	As of 06/2006	System diagnosis(CAN)	●	●	●	●
E-Class	211	As of 06/2006	Dr-side SAM-Driver signal acquisition and actuationmodule	●	●	●	●
E-Class	211	As of 06/2006	Pass-side SAM-Passenger-side signal acquisition andactuation module	●	●	●	●
E-Class	211	As of 06/2006	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
E-Class	211	As of 06/2006	AHE-Trailer recognition	●	●	●	●
E-Class	211	As of 06/2006	MSS-Special vehicle multifunction control module	●	●	●	●
E-Class	211	As of 06/2006	LCP-Lower control panel	●	●	●	●
E-Class	211	As of 06/2006	UCP-Upper control panel	●	●	●	●
E-Class	211	As of 06/2006	OCP-Overhead control panel	●	●	●	●

E-Class	211	As of 06/2006	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
E-Class	211	As of 06/2006	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
E-Class	211	As of 06/2006	XALWA-L-Xenon headlamp, left	●	●	●	●
E-Class	211	As of 06/2006	XALWA-R-Xenon headlamp, right	●	●	●	●
E-Class	211	As of 06/2006	PTS-Parktronic system	●	●	●	●
E-Class	211	As of 06/2006	SCM [MRM]-Steering column module	●	●	●	●
E-Class	211	As of 06/2006	SCM [MRM]-Steering column module	●	●	●	●
E-Class	211	As of 06/2006	IC-Instrument cluster	●	●	●	●
E-Class	211	As of 06/2006	ASSYST-Active Service System	●	●	●	●
E-Class	211	As of 06/2006	ASSYST PLUS-PLUS Active Service System	●	●	●	●
E-Class	211	As of 06/2006	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
E-Class	211	As of 06/2006	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
E-Class	211	As of 06/2006	CTEL-Telecommunication for telematics services	●	●	●	●
E-Class	211	As of 06/2006	Telephone adapter for portable CTET-Telecommunicationfor telematics services	●	●	●	●
E-Class	211	As of 06/2006	CTEL-Mobile phone adapter with universal interface	●	●	●	●
E-Class	211	As of 06/2006	AUDIO	●	●	●	●
E-Class	211	As of 06/2006	COMAND or AUDIO	●	●	●	●
E-Class	211	As of 06/2006	NAVI-Navigation system	●	●	●	●
E-Class	211	As of 06/2006	CDC-CD changer	●	●	●	●
E-Class	211	As of 06/2006	VCS-Voice control system	●	●	●	●
E-Class	211	As of 06/2006	TV-TV tuner	●	●	●	●
E-Class	211	As of 06/2006	TV-TV tuner (AGW)	●	●	●	●
E-Class	211	As of 06/2006	SDAR-Satellite radio	●	●	●	●
E-Class	211	As of 06/2006	GPS box	●	●	●	●
E-Class	211	As of 06/2006	TELE AID-Control unit	●	●	●	●
E-Class	211	As of 06/2006	TELE AID-Telematic services Emergency call	●	●	●	●
E-Class	211	As of 06/2006	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
E-Class	211	As of 06/2006	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
E-Class	211	As of 06/2006	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●

E-Class	211	As of 06/2006	COMAND or AUDIO	●	●	●	●
E-Class	211	As of 06/2006	Sound system (Main amplifier)	●	●	●	●
E-Class	211	As of 06/2006	UCI-Media interface	●	●	●	●
E-Class	211	As of 06/2006	DAB-Digital radio	●	●	●	●
E-Class	211	As of 06/2006	SDAR-Satellite radio(Valid for USA)	●	●	●	●
E-Class	211	As of 06/2006	TV-TV tuner	●	●	●	●
E-Class	211	As of 06/2006	CTEL-Cellular telephone(JAPAN)	●	●	●	●
E-Class	211	As of 06/2006	ESA driver-Electric seat adjustment driver	●	●	●	●
E-Class	211	As of 06/2006	ESA driver-Electric seat adjustment driver (with	●	●	●	●
E-Class	211	As of 06/2006	ESA passenger-Electric seat adjustment passenger	●	●	●	●
E-Class	211	As of 06/2006	ESA passenger-Electric seat adjustment passenger	●	●	●	●
E-Class	211	As of 06/2006	DS-LF-Left front dynamic seat	●	●	●	●
E-Class	211	As of 06/2006	DS-RF-Right front dynamic seat	●	●	●	●
E-Class	211	As of 06/2006	DSP-Pneumatic pump for dynamic seat	●	●	●	●
E-Class	211	As of 06/2006	HS-Seat heater	●	●	●	●
E-Class	211	As of 06/2006	HS-Seat heater	●	●	●	●
E-Class	211	As of 06/2006	DCM-FL-Door control module front left	●	●	●	●
E-Class	211	As of 06/2006	DCM-FR-Door control module front right	●	●	●	●
E-Class	211	As of 06/2006	DCM-RL-Door control module rear left	●	●	●	●
E-Class	211	As of 06/2006	DCM-RR-Door control module rear right	●	●	●	●
E-Class	211	As of 06/2006	TLC-Trunk lid control	●	●	●	●
E-Class	211	As of 06/2006	LAE [LAA]-Loading floor automatically extendable	●	●	●	●
E-Class	211	As of 06/2006	RWT-Rear-end door control module	●	●	●	●
E-Class	211	As of 06/2006	TLC-Trunk lid control	●	●	●	●
E-Class	211	As of 06/2006	ARWT-Automatic rear-end door	●	●	●	●
E-Class	211	As of 06/2006	AAC-Automatic air conditioning	●	●	●	●
E-Class	211	As of 06/2006	HSW-Heated steering wheel	●	●	●	●
E-Class	211	As of 06/2006	HSW-Heated steering wheel	●	●	●	●
E-Class	211	As of 06/2006	STH-Stationary heater	●	●	●	●
E-Class	212	ALL	ETC-Electronic transmission control	●	●	●	●
E-Class	212	ALL	ETC-Electronic transmission control	●	●	●	●
E-Class	212	ALL	ME 9.7-Motor electronics 9.7	●	●	●	●



E-Class	212	ALL	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
E-Class	212	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
E-Class	212	ALL	ME-Motor electronics 'MED40' for combustion engine' M270' (N3/10)	●	●	●	●
E-Class	212	ALL	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●
E-Class	212	ALL	ME-Motor electronics 'MED40CNG' for combustion engine' M274' (N3/10)	●	●	●	●
E-Class	212	ALL	ME - Motor electronics 'SIM271DE20' for combustionengine 'M271EVO' (N3/10)	●	●	●	●
E-Class	212	ALL	FSCU-Fuel pump	●	●	●	●
E-Class	212	ALL	FSCU-Fuel pump	●	●	●	●
E-Class	212	ALL	DTR-Distronic	●	●	●	●
E-Class	212	ALL	ESM-Electronic selector module	●	●	●	●
E-Class	212	ALL	ISM-Shift module (A80)	●	●	●	●
E-Class	212	ALL	mbrace-mbrace (N123/4)	●	●	●	●
E-Class	212	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
E-Class	212	ALL	FSCU-Fuel pump	●	●	●	●
E-Class	212	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
E-Class	212	ALL	CDI 60LS-Common Rail Diesel Injection	●	●	●	●
E-Class	212	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
E-Class	212	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
E-Class	212	ALL	CDID-Common Rail Diesel Injection	●	●	●	●
E-Class	212	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
E-Class	212	ALL	CDI-Motor electronics 'CR42' for combustion engine'OM607' (N3/9)	●	●	●	●
E-Class	212	ALL	CDI-Motor electronics 'CR43' for combustion engine'OM651' (N3/9)	●	●	●	●
E-Class	212	ALL	CDI-Motor electronics 'CDI61' for combustion engine'OM642' (N3/9)	●	●	●	●
E-Class	212	ALL	ES-Electrical power steering (N68)	●	●	●	●
E-Class	212	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
E-Class	212	ALL	ESP-Regenerative braking system (N30/6)	●	●	●	●
E-Class	212	ALL	ESP-Electronic stability program	●	●	●	●
E-Class	212	ALL	TPC-Tire pressure monitor	●	●	●	●
E-Class	212	ALL	TPM - Tire pressure monitor (N88)	●	●	●	●
E-Class	212	ALL	AIRMATIC-AIRMATIC	●	●	●	●
E-Class	212	ALL	FWGW-Chassis gateway (N97/7)	●	●	●	●
E-Class	212	ALL	CGW-Central gateway	●	●	●	●
E-Class	212	ALL	CGW[ZGW]-Central gateway (CGW[ZGW])	●	●	●	●
E-Class	212	ALL	CGW-Central gateway	●	●	●	●
E-Class	212	ALL	EZS-Electronic ignition lock	●	●	●	●
E-Class	212	ALL	EZS-Electronic ignition lock (N73)	●	●	●	●
E-Class	212	ALL	KG-Keyless Go	●	●	●	●
E-Class	212	ALL	KG-KEYLESS GO (N69/5)	●	●	●	●
E-Class	212	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
E-Class	212	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
E-Class	212	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
E-Class	212	ALL	SRS-Supplemental restraint system	●	●	●	●

E-Class	212	ALL	WSS-Weight sensing system	●	●	●	●
E-Class	212	ALL	OCP-Overhead control panel (N70)	●	●	●	●
E-Class	212	ALL	PSD-Control module 'Panoramic sliding roof' (A98)	●	●	●	●
E-Class	212	ALL	SGR-Radar sensors control unit	●	●	●	●
E-Class	212	ALL	SGR-Radar sensors control unit	●	●	●	●
E-Class	212	ALL	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
E-Class	212	ALL	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●
E-Class	212	ALL	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●
E-Class	212	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
E-Class	212	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
E-Class	212	ALL	BMS-Battery management system (N82/2)	●	●	●	●
E-Class	212	ALL	Trailer recognition module	●	●	●	●
E-Class	212	ALL	Multifunction control unit- Multifunction control unit (N26/14)	●	●	●	●
E-Class	212	ALL	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●
E-Class	212	ALL	RevETR-LF-Left front reversible emergency tensioning retractor (A76)	●	●	●	●
E-Class	212	ALL	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●
E-Class	212	ALL	RevETR-RF-Right front reversible emergency tensioning retractor (A76/1)	●	●	●	●
E-Class	212	ALL	XALWA-L-Left xenon headlamp (E1n1)	●	●	●	●
E-Class	212	ALL	XALWA-R-Right xenon headlamp (E2n1)	●	●	●	●
E-Class	212	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
E-Class	212	ALL	KG-KEYLESS GO (N69/5)	●	●	●	●
E-Class	212	ALL	SG-EM-Power electronics (N129/1)	●	●	●	●
E-Class	212	ALL	RFK-Backup camera (B84/3)	●	●	●	●
E-Class	212	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
E-Class	212	ALL	SCM-Steering column module (N80)	●	●	●	●
E-Class	212	ALL	ES-Electrical power steering	●	●	●	●
E-Class	212	ALL	AMG DRVU-AMG DRIVE UNIT (N145)	●	●	●	●
E-Class	212	ALL	NSA-Night View Assist	●	●	●	●
E-Class	212	ALL	ICM-Instrument cluster with maintenance interval display	●	●	●	●
E-Class	212	ALL	IC-Instrument cluster (A1)	●	●	●	●
E-Class	212	ALL	IC-Instrument cluster (A1)	●	●	●	●
E-Class	212	ALL	ICI-InCar Internet (N125/3)	●	●	●	●
E-Class	212	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
E-Class	212	ALL	RFK-Backup camera (B84/3)	●	●	●	●
E-Class	212	ALL	SCCM-Steering column module (N80)	●	●	●	●
E-Class	212	ALL	COMAND or AUDIO	●	●	●	●
E-Class	212	ALL	COMAND or AUDIO	●	●	●	●
E-Class	212	ALL	COU [ZBE]-Central operating unit	●	●	●	●
E-Class	212	ALL	ZBE-Audio/COMAND operating unit (A40/9)	●	●	●	●
E-Class	212	ALL	ZAN-Central display	●	●	●	●
E-Class	212	ALL	TV-TV tuner (AGW)	●	●	●	●
E-Class	212	ALL	CTEL-Cellular telephone (JAPAN)	●	●	●	●

E-Class	212	ALL	DAB-Digital radio	●	●	●	●
E-Class	212	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
E-Class	212	ALL	Sound system (Main amplifier)	●	●	●	●
E-Class	212	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
E-Class	212	ALL	UCI-Media interface	●	●	●	●
E-Class	212	ALL	AVE-H-Rear audio video unit	●	●	●	●
E-Class	212	ALL	Left rear screen	●	●	●	●
E-Class	212	ALL	Right rear screen	●	●	●	●
E-Class	212	ALL	TELE AID-Control unit	●	●	●	●
E-Class	212	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
E-Class	212	ALL	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
E-Class	212	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
E-Class	212	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
E-Class	212	ALL	MFK-Multifunction camera	●	●	●	●
E-Class	212	ALL	DSI-DIRECT SELECT interface (N150)	●	●	●	●
E-Class	212	ALL	Drive-side SAM-Front signal acquisition and actuationmodule (N10/1)	●	●	●	●
E-Class	212	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
E-Class	212	ALL	NAV-Navigation module (A2/30)	●	●	●	●
E-Class	212	ALL	NSA-Night View Assist (N101)	●	●	●	●
E-Class	212	ALL	PTS-Parktronic	●	●	●	●
E-Class	212	ALL	Sound system (Main amplifier)	●	●	●	●
E-Class	212	ALL	Sound system (Bass amplifier)	●	●	●	●
E-Class	212	ALL	360° camera-360° camera (N148)	●	●	●	●
E-Class	212	ALL	NAVI20 - Navigation (N125/2)	●	●	●	●
E-Class	212	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●
E-Class	212	ALL	DCU-LF-Left front door	●	●	●	●
E-Class	212	ALL	DCU-RF-Right front door	●	●	●	●
E-Class	212	ALL	DCU-LR-Left rear door	●	●	●	●
E-Class	212	ALL	DCU-RR-Right rear door	●	●	●	●
E-Class	212	ALL	AMKS-LF-Active multicontour seat (N32/19)	●	●	●	●
E-Class	212	ALL	AMKS-RF-Active multicontour seat (N32/22)	●	●	●	●
E-Class	212	ALL	TLC-Trunk lid control	●	●	●	●
E-Class	212	ALL	ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)	●	●	●	●
E-Class	212	ALL	ESA driver	●	●	●	●
E-Class	212	ALL	ESA'Front passenger'-Electric seat adjustment 'Frontpassenger' with memory function (N32/2)	●	●	●	●
E-Class	212	ALL	ESA passenger	●	●	●	●
E-Class	212	ALL	ESA-Electirc seat adjustment 'Front passenger' (N32/2)	●	●	●	●
E-Class	212	ALL	SIH-FOND-Rear passenger compartment seat heater	●	●	●	●
E-Class	212	ALL	Stationary heater	●	●	●	●
E-Class	212	ALL	AAC-Air conditioining	●	●	●	●
E-Class	212	ALL	LRH-Steering wheel heater	●	●	●	●

E-Class	212	ALL	EKMK-Electric refrigerant compressor (A9/5)	●	●	●	●
E-Class	212	ALL	LCP-Lower control panel (S77)	●	●	●	●
E-Class	212	ALL	AU-Analog clock (A70/1)	●	●	●	●
E-Class	212	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
E-Class	213	ALL	ECM-Engine Control Module(ME)	●	●	●	●
E-Class	213	ALL	VG-All-wheel drive	●	●	●	●
E-Class	213	ALL	PTCU-Drivetrain	●	●	●	●
E-Class	213	ALL	HFPM-Haptic accelerator pedal module	●	●	●	●
E-Class	213	ALL	FSCU-Fuel pump	●	●	●	●
E-Class	213	ALL	SG-EM-Power electronics	●	●	●	●
E-Class	213	ALL	ADS-Adaptive damping system	●	●	●	●
E-Class	213	ALL	IC-Instrument cluster	●	●	●	●
E-Class	213	ALL	SG-AMGL-Control unit 'Active engine and transmission mount'	●	●	●	●
E-Class	213	ALL	ELC-Electric level control	●	●	●	●
E-Class	213	ALL	ES-Electronic Power Steering	●	●	●	●
E-Class	213	ALL	ESP-Electronic stability program	●	●	●	●
E-Class	213	ALL	AIRMATIC PLUS	●	●	●	●
E-Class	213	ALL	ABA-Active Brake Assist	●	●	●	●
E-Class	213	ALL	DTR-DISTRONIC	●	●	●	●
E-Class	213	ALL	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	●	●
E-Class	213	ALL	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	●	●
E-Class	213	ALL	MFK-Multifunction camera	●	●	●	●
E-Class	213	ALL	NBR-LF-Left front short range radar	●	●	●	●
E-Class	213	ALL	NBR-RF-Right front short range radar	●	●	●	●
E-Class	213	ALL	NBR-LR-Left rear short range radar	●	●	●	●
E-Class	213	ALL	NBR-RR-Right rear short range radar	●	●	●	●
E-Class	213	ALL	PTS-PARKTRONIC	●	●	●	●
E-Class	213	ALL	RFK-Backup camera	●	●	●	●
E-Class	213	ALL	Mercedes-Benz Intelligent Drive	●	●	●	●
E-Class	213	ALL	TPM-Tire pressure monitor	●	●	●	●
E-Class	213	ALL	AML-Ambiance light	●	●	●	●
E-Class	213	ALL	BMS-Battery management system	●	●	●	●
E-Class	213	ALL	OCP-Overhead control panel	●	●	●	●
E-Class	213	ALL	EZS-Electronic ignition lock	●	●	●	●
E-Class	213	ALL	SG-SW_L-Left headlamp	●	●	●	●
E-Class	213	ALL	SG-SW_R-Right headlamp	●	●	●	●
E-Class	213	ALL	KG-Keyless GO	●	●	●	●
E-Class	213	ALL	SG-LG-Charger	●	●	●	●
E-Class	213	ALL	SCM-Steering column module	●	●	●	●
E-Class	213	ALL	SG-LML-VL-LED matrix of left front lamp unit	●	●	●	●
E-Class	213	ALL	SG-LML-VR-LED matrix of right front lamp unit	●	●	●	●
E-Class	213	ALL	RevETR_LF-Left front reversible emergency tensioning retractor	●	●	●	●
E-Class	213	ALL	RevETR_RF-Right front reversible emergency tensioning retractor	●	●	●	●
E-Class	213	ALL	Driver-side SAM-Front signal acquisition and actuation module	●	●	●	●
E-Class	213	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●

E-Class	213	ALL	SD-Sliding roof/Panoramic sliding sunroof	●	●	●	●
E-Class	213	ALL	SG-SOGE-E-Sound generator for electric vehicle	●	●	●	●
E-Class	213	ALL	SRS-Supplemental restraint system	●	●	●	●
E-Class	213	ALL	STM-Mirror txximeter	●	●	●	●
E-Class	213	ALL	AHE-Trailer recognition	●	●	●	●
E-Class	213	ALL	Control unit for telematics services	●	●	●	●
E-Class	213	ALL	COU[ZBE]-Audio/COMAND operating unit	●	●	●	●
E-Class	213	ALL	DAB-Digital Audio Broadcasting	●	●	●	●
E-Class	213	ALL	ZAN-Audio/COMMAND display	●	●	●	●
E-Class	213	ALL	Head-up display -head-up display	●	●	●	●
E-Class	213	ALL	SG-MSND-Engine sound	●	●	●	●
E-Class	213	ALL	SOUND-Sound system	●	●	●	●
E-Class	213	ALL	TPAD-Touchpad	●	●	●	●
E-Class	213	ALL	TSC-H-Touchscreen in rear passenger compartment	●	●	●	●
E-Class	213	ALL	TV-TV tuner	●	●	●	●
E-Class	213	ALL	MTAS-Mobile phone cradle	●	●	●	●
E-Class	213	ALL	ESA_DR-Electric Seat adjustment driver	●	●	●	●
E-Class	213	ALL	ESA Front passenger-Electrical seat adjustment Front passenger	●	●	●	●
E-Class	213	ALL	Left rear ESE-Left rear electrical seat adjustment	●	●	●	●
E-Class	213	ALL	Right rear ESE-Right rear electrical seat adjustment	●	●	●	●
E-Class	213	ALL	MKS-LF-Left front multicontour seat	●	●	●	●
E-Class	213	ALL	MKS-RF-Right front multicontour seat	●	●	●	●
E-Class	213	ALL	MKS-LR-Left rear multicontour seat	●	●	●	●
E-Class	213	ALL	MKS-RR-Right rear multicontour seat	●	●	●	●
E-Class	213	ALL	PPMKS-Pneumatic pump for multicontour seat	●	●	●	●
E-Class	213	ALL	HKS-Tailgate control	●	●	●	●
E-Class	213	ALL	DCU-LF-Left front door	●	●	●	●
E-Class	213	ALL	DCU-RF-Right front door	●	●	●	●
E-Class	213	ALL	DCU-LR-Left rear door	●	●	●	●
E-Class	213	ALL	DCU-RR-Right rear door	●	●	●	●
E-Class	213	ALL	AC-Air conditioning	●	●	●	●
G-Class	461 (OBD 16)	ALL	ETC-Electronic transmission control	●	●	●	●
G-Class	461 (OBD 16)	ALL	ESM-Electronic selector module	●	●	●	●
G-Class	461 (OBD 16)	ALL	N15/7(Transfer case control module)	●	●	●	●
G-Class	461 (OBD 16)	ALL	CDI 2-Common Rail Diesel Injection	●	●	●	●
G-Class	461 (OBD 16)	ALL	ETC-Electronic transmission control	●	●	●	●
G-Class	461 (OBD 16)	ALL	CDI 4-Common Rail Diesel Injection	●	●	●	●
G-Class	461 (OBD 16)	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
G-Class	461 (OBD 16)	ALL	ABS-Antilock brake system	●	●	●	●
G-Class	461 (OBD 16)	ALL	Traction systems ABS	●	●	●	●
G-Class	461 (OBD 16)	ALL	AB-Airbag	●	●	●	●

G-Class	461 (OBD 16)	ALL	CGW-Central gateway	●	●	●	●
G-Class	461 (OBD 16)	ALL	WSP immobilizer	●	●	●	●
G-Class	461 (OBD 16)	ALL	IC-Instrument cluster	●	●	●	●
G-Class	461 (OBD 16)	ALL	AUDIO	●	●	●	●
G-Class	461 (OBD 16)	ALL	STH-Stationary heater	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ETC-Electronic transmission control	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ETC-Electronic transmission control	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ESM-Electronic selector module	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	N15/7 (Transfer case control module)	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	CDI-V-Common Rail Diesel Injection	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	CDI 2-Common Rail Diesel Injection	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ABS-Antilock brake system	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ESP-Electronic stability program	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	AB-Airbag	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	EZS-Electronic ignition switch	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	EZS-Electronic ignition switch	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	UCP-Upper control panel	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	SAM-F-Signal acquisition and actuation module front	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	OCP-Overhead control panel	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	MSS-Special vehicle multifunction control module	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	AHE-Trailer recognition	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ICM-Instrument cluster with maintenance interval display	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	SCM [MRM]-Steering column module	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	SCM [MRM]-Steering column module	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	D2B-COMAND, MCS or AUDIO	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	AUDIO	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	COMAND	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	CDC-CD changer	●	●	●	●

G-Class	463 (OBD 16)	Up to 03/2004	VCS-Voice control system	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	SDAR-Satellite radio	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	TV-TV tuner	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	E-call [Japan]-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	E-call [USA]-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	TELE AID-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	CTEL over K-wire-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	DCM-FL-Door control module front left	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	DCM-FR-Door control module front right	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	DCM-RL-Door control module rear left	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	DCM-RR-Door control module rear right	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ESA passenger-Electric seat adjustment passenger	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ESA passenger-Electric seat adjustment passenger	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ESA passenger-Electric seat adjustment passenger	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ESA driver-Electric seat adjustment driver	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ESA driver-Electric seat adjustment driver	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	AAC-Automatic air conditioning	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	STH-Stationary heater	●	●	●	●
G-Class	463 (OBD 16)	Up to 03/2004	HSW-Heated steering wheel	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to 08/2006	ETC-Electronic transmission control	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to 08/2006	ETC-Electronic transmission control	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to 08/2006	ESM-Electronic selector module	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to 08/2006	N15/7 (Transfer case control module)	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to 08/2006	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to 08/2006	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to 08/2006	CDI-V-Common Rail Diesel Injection	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to 08/2006	CDI 2-Common Rail Diesel Injection	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to 08/2006	ABS-Antilock brake system	●	●	●	●

G-Class	463 (OBD 16)	From 04/2004 to08/2006	ESP-Electronic stability program	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	EZS-Electronic ignition switch	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	AB-Airbag	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	UCP-Upper control panel	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	SAM-F-Signal acquisition and actuation module front	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	OCP-Overhead control panel	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	MSS-Special vehicle multifunction control module	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	AHE-Trailer recognition	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	SCM [MRM]-Steering column module	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	SCM [MRM]-Steering column module	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	D2B-COMAND, MCS or AUDIO	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	AUDIO	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	COMAND	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	CDC-CD changer	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	VCS-Voice control system	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	SDAR-Satellite radio	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	CTEL- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	UHI- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	TV-TV tuner	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	E-call [Japan]-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	E-call [USA]-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	TELE AID-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	CTEL over K-wire-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	DCM-FL-Door control module front left	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	DCM-FR-Door control module front right	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	DCM-RL-Door control module rear left	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	DCM-RR-Door control module rear right	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	ESA passenger-Electric seat adjustment passenger	●	●	●	●



G-Class	463 (OBD 16)	From 04/2004 to08/2006	ESA passenger-Electric seat adjustment passenger	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	ESA passenger-Electric seat adjustment passenger	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	ESA driver-Electric seat adjustment driver	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	ESA driver-Electric seat adjustment driver	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	ESA driver-Electric seat adjustment driver (withmemory)	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	AAC-Automatic air conditioning	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	STH-Stationary heater	●	●	●	●
G-Class	463 (OBD 16)	From 04/2004 to08/2006	HSW-Heated steering wheel	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ETC-Electronic transmission control	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ETC-Electronic transmission control	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ETC-Electronic transmission control	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ESM-Electronic selector module	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	N15/7 (Transfer case control module)	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	CDI 4-Common Rail Diesel Injection	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ABS-Antilock brake system	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ESP-Electronic stability program	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ESP-Electronic stability program	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	EZS-Electronic ignition switch	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	AB-Airbag	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	UCP-Upper control panel	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	SAM-F-Signal acquisition and actuation module front	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	OCP-Overhead control panel	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ALWR-Headlamp range adjustment	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	MSS-Special vehicle multifunction control module	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	AHE-Trailer recognition	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	SCM [MRM]-Steering column module	●	●	●	●

G-Class	463 (OBD 16)	From 09/2006 to02/2007	SCM [MRM]-Steering column module	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	D2B-COMAND, MCS or AUDIO	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	AUDIO	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	COMAND	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	CDC-CD changer	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	VCS-Voice control system	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	SDAR-Satellite radio	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	CTEL- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	UHI- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	TV-TV tuner	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	E-call [Japan]-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	E-call [USA]-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	TELE AID-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	CTEL over K-wire-Telematic system	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	AUDIO	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	COMAND or AUDIO	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	CDC-CD changer	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	VCS-Voice control system	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	SDAR-Satellite radio	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	SOUND- Sound system	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	TV-TV tuner (AGW)	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	CTEL-Mobile phone adapter with universal interface	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	NAVI-Navigation system	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	TELE AID-Control unit	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	TELE AID-Telematic services Emergency call	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●

G-Class	463 (OBD 16)	From 09/2006 to02/2007	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	DCM-FL-Door control module front left	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	DCM-FR-Door control module front right	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	DCM-RL-Door control module rear left	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	DCM-RR-Door control module rear right	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ESA passenger-Electric seat adjustment passenger	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ESA passenger-Electric seat adjustment passenger	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ESA passenger-Electric seat adjustment passenger	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ESA driver-Electric seat adjustment driver	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ESA driver-Electric seat adjustment driver	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	ESA driver-Electric seat adjustment driver (withmemory)	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	AAC-Automatic air conditioning	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	STH-Stationary heater	●	●	●	●
G-Class	463 (OBD 16)	From 09/2006 to02/2007	HSW-Heated steering wheel	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ETC-Electronic transmission control	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ETC-Electronic transmission control	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ETC-Electronic transmission control	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ESM-Electronic selector module	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	N15/7(Transfer case control module)	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	TV-TV tuner	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ME 9.7-Motor electronics 9.7	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	CDI 4-Common Rail Diesel Injection	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	CDI 6-Common Rail Diesel Injection	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	SCR-Selective Catalytic Reduction	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ABS-Antilock brake system	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ESP-Electronic stability program	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ESP-Electronic stability program	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	TPC-Tire pressure monitor	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	EZS-Electronic ignition switch	●	●	●	●

G-Class	463 (OBD 16)	As of 03/2007	AB-Airbag	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	UCP-Upper control panel	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	SAM-F-Signal acquisition and actuation module front	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	OCP-Overhead control panel	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ALWR-Headlamp range adjustment	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	MSS-Special vehicle multifunction control module	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	AHE-Trailer recognition	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	AHE-Trailer recognition	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ICM-Instrument cluster with maintenance interval display	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	SCM [MRM]-Steering column module	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	SCM [MRM]-Steering column module	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	AUDIO	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	COMAND or AUDIO	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	CDC-CD changer	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	VCS-Voice control system	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	SDAR-Satellite radio	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	SOUND- Sound system	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	TV-TV tuner (AGW)	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	CTEL-Mobile phone adapter with universal interface	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	NAVI-Navigation system	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	COMAND or AUDIO	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	Sound system (Main amplifier)	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	UCI-Media interface	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	DAB-Digital radio	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	SDAR-Satellite radio (Valid for USA)	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	TV-TV tuner	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	CTEL-Cellular telephone (JAPAN)	●	●	●	●

G-Class	463 (OBD 16)	As of 03/2007	TELE AID-Control unit	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	TELE AID-Telematic services Emergency call	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	DCM-FL-Door control module front left	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	DCM-FR-Door control module front right	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	DCM-RL-Door control module rear left	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	DCM-RR-Door control module rear right	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ESA passenger-Electric seat adjustment passenger	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ESA passenger-Electric seat adjustment passenger	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ESA passenger-Electric seat adjustment passenger	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ESA driver-Electric seat adjustment driver	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ESA driver-Electric seat adjustment driver	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	ESA driver-Electric seat adjustment driver (withmemory)	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	HS-Seat heater	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	AAC-Automatic air conditioning	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	STH-Stationary heater	●	●	●	●
G-Class	463 (OBD 16)	As of 03/2007	HSW-Heated steering wheel	●	●	●	●
GL-Class	164	ALL	ETC-Electronic transmission control	●	●	●	●
GL-Class	164	ALL	VG-Transfer case	●	●	●	●
GL-Class	164	ALL	HAQ-Interwheel differential lock at rear axle	●	●	●	●
GL-Class	164	ALL	ISM-Intelligent servo module	●	●	●	●
GL-Class	164	ALL	ISM-Shift module (A80)	●	●	●	●
GL-Class	164	ALL	ME 9.7-Motor electronics 9.7	●	●	●	●
GL-Class	164	ALL	FSCU-Fuel pump	●	●	●	●
GL-Class	164	ALL	DTR-Distronic	●	●	●	●
GL-Class	164	ALL	DTR-Distronic	●	●	●	●
GL-Class	164	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
GL-Class	164	ALL	IRS-HLA - Outer left rear intelligent radar sensorsystem	●	●	●	●
GL-Class	164	ALL	TV-TV tuner	●	●	●	●
GL-Class	164	ALL	CDI 4-Common Rail Diesel Injection	●	●	●	●
GL-Class	164	ALL	CDI 5-Common Rail Diesel Injection	●	●	●	●
GL-Class	164	ALL	CDI 6BIN5-Common Rail Diesel Injection	●	●	●	●
GL-Class	164	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
GL-Class	164	ALL	SCR-Selective Catalytic Reduction	●	●	●	●

GL-Class	164	ALL	CDI 60LS-Common Rail Diesel Injection	●	●	●	●
GL-Class	164	ALL	ESP-Electronic stability program	●	●	●	●
GL-Class	164	ALL	EHPS-Electrohydraulic Power Steering	●	●	●	●
GL-Class	164	ALL	Suspension	●	●	●	●
GL-Class	164	ALL	TPC-Tire pressure monitor	●	●	●	●
GL-Class	164	ALL	TPM - Tire pressure monitor (N88)	●	●	●	●
GL-Class	164	ALL	CGW-Central gateway	●	●	●	●
GL-Class	164	ALL	EZS-Electronic ignition switch	●	●	●	●
GL-Class	164	ALL	EZS-Electronic ignition switch	●	●	●	●
GL-Class	164	ALL	KG-Keyless Go	●	●	●	●
GL-Class	164	ALL	KG-KEYLESS GO	●	●	●	●
GL-Class	164	ALL	AB-Airbag	●	●	●	●
GL-Class	164	ALL	OCP-Overhead control panel	●	●	●	●
GL-Class	164	ALL	WSS-Weight sensing system	●	●	●	●
GL-Class	164	ALL	UCP-Upper control panel	●	●	●	●
GL-Class	164	ALL	HBF (Rear control panel)-Rear control field	●	●	●	●
GL-Class	164	ALL	SAM-F-Signal acquisition and actuation module front	●	●	●	●
GL-Class	164	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
GL-Class	164	ALL	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
GL-Class	164	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
GL-Class	164	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
GL-Class	164	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
GL-Class	164	ALL	HRA-Automatic headlamp range adjustment and headlampcontrol	●	●	●	●
GL-Class	164	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
GL-Class	164	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
GL-Class	164	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
GL-Class	164	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
GL-Class	164	ALL	System diagnosis (CAN)	●	●	●	●
GL-Class	164	ALL	SCM [MRM]-Steering column module	●	●	●	●
GL-Class	164	ALL	CM-Compass module	●	●	●	●
GL-Class	164	ALL	IC-Instrument cluster	●	●	●	●
GL-Class	164	ALL	ASSYST-Active Service System	●	●	●	●
GL-Class	164	ALL	ASSYST PLUS-PLUS Active Service System	●	●	●	●
GL-Class	164	ALL	PTS-Parktronic system	●	●	●	●
GL-Class	164	ALL	PTS-Parktronic system	●	●	●	●
GL-Class	164	ALL	RFK-Backup camera	●	●	●	●
GL-Class	164	ALL	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
GL-Class	164	ALL	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
GL-Class	164	ALL	CDC-CD changer	●	●	●	●
GL-Class	164	ALL	VCS-Voice control system	●	●	●	●
GL-Class	164	ALL	AUDIO	●	●	●	●
GL-Class	164	ALL	COMAND or AUDIO	●	●	●	●
GL-Class	164	ALL	TV-TV tuner	●	●	●	●

GL-Class	164	ALL	TV-TV tuner (AGW)	●	●	●	●
GL-Class	164	ALL	SDAR-Satellite radio	●	●	●	●
GL-Class	164	ALL	SOUND- Sound system	●	●	●	●
GL-Class	164	ALL	CTEL-Mobile phone adapter with universal interface	●	●	●	●
GL-Class	164	ALL	NAVI-Navigation system	●	●	●	●
GL-Class	164	ALL	AVE-H-Rear audio video unit	●	●	●	●
GL-Class	164	ALL	CTEL-Cellular telephone	●	●	●	●
GL-Class	164	ALL	COMAND or AUDIO	●	●	●	●
GL-Class	164	ALL	Sound system (Main amplifier)	●	●	●	●
GL-Class	164	ALL	UCI-Media interface	●	●	●	●
GL-Class	164	ALL	DAB-Digital radio	●	●	●	●
GL-Class	164	ALL	SDAR-Satellite radio (Valid for USA)	●	●	●	●
GL-Class	164	ALL	TV-TV tuner	●	●	●	●
GL-Class	164	ALL	CTEL-Cellular telephone (JAPAN)	●	●	●	●
GL-Class	164	ALL	AVE-H-Rear audio video unit	●	●	●	●
GL-Class	164	ALL	Left rear screen	●	●	●	●
GL-Class	164	ALL	Right rear screen	●	●	●	●
GL-Class	164	ALL	TELE AID-Control unit	●	●	●	●
GL-Class	164	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
GL-Class	164	ALL	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
GL-Class	164	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
GL-Class	164	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
GL-Class	164	ALL	DCM-FL-Door control module front left	●	●	●	●
GL-Class	164	ALL	DCM-FR-Door control module front right	●	●	●	●
GL-Class	164	ALL	ESA driver-Electric seat adjustment driver (with	●	●	●	●
GL-Class	164	ALL	ESA passenger-Electric seat adjustment passenger	●	●	●	●
GL-Class	164	ALL	DS-LF-Left front dynamic seat	●	●	●	●
GL-Class	164	ALL	DS-RF-Right front dynamic seat	●	●	●	●
GL-Class	164	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●
GL-Class	164	ALL	ERA-Electric fold-down backrest system (3rd seat row)	●	●	●	●
GL-Class	164	ALL	REDC-Rear-end door closing control module	●	●	●	●
GL-Class	164	ALL	REDC-Rear-end door closing control module	●	●	●	●
GL-Class	164	ALL	HS-Seat heater	●	●	●	●
GL-Class	164	ALL	AAC-Automatic air conditioning	●	●	●	●
GL-Class	164	ALL	HSW-Heated steering wheel	●	●	●	●
GL-Class	164	ALL	STH-Stationary heater with remote control	●	●	●	●
GL-Class	166	ALL	DTR-Distronic	●	●	●	●
GL-Class	166	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
GL-Class	166	ALL	ISM-Shift module (A80)	●	●	●	●
GL-Class	166	ALL	FSCU-Fuel pump	●	●	●	●
GL-Class	166	ALL	FSCU-Fuel pump	●	●	●	●
GL-Class	166	ALL	mbrace-mbrace (N123/4)	●	●	●	●

GL-Class	166	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
GL-Class	166	ALL	N15/7(Transfer case control module)	●	●	●	●
GL-Class	166	ALL	ETC-Electronic transmission control	●	●	●	●
GL-Class	166	ALL	CDI-Motor electronics 'CR43' for combustion engine'OM651' (N3/9)	●	●	●	●
GL-Class	166	ALL	CDI 60LS-Common Rail Diesel Injection	●	●	●	●
GL-Class	166	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
GL-Class	166	ALL	Roll control-Roll control (N51/6)	●	●	●	●
GL-Class	166	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
GL-Class	166	ALL	TPM-Tire pressure monitor	●	●	●	●
GL-Class	166	ALL	EFB-Electronic parking break (N128)	●	●	●	●
GL-Class	166	ALL	ES-Electrical power steering (N68)	●	●	●	●
GL-Class	166	ALL	ESP-Regenerative braking system (N30/6)	●	●	●	●
GL-Class	166	ALL	AIRMATIC - AIRMATIC(N51/3)	●	●	●	●
GL-Class	166	ALL	EZS-Electronic ignition switch	●	●	●	●
GL-Class	166	ALL	KG-KEYLESS GO	●	●	●	●
GL-Class	166	ALL	KG-KEYLESS GO (N69/5)	●	●	●	●
GL-Class	166	ALL	BMS-Battery management system (N82/2)	●	●	●	●
GL-Class	166	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
GL-Class	166	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
GL-Class	166	ALL	SAM-Signal acquisition and actuation module (N10)	●	●	●	●
GL-Class	166	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
GL-Class	166	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
GL-Class	166	ALL	SG-EM-Power electronics (N129/1)	●	●	●	●
GL-Class	166	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
GL-Class	166	ALL	HKS-Tailgate control (N121/1)	●	●	●	●
GL-Class	166	ALL	Rear-Rear control unit (N10/8)	●	●	●	●
GL-Class	166	ALL	RevETR-LF-Left front reversible emergency tensioningretractor (A76)	●	●	●	●
GL-Class	166	ALL	RevETR-RF-Right front reversible emergency tensioningretractor (A76/1)	●	●	●	●
GL-Class	166	ALL	SGR-Radar sensors control unit	●	●	●	●
GL-Class	166	ALL	SCM-Steering column module(N80)	●	●	●	●
GL-Class	166	ALL	SD-Control module 'Sliding roof (A98/1)'	●	●	●	●
GL-Class	166	ALL	Trailer recognition module-Trailer recognition(N28/1)	●	●	●	●
GL-Class	166	ALL	PSD-Control module 'Panoramic sliding roof' (A98)	●	●	●	●
GL-Class	166	ALL	SGR-Radar sensors control unit	●	●	●	●
GL-Class	166	ALL	ATA-ATA[EDW]/tow-away protection/interiorprotection(N26/6)	●	●	●	●
GL-Class	166	ALL	IC-Instrument cluster (A1)	●	●	●	●
GL-Class	166	ALL	IC-Instrument cluster (A1)	●	●	●	●
GL-Class	166	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
GL-Class	166	ALL	COU [ZBE]-Central operating unit	●	●	●	●
GL-Class	166	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
GL-Class	166	ALL	DAB-Digital radio	●	●	●	●



GL-Class	166	ALL	ZAN-Central display	●	●	●	●
GL-Class	166	ALL	Left rear screen	●	●	●	●
GL-Class	166	ALL	Right rear screen	●	●	●	●
GL-Class	166	ALL	AVE-H-Rear audio video unit	●	●	●	●
GL-Class	166	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
GL-Class	166	ALL	MFK-Multifunction camera	●	●	●	●
GL-Class	166	ALL	NAV-Navigation module (A2/30)	●	●	●	●
GL-Class	166	ALL	NSA-Night View Assist	●	●	●	●
GL-Class	166	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
GL-Class	166	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
GL-Class	166	ALL	SOUND - Sound system(N40/3)	●	●	●	●
GL-Class	166	ALL	Sound system (Main amplifier)	●	●	●	●
GL-Class	166	ALL	Sound system (Bass amplifier)	●	●	●	●
GL-Class	166	ALL	360° camera-360° camera(N148)	●	●	●	●
GL-Class	166	ALL	TV-TV tuner(AGW)	●	●	●	●
GL-Class	166	ALL	UCI-Media interface	●	●	●	●
GL-Class	166	ALL	TELE AID-Control unit	●	●	●	●
GL-Class	166	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
GL-Class	166	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
GL-Class	166	ALL	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
GL-Class	166	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
GL-Class	166	ALL	DCU-LF-Left front door (N69/1)	●	●	●	●
GL-Class	166	ALL	DCU-RF-Right front door (N69/2)	●	●	●	●
GL-Class	166	ALL	DCU-LR-Left rear door (N69/3)	●	●	●	●
GL-Class	166	ALL	DCU-RR-Right rear door (N69/4)	●	●	●	●
GL-Class	166	ALL	MKS-FS-Multicontour seat 'Driver' (N32/29)	●	●	●	●
GL-Class	166	ALL	MKS-BFS-Multicontour seat 'Front passenger' (N32/30)	●	●	●	●
GL-Class	166	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●
GL-Class	166	ALL	ESA 'Driver'-Electrical seat adjustment 'Driver' withmemory function(N32/1)	●	●	●	●
GL-Class	166	ALL	ESA' Front passenger'-Electric seat adjustment 'Frontpassenger' with memory function(N32/2)	●	●	●	●
GL-Class	166	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
GL-Class	166	ALL	HBF-Rear control panel (N72/2)	●	●	●	●
GL-Class	166	ALL	STH-Stationary heater (A6n1)	●	●	●	●
GL-Class	166	ALL	LCP-Lower control panel (N72)	●	●	●	●
GL-Class	166	ALL	UCP-Upper control panel (N72/1)	●	●	●	●
GL-Class	166	ALL	BSN-Battery sensor (B95)	●	●	●	●
GL-Class	166	ALL	AISP-Dimming inside rearview mirror (A67)	●	●	●	●
GL-Class	166	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
GL-Class	166	ALL	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	●	●	●	●
GL-Class	166	ALL	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	●	●	●	●
GL-Class	166	ALL	RGLS-Rain/light sensor (B38/2)	●	●	●	●

GL-Class	166	ALL	ORBF-Off-road operating panel (N72/3)	●	●	●	●
GL-Class	166	ALL	OCP-Control unit 'Overhead control panel' (N70)	●	●	●	●
GL-Class	166	ALL	AS-Alarm siren(H3/1)	●	●	●	●
GLA	156	ALL	EZS-Electronic ignition lock	●	●	●	●
GLA	156	ALL	Driver-side SAM-Front signal acquisition and actuation module	●	●	●	●
GLA	156	ALL	AHE-Trailer recognition	●	●	●	●
GLA	156	ALL	KG-KEYLESS GO	●	●	●	●
GLA	156	ALL	SCM-Steering column module	●	●	●	●
GLA	156	ALL	Multifunction control unit-Multifunction control unit	●	●	●	●
GLA	156	ALL	PSD-Panoramic sliding sunroof	●	●	●	●
GLA	156	ALL	RevETR_LF-Left front reversible emergency tensioning retractor	●	●	●	●
GLA	156	ALL	RevETR_RF-Right front reversible emergency tensioning retractor	●	●	●	●
GLA	156	ALL	ATA-interior mat ion sensor	●	●	●	●
GLA	156	ALL	AC-Air conditioning	●	●	●	●
GLA	156	ALL	AWD-All-wheel drive	●	●	●	●
GLA	156	ALL	PTCU-Drivetrain	●	●	●	●
GLA	156	ALL	FSCU-Fuel pump	●	●	●	●
GLA	156	ALL	ECM-Engine Control Module(MED40)	●	●	●	●
GLA	156	ALL	EPB-Electric parking brake	●	●	●	●
GLA	156	ALL	ES-Electronic Power Steering	●	●	●	●
GLA	156	ALL	ESP-Electronic stability program	●	●	●	●
GLA	156	ALL	CPF-Camera cover	●	●	●	●
GLA	156	ALL	DTR-DITRONIC	●	●	●	●
GLA	156	ALL	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	●	●
GLA	156	ALL	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	●	●
GLA	156	ALL	MFK-Multifunction camera	●	●	●	●
GLA	156	ALL	PTS-PARKTRONIC	●	●	●	●
GLA	156	ALL	RFK-Backup camera	●	●	●	●
GLA	156	ALL	SG-AWF-COLLISION PREVENTION ASSIST	●	●	●	●
GLA	156	ALL	TPMS-Tire Pressure Monitoring System	●	●	●	●
GLA	156	ALL	IC-Instrument cluster	●	●	●	●
GLA	156	ALL	SRS-Supplemental restraint system	●	●	●	●
GLA	156	ALL	KOMO/mbrace-Communication module' Telematics services' /Notrufsystem	●	●	●	●
GLA	156	ALL	COU[ZBE]-Audio/COMAND operating unit	●	●	●	●
GLA	156	ALL	DAB-Digital Audio Broadcasting	●	●	●	●
GLA	156	ALL	ZAN-Audio/COMAND display	●	●	●	●
GLA	156	ALL	TV-TV tuner	●	●	●	●
GLA	156	ALL	DCU_LF-Left front door	●	●	●	●
GLA	156	ALL	DCU_RF-Right front door	●	●	●	●
GLA	156	ALL	ESA Driver-Electrical seat adjustment Driver	●	●	●	●
GLA	156	ALL	ESA Front passenger-Electrical seat adjustment Front passenger	●	●	●	●
GLA	156	ALL	ADS-Adaptive damping system(N51/5)	●	●	●	●
GLC	253	ALL	ECM-Engine Control Module	●	●	●	●
GLC	253	ALL	BMS-Battery management system	●	●	●	●
GLC	253	ALL	DC/DC-DC/DC converter	●	●	●	●

GLC	253	ALL	ATA-interior mation sensor	●	●	●	●
GLC	253	ALL	KG-KEYLESS GO	●	●	●	●
GLC	253	ALL	SCM-Steering column module	●	●	●	●
GLC	253	ALL	SD-Control module Sliding roof	●	●	●	●
GLC	253	ALL	SG-SOGE-E-Sound generator for electric vehicle	●	●	●	●
GLC	253	ALL	AHE-Trailer recognition	●	●	●	●
GLC	253	ALL	ISM-Shift module	●	●	●	●
GLC	253	ALL	ESP-Electronic stability program	●	●	●	●
GLC	253	ALL	ES-Electrical power steering	●	●	●	●
GLC	253	ALL	ADS-Adaptive damping system	●	●	●	●
GLC	253	ALL	IC-Instrument cluster	●	●	●	●
GLC	253	ALL	RevETR_LF-Left front reversible emergency tensioning retractor	●	●	●	●
GLC	253	ALL	RevETR_RF-Right front reversible emergency tensioning retractor	●	●	●	●
GLC	253	ALL	HKS-Tailgate control	●	●	●	●
GLC	253	ALL	KOMO/mbrace-Communication module' Telematics services' /Notrufsystem	●	●	●	●
GLC	253	ALL	COU[ZBE]-Audio/COMMAND display	●	●	●	●
GLC	253	ALL	DAB-Digital Audio Broadcasting	●	●	●	●
GLC	253	ALL	ZAN-Audio/COMMAND display	●	●	●	●
GLC	253	ALL	TV-TV tuner	●	●	●	●
GLC	253	ALL	TPAD-Touchpad	●	●	●	●
GLC	253	ALL	DCU_LF-Left front door	●	●	●	●
GLC	253	ALL	DCU_RF-Right front door	●	●	●	●
GLC	253	ALL	DCU_LR-Left rear door	●	●	●	●
GLC	253	ALL	DCU_RR-Right rear door	●	●	●	●
GLC	253	ALL	ESA_DR-Electric Seat adjustment driver	●	●	●	●
GLC	253	ALL	ESA Front passenger-Electric seat adjustment Front passenger	●	●	●	●
GLC	253	ALL	SG-LG-Charger	●	●	●	●
GLC	253	ALL	TPM-Tire pressure monitor	●	●	●	●
GLC	253	ALL	PTS-PARKTRONIC	●	●	●	●
GLE	166	ALL	DTR-Distronic	●	●	●	●
GLE	166	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
GLE	166	ALL	ISM-Shift module (A80)	●	●	●	●
GLE	166	ALL	FSCU-Fuel pump	●	●	●	●
GLE	166	ALL	FSCU-Fuel pump	●	●	●	●
GLE	166	ALL	mbrace-mbrace (N123/4)	●	●	●	●
GLE	166	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
GLE	166	ALL	N15/7 (Transfer case control module)	●	●	●	●
GLE	166	ALL	ETC-Electronic transmission control	●	●	●	●
GLE	166	ALL	CDI-Motor electronics 'CR43' for combustion engine' OM651' (N3/9)	●	●	●	●
GLE	166	ALL	CDI 60LS-Common Rail Diesel Injection	●	●	●	●
GLE	166	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
GLE	166	ALL	Roll control-Roll control (N51/6)	●	●	●	●
GLE	166	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
GLE	166	ALL	TPM-Tire pressure monitor	●	●	●	●
GLE	166	ALL	EFB-Electronic parking break (N128)	●	●	●	●

GLE	166	ALL	ES-Electrical power steering (N68)	●	●	●	●
GLE	166	ALL	ESP-Regenerative braking system (N30/6)	●	●	●	●
GLE	166	ALL	AIRMATIC - AIRMATIC(N51/3)	●	●	●	●
GLE	166	ALL	EZS-Electronic ignition switch	●	●	●	●
GLE	166	ALL	KG-KEYLESS GO	●	●	●	●
GLE	166	ALL	KG-KEYLESS GO (N69/5)	●	●	●	●
GLE	166	ALL	BMS-Battery management system (N82/2)	●	●	●	●
GLE	166	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
GLE	166	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
GLE	166	ALL	SAM-Signal acquisition and actuation module (N10)	●	●	●	●
GLE	166	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
GLE	166	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
GLE	166	ALL	SG-EM-Power electronics (N129/1)	●	●	●	●
GLE	166	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
GLE	166	ALL	HKS-Tailgate control (N121/1)	●	●	●	●
GLE	166	ALL	Rear-Rear control unit (N10/8)	●	●	●	●
GLE	166	ALL	RevETR-LF-Left front reversible emergency tensioningretractor (A76)	●	●	●	●
GLE	166	ALL	RevETR-RF-Right front reversible emergency tensioningretractor (A76/1)	●	●	●	●
GLE	166	ALL	SGR-Radar sensors control unit	●	●	●	●
GLE	166	ALL	SCM-Steering column module(N80)	●	●	●	●
GLE	166	ALL	SD-Control module 'Sliding roof (A98/1)'	●	●	●	●
GLE	166	ALL	Trailer recognition module-Trailer recognition(N28/1)	●	●	●	●
GLE	166	ALL	PSD-Control module 'Panoramic sliding roof' (A98)	●	●	●	●
GLE	166	ALL	SGR-Radar sensors control unit	●	●	●	●
GLE	166	ALL	ATA-ATA[EDW]/tow-away protection/interiorprotection(N26/6)	●	●	●	●
GLE	166	ALL	IC-Instrument cluster (A1)	●	●	●	●
GLE	166	ALL	IC-Instrument cluster (A1)	●	●	●	●
GLE	166	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
GLE	166	ALL	COU [ZBE]-Central operating unit	●	●	●	●
GLE	166	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
GLE	166	ALL	DAB-Digital radio	●	●	●	●
GLE	166	ALL	ZAN-Central display	●	●	●	●
GLE	166	ALL	Left rear screen	●	●	●	●
GLE	166	ALL	Right rear screen	●	●	●	●
GLE	166	ALL	AVE-H-Rear audio video unit	●	●	●	●
GLE	166	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
GLE	166	ALL	MFK-Multifunction camera	●	●	●	●
GLE	166	ALL	NAV-Navigation module (A2/30)	●	●	●	●
GLE	166	ALL	NSA-Night View Assist	●	●	●	●
GLE	166	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
GLE	166	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
GLE	166	ALL	SOUND - Sound system(N40/3)	●	●	●	●
GLE	166	ALL	Sound system (Main amplifier)	●	●	●	●

GLE	166	ALL	Sound system (Bass amplifier)	●	●	●	●
GLE	166	ALL	360° camera-360° camera(N148)	●	●	●	●
GLE	166	ALL	TV-TV tuner(AGW)	●	●	●	●
GLE	166	ALL	UCI-Media interface	●	●	●	●
GLE	166	ALL	TELE AID-Control unit	●	●	●	●
GLE	166	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
GLE	166	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
GLE	166	ALL	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
GLE	166	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
GLE	166	ALL	DCU-LF-Left front door (N69/1)	●	●	●	●
GLE	166	ALL	DCU-RF-Right front door (N69/2)	●	●	●	●
GLE	166	ALL	DCU-LR-Left rear door (N69/3)	●	●	●	●
GLE	166	ALL	DCU-RR-Right rear door (N69/4)	●	●	●	●
GLE	166	ALL	MKS-FS-Multicontour seat 'Driver' (N32/29)	●	●	●	●
GLE	166	ALL	MKS-BFS-Multicontour seat 'Front passenger' (N32/30)	●	●	●	●
GLE	166	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●
GLE	166	ALL	ESA 'Driver'-Electrical seat adjustment 'Driver' withmemory function(N32/1)	●	●	●	●
GLE	166	ALL	ESA'Front passenger'-Electric seat adjustment 'Frontpassenger' with memory function(N32/2)	●	●	●	●
GLE	166	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
GLE	166	ALL	HBF-Rear control panel (N72/2)	●	●	●	●
GLE	166	ALL	STH-Stationary heater (A6n1)	●	●	●	●
GLE	166	ALL	LCP-Lower control panel (N72)	●	●	●	●
GLE	166	ALL	UCP-Upper control panel (N72/1)	●	●	●	●
GLE	166	ALL	BSN-Battery sensor (B95)	●	●	●	●
GLE	166	ALL	AISP-Dimming inside rearview mirror (A67)	●	●	●	●
GLE	166	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
GLE	166	ALL	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	●	●	●	●
GLE	166	ALL	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	●	●	●	●
GLE	166	ALL	RGLS-Rain/light sensor (B38/2)	●	●	●	●
GLE	166	ALL	ORBF-Off-road operating panel (N72/3)	●	●	●	●
GLE	166	ALL	OCP-Control unit 'Overhead control panel' (N70)	●	●	●	●
GLE	166	ALL	AS-Alarm siren(H3/1)	●	●	●	●
GLE	292	ALL	ATA-interior motion sensor	●	●	●	●
GLE	292	ALL	SG_FOND-Rear control unit	●	●	●	●
GLE	292	ALL	KG-KEYLESS GO	●	●	●	●
GLE	292	ALL	SCM-Steering column module	●	●	●	●
GLE	292	ALL	Multifunction control unit	●	●	●	●
GLE	292	ALL	PSD-Panoramic sliding sunroof	●	●	●	●
GLE	292	ALL	RevETR_LF-Left front reversible emergency tensioning retractor	●	●	●	●
GLE	292	ALL	RevETR_RF-Right front reversible emergency tensioning retractor	●	●	●	●

GLE	292	ALL	SD-Control module Sliding roof	●	●	●	●
GLE	292	ALL	AC-Air conditioning	●	●	●	●
GLE	292	ALL	DCU_LF-Left front door	●	●	●	●
GLE	292	ALL	DCU_LR-Left rear door	●	●	●	●
GLE	292	ALL	DCU_RF-Right front door	●	●	●	●
GLE	292	ALL	DCU_RR-Right rear door	●	●	●	●
GLE	292	ALL	ESA_DR-Electric Seat adjustment driver	●	●	●	●
GLE	292	ALL	ESA Front passenger-Electrical seat adjustment Front passenger	●	●	●	●
GLE	292	ALL	MKS_LF-Left front multicontour seat	●	●	●	●
GLE	292	ALL	MKS_RF-Right front multicontour seat	●	●	●	●
GLE	292	ALL	FSCU-Fuel pump	●	●	●	●
GLE	292	ALL	ECM-Engine Control Module	●	●	●	●
GLE	292	ALL	VG-Transfer case	●	●	●	●
GLE	292	ALL	ISM-Shift module	●	●	●	●
GLE	292	ALL	TCM-Transmission Control Module	●	●	●	●
GLE	292	ALL	EPB-Electrical Parking Brake	●	●	●	●
GLE	292	ALL	ES-Electronic Power Steering	●	●	●	●
GLE	292	ALL	ESP-Electronic stability program	●	●	●	●
GLE	292	ALL	Roll control	●	●	●	●
GLE	292	ALL	FGW-Chassis gateway	●	●	●	●
GLE	292	ALL	SGR-Radar sensors control unit	●	●	●	●
GLE	292	ALL	NSA-Night View Assist	●	●	●	●
GLE	292	ALL	MFK-Multifunction camera	●	●	●	●
GLE	292	ALL	PTS-PARKTRONIC	●	●	●	●
GLE	292	ALL	RFK-Backup camera	●	●	●	●
GLE	292	ALL	TPMS-Tire Pressure Monitoring System	●	●	●	●
GLE	292	ALL	IC-Instrument cluster	●	●	●	●
GLE	292	ALL	SRS-Supplemental restraint system	●	●	●	●
GLE	292	ALL	KOMO/mbrace-Communication module' Telematics services' /Notrufsystem	●	●	●	●
GLE	292	ALL	COU[ZBE]-Audio/COMAND operating unit	●	●	●	●
GLE	292	ALL	DAB-Digital Audio Broadcasting	●	●	●	●
GLE	292	ALL	ZAN-Audio/COMMAND display	●	●	●	●
GLE	292	ALL	TV-TV tuner	●	●	●	●
GLE	292	ALL	TPAD-Touchpad	●	●	●	●
GLK	204	ALL	ETC-Electronic transmission control	●	●	●	●
GLK	204	ALL	ETC-Electronic transmission control	●	●	●	●
GLK	204	ALL	ME 9.7-Motor electronics 9.7	●	●	●	●
GLK	204	ALL	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
GLK	204	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
GLK	204	ALL	ME-Motor electronics 'MED40' for combustion engine' M270' (N3/10)	●	●	●	●
GLK	204	ALL	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●
GLK	204	ALL	FSCU-Fuel pump	●	●	●	●
GLK	204	ALL	FSCU-Fuel pump	●	●	●	●
GLK	204	ALL	FSCU-Fuel pump	●	●	●	●
GLK	204	ALL	FSCU Left-Control unit ' left fuel	●	●	●	●

GLK	204	ALL	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●
GLK	204	ALL	ME - Motor electronics 'SIM271DE20' for combustionengine 'M271EVO' (N3/10)	●	●	●	●
GLK	204	ALL	ME-SFI-Motor electronics	●	●	●	●
GLK	204	ALL	ESM-Electronic selector module	●	●	●	●
GLK	204	ALL	DTR-Distronic	●	●	●	●
GLK	204	ALL	PTCU-Common powertrain controller (N127)	●	●	●	●
GLK	204	ALL	ISM-Shift module (A80)	●	●	●	●
GLK	204	ALL	mbrace-mbrace (N123/4)	●	●	●	●
GLK	204	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
GLK	204	ALL	FSCU-Fuel pump	●	●	●	●
GLK	204	ALL	CDID-Common Rail Diesel Injection	●	●	●	●
GLK	204	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
GLK	204	ALL	ESM-Electronic selector module	●	●	●	●
GLK	204	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
GLK	204	ALL	CDI 60LS-Common Rail Diesel Injection	●	●	●	●
GLK	204	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
GLK	204	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
GLK	204	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
GLK	204	ALL	ABR-Adaptive Brake	●	●	●	●
GLK	204	ALL	TPC-Tire pressure monitor	●	●	●	●
GLK	204	ALL	TPM - Tire pressure monitor(N88)	●	●	●	●
GLK	204	ALL	AIRMATIC-AIRMATIC	●	●	●	●
GLK	204	ALL	EHPS-Electrohydraulic Power Steering	●	●	●	●
GLK	204	ALL	ES-Electrical power steering (N68)	●	●	●	●
GLK	204	ALL	ESP-Electronic stability program	●	●	●	●
GLK	204	ALL	ESP-Regenerative braking system (N30/6)	●	●	●	●
GLK	204	ALL	CGW-Central gateway	●	●	●	●
GLK	204	ALL	CGW[ZGW]-Central gateway (CGW[ZGW])	●	●	●	●
GLK	204	ALL	CGW-Central gateway	●	●	●	●
GLK	204	ALL	EZS-Electronic ignition switch	●	●	●	●
GLK	204	ALL	KG-Keyless Go	●	●	●	●
GLK	204	ALL	KG-KEYLESS GO(N69/5)	●	●	●	●
GLK	204	ALL	Trailer recognition module	●	●	●	●
GLK	204	ALL	AB-Airbag	●	●	●	●
GLK	204	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
GLK	204	ALL	SRS-Supplemental restraint system	●	●	●	●
GLK	204	ALL	WSS-Weight sensing system	●	●	●	●
GLK	204	ALL	OCP-Overhead control panel	●	●	●	●
GLK	204	ALL	PSD-Control module 'Panoramic sliding roof' (A98)	●	●	●	●
GLK	204	ALL	PSD-Control module 'Panoramic sliding roof' (A98)	●	●	●	●
GLK	204	ALL	Dr-side SAM-Driver signal acquisition and actuationmodule	●	●	●	●
GLK	204	ALL	Driver-side SAM-Driver signal acquisition andactuation module	●	●	●	●
GLK	204	ALL	Driver-side SAM-Driver signal acquisition andactuation module	●	●	●	●

GLK	204	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
GLK	204	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
GLK	204	ALL	AHE-Trailer recognition	●	●	●	●
GLK	204	ALL	MSS-Special vehicle multifunction control module	●	●	●	●
GLK	204	ALL	Multifunction control unit- Multifunction control unit (N26/14)	●	●	●	●
GLK	204	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
GLK	204	ALL	RevETR-LF-Left front reversible emergency tensioningretractor (A76)	●	●	●	●
GLK	204	ALL	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
GLK	204	ALL	RevETR-RF-Right front reversible emergency tensioningretractor (A76/1)	●	●	●	●
GLK	204	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
GLK	204	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
GLK	204	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
GLK	204	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
GLK	204	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
GLK	204	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
GLK	204	ALL	EZS-Electronic ignition lock	●	●	●	●
GLK	204	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
GLK	204	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
GLK	204	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
GLK	204	ALL	SGR-Radar sensors control unit	●	●	●	●
GLK	204	ALL	RFK-Backup camera (B84/3)	●	●	●	●
GLK	204	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
GLK	204	ALL	SCM-Steering column module (N80)	●	●	●	●
GLK	204	ALL	SGR-Radar sensors control unit	●	●	●	●
GLK	204	ALL	ES-Electrical power steering	●	●	●	●
GLK	204	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
GLK	204	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
GLK	204	ALL	IC-Instrument cluster (A1)	●	●	●	●
GLK	204	ALL	IC-Instrument cluster (A1)	●	●	●	●
GLK	204	ALL	ICI-InCar Internet (N125/3)	●	●	●	●
GLK	204	ALL	PTS-Parktronic	●	●	●	●
GLK	204	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
GLK	204	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
GLK	204	ALL	RFK-Backup camera (B84/3)	●	●	●	●
GLK	204	ALL	SCM [MRM]-Steering column module	●	●	●	●
GLK	204	ALL	SCCM-Steering column module (N80)	●	●	●	●
GLK	204	ALL	COMAND or AUDIO	●	●	●	●
GLK	204	ALL	COMAND or AUDIO	●	●	●	●
GLK	204	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
GLK	204	ALL	COU [ZBE]-Central operating unit	●	●	●	●
GLK	204	ALL	ZBE-Audio/COMAND operating unit (A40/9)	●	●	●	●
GLK	204	ALL	ZAN-Central display	●	●	●	●



GLK	204	ALL	TV-TV tuner	●	●	●	●
GLK	204	ALL	TV-TV tuner(AGW)	●	●	●	●
GLK	204	ALL	CTEL-Cellular telephone(JAPAN)	●	●	●	●
GLK	204	ALL	DAB-Digital radio	●	●	●	●
GLK	204	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
GLK	204	ALL	Sound system (Main amplifier)	●	●	●	●
GLK	204	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
GLK	204	ALL	UCI-Media interface	●	●	●	●
GLK	204	ALL	AVE-H-Rear audio video unit	●	●	●	●
GLK	204	ALL	Left rear screen	●	●	●	●
GLK	204	ALL	Right rear screen	●	●	●	●
GLK	204	ALL	TELE AID-Control unit	●	●	●	●
GLK	204	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
GLK	204	ALL	TELE AID-Telematic services MB Info, Roadsideassistance(USA, Canada), Tele diagnosis(ECE)	●	●	●	●
GLK	204	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
GLK	204	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
GLK	204	ALL	AMG PM-AMG Performance Media(N125/2)	●	●	●	●
GLK	204	ALL	AMG DRVU-AMG DRIVE UNIT (N145)	●	●	●	●
GLK	204	ALL	Drive-side SAM-Front signal acquisition and actuationmodule (N10/1)	●	●	●	●
GLK	204	ALL	MFK-Multifunction camera	●	●	●	●
GLK	204	ALL	NAV-Navigation module (A2/30)	●	●	●	●
GLK	204	ALL	360° camera-360° camera(N148)	●	●	●	●
GLK	204	ALL	NAVI20 - Navigation(N125/2)	●	●	●	●
GLK	204	ALL	DCM-FL-Door control module front left	●	●	●	●
GLK	204	ALL	DCU-LF-Left front door	●	●	●	●
GLK	204	ALL	DCM-FR-Door control module front right	●	●	●	●
GLK	204	ALL	DCU-RF-Right front door	●	●	●	●
GLK	204	ALL	DCM-RL-Door control module rear left	●	●	●	●
GLK	204	ALL	DCU-LR-Left rear door	●	●	●	●
GLK	204	ALL	DCM-RR-Door control module rear right	●	●	●	●
GLK	204	ALL	DCU-RR-Right rear door	●	●	●	●
GLK	204	ALL	HKS-Tailgate control (N121/1)	●	●	●	●
GLK	204	ALL	ESA driver	●	●	●	●
GLK	204	ALL	ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)	●	●	●	●
GLK	204	ALL	ESA passenger	●	●	●	●
GLK	204	ALL	ESA-Electirc seat adjustment 'Front passenger' (N32/2)	●	●	●	●
GLK	204	ALL	ESA' Front passenger'-Electric seat adjustment 'Frontpassenger' with memory function(N32/2)	●	●	●	●
GLK	204	ALL	Stationary heater	●	●	●	●
GLK	204	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
GLK	204	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
GLK	204	ALL	EKMK-Electric refrigerant compressor (A9/5)	●	●	●	●
GLK	204	ALL	LCP-Lower control panel (S77)	●	●	●	●
GLK	204	ALL	GTO-Garage door opener (A67n2)	●	●	●	●

GLK	204	ALL	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	●	●	●	●
GLK	204	ALL	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	●	●	●	●
GLS	166	ALL	DTR-Distronic	●	●	●	●
GLS	166	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
GLS	166	ALL	ISM-Shift module (A80)	●	●	●	●
GLS	166	ALL	FSCU-Fuel pump	●	●	●	●
GLS	166	ALL	FSCU-Fuel pump	●	●	●	●
GLS	166	ALL	mbrace-mbrace (N123/4)	●	●	●	●
GLS	166	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
GLS	166	ALL	N15/7(Transfer case control module)	●	●	●	●
GLS	166	ALL	ETC-Electronic transmission control	●	●	●	●
GLS	166	ALL	CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9)	●	●	●	●
GLS	166	ALL	CDI 6OLS-Common Rail Diesel Injection	●	●	●	●
GLS	166	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
GLS	166	ALL	Roll control-Roll control (N51/6)	●	●	●	●
GLS	166	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
GLS	166	ALL	TPM-Tire pressure monitor	●	●	●	●
GLS	166	ALL	EFB-Electronic parking break (N128)	●	●	●	●
GLS	166	ALL	ES-Electrical power steering (N68)	●	●	●	●
GLS	166	ALL	ESP-Regenerative braking system (N30/6)	●	●	●	●
GLS	166	ALL	AIRMATIC - AIRMATIC (N51/3)	●	●	●	●
GLS	166	ALL	EZS-Electronic ignition switch	●	●	●	●
GLS	166	ALL	KG-KEYLESS GO	●	●	●	●
GLS	166	ALL	KG-KEYLESS GO (N69/5)	●	●	●	●
GLS	166	ALL	BMS-Battery management system (N82/2)	●	●	●	●
GLS	166	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
GLS	166	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
GLS	166	ALL	SAM-Signal acquisition and actuation module (N10)	●	●	●	●
GLS	166	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
GLS	166	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
GLS	166	ALL	SG-EM-Power electronics (N129/1)	●	●	●	●
GLS	166	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
GLS	166	ALL	HKS-Tailgate control (N121/1)	●	●	●	●
GLS	166	ALL	Rear-Rear control unit (N10/8)	●	●	●	●
GLS	166	ALL	RevETR-LF-Left front reversible emergency tensioningretractor (A76)	●	●	●	●
GLS	166	ALL	RevETR-RF-Right front reversible emergency tensioningretractor (A76/1)	●	●	●	●
GLS	166	ALL	SGR-Radar sensors control unit	●	●	●	●
GLS	166	ALL	SCM-Steering column module(N80)	●	●	●	●
GLS	166	ALL	SD-Control module 'Sliding roof (A98/1)'	●	●	●	●
GLS	166	ALL	Trailer recognition module-Trailer recognition(N28/1)	●	●	●	●
GLS	166	ALL	PSD-Control module 'Panoramic sliding roof' (A98)	●	●	●	●

GLS	166	ALL	SGR-Radar sensors control unit	●	●	●	●
GLS	166	ALL	ATA-ATA[EDW]/tow-away protection/interiorprotection (N26/6)	●	●	●	●
GLS	166	ALL	IC-Instrument cluster (A1)	●	●	●	●
GLS	166	ALL	IC-Instrument cluster (A1)	●	●	●	●
GLS	166	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
GLS	166	ALL	COU [ZBE]-Central operating unit	●	●	●	●
GLS	166	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
GLS	166	ALL	DAB-Digital radio	●	●	●	●
GLS	166	ALL	ZAN-Central display	●	●	●	●
GLS	166	ALL	Left rear screen	●	●	●	●
GLS	166	ALL	Right rear screen	●	●	●	●
GLS	166	ALL	AVE-H-Rear audio video unit	●	●	●	●
GLS	166	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
GLS	166	ALL	MFK-Multifunction camera	●	●	●	●
GLS	166	ALL	NAV-Navigation module (A2/30)	●	●	●	●
GLS	166	ALL	NSA-Night View Assist	●	●	●	●
GLS	166	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
GLS	166	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
GLS	166	ALL	SOUND - Sound system(N40/3)	●	●	●	●
GLS	166	ALL	Sound system (Main amplifier)	●	●	●	●
GLS	166	ALL	Sound system (Bass amplifier)	●	●	●	●
GLS	166	ALL	360° camera-360° camera(N148)	●	●	●	●
GLS	166	ALL	TV-TV tuner(AGW)	●	●	●	●
GLS	166	ALL	UCI-Media interface	●	●	●	●
GLS	166	ALL	TELE AID-Control unit	●	●	●	●
GLS	166	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
GLS	166	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
GLS	166	ALL	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
GLS	166	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
GLS	166	ALL	DCU-LF-Left front door (N69/1)	●	●	●	●
GLS	166	ALL	DCU-RF-Right front door (N69/2)	●	●	●	●
GLS	166	ALL	DCU-LR-Left rear door (N69/3)	●	●	●	●
GLS	166	ALL	DCU-RR-Right rear door (N69/4)	●	●	●	●
GLS	166	ALL	MKS-FS-Multicontour seat 'Driver' (N32/29)	●	●	●	●
GLS	166	ALL	MKS-BFS-Multicontour seat 'Front passenger' (N32/30)	●	●	●	●
GLS	166	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●
GLS	166	ALL	ESA 'Driver'-Electrical seat adjustment 'Driver' withmemory function(N32/1)	●	●	●	●
GLS	166	ALL	ESA'Front passenger'-Electric seat adjustment 'Frontpassenger' with memory function(N32/2)	●	●	●	●
GLS	166	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
GLS	166	ALL	HBF-Rear control panel (N72/2)	●	●	●	●
GLS	166	ALL	STH-Stationary heater (A6n1)	●	●	●	●
GLS	166	ALL	LCP-Lower control panel (N72)	●	●	●	●

GLS	166	ALL	UCP-Upper control panel (N72/1)	●	●	●	●
GLS	166	ALL	BSN-Battery sensor (B95)	●	●	●	●
GLS	166	ALL	AISP-Dimming inside rearview mirror (A67)	●	●	●	●
GLS	166	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
GLS	166	ALL	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	●	●	●	●
GLS	166	ALL	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	●	●	●	●
GLS	166	ALL	RGLS-Rain/light sensor (B38/2)	●	●	●	●
GLS	166	ALL	ORBF-Off-road operating panel (N72/3)	●	●	●	●
GLS	166	ALL	OCP-Control unit 'Overhead control panel' (N70)	●	●	●	●
GLS	166	ALL	AS-Alarm siren(H3/1)	●	●	●	●
ML	163	ALL	ETC-Electronic transmission control	●	●	●	●
ML	163	ALL	ETC-Electronic transmission control	●	●	●	●
ML	163	ALL	ESM-Electronic selector module	●	●	●	●
ML	163	ALL	ME2-SFI-Motor electronics 2	●	●	●	●
ML	163	ALL	VG-Transfer case	●	●	●	●
ML	163	ALL	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
ML	163	ALL	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
ML	163	ALL	CDI 2-Common Rail Diesel Injection	●	●	●	●
ML	163	ALL	CDI-V-Common Rail Diesel Injection	●	●	●	●
ML	163	ALL	ESP-Electronic stability program	●	●	●	●
ML	163	ALL	ESP-Electronic stability program	●	●	●	●
ML	163	ALL	ESP-Electronic stability program	●	●	●	●
ML	163	ALL	ESP-Electronic stability program	●	●	●	●
ML	163	ALL	ETS-Electronic traction system	●	●	●	●
ML	163	ALL	ETS-Electronic traction system	●	●	●	●
ML	163	ALL	BAS-Brake assist	●	●	●	●
ML	163	ALL	VP-Vacuum pump brake booster	●	●	●	●
ML	163	ALL	AB-Airbag	●	●	●	●
ML	163	ALL	AB-Airbag	●	●	●	●
ML	163	ALL	EAM-Extended activity module	●	●	●	●
ML	163	ALL	AAM-All Activity Module	●	●	●	●
ML	163	ALL	AAM-All Activity Module	●	●	●	●
ML	163	ALL	DAS-Drive authorization system	●	●	●	●
ML	163	ALL	HRA-Headlamp range adjustment	●	●	●	●
ML	163	ALL	LCP-Lower operating panel with power window function	●	●	●	●
ML	163	ALL	SEM-Security Module	●	●	●	●
ML	163	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
ML	163	ALL	PTS-Parktronic system	●	●	●	●
ML	163	ALL	COMAND	●	●	●	●
ML	163	ALL	MCS-Modular control system	●	●	●	●
ML	163	ALL	AUDIO	●	●	●	●
ML	163	ALL	CTEL- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
ML	163	ALL	UHI- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
ML	163	ALL	CDC-CD changer	●	●	●	●
ML	163	ALL	VCS-Voice control system	●	●	●	●
ML	163	ALL	SOUND- Sound system	●	●	●	●

ML	163	ALL	SDAR-Satellite radio	●	●	●	●
ML	163	ALL	MCS navigation-Navigation in MCS	●	●	●	●
ML	163	ALL	E-call [USA]-Telematic system	●	●	●	●
ML	163	ALL	CTEL over K-wire-Telematic system	●	●	●	●
ML	163	ALL	STH-Stationary heater	●	●	●	●
ML	163	ALL	AAC-Automatic air conditioning	●	●	●	●
ML	164	ALL	ETC-Electronic transmission control	●	●	●	●
ML	164	ALL	VG-Transfer case	●	●	●	●
ML	164	ALL	HAQ-Interwheel differential lock at rear axle	●	●	●	●
ML	164	ALL	ISM-Intelligent servo module	●	●	●	●
ML	164	ALL	ISM-Shift module (A80)	●	●	●	●
ML	164	ALL	ME 9.7-Motor electronics 9.7	●	●	●	●
ML	164	ALL	FSCU-Fuel pump	●	●	●	●
ML	164	ALL	DTR-Distronic	●	●	●	●
ML	164	ALL	DTR-Distronic	●	●	●	●
ML	164	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
ML	164	ALL	IRS-HLA - Outer left rear intelligent radar sensorsystem	●	●	●	●
ML	164	ALL	TV-TV tuner	●	●	●	●
ML	164	ALL	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
ML	164	ALL	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
ML	164	ALL	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
ML	164	ALL	FSCU Left-Control unit 'Left fuel	●	●	●	●
ML	164	ALL	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●
ML	164	ALL	CDI 4-Common Rail Diesel Injection	●	●	●	●
ML	164	ALL	CDI 6BIN5-Common Rail Diesel Injection	●	●	●	●
ML	164	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
ML	164	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
ML	164	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
ML	164	ALL	CDI 5-Common Rail Diesel Injection	●	●	●	●
ML	164	ALL	ETC-Electronic transmission control	●	●	●	●
ML	164	ALL	ME-SF 17.7-Motor electronics 17.7	●	●	●	●
ML	164	ALL	FSCU-Fuel pump	●	●	●	●
ML	164	ALL	HSG-Hybrid control unit	●	●	●	●
ML	164	ALL	ESP-Electronic stability program	●	●	●	●
ML	164	ALL	Suspension	●	●	●	●
ML	164	ALL	TPC-Tire pressure monitor	●	●	●	●
ML	164	ALL	TPM - Tire pressure monitor (N88)	●	●	●	●
ML	164	ALL	EHPS-Electrohydraulic Power Steering	●	●	●	●
ML	164	ALL	RBS-Brake system	●	●	●	●
ML	164	ALL	CGW-Central gateway	●	●	●	●
ML	164	ALL	EZS-Electronic ignition switch	●	●	●	●
ML	164	ALL	EZS-Electronic ignition switch	●	●	●	●
ML	164	ALL	KG-Keyless Go	●	●	●	●
ML	164	ALL	KG-KEYLESS GO	●	●	●	●
ML	164	ALL	AB-Airbag	●	●	●	●
ML	164	ALL	OCP-Overhead control panel	●	●	●	●
ML	164	ALL	WSS-Weight sensing system	●	●	●	●
ML	164	ALL	UCP-Upper control panel	●	●	●	●

ML	164	ALL	HBF (Rear control panel)-Rear control field	●	●	●	●
ML	164	ALL	SAM-F-Signal acquisition and actuation module front	●	●	●	●
ML	164	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
ML	164	ALL	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
ML	164	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
ML	164	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
ML	164	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
ML	164	ALL	HRA-Automatic headlamp range adjustment and headlampcontrol	●	●	●	●
ML	164	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
ML	164	ALL	XALWA-L-Xenon headlamp, left	●	●	●	●
ML	164	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
ML	164	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
ML	164	ALL	System diagnosis (CAN)	●	●	●	●
ML	164	ALL	SG-DDW - DC/DC converter control unit	●	●	●	●
ML	164	ALL	SG-BMS - Battery management system control unit	●	●	●	●
ML	164	ALL	SCM [MRM]-Steering column module	●	●	●	●
ML	164	ALL	CM-Compass module	●	●	●	●
ML	164	ALL	IC-Instrument cluster	●	●	●	●
ML	164	ALL	ASSYST-Active Service System	●	●	●	●
ML	164	ALL	ASSYST PLUS-PLUS Active Service System	●	●	●	●
ML	164	ALL	PTS-Parktronic system	●	●	●	●
ML	164	ALL	PTS-Parktronic system	●	●	●	●
ML	164	ALL	RFK-Backup camera	●	●	●	●
ML	164	ALL	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
ML	164	ALL	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
ML	164	ALL	CDC-CD changer	●	●	●	●
ML	164	ALL	VCS-Voice control system	●	●	●	●
ML	164	ALL	AUDIO	●	●	●	●
ML	164	ALL	COMAND or AUDIO	●	●	●	●
ML	164	ALL	TV-TV tuner	●	●	●	●
ML	164	ALL	TV-TV tuner (AGW)	●	●	●	●
ML	164	ALL	SDAR-Satellite radio	●	●	●	●
ML	164	ALL	SOUND- Sound system	●	●	●	●
ML	164	ALL	CTEL-Mobile phone adapter with universal interface	●	●	●	●
ML	164	ALL	NAVI-Navigation system	●	●	●	●
ML	164	ALL	AVE-H-Rear audio video unit	●	●	●	●
ML	164	ALL	CTEL-Cellular telephone	●	●	●	●
ML	164	ALL	COMAND or AUDIO	●	●	●	●
ML	164	ALL	Sound system (Main amplifier)	●	●	●	●
ML	164	ALL	UCI-Media interface	●	●	●	●
ML	164	ALL	DAB-Digital radio	●	●	●	●

ML	164	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
ML	164	ALL	TV-TV tuner	●	●	●	●
ML	164	ALL	CTEL-Cellular telephone(JAPAN)	●	●	●	●
ML	164	ALL	AVE-H-Rear audio video unit	●	●	●	●
ML	164	ALL	Left rear screen	●	●	●	●
ML	164	ALL	Right rear screen	●	●	●	●
ML	164	ALL	TELE AID-Control unit	●	●	●	●
ML	164	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
ML	164	ALL	TELE AID-Telematic services MB Info, Roadsideassistance(USA, Canada), Tele diagnosis(ECE)	●	●	●	●
ML	164	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
ML	164	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
ML	164	ALL	DCM-FL-Door control module front left	●	●	●	●
ML	164	ALL	DCM-FR-Door control module front right	●	●	●	●
ML	164	ALL	ESA driver-Electric seat adjustment driver (with	●	●	●	●
ML	164	ALL	ESA passenger-Electric seat adjustment passenger	●	●	●	●
ML	164	ALL	DS-LF-Left front dynamic seat	●	●	●	●
ML	164	ALL	DS-RF-Right front dynamic seat	●	●	●	●
ML	164	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●
ML	164	ALL	REDC-Rear-end door closing control module	●	●	●	●
ML	164	ALL	REDC-Rear-end door closing control module	●	●	●	●
ML	164	ALL	HS-Seat heater	●	●	●	●
ML	164	ALL	AAC-Automatic air conditioning	●	●	●	●
ML	164	ALL	HSW-Heated steering wheel	●	●	●	●
ML	164	ALL	STH-Stationary heater with remote control	●	●	●	●
ML	164	ALL	EKMK-Electric refrigerant compressor (A9/5)	●	●	●	●
ML	166	ALL	DTR-Distronic	●	●	●	●
ML	166	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
ML	166	ALL	ISM-Shift module (A80)	●	●	●	●
ML	166	ALL	FSCU-Fuel pump	●	●	●	●
ML	166	ALL	FSCU-Fuel pump	●	●	●	●
ML	166	ALL	mbrace-mbrace (N123/4)	●	●	●	●
ML	166	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
ML	166	ALL	N15/7(Transfer case control module)	●	●	●	●
ML	166	ALL	ETC-Electronic transmission control	●	●	●	●
ML	166	ALL	CDI-Motor electronics 'CR43' for combustion engine'OM651' (N3/9)	●	●	●	●
ML	166	ALL	CDI 60LS-Common Rail Diesel Injection	●	●	●	●
ML	166	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
ML	166	ALL	Roll control-Roll control (N51/6)	●	●	●	●
ML	166	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
ML	166	ALL	TPM-Tire pressure monitor	●	●	●	●
ML	166	ALL	EFB-Electronic parking break (N128)	●	●	●	●
ML	166	ALL	ES-Electrical power steering (N68)	●	●	●	●

ML	166	ALL	ESP-Regenerative braking system (N30/6)	●	●	●	●
ML	166	ALL	AIRMATIC - AIRMATIC (N51/3)	●	●	●	●
ML	166	ALL	EZS-Electronic ignition switch	●	●	●	●
ML	166	ALL	KG-KEYLESS GO	●	●	●	●
ML	166	ALL	KG-KEYLESS GO (N69/5)	●	●	●	●
ML	166	ALL	BMS-Battery management system (N82/2)	●	●	●	●
ML	166	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
ML	166	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
ML	166	ALL	SAM-Signal acquisition and actuation module (N10)	●	●	●	●
ML	166	ALL	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	●	●
ML	166	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
ML	166	ALL	SG-EM-Power electronics (N129/1)	●	●	●	●
ML	166	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
ML	166	ALL	HKS-Tailgate control (N121/1)	●	●	●	●
ML	166	ALL	Rear-Rear control unit (N10/8)	●	●	●	●
ML	166	ALL	RevETR-LF-Left front reversible emergency tensioningretractor (A76)	●	●	●	●
ML	166	ALL	RevETR-RF-Right front reversible emergency tensioningretractor (A76/1)	●	●	●	●
ML	166	ALL	SGR-Radar sensors control unit	●	●	●	●
ML	166	ALL	SCM-Steering column module (N80)	●	●	●	●
ML	166	ALL	SD-Control module 'Sliding roof (A98/1)'	●	●	●	●
ML	166	ALL	Trailer recognition module-Trailer recognition (N28/1)	●	●	●	●
ML	166	ALL	PSD-Control module 'Panoramic sliding roof' (A98)	●	●	●	●
ML	166	ALL	SGR-Radar sensors control unit	●	●	●	●
ML	166	ALL	ATA-ATA[EDW]/tow-away protection/interiorprotection (N26/6)	●	●	●	●
ML	166	ALL	IC-Instrument cluster (A1)	●	●	●	●
ML	166	ALL	IC-Instrument cluster (A1)	●	●	●	●
ML	166	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
ML	166	ALL	COU [ZBE]-Central operating unit	●	●	●	●
ML	166	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
ML	166	ALL	DAB-Digital radio	●	●	●	●
ML	166	ALL	ZAN-Central display	●	●	●	●
ML	166	ALL	Left rear screen	●	●	●	●
ML	166	ALL	Right rear screen	●	●	●	●
ML	166	ALL	AVE-H-Rear audio video unit	●	●	●	●
ML	166	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
ML	166	ALL	MFK-Multifunction camera	●	●	●	●
ML	166	ALL	NAV-Navigation module (A2/30)	●	●	●	●
ML	166	ALL	NSA-Night View Assist	●	●	●	●
ML	166	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
ML	166	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
ML	166	ALL	SOUND - Sound system(N40/3)	●	●	●	●
ML	166	ALL	Sound system (Main amplifier)	●	●	●	●
ML	166	ALL	Sound system (Bass amplifier)	●	●	●	●



ML	166	ALL	360° camera-360° camera(N148)	●	●	●	●
ML	166	ALL	TV-TV tuner(AGW)	●	●	●	●
ML	166	ALL	UCI-Media interface	●	●	●	●
ML	166	ALL	TELE AID-Control unit	●	●	●	●
ML	166	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
ML	166	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
ML	166	ALL	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
ML	166	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
ML	166	ALL	DCU-LF-Left front door (N69/1)	●	●	●	●
ML	166	ALL	DCU-RF-Right front door (N69/2)	●	●	●	●
ML	166	ALL	DCU-LR-Left rear door (N69/3)	●	●	●	●
ML	166	ALL	DCU-RR-Right rear door (N69/4)	●	●	●	●
ML	166	ALL	MKS-FS-Multicontour seat 'Driver' (N32/29)	●	●	●	●
ML	166	ALL	MKS-BFS-Multicontour seat 'Front passenger' (N32/30)	●	●	●	●
ML	166	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●
ML	166	ALL	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function(N32/1)	●	●	●	●
ML	166	ALL	ESA' Front passenger'-Electric seat adjustment 'Frontpassenger' with memory function(N32/2)	●	●	●	●
ML	166	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
ML	166	ALL	HBF-Rear control panel (N72/2)	●	●	●	●
ML	166	ALL	STH-Stationary heater (A6n1)	●	●	●	●
ML	166	ALL	LCP-Lower control panel (N72)	●	●	●	●
ML	166	ALL	UCP-Upper control panel (N72/1)	●	●	●	●
ML	166	ALL	BSN-Battery sensor (B95)	●	●	●	●
ML	166	ALL	AISP-Dimming inside rearview mirror (A67)	●	●	●	●
ML	166	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
ML	166	ALL	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	●	●	●	●
ML	166	ALL	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	●	●	●	●
ML	166	ALL	RGLS-Rain/light sensor (B38/2)	●	●	●	●
ML	166	ALL	ORBF-Off-road operating panel (N72/3)	●	●	●	●
ML	166	ALL	OCP-Control unit 'Overhead control panel' (N70)	●	●	●	●
ML	166	ALL	AS-Alarm siren (H3/1)	●	●	●	●
MayBach	240	Up to 08/2006	ETC-Electronic transmission control	●	●	●	●
MayBach	240	Up to 08/2006	ETC-Electronic transmission control	●	●	●	●
MayBach	240	Up to 08/2006	ESM-Electronic selector module	●	●	●	●
MayBach	240	Up to 08/2006	SGR-Radar sensors control unit	●	●	●	●
MayBach	240	Up to 08/2006	DTR-Distronic	●	●	●	●
MayBach	240	Up to 08/2006	DTR-Distronic	●	●	●	●

MayBach	240	Up to 08/2006	ME-SFI 2.7.1-Motor electronics 2.7.1	●	●	●	●
MayBach	240	Up to 08/2006	SBC-Sensotronic Brake Control	●	●	●	●
MayBach	240	Up to 08/2006	SBC-Right Sensotronic Brake Control	●	●	●	●
MayBach	240	Up to 08/2006	ESP-Electronic stability program	●	●	●	●
MayBach	240	Up to 08/2006	AIRmatic	●	●	●	●
MayBach	240	Up to 08/2006	TPC-Tire pressure monitor	●	●	●	●
MayBach	240	Up to 08/2006	CGW-Central gateway	●	●	●	●
MayBach	240	Up to 08/2006	EZS-Electronic ignition switch	●	●	●	●
MayBach	240	Up to 08/2006	AB-Airbag	●	●	●	●
MayBach	240	Up to 08/2006	WSS-Weight sensing system	●	●	●	●
MayBach	240	Up to 08/2006	BNS-Vehicle power supply control module	●	●	●	●
MayBach	240	Up to 08/2006	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
MayBach	240	Up to 08/2006	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●
MayBach	240	Up to 08/2006	Rear SAM 1-Rear signal acquisition and actuation	●	●	●	●
MayBach	240	Up to 08/2006	Rear SAM 2-Rear signal acquisition and actuation	●	●	●	●
MayBach	240	Up to 08/2006	MSS-Special vehicle multifunction control module	●	●	●	●
MayBach	240	Up to 08/2006	VBF (Front control panel)-Front control panel	●	●	●	●
MayBach	240	Up to 08/2006	HBF (Rear control panel)-Rear control field	●	●	●	●
MayBach	240	Up to 08/2006	BCG-Remote control (Rear control field)	●	●	●	●
MayBach	240	Up to 08/2006	OCP-Overhead control panel	●	●	●	●
MayBach	240	Up to 08/2006	CRN-Center roof node	●	●	●	●
MayBach	240	Up to 08/2006	PSE-Pneumatic system equipment	●	●	●	●
MayBach	240	Up to 08/2006	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●
MayBach	240	Up to 08/2006	System diagnosis (CAN)	●	●	●	●
MayBach	240	Up to 08/2006	PTS-Parktronic system	●	●	●	●
MayBach	240	Up to 08/2006	SCM [MRM]-Steering column module	●	●	●	●
MayBach	240	Up to 08/2006	ICM-Instrument cluster	●	●	●	●
MayBach	240	Up to 08/2006	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
MayBach	240	Up to 08/2006	CTEL-Telecommunication for telematics services	●	●	●	●
MayBach	240	Up to 08/2006	Telephone adapter for portable CTET-Telecommunication for telematics services	●	●	●	●

MayBach	240	Up to 08/2006	AUDIO	●	●	●	●
MayBach	240	Up to 08/2006	COMAND or AUDIO	●	●	●	●
MayBach	240	Up to 08/2006	NAVI-Navigation system	●	●	●	●
MayBach	240	Up to 08/2006	VCS-Voice control system	●	●	●	●
MayBach	240	Up to 08/2006	TV-TV tuner	●	●	●	●
MayBach	240	Up to 08/2006	TV-TV tuner (AGW)	●	●	●	●
MayBach	240	Up to 08/2006	SOUND-Bose sound system	●	●	●	●
MayBach	240	Up to 08/2006	SDAR-Satellite radio	●	●	●	●
MayBach	240	Up to 08/2006	CTEL-Mobile phone adapter with universal interface	●	●	●	●
MayBach	240	Up to 08/2006	AVC-Audio video controller	●	●	●	●
MayBach	240	Up to 08/2006	TV-TV tuner (REAR)	●	●	●	●
MayBach	240	Up to 08/2006	TV-TV tuner (rear)	●	●	●	●
MayBach	240	Up to 08/2006	CDC-CD changer (REAR)	●	●	●	●
MayBach	240	Up to 08/2006	KTL-Left headphone transmitter	●	●	●	●
MayBach	240	Up to 08/2006	KTR-Right headphone transmitter	●	●	●	●
MayBach	240	Up to 08/2006	GPS box	●	●	●	●
MayBach	240	Up to 08/2006	TELE AID-Control unit	●	●	●	●
MayBach	240	Up to 08/2006	TELE AID-Telematic services Emergency call	●	●	●	●
MayBach	240	Up to 08/2006	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
MayBach	240	Up to 08/2006	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
MayBach	240	Up to 08/2006	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
MayBach	240	Up to 08/2006	ESA-FL-Electric seat adjustment front left	●	●	●	●
MayBach	240	Up to 08/2006	ESA-FR-Electric seat adjustment front right	●	●	●	●
MayBach	240	Up to 08/2006	ESA-LR-Left rear electrical seat adjustment	●	●	●	●
MayBach	240	Up to 08/2006	ESA-RR-Right rear electrical seat adjustment	●	●	●	●
MayBach	240	Up to 08/2006	OSB-FL-Multicontour backrest front left	●	●	●	●
MayBach	240	Up to 08/2006	OSB-FR-Multicontour backrest front right	●	●	●	●
MayBach	240	Up to 08/2006	MKL-HL-Rear left multicontour backrest	●	●	●	●
MayBach	240	Up to 08/2006	MKL-HR-Rear right multicontour backrest	●	●	●	●
MayBach	240	Up to 08/2006	DCM-FL-Door control module front left	●	●	●	●
MayBach	240	Up to 08/2006	DCM-FR-Door control module front right	●	●	●	●

MayBach	240	Up to 08/2006	DCM-RL-Door control module rear left	●	●	●	●
MayBach	240	Up to 08/2006	DCM-RR-Door control module rear right	●	●	●	●
MayBach	240	Up to 08/2006	PWC-Partition wall control module	●	●	●	●
MayBach	240	Up to 08/2006	LDCA-Electric left door closing assist	●	●	●	●
MayBach	240	Up to 08/2006	RDCA-Electric right door closing assist	●	●	●	●
MayBach	240	Up to 08/2006	TLC-Trunk lid control	●	●	●	●
MayBach	240	Up to 08/2006	AAC-Automatic air conditioning	●	●	●	●
MayBach	240	Up to 08/2006	REAR AC-Rear air conditioning	●	●	●	●
MayBach	240	Up to 08/2006	STH-Stationary heater	●	●	●	●
MayBach	240	Up to 08/2006	HSW-Heated steering wheel	●	●	●	●
MayBach	240	As of 09/2006	ETC-Electronic transmission control	●	●	●	●
MayBach	240	As of 09/2006	ETC-Electronic transmission control	●	●	●	●
MayBach	240	As of 09/2006	ESM-Electronic selector module	●	●	●	●
MayBach	240	As of 09/2006	SGR-Radar sensors control unit	●	●	●	●
MayBach	240	As of 09/2006	DTR-Distronic	●	●	●	●
MayBach	240	As of 09/2006	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
MayBach	240	As of 09/2006	FSCU-Fuel pump	●	●	●	●
MayBach	240	As of 09/2006	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
MayBach	240	As of 09/2006	SBC-Sensotronic Brake Control	●	●	●	●
MayBach	240	As of 09/2006	SBC-Right Sensotronic Brake Control	●	●	●	●
MayBach	240	As of 09/2006	ESP-Electronic stability program	●	●	●	●
MayBach	240	As of 09/2006	AIRmatic	●	●	●	●
MayBach	240	As of 09/2006	TPC-Tire pressure monitor	●	●	●	●
MayBach	240	As of 09/2006	CGW-Central gateway	●	●	●	●
MayBach	240	As of 09/2006	EZS-Electronic ignition switch	●	●	●	●
MayBach	240	As of 09/2006	AB-Airbag	●	●	●	●
MayBach	240	As of 09/2006	WSS-Weight sensing system	●	●	●	●
MayBach	240	As of 09/2006	BNS-Vehicle power supply control module	●	●	●	●
MayBach	240	As of 09/2006	Dr-side SAM-Driver signal acquisition and actuationmodule	●	●	●	●
MayBach	240	As of 09/2006	Pass-side SAM-Passenger-side signal acquisition andactuation module	●	●	●	●
MayBach	240	As of 09/2006	Rear SAM 1-Rear signal acquisition and actuation	●	●	●	●

MayBach	240	As of 09/2006	Rear SAM 2-Rear signal acquisition and actuation	●	●	●	●
MayBach	240	As of 09/2006	MSS-Special vehicle multifunction control module	●	●	●	●
MayBach	240	As of 09/2006	VBF (Front control panel)-Front control panel	●	●	●	●
MayBach	240	As of 09/2006	HBF (Rear control panel)-Rear control field	●	●	●	●
MayBach	240	As of 09/2006	BCG-Remote control (Rear control field)	●	●	●	●
MayBach	240	As of 09/2006	OCP-Overhead control panel	●	●	●	●
MayBach	240	As of 09/2006	CRN-Center roof node	●	●	●	●
MayBach	240	As of 09/2006	PSE-Pneumatic system equipment	●	●	●	●
MayBach	240	As of 09/2006	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●
MayBach	240	As of 09/2006	System diagnosis (CAN)	●	●	●	●
MayBach	240	As of 09/2006	PTS-Parktronic system	●	●	●	●
MayBach	240	As of 09/2006	SCM [MRM]-Steering column module	●	●	●	●
MayBach	240	As of 09/2006	ICM-Instrument cluster	●	●	●	●
MayBach	240	As of 09/2006	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
MayBach	240	As of 09/2006	CTEL-Telecommunication for telematics services	●	●	●	●
MayBach	240	As of 09/2006	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●
MayBach	240	As of 09/2006	AUDIO	●	●	●	●
MayBach	240	As of 09/2006	COMAND or AUDIO	●	●	●	●
MayBach	240	As of 09/2006	NAVI-Navigation system	●	●	●	●
MayBach	240	As of 09/2006	VCS-Voice control system	●	●	●	●
MayBach	240	As of 09/2006	TV-TV tuner	●	●	●	●
MayBach	240	As of 09/2006	TV-TV tuner (AGW)	●	●	●	●
MayBach	240	As of 09/2006	SOUND-Bose sound system	●	●	●	●
MayBach	240	As of 09/2006	SDAR-Satellite radio	●	●	●	●
MayBach	240	As of 09/2006	CTEL-Mobile phone adapter with universal interface	●	●	●	●
MayBach	240	As of 09/2006	AVC-Audio video controller	●	●	●	●
MayBach	240	As of 09/2006	TV-TV tuner (REAR)	●	●	●	●
MayBach	240	As of 09/2006	TV-TV tuner (rear)	●	●	●	●
MayBach	240	As of 09/2006	CDC-CD changer (REAR)	●	●	●	●
MayBach	240	As of 09/2006	KTL-Left headphone transmitter	●	●	●	●

MayBach	240	As of 09/2006	KTR-Right headphone transmitter	●	●	●	●
MayBach	240	As of 09/2006	GPS box	●	●	●	●
MayBach	240	As of 09/2006	TELE AID-Control unit	●	●	●	●
MayBach	240	As of 09/2006	TELE AID-Telematic services Emergency call	●	●	●	●
MayBach	240	As of 09/2006	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
MayBach	240	As of 09/2006	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
MayBach	240	As of 09/2006	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
MayBach	240	As of 09/2006	ESA-FL-Electric seat adjustment front left	●	●	●	●
MayBach	240	As of 09/2006	ESA-FR-Electric seat adjustment front right	●	●	●	●
MayBach	240	As of 09/2006	ESA-LR-Left rear electrical seat adjustment	●	●	●	●
MayBach	240	As of 09/2006	ESA-RR-Right rear electrical seat adjustment	●	●	●	●
MayBach	240	As of 09/2006	OSB-FL-Multicontour backrest front left	●	●	●	●
MayBach	240	As of 09/2006	OSB-FR-Multicontour backrest front right	●	●	●	●
MayBach	240	As of 09/2006	MKL-HL-Rear left multicontour backrest	●	●	●	●
MayBach	240	As of 09/2006	MKL-HR-Rear right multicontour backrest	●	●	●	●
MayBach	240	As of 09/2006	DCM-FL-Door control module front left	●	●	●	●
MayBach	240	As of 09/2006	DCM-FR-Door control module front right	●	●	●	●
MayBach	240	As of 09/2006	DCM-RL-Door control module rear left	●	●	●	●
MayBach	240	As of 09/2006	DCM-RR-Door control module rear right	●	●	●	●
MayBach	240	As of 09/2006	PWC-Partition wall control module	●	●	●	●
MayBach	240	As of 09/2006	LDCA-Electric left door closing assist	●	●	●	●
MayBach	240	As of 09/2006	RDCA-Electric right door closing assist	●	●	●	●
MayBach	240	As of 09/2006	TLC-Trunk lid control	●	●	●	●
MayBach	240	As of 09/2006	AAC-Automatic air conditioning	●	●	●	●
MayBach	240	As of 09/2006	REAR AC-Rear air conditioning	●	●	●	●
MayBach	240	As of 09/2006	STH-Stationary heater	●	●	●	●
MayBach	240	As of 09/2006	HSW-Heated steering wheel	●	●	●	●
R-Class	251	ALL	ISM-Intelligent servo module	●	●	●	●
R-Class	251	ALL	ISM-Shift module (A80)	●	●	●	●
R-Class	251	ALL	ETC-Electronic transmission control	●	●	●	●
R-Class	251	ALL	ME 9.7-Motor electronics 9.7	●	●	●	●
R-Class	251	ALL	FSCU-Fuel pump	●	●	●	●
R-Class	251	ALL	DTR-Distronic	●	●	●	●

R-Class	251	ALL	DTR-Distronic	●	●	●	●
R-Class	251	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
R-Class	251	ALL	IRS-HLA - Outer left rear intelligent radar sensorsystem	●	●	●	●
R-Class	251	ALL	TV-TV tuner	●	●	●	●
R-Class	251	ALL	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
R-Class	251	ALL	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
R-Class	251	ALL	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
R-Class	251	ALL	FSCU Left-Control unit 'Left fuel	●	●	●	●
R-Class	251	ALL	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●
R-Class	251	ALL	CDI 4-Common Rail Diesel Injection	●	●	●	●
R-Class	251	ALL	CDI 6BIN5-Common Rail Diesel Injection	●	●	●	●
R-Class	251	ALL	CDI 6-Common Rail Diesel Injection	●	●	●	●
R-Class	251	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
R-Class	251	ALL	CDI 6OLS-Common Rail Diesel Injection	●	●	●	●
R-Class	251	ALL	ESP-Electronic stability program	●	●	●	●
R-Class	251	ALL	Suspension	●	●	●	●
R-Class	251	ALL	Suspension	●	●	●	●
R-Class	251	ALL	TPC-Tire pressure monitor	●	●	●	●
R-Class	251	ALL	TPM - Tire pressure monitor (N88)	●	●	●	●
R-Class	251	ALL	EHPS-Electrohydraulic Power Steering	●	●	●	●
R-Class	251	ALL	CGW-Central gateway	●	●	●	●
R-Class	251	ALL	EZS-Electronic ignition switch	●	●	●	●
R-Class	251	ALL	EZS-Electronic ignition switch	●	●	●	●
R-Class	251	ALL	KG-Keyless Go	●	●	●	●
R-Class	251	ALL	KG-KEYLESS GO	●	●	●	●
R-Class	251	ALL	AB-Airbag	●	●	●	●
R-Class	251	ALL	OCP-Overhead control panel	●	●	●	●
R-Class	251	ALL	WSS-Weight sensing system	●	●	●	●
R-Class	251	ALL	UCP-Upper control panel	●	●	●	●
R-Class	251	ALL	HBF (Rear control panel)-Rear control field	●	●	●	●
R-Class	251	ALL	SAM-F-Signal acquisition and actuation module front	●	●	●	●
R-Class	251	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
R-Class	251	ALL	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
R-Class	251	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
R-Class	251	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
R-Class	251	ALL	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
R-Class	251	ALL	HRA-Automatic headlamp range adjustment and headlampcontrol	●	●	●	●
R-Class	251	ALL	HRA-FL-Front left headlamp range control	●	●	●	●
R-Class	251	ALL	XALWA-R-Xenon headlamp, right	●	●	●	●
R-Class	251	ALL	System diagnosis (CAN)	●	●	●	●
R-Class	251	ALL	SCM [MRM]-Steering column module	●	●	●	●
R-Class	251	ALL	CM-Compass module	●	●	●	●

R-Class	251	ALL	IC-Instrument cluster	●	●	●	●
R-Class	251	ALL	ASSYST-Active Service System	●	●	●	●
R-Class	251	ALL	ASSYST PLUS-PLUS Active Service System	●	●	●	●
R-Class	251	ALL	PTS-Parktronic system	●	●	●	●
R-Class	251	ALL	PTS-Parktronic system	●	●	●	●
R-Class	251	ALL	RFK-Backup camera	●	●	●	●
R-Class	251	ALL	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
R-Class	251	ALL	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
R-Class	251	ALL	CDC-CD changer	●	●	●	●
R-Class	251	ALL	VCS-Voice control system	●	●	●	●
R-Class	251	ALL	AUDIO	●	●	●	●
R-Class	251	ALL	COMAND or AUDIO	●	●	●	●
R-Class	251	ALL	TV-TV tuner	●	●	●	●
R-Class	251	ALL	TV-TV tuner (AGW)	●	●	●	●
R-Class	251	ALL	SDAR-Satellite radio	●	●	●	●
R-Class	251	ALL	SOUND- Sound system	●	●	●	●
R-Class	251	ALL	CTEL-Mobile phone adapter with universal interface	●	●	●	●
R-Class	251	ALL	NAVI-Navigation system	●	●	●	●
R-Class	251	ALL	AVE-H-Rear audio video unit	●	●	●	●
R-Class	251	ALL	CTEL-Cellular telephone	●	●	●	●
R-Class	251	ALL	COMAND or AUDIO	●	●	●	●
R-Class	251	ALL	Sound system (Main amplifier)	●	●	●	●
R-Class	251	ALL	UCI-Media interface	●	●	●	●
R-Class	251	ALL	DAB-Digital radio	●	●	●	●
R-Class	251	ALL	SDAR-Satellite radio (Valid for USA)	●	●	●	●
R-Class	251	ALL	TV-TV tuner	●	●	●	●
R-Class	251	ALL	CTEL-Cellular telephone (JAPAN)	●	●	●	●
R-Class	251	ALL	AVE-H-Rear audio video unit	●	●	●	●
R-Class	251	ALL	Left rear screen	●	●	●	●
R-Class	251	ALL	Right rear screen	●	●	●	●
R-Class	251	ALL	TELE AID-Control unit	●	●	●	●
R-Class	251	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
R-Class	251	ALL	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
R-Class	251	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
R-Class	251	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
R-Class	251	ALL	DCM-FL-Door control module front left	●	●	●	●
R-Class	251	ALL	DCM-FR-Door control module front right	●	●	●	●
R-Class	251	ALL	ESA driver-Electric seat adjustment driver (with	●	●	●	●
R-Class	251	ALL	ESA passenger-Electric seat adjustment passenger	●	●	●	●
R-Class	251	ALL	DS-LF-Left front dynamic seat	●	●	●	●
R-Class	251	ALL	DS-RF-Right front dynamic seat	●	●	●	●
R-Class	251	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●



R-Class	251	ALL	REDC-Rear-end door closing control module	●	●	●	●
R-Class	251	ALL	REDC-Rear-end door closing control module	●	●	●	●
R-Class	251	ALL	HS-Seat heater	●	●	●	●
R-Class	251	ALL	AAC-Automatic air conditioning	●	●	●	●
R-Class	251	ALL	STH-Stationary heater with remote control	●	●	●	●
R-Class	251	ALL	HSW-Heated steering wheel	●	●	●	●
S-Class	217	ALL	NSA-Night View Assist	●	●	●	●
S-Class	217	ALL	SG_FOND-Rear control unit	●	●	●	●
S-Class	217	ALL	BMS-Battery management system	●	●	●	●
S-Class	217	ALL	ATA-interior motion sensor	●	●	●	●
S-Class	217	ALL	KG-KEYLESS GO	●	●	●	●
S-Class	217	ALL	SCM-Steering column module	●	●	●	●
S-Class	217	ALL	PSD-Panoramic sliding sunroof	●	●	●	●
S-Class	217	ALL	RevETR_LF-Left front reversible emergency tensioning retractor	●	●	●	●
S-Class	217	ALL	RevETR_RF-Right front reversible emergency tensioning retractor	●	●	●	●
S-Class	217	ALL	AC-Air conditioning	●	●	●	●
S-Class	217	ALL	PTCU-Common powetrain controller	●	●	●	●
S-Class	217	ALL	SG-EM-Power electronics	●	●	●	●
S-Class	217	ALL	FSCU-Fuel pump	●	●	●	●
S-Class	217	ALL	ECM-Engine Control Module	●	●	●	●
S-Class	217	ALL	ISM-Shift module	●	●	●	●
S-Class	217	ALL	ADS-Adaptive damping system	●	●	●	●
S-Class	217	ALL	EFB-Electric parking brake	●	●	●	●
S-Class	217	ALL	ES-Electrical power steering	●	●	●	●
S-Class	217	ALL	ESP-Electronic stability program	●	●	●	●
S-Class	217	ALL	SCR-Selective Catalytic Reduction	●	●	●	●
S-Class	217	ALL	PTS-PARKTRONIC	●	●	●	●
S-Class	217	ALL	RFK-Backup camera	●	●	●	●
S-Class	217	ALL	SGR-Radar sensors control unit	●	●	●	●
S-Class	217	ALL	TPM-Tire pressure monitor	●	●	●	●
S-Class	217	ALL	SG-AWF-COLLISION PREVENTION ASSIST	●	●	●	●
S-Class	217	ALL	KAB-Camera cover	●	●	●	●
S-Class	217	ALL	MFK-Multifunction camera	●	●	●	●
S-Class	217	ALL	DTR-Distronic	●	●	●	●
S-Class	217	ALL	KOMO/mbrace-N112/2(Telematics services communication module)/Notrufsystem	●	●	●	●
S-Class	217	ALL	COU[ZBE]-Audio/COMAND operating unit	●	●	●	●
S-Class	217	ALL	DAB-Digital Audio Broadcasting	●	●	●	●
S-Class	217	ALL	ZAN-Audio/COMAND display	●	●	●	●
S-Class	217	ALL	TV-TV tuner	●	●	●	●
S-Class	217	ALL	TPAD-Touchpad	●	●	●	●
S-Class	220	Up to 08/2002	ETC-Electronic transmission control	●	●	●	●
S-Class	220	Up to 08/2002	ETC-Electronic transmission control	●	●	●	●
S-Class	220	Up to 08/2002	ESM-Electronic selector module	●	●	●	●
S-Class	220	Up to 08/2002	DTR-Distronic	●	●	●	●

S-Class	220	Up to 08/2002	ME-SFI 2.0-Motor electronics 2.0	●	●	●	●
S-Class	220	Up to 08/2002	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
S-Class	220	Up to 08/2002	ME-SFI 2.0-Motor electronics 2.0	●	●	●	●
S-Class	220	Up to 08/2002	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
S-Class	220	Up to 08/2002	ETC-Electronic transmission control	●	●	●	●
S-Class	220	Up to 08/2002	DTR-Distronic	●	●	●	●
S-Class	220	Up to 08/2002	ME-SFI 2.7-Motor electronics 2.7	●	●	●	●
S-Class	220	Up to 08/2002	CDI 2-Common Rail Diesel Injection	●	●	●	●
S-Class	220	Up to 08/2002	CDI-V-Common Rail Diesel Injection	●	●	●	●
S-Class	220	Up to 08/2002	ESP-Electronic stability program	●	●	●	●
S-Class	220	Up to 08/2002	AIRmatic	●	●	●	●
S-Class	220	Up to 08/2002	ABC-ABC active body control	●	●	●	●
S-Class	220	Up to 08/2002	TPM - Tire pressure monitor (N88)	●	●	●	●
S-Class	220	Up to 08/2002	AB-Airbag	●	●	●	●
S-Class	220	Up to 08/2002	EZS-Electronic ignition switch	●	●	●	●
S-Class	220	Up to 08/2002	EZS-Electronic ignition switch	●	●	●	●
S-Class	220	Up to 08/2002	SAM-FL-Front left signal acquisition and actuation module	●	●	●	●
S-Class	220	Up to 08/2002	SAM-FR-Front right signal acquisition and actuation module	●	●	●	●
S-Class	220	Up to 08/2002	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
S-Class	220	Up to 08/2002	AHE-Trailer recognition	●	●	●	●
S-Class	220	Up to 08/2002	OCP-Overhead control panel	●	●	●	●
S-Class	220	Up to 08/2002	PSE-Pneumatic system equipment	●	●	●	●
S-Class	220	Up to 08/2002	UCP-Upper control panel	●	●	●	●
S-Class	220	Up to 08/2002	KG-Keyless Go	●	●	●	●
S-Class	220	Up to 08/2002	MSS-Special vehicle multifunction control module	●	●	●	●
S-Class	220	Up to 08/2002	HRA-Headlamp range adjustment	●	●	●	●
S-Class	220	Up to 08/2002	EZS-Electronic ignition switch	●	●	●	●
S-Class	220	Up to 08/2002	HRA-Headlamp range adjustment	●	●	●	●
S-Class	220	Up to 08/2002	HRA-FR-Front right headlamp range control	●	●	●	●
S-Class	220	Up to 08/2002	HRA-FL-Front left headlamp range control	●	●	●	●
S-Class	220	Up to 08/2002	CGW-Central gateway	●	●	●	●

S-Class	220	Up to 08/2002	AB-Airbag	●	●	●	●
S-Class	220	Up to 08/2002	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
S-Class	220	Up to 08/2002	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
S-Class	220	Up to 08/2002	OCP-Overhead control panel	●	●	●	●
S-Class	220	Up to 08/2002	UCP-Upper control panel	●	●	●	●
S-Class	220	Up to 08/2002	System diagnosis (CAN)	●	●	●	●
S-Class	220	Up to 08/2002	PTS-Parktronic system	●	●	●	●
S-Class	220	Up to 08/2002	SCM [MRM]-Steering column module	●	●	●	●
S-Class	220	Up to 08/2002	TSTH-Radio remote control of stationary heater	●	●	●	●
S-Class	220	Up to 08/2002	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
S-Class	220	Up to 08/2002	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
S-Class	220	Up to 08/2002	COMAND	●	●	●	●
S-Class	220	Up to 08/2002	AUDIO	●	●	●	●
S-Class	220	Up to 08/2002	CDC-CD changer	●	●	●	●
S-Class	220	Up to 08/2002	CTEL- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
S-Class	220	Up to 08/2002	UHI- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
S-Class	220	Up to 08/2002	SOUND- Sound system	●	●	●	●
S-Class	220	Up to 08/2002	VCS-Voice control system	●	●	●	●
S-Class	220	Up to 08/2002	TV-TV tuner	●	●	●	●
S-Class	220	Up to 08/2002	E-call [Japan]-Emergency call system	●	●	●	●
S-Class	220	Up to 08/2002	E-call [Japan]-Telematic system	●	●	●	●
S-Class	220	Up to 08/2002	E-call [USA]-Emergency call system	●	●	●	●
S-Class	220	Up to 08/2002	TELE AID-Emergency call system	●	●	●	●
S-Class	220	Up to 08/2002	E-call [USA]-Telematic system	●	●	●	●
S-Class	220	Up to 08/2002	TELE AID-Telematic system	●	●	●	●
S-Class	220	Up to 08/2002	CTEL over K-wire-Telematic system	●	●	●	●
S-Class	220	Up to 08/2002	DN-Dynamic navigation by means of CTEL	●	●	●	●
S-Class	220	Up to 08/2002	SCM [MRM]-Steering column module	●	●	●	●
S-Class	220	Up to 08/2002	SDAR-Satellite radio	●	●	●	●
S-Class	220	Up to 08/2002	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
S-Class	220	Up to 08/2002	CTEL-Telecommunication for telematics services	●	●	●	●

S-Class	220	Up to 08/2002	Telephone adapter for portable CTCL-Telecommunicationfor telematics services	●	●	●	●
S-Class	220	Up to 08/2002	CTEL-Mobile phone adapter with universal interface	●	●	●	●
S-Class	220	Up to 08/2002	AUDIO	●	●	●	●
S-Class	220	Up to 08/2002	COMAND or AUDIO	●	●	●	●
S-Class	220	Up to 08/2002	NAVI-Navigation system	●	●	●	●
S-Class	220	Up to 08/2002	CDC-CD changer	●	●	●	●
S-Class	220	Up to 08/2002	VCS-Voice control system	●	●	●	●
S-Class	220	Up to 08/2002	SOUND-Bose sound system	●	●	●	●
S-Class	220	Up to 08/2002	TV-TV tuner	●	●	●	●
S-Class	220	Up to 08/2002	TV-TV tuner (AGW)	●	●	●	●
S-Class	220	Up to 08/2002	SDAR-Satellite radio	●	●	●	●
S-Class	220	Up to 08/2002	GPS box	●	●	●	●
S-Class	220	Up to 08/2002	TELE AID-Control unit	●	●	●	●
S-Class	220	Up to 08/2002	TELE AID-Telematic services Emergency call	●	●	●	●
S-Class	220	Up to 08/2002	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
S-Class	220	Up to 08/2002	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
S-Class	220	Up to 08/2002	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
S-Class	220	Up to 08/2002	DCM-FL-Door control module front left	●	●	●	●
S-Class	220	Up to 08/2002	DCM-FR-Door control module front right	●	●	●	●
S-Class	220	Up to 08/2002	DCM-RL-Door control module rear left	●	●	●	●
S-Class	220	Up to 08/2002	DCM-RR-Door control module rear right	●	●	●	●
S-Class	220	Up to 08/2002	ESA-R-Electric seat adjustment rear	●	●	●	●
S-Class	220	Up to 08/2002	ESA-FL-Electric seat adjustment front left	●	●	●	●
S-Class	220	Up to 08/2002	ESA-FR-Electric seat adjustment front right	●	●	●	●
S-Class	220	Up to 08/2002	OSB-R-Multicontour backrest rear	●	●	●	●
S-Class	220	Up to 08/2002	OSB-FL-Multicontour backrest front left	●	●	●	●
S-Class	220	Up to 08/2002	OSB-FR-Multicontour backrest front right	●	●	●	●
S-Class	220	Up to 08/2002	DS-LF-Left front dynamic seat	●	●	●	●
S-Class	220	Up to 08/2002	DS-RF-Right front dynamic seat	●	●	●	●
S-Class	220	Up to 08/2002	DSP-Pneumatic pump for dynamic seat	●	●	●	●

S-Class	220	Up to 08/2002	AAC-Automatic air conditioning	●	●	●	●
S-Class	220	Up to 08/2002	REAR AC- Rear air conditioning	●	●	●	●
S-Class	220	Up to 08/2002	STH-Stationary heater	●	●	●	●
S-Class	220	Up to 08/2002	HSW-Heated steering wheel	●	●	●	●
S-Class	220	Up to 08/2002	STH-Stationary heater	●	●	●	●
S-Class	220	Up to 08/2002	STH-Stationary heater	●	●	●	●
S-Class	220	As of 09/2002	ETC-Electronic transmission control	●	●	●	●
S-Class	220	As of 09/2002	ETC-Electronic transmission control	●	●	●	●
S-Class	220	As of 09/2002	ESM-Electronic selector module	●	●	●	●
S-Class	220	As of 09/2002	DTR-Distronic	●	●	●	●
S-Class	220	As of 09/2002	DTR-Distronic	●	●	●	●
S-Class	220	As of 09/2002	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
S-Class	220	As of 09/2002	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
S-Class	220	As of 09/2002	ME-SFI 2.7.1-Motor electronics 2.7.1	●	●	●	●
S-Class	220	As of 09/2002	CDI 3-Common Rail Diesel Injection3	●	●	●	●
S-Class	220	As of 09/2002	CDI 3-Common Rail Diesel Injection3	●	●	●	●
S-Class	220	As of 09/2002	CDI-V-Common Rail Diesel Injection	●	●	●	●
S-Class	220	As of 09/2002	ESP-Electronic stability program	●	●	●	●
S-Class	220	As of 09/2002	AIRmatic	●	●	●	●
S-Class	220	As of 09/2002	ABC-ABC active body control	●	●	●	●
S-Class	220	As of 09/2002	TPM - Tire pressure monitor (N88)	●	●	●	●
S-Class	220	As of 09/2002	EZS-Electronic ignition switch	●	●	●	●
S-Class	220	As of 09/2002	SAM-FL-Front left signal acquisition and actuationmodule	●	●	●	●
S-Class	220	As of 09/2002	SAM-FR-Front right signal acquisition and actuationmodule	●	●	●	●
S-Class	220	As of 09/2002	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
S-Class	220	As of 09/2002	AHE-Trailer recognition	●	●	●	●
S-Class	220	As of 09/2002	PSE-Pneumatic system equipment	●	●	●	●
S-Class	220	As of 09/2002	KG-Keyless Go	●	●	●	●
S-Class	220	As of 09/2002	MSS-Special vehicle multifunction control module	●	●	●	●
S-Class	220	As of 09/2002	HRA-Headlamp range adjustment	●	●	●	●
S-Class	220	As of 09/2002	HRA-FR-Front right headlamp range control	●	●	●	●

S-Class	220	As of 09/2002	HRA-FL-Front left headlamp range control	●	●	●	●
S-Class	220	As of 09/2002	CGW-Central gateway	●	●	●	●
S-Class	220	As of 09/2002	AB-Airbag	●	●	●	●
S-Class	220	As of 09/2002	RevETR-LF-Left front reversible emergency tensioningretractor	●	●	●	●
S-Class	220	As of 09/2002	RevETR-RF-Right front reversible emergency tensioningretractor	●	●	●	●
S-Class	220	As of 09/2002	OCP-Overhead control panel	●	●	●	●
S-Class	220	As of 09/2002	UCP-Upper control panel	●	●	●	●
S-Class	220	As of 09/2002	System diagnosis (CAN)	●	●	●	●
S-Class	220	As of 09/2002	PTS-Parktronic system	●	●	●	●
S-Class	220	As of 09/2002	SCM [MRM]-Steering column module	●	●	●	●
S-Class	220	As of 09/2002	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
S-Class	220	As of 09/2002	COMAND	●	●	●	●
S-Class	220	As of 09/2002	AUDIO	●	●	●	●
S-Class	220	As of 09/2002	CDC-CD changer	●	●	●	●
S-Class	220	As of 09/2002	CTEL- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
S-Class	220	As of 09/2002	UHI- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
S-Class	220	As of 09/2002	SOUND- Sound system	●	●	●	●
S-Class	220	As of 09/2002	VCS-Voice control system	●	●	●	●
S-Class	220	As of 09/2002	SDAR-Satellite radio	●	●	●	●
S-Class	220	As of 09/2002	TV-TV tuner	●	●	●	●
S-Class	220	As of 09/2002	E-call [Japan]-Telematic system	●	●	●	●
S-Class	220	As of 09/2002	E-call [USA]-Telematic system	●	●	●	●
S-Class	220	As of 09/2002	TELE AID-Telematic system	●	●	●	●
S-Class	220	As of 09/2002	CTEL over K-wire-Telematic system	●	●	●	●
S-Class	220	As of 09/2002	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
S-Class	220	As of 09/2002	CTEL-Telecommunication for telematics services	●	●	●	●
S-Class	220	As of 09/2002	Telephone adapter for portable CTEL-Telecommunicationfor telematics services	●	●	●	●
S-Class	220	As of 09/2002	CTEL-Mobile phone adapter with universal interface	●	●	●	●
S-Class	220	As of 09/2002	AUDIO	●	●	●	●
S-Class	220	As of 09/2002	COMAND or AUDIO	●	●	●	●

S-Class	220	As of 09/2002	NAVI-Navigation system	●	●	●	●
S-Class	220	As of 09/2002	CDC-CD changer	●	●	●	●
S-Class	220	As of 09/2002	VCS-Voice control system	●	●	●	●
S-Class	220	As of 09/2002	SOUND-Bose sound system	●	●	●	●
S-Class	220	As of 09/2002	TV-TV tuner	●	●	●	●
S-Class	220	As of 09/2002	TV-TV tuner (AGW)	●	●	●	●
S-Class	220	As of 09/2002	SDAR-Satellite radio	●	●	●	●
S-Class	220	As of 09/2002	GPS box	●	●	●	●
S-Class	220	As of 09/2002	TELE AID-Control unit	●	●	●	●
S-Class	220	As of 09/2002	TELE AID-Telematic services Emergency call	●	●	●	●
S-Class	220	As of 09/2002	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
S-Class	220	As of 09/2002	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
S-Class	220	As of 09/2002	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
S-Class	220	As of 09/2002	DCM-FL-Door control module front left	●	●	●	●
S-Class	220	As of 09/2002	DCM-FR-Door control module front right	●	●	●	●
S-Class	220	As of 09/2002	DCM-RL-Door control module rear left	●	●	●	●
S-Class	220	As of 09/2002	DCM-RR-Door control module rear right	●	●	●	●
S-Class	220	As of 09/2002	ESA-R-Electric seat adjustment rear	●	●	●	●
S-Class	220	As of 09/2002	ESA-FL-Electric seat adjustment front left	●	●	●	●
S-Class	220	As of 09/2002	ESA-FR-Electric seat adjustment front right	●	●	●	●
S-Class	220	As of 09/2002	OSB-R-Multicontour backrest rear	●	●	●	●
S-Class	220	As of 09/2002	OSB-FL-Multicontour backrest front left	●	●	●	●
S-Class	220	As of 09/2002	OSB-FR-Multicontour backrest front right	●	●	●	●
S-Class	220	As of 09/2002	DS-LF-Left front dynamic seat	●	●	●	●
S-Class	220	As of 09/2002	DS-RF-Right front dynamic seat	●	●	●	●
S-Class	220	As of 09/2002	DSP-Pneumatic pump for dynamic seat	●	●	●	●
S-Class	220	As of 09/2002	AAC-Automatic air conditioning	●	●	●	●
S-Class	220	As of 09/2002	REAR AC- Rear air conditioning	●	●	●	●
S-Class	220	As of 09/2002	HSW-Heated steering wheel	●	●	●	●
S-Class	220	As of 09/2002	STH-Stationary heater	●	●	●	●
S-Class	221	Up to 06/2009	ISM-Intelligent servo module	●	●	●	●

S-Class	221	Up to 06/2009	ISM-Shift module (A80)	●	●	●	●
S-Class	221	Up to 06/2009	ETC-Electronic transmission control	●	●	●	●
S-Class	221	Up to 06/2009	ETC-Electronic transmission control	●	●	●	●
S-Class	221	Up to 06/2009	ETC-Electronic transmission control	●	●	●	●
S-Class	221	Up to 06/2009	ME 9.7-Motor electronics 9.7	●	●	●	●
S-Class	221	Up to 06/2009	FSCU-Fuel pump	●	●	●	●
S-Class	221	Up to 06/2009	FSCU-Fuel pump	●	●	●	●
S-Class	221	Up to 06/2009	FSCU-Fuel pump	●	●	●	●
S-Class	221	Up to 06/2009	DTR-Distronic	●	●	●	●
S-Class	221	Up to 06/2009	SGR-Radar sensors control unit	●	●	●	●
S-Class	221	Up to 06/2009	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
S-Class	221	Up to 06/2009	FSCU-Fuel pump AMG	●	●	●	●
S-Class	221	Up to 06/2009	FSCU-Fuel pump	●	●	●	●
S-Class	221	Up to 06/2009	CDI 5-Common Rail Diesel Injection	●	●	●	●
S-Class	221	Up to 06/2009	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
S-Class	221	Up to 06/2009	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
S-Class	221	Up to 06/2009	ABR-Adaptive Brake	●	●	●	●
S-Class	221	Up to 06/2009	AIRmatic	●	●	●	●
S-Class	221	Up to 06/2009	ABC-ABC active body control	●	●	●	●
S-Class	221	Up to 06/2009	Electronic parking brake-Electric parking brake	●	●	●	●
S-Class	221	Up to 06/2009	TPC-Tire pressure monitor	●	●	●	●
S-Class	221	Up to 06/2009	CGW-Central gateway	●	●	●	●
S-Class	221	Up to 06/2009	EZS-Electronic ignition switch	●	●	●	●
S-Class	221	Up to 06/2009	EZS-Electronic ignition switch	●	●	●	●
S-Class	221	Up to 06/2009	KG-Keyless Go	●	●	●	●
S-Class	221	Up to 06/2009	KG-KEYLESS GO	●	●	●	●
S-Class	221	Up to 06/2009	MSS-Special vehicle multifunction control module	●	●	●	●
S-Class	221	Up to 06/2009	AB-Airbag	●	●	●	●
S-Class	221	Up to 06/2009	WSS-Weight sensing system	●	●	●	●
S-Class	221	Up to 06/2009	WSS-Weight sensing system	●	●	●	●
S-Class	221	Up to 06/2009	OCP-Overhead control panel	●	●	●	●



S-Class	221	Up to 06/2009	UCP-Upper control panel	●	●	●	●
S-Class	221	Up to 06/2009	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
S-Class	221	Up to 06/2009	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
S-Class	221	Up to 06/2009	BNS-Vehicle power supply control module	●	●	●	●
S-Class	221	Up to 06/2009	AHE-Trailer recognition	●	●	●	●
S-Class	221	Up to 06/2009	PSD-Panoramic sliding roof (Interior CAN bus)	●	●	●	●
S-Class	221	Up to 06/2009	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●
S-Class	221	Up to 06/2009	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●
S-Class	221	Up to 06/2009	XALWA-L-Xenon headlamp, left	●	●	●	●
S-Class	221	Up to 06/2009	XALWA-L-Xenon headlamp, left	●	●	●	●
S-Class	221	Up to 06/2009	XALWA-R-Xenon headlamp, right	●	●	●	●
S-Class	221	Up to 06/2009	XALWA-R-Xenon headlamp, right	●	●	●	●
S-Class	221	Up to 06/2009	System diagnosis (CAN)	●	●	●	●
S-Class	221	Up to 06/2009	COU [ZBE]-Central operating unit	●	●	●	●
S-Class	221	Up to 06/2009	HBF (Rear control panel)-Rear control field	●	●	●	●
S-Class	221	Up to 06/2009	NSA-Night View Assist	●	●	●	●
S-Class	221	Up to 06/2009	SCM [MRM]-Steering column module	●	●	●	●
S-Class	221	Up to 06/2009	IC-Instrument cluster	●	●	●	●
S-Class	221	Up to 06/2009	ASSYST-Active Service System	●	●	●	●
S-Class	221	Up to 06/2009	ASSYST PLUS	●	●	●	●
S-Class	221	Up to 06/2009	PTS-Parktronic	●	●	●	●
S-Class	221	Up to 06/2009	RFK-Backup camera (B84/3)	●	●	●	●
S-Class	221	Up to 06/2009	COMAND	●	●	●	●
S-Class	221	Up to 06/2009	COMAND	●	●	●	●
S-Class	221	Up to 06/2009	Tuner-Standard tuner	●	●	●	●
S-Class	221	Up to 06/2009	Tuner-Tuner sound	●	●	●	●
S-Class	221	Up to 06/2009	Tuner-Tuner sound	●	●	●	●
S-Class	221	Up to 06/2009	VCS-Voice control	●	●	●	●
S-Class	221	Up to 06/2009	CTEL-Mobile phone adapter with universal interface	●	●	●	●
S-Class	221	Up to 06/2009	TV-TV tuner (AGW)	●	●	●	●
S-Class	221	Up to 06/2009	SDAR-Satellite radio (Valid for USA)	●	●	●	●

S-Class	221	Up to 06/2009	DAB-Digital radio	●	●	●	●
S-Class	221	Up to 06/2009	ZAN-Central display	●	●	●	●
S-Class	221	Up to 06/2009	AVE-H-Rear audio video unit	●	●	●	●
S-Class	221	Up to 06/2009	UCI-Media interface	●	●	●	●
S-Class	221	Up to 06/2009	AVE-H-Rear audio video unit	●	●	●	●
S-Class	221	Up to 06/2009	Left rear screen	●	●	●	●
S-Class	221	Up to 06/2009	Right rear screen	●	●	●	●
S-Class	221	Up to 06/2009	TELE AID-Control unit	●	●	●	●
S-Class	221	Up to 06/2009	TELE AID-Telematic services Emergency call	●	●	●	●
S-Class	221	Up to 06/2009	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
S-Class	221	Up to 06/2009	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
S-Class	221	Up to 06/2009	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
S-Class	221	Up to 06/2009	DS-LF-Left front dynamic seat	●	●	●	●
S-Class	221	Up to 06/2009	DS-RF-Right front dynamic seat	●	●	●	●
S-Class	221	Up to 06/2009	MKL-HL-Rear left multicontour backrest	●	●	●	●
S-Class	221	Up to 06/2009	MKL-HR-Rear right multicontour backrest	●	●	●	●
S-Class	221	Up to 06/2009	DSP-Pneumatic pump for dynamic seat	●	●	●	●
S-Class	221	Up to 06/2009	DCM-FL-Door control module front left	●	●	●	●
S-Class	221	Up to 06/2009	DCM-FR-Door control module front right	●	●	●	●
S-Class	221	Up to 06/2009	DCM-RL-Door control module rear left	●	●	●	●
S-Class	221	Up to 06/2009	DCM-RR-Door control module rear right	●	●	●	●
S-Class	221	Up to 06/2009	ESA-FL-Electric seat adjustment front left	●	●	●	●
S-Class	221	Up to 06/2009	ESA-FR-Electric seat adjustment front right	●	●	●	●
S-Class	221	Up to 06/2009	ESA-R-Electric seat adjustment rear	●	●	●	●
S-Class	221	Up to 06/2009	TLC-Trunk lid control	●	●	●	●
S-Class	221	Up to 06/2009	TLC-Trunk lid control	●	●	●	●
S-Class	221	Up to 06/2009	TSG-ML-Left center door control unit (interior Can	●	●	●	●
S-Class	221	Up to 06/2009	TSG-MR-Right center door control unit (interior Can	●	●	●	●
S-Class	221	Up to 06/2009	AAC-Automatic air conditioning	●	●	●	●
S-Class	221	Up to 06/2009	STH-Stationary heater with remote control	●	●	●	●
S-Class	221	Up to 06/2009	KBE-H-Rear A/C operating unit	●	●	●	●

S-Class	221	As of 07/2009	ISM-Shift module (A80)	●	●	●	●
S-Class	221	As of 07/2009	ETC-Electronic transmission control	●	●	●	●
S-Class	221	As of 07/2009	ETC-Electronic transmission control	●	●	●	●
S-Class	221	As of 07/2009	ME 9.7-Motor electronics 9.7	●	●	●	●
S-Class	221	As of 07/2009	FSCU-Fuel pump	●	●	●	●
S-Class	221	As of 07/2009	FSCU-Fuel pump	●	●	●	●
S-Class	221	As of 07/2009	FSCU-Fuel pump	●	●	●	●
S-Class	221	As of 07/2009	DTR-Distronic	●	●	●	●
S-Class	221	As of 07/2009	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
S-Class	221	As of 07/2009	ME-SF 17.7-Motor electronics 17.7	●	●	●	●
S-Class	221	As of 07/2009	SG-EM - Electric motor control unit	●	●	●	●
S-Class	221	As of 07/2009	FSCU-Fuel pump	●	●	●	●
S-Class	221	As of 07/2009	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
S-Class	221	As of 07/2009	FSCU-Fuel pump AMG	●	●	●	●
S-Class	221	As of 07/2009	CDI 3-Common Rail Diesel Injection3	●	●	●	●
S-Class	221	As of 07/2009	CDI 5-Common Rail Diesel Injection	●	●	●	●
S-Class	221	As of 07/2009	CDI 60LS-Common Rail Diesel Injection	●	●	●	●
S-Class	221	As of 07/2009	SCR-Selective Catalytic Reduction	●	●	●	●
S-Class	221	As of 07/2009	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
S-Class	221	As of 07/2009	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
S-Class	221	As of 07/2009	ABR-Adaptive Brake	●	●	●	●
S-Class	221	As of 07/2009	ABR-Adaptive Brake	●	●	●	●
S-Class	221	As of 07/2009	AIRmatic	●	●	●	●
S-Class	221	As of 07/2009	ABC-ABC active body control	●	●	●	●
S-Class	221	As of 07/2009	Electronic parking brake-Electric parking brake	●	●	●	●
S-Class	221	As of 07/2009	TPM - Tire pressure monitor (N88)	●	●	●	●
S-Class	221	As of 07/2009	EHPS-Electrohydraulic Power Steering	●	●	●	●
S-Class	221	As of 07/2009	RBS-Brake system	●	●	●	●
S-Class	221	As of 07/2009	CGW-Central gateway	●	●	●	●
S-Class	221	As of 07/2009	EZS-Electronic ignition switch	●	●	●	●
S-Class	221	As of 07/2009	KG-Keyless Go	●	●	●	●

S-Class	221	As of 07/2009	KG-KEYLESS GO	●	●	●	●
S-Class	221	As of 07/2009	MSS-Special vehicle multifunction control module	●	●	●	●
S-Class	221	As of 07/2009	AB-Airbag	●	●	●	●
S-Class	221	As of 07/2009	SGR-Radar sensors control unit	●	●	●	●
S-Class	221	As of 07/2009	SGR-Radar sensors control unit	●	●	●	●
S-Class	221	As of 07/2009	WSS-Weight sensing system	●	●	●	●
S-Class	221	As of 07/2009	OCP-Overhead control panel	●	●	●	●
S-Class	221	As of 07/2009	UCP-Upper control panel	●	●	●	●
S-Class	221	As of 07/2009	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
S-Class	221	As of 07/2009	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
S-Class	221	As of 07/2009	Trailer recognition module	●	●	●	●
S-Class	221	As of 07/2009	PSD-Panoramic sliding roof(Interior CAN bus)	●	●	●	●
S-Class	221	As of 07/2009	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●
S-Class	221	As of 07/2009	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●
S-Class	221	As of 07/2009	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●
S-Class	221	As of 07/2009	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●
S-Class	221	As of 07/2009	XALWA-L-Xenon headlamp, left	●	●	●	●
S-Class	221	As of 07/2009	XALWA-L-Xenon headlamp, left	●	●	●	●
S-Class	221	As of 07/2009	XALWA-R-Xenon headlamp, right	●	●	●	●
S-Class	221	As of 07/2009	XALWA-R-Xenon headlamp, right	●	●	●	●
S-Class	221	As of 07/2009	System diagnosis (CAN)	●	●	●	●
S-Class	221	As of 07/2009	COU [ZBE]-Central operating unit	●	●	●	●
S-Class	221	As of 07/2009	HBf (Rear control panel)-Rear control field	●	●	●	●
S-Class	221	As of 07/2009	SG-BMS - Battery management system control unit	●	●	●	●
S-Class	221	As of 07/2009	SG-DDW - DC/DC converter control unit	●	●	●	●
S-Class	221	As of 07/2009	BNS-Vehicle power supply control module	●	●	●	●
S-Class	221	As of 07/2009	NSA-Night View Assist	●	●	●	●
S-Class	221	As of 07/2009	MFK-Multifunction camera	●	●	●	●
S-Class	221	As of 07/2009	SCM [MRM]-Steering column module	●	●	●	●
S-Class	221	As of 07/2009	IC-Instrument cluster	●	●	●	●
S-Class	221	As of 07/2009	ASSYST-Active Service System	●	●	●	●

S-Class	221	As of 07/2009	ASSYST PLUS	●	●	●	●
S-Class	221	As of 07/2009	PTS-PARKTRONIC (N62)	●	●	●	●
S-Class	221	As of 07/2009	RFK-Backup camera (B84/3)	●	●	●	●
S-Class	221	As of 07/2009	COMAND	●	●	●	●
S-Class	221	As of 07/2009	COMAND	●	●	●	●
S-Class	221	As of 07/2009	Sound system (Main amplifier)	●	●	●	●
S-Class	221	As of 07/2009	Sound system (Bass amplifier)	●	●	●	●
S-Class	221	As of 07/2009	Tuner-Standard tuner	●	●	●	●
S-Class	221	As of 07/2009	Tuner-Tuner sound	●	●	●	●
S-Class	221	As of 07/2009	Tuner-Tuner sound	●	●	●	●
S-Class	221	As of 07/2009	VCS-Voice control	●	●	●	●
S-Class	221	As of 07/2009	CTEL-Mobile phone adapter with universal interface	●	●	●	●
S-Class	221	As of 07/2009	TV-TV tuner (AGW)	●	●	●	●
S-Class	221	As of 07/2009	SDAR-Satellite radio (Valid for USA)	●	●	●	●
S-Class	221	As of 07/2009	DAB-Digital radio	●	●	●	●
S-Class	221	As of 07/2009	ZAN-Central display	●	●	●	●
S-Class	221	As of 07/2009	AVE-H-Rear audio video unit	●	●	●	●
S-Class	221	As of 07/2009	UCI-Media interface	●	●	●	●
S-Class	221	As of 07/2009	AVE-H-Rear audio video unit	●	●	●	●
S-Class	221	As of 07/2009	Left rear screen	●	●	●	●
S-Class	221	As of 07/2009	Right rear screen	●	●	●	●
S-Class	221	As of 07/2009	TELE AID-Control unit	●	●	●	●
S-Class	221	As of 07/2009	TELE AID-Telematic services Emergency call	●	●	●	●
S-Class	221	As of 07/2009	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
S-Class	221	As of 07/2009	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
S-Class	221	As of 07/2009	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
S-Class	221	As of 07/2009	ICI-InCar Internet (N125/3)	●	●	●	●
S-Class	221	As of 07/2009	DS-LF-Left front dynamic seat	●	●	●	●
S-Class	221	As of 07/2009	DS-RF-Right front dynamic seat	●	●	●	●
S-Class	221	As of 07/2009	MKL-HL-Rear left multicontour backrest	●	●	●	●
S-Class	221	As of 07/2009	MKL-HR-Rear right multicontour backrest	●	●	●	●

S-Class	221	As of 07/2009	DSP-Pneumatic pump for dynamic seat	●	●	●	●
S-Class	221	As of 07/2009	DCM-FL-Door control module front left	●	●	●	●
S-Class	221	As of 07/2009	DCM-FR-Door control module front right	●	●	●	●
S-Class	221	As of 07/2009	DCM-RL-Door control module rear left	●	●	●	●
S-Class	221	As of 07/2009	DCM-RR-Door control module rear right	●	●	●	●
S-Class	221	As of 07/2009	ESA-FL-Electric seat adjustment front left	●	●	●	●
S-Class	221	As of 07/2009	ESA-FR-Electric seat adjustment front right	●	●	●	●
S-Class	221	As of 07/2009	ESA-R-Electric seat adjustment rear	●	●	●	●
S-Class	221	As of 07/2009	TLC-Trunk lid control	●	●	●	●
S-Class	221	As of 07/2009	TSG-ML-Left center door control unit (interior Can	●	●	●	●
S-Class	221	As of 07/2009	TSG-MR-Right center door control unit (interior Can	●	●	●	●
S-Class	221	As of 07/2009	AAC-Automatic air conditioning	●	●	●	●
S-Class	221	As of 07/2009	STH-Stationary heater with remote control	●	●	●	●
S-Class	221	As of 07/2009	KBE-H-Rear A/C operating unit	●	●	●	●
S-Class	222	All	ECM-Engine Control Module	●	●	●	●
S-Class	222	All	PTCU-Common powetrain controller	●	●	●	●
S-Class	222	All	TCM-Transmission Control Module	●	●	●	●
S-Class	222	All	ESP-Electronic stability program	●	●	●	●
S-Class	222	All	AGS-Active belt buckle	●	●	●	●
S-Class	222	All	BMS-Battery management system	●	●	●	●
S-Class	222	All	DC/DC-DC/DC converter	●	●	●	●
S-Class	222	All	SG-SW_L-Left headlamp	●	●	●	●
S-Class	222	All	SG-SW_R-Right headlamp	●	●	●	●
S-Class	222	All	Audio-Audio or COMAND	●	●	●	●
S-Class	222	All	AVE-H-Controller unit 'Rear entertainment system'	●	●	●	●
S-Class	222	All	COU[ZBE]-Audio/COMAND operating unit	●	●	●	●
S-Class	222	All	DAB-Digital Audio Broadcasting	●	●	●	●
S-Class	222	All	D_FOL-Display in left rear passenger compartment	●	●	●	●
S-Class	222	All	D_FOR-Display in right rear passenger compartmentDF	●	●	●	●
S-Class	222	All	Head-up display -head-up display	●	●	●	●
S-Class	222	All	KOMO/mbrace-Communication module' Telematics services'/Emergency call system	●	●	●	●
S-Class	222	All	SOUND-Sound system	●	●	●	●
S-Class	222	All	TPAD-Touchpad	●	●	●	●
S-Class	222	All	TV-TV tuner	●	●	●	●
S-Class	222	All	ZAN-Audio/COMAND display	●	●	●	●
S-Class	222	All	STH-Stationary heater	●	●	●	●
S-Class	222	All	MKS_LF-Left front multicontour seat	●	●	●	●
S-Class	222	All	MKS_LR-Left rear multicontour seat	●	●	●	●
S-Class	222	All	MKS_RF-Right front multicontour seat	●	●	●	●

S-Class	222	A11	MKS_RR-Right rear multicontour seat	●	●	●	●
S-Class	222	A11	Driver-side SAM-Front signal acquisition and actuation module	●	●	●	●
S-Class	222	A11	360 degree camera-360 degree camera	●	●	●	●
S-Class	222	A11	FSCU-Fuel pump	●	●	●	●
S-Class	222	A11	HKS-Tailgate control	●	●	●	●
S-Class	222	A11	PPMKS-Pneumatic pump for multicontour seat	●	●	●	●
S-Class	222	A11	PSD-Panoramic sliding sunroof	●	●	●	●
S-Class	222	A11	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
S-Class	222	A11	RevETR_LF-Left front reversible emergency tensioning retractor	●	●	●	●
S-Class	222	A11	RevETR_RF-Right front reversible emergency tensioning retractor	●	●	●	●
S-Class	222	A11	SCR-Selective Catalytic Reduction	●	●	●	●
S-Class	222	A11	SG-SOGE-E-Sound generator for electric vehicle	●	●	●	●
S-Class	222	A11	SG-LG-Charger	●	●	●	●
S-Class	222	A11	SGR-Radar sensors control unit	●	●	●	●
S-Class	222	A11	SCM-Steering column module	●	●	●	●
S-Class	222	A11	Trailer recognition module-Trailer recognition(N28/1)	●	●	●	●
S-Class	222	A11	FLANFS-Fire extinguishing system and emergency fresh air system	●	●	●	●
S-Class	222	A11	SRS-Supplemental restraint system(N2/10)	●	●	●	●
S-Class	222	A11	TPM-Tire pressure monitor	●	●	●	●
S-Class	222	A11	PTS-PARKTRONIC	●	●	●	●
S-Class	222	A11	AC-Air conditioning	●	●	●	●
SL	230	Up to 08/2003	ETC-Electronic transmission control	●	●	●	●
SL	230	Up to 08/2003	SEQ-Sequentronic automated manual transmission	●	●	●	●
SL	230	Up to 08/2003	ETC-Electronic transmission control	●	●	●	●
SL	230	Up to 08/2003	ESM-Electronic selector module	●	●	●	●
SL	230	Up to 08/2003	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
SL	230	Up to 08/2003	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
SL	230	Up to 08/2003	DTR-Distronic	●	●	●	●
SL	230	Up to 08/2003	SBC-Sensotronic Brake Control	●	●	●	●
SL	230	Up to 08/2003	ESP-Electronic stability program	●	●	●	●
SL	230	Up to 08/2003	ABC-ABC active body control	●	●	●	●
SL	230	Up to 08/2003	TPM - Tire pressure monitor(N88)	●	●	●	●
SL	230	Up to 08/2003	System diagnosis (CAN)	●	●	●	●
SL	230	Up to 08/2003	AB-Airbag	●	●	●	●
SL	230	Up to 08/2003	AB-Airbag	●	●	●	●
SL	230	Up to 08/2003	EZS-Electronic ignition switch	●	●	●	●

SL	230	Up to 08/2003	OCP-Overhead control panel	●	●	●	●
SL	230	Up to 08/2003	LCP-Lower control panel	●	●	●	●
SL	230	Up to 08/2003	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●
SL	230	Up to 08/2003	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
SL	230	Up to 08/2003	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
SL	230	Up to 08/2003	BNS-Vehicle power supply control module	●	●	●	●
SL	230	Up to 08/2003	RVC-Rollover bar/vario roof control module	●	●	●	●
SL	230	Up to 08/2003	PSE-Pneumatic system equipment	●	●	●	●
SL	230	Up to 08/2003	KG-Keyless Go	●	●	●	●
SL	230	Up to 08/2003	HRA-FR-Front right headlamp range control	●	●	●	●
SL	230	Up to 08/2003	HRA-FL-Front left headlamp range control	●	●	●	●
SL	230	Up to 08/2003	PTS-Parktronic system	●	●	●	●
SL	230	Up to 08/2003	SCM [MRM]-Steering column module	●	●	●	●
SL	230	Up to 08/2003	ICM-Instrument cluster with maintenance interval display	●	●	●	●
SL	230	Up to 08/2003	TV-TV tuner	●	●	●	●
SL	230	Up to 08/2003	E-call [Japan]-Telematic system	●	●	●	●
SL	230	Up to 08/2003	E-call [USA]-Telematic system	●	●	●	●
SL	230	Up to 08/2003	TELE AID-Telematic system	●	●	●	●
SL	230	Up to 08/2003	CTEL over K-wire-Telematic system	●	●	●	●
SL	230	Up to 08/2003	COMAND	●	●	●	●
SL	230	Up to 08/2003	D2B-COMAND, MCS or AUDIO	●	●	●	●
SL	230	Up to 08/2003	AUDIO	●	●	●	●
SL	230	Up to 08/2003	CDC-CD changer	●	●	●	●
SL	230	Up to 08/2003	VCS-Voice control system	●	●	●	●
SL	230	Up to 08/2003	SOUND- Sound system	●	●	●	●
SL	230	Up to 08/2003	SDAR-Satellite radio	●	●	●	●
SL	230	Up to 08/2003	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●
SL	230	Up to 08/2003	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●
SL	230	Up to 08/2003	DCM-L-Door control module left	●	●	●	●
SL	230	Up to 08/2003	DCM-R-Door control module right	●	●	●	●
SL	230	Up to 08/2003	ESA-FL-Electric seat adjustment front left	●	●	●	●



SL	230	Up to 08/2003	ESA-FR-Electric seat adjustment front right	●	●	●	●
SL	230	Up to 08/2003	OSB-FL-Multicontour backrest front left	●	●	●	●
SL	230	Up to 08/2003	OSB-FR-Multicontour backrest front right	●	●	●	●
SL	230	Up to 08/2003	AAC-Automatic air conditioning	●	●	●	●
SL	230	Up to 08/2003	STH-Stationary heater	●	●	●	●
SL	230	Up to 08/2003	HSW-Heated steering wheel	●	●	●	●
SL	230	From 09/2003 to 05/2006	ETC-Electronic transmission control	●	●	●	●
SL	230	From 09/2003 to 05/2006	ETC-Electronic transmission control	●	●	●	●
SL	230	From 09/2003 to 05/2006	SEQ-Sequentronic automated manual transmission	●	●	●	●
SL	230	From 09/2003 to 05/2006	ETC-Electronic transmission control	●	●	●	●
SL	230	From 09/2003 to 05/2006	ESM-Electronic selector module	●	●	●	●
SL	230	From 09/2003 to 05/2006	DTR-Distronic	●	●	●	●
SL	230	From 09/2003 to 05/2006	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
SL	230	From 09/2003 to 05/2006	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
SL	230	From 09/2003 to 05/2006	DTR-Distronic	●	●	●	●
SL	230	From 09/2003 to 05/2006	ME 9.7-Motor electronics 9.7	●	●	●	●
SL	230	From 09/2003 to 05/2006	ME-SFI 2.7.1-Motor electronics 2.7.1	●	●	●	●
SL	230	From 09/2003 to 05/2006	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
SL	230	From 09/2003 to 05/2006	SBC-Sensotronic Brake Control	●	●	●	●
SL	230	From 09/2003 to 05/2006	SBC-Sensotronic Brake Control	●	●	●	●
SL	230	From 09/2003 to 05/2006	ESP-Electronic stability program	●	●	●	●
SL	230	From 09/2003 to 05/2006	ESP-Electronic stability program	●	●	●	●
SL	230	From 09/2003 to 05/2006	ABC-ABC active body control	●	●	●	●
SL	230	From 09/2003 to 05/2006	ABC-ABC active body control	●	●	●	●
SL	230	From 09/2003 to 05/2006	TPM - Tire pressure monitor (N88)	●	●	●	●
SL	230	From 09/2003 to 05/2006	TPC-Tire pressure monitor	●	●	●	●
SL	230	From 09/2003 to 05/2006	CGW-Central gateway	●	●	●	●
SL	230	From 09/2003 to 05/2006	EZS-Electronic ignition switch	●	●	●	●
SL	230	From 09/2003 to 05/2006	System diagnosis (CAN)	●	●	●	●
SL	230	From 09/2003 to 05/2006	AB-Airbag	●	●	●	●
SL	230	From 09/2003 to 05/2006	WSS-Weight sensing system	●	●	●	●

SL	230	From 09/2003 to05/2006	OCP-Overhead control panel	●	●	●	●
SL	230	From 09/2003 to05/2006	LCP-Lower control panel	●	●	●	●
SL	230	From 09/2003 to05/2006	Dr-side SAM-Driver signal acquisition and actuationmodule	●	●	●	●
SL	230	From 09/2003 to05/2006	Pass-side SAM-Passenger-side signal acquisition andactuation module	●	●	●	●
SL	230	From 09/2003 to05/2006	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
SL	230	From 09/2003 to05/2006	BNS-Vehicle power supply control module	●	●	●	●
SL	230	From 09/2003 to05/2006	RVC-Rollover bar/vario roof control module	●	●	●	●
SL	230	From 09/2003 to05/2006	RVC-Rollover bar/vario roof control module	●	●	●	●
SL	230	From 09/2003 to05/2006	PSE-Pneumatic system equipment	●	●	●	●
SL	230	From 09/2003 to05/2006	KG-Keyless Go	●	●	●	●
SL	230	From 09/2003 to05/2006	KG-Keyless Go	●	●	●	●
SL	230	From 09/2003 to05/2006	HRA-FR-Front right headlamp range control	●	●	●	●
SL	230	From 09/2003 to05/2006	HRA-FL-Front left headlamp range control	●	●	●	●
SL	230	From 09/2003 to05/2006	System diagnosis (CAN)	●	●	●	●
SL	230	From 09/2003 to05/2006	PTS-Parktronic system	●	●	●	●
SL	230	From 09/2003 to05/2006	SCM [MRM]-Steering column module	●	●	●	●
SL	230	From 09/2003 to05/2006	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
SL	230	From 09/2003 to05/2006	TV-TV tuner	●	●	●	●
SL	230	From 09/2003 to05/2006	E-call [Japan]-Telematic system	●	●	●	●
SL	230	From 09/2003 to05/2006	E-call [USA]-Telematic system	●	●	●	●
SL	230	From 09/2003 to05/2006	TELE AID-Telematic system	●	●	●	●
SL	230	From 09/2003 to05/2006	CTEL over K-wire-Telematic system	●	●	●	●
SL	230	From 09/2003 to05/2006	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
SL	230	From 09/2003 to05/2006	CTEL-Telecommunication for telematics services	●	●	●	●
SL	230	From 09/2003 to05/2006	Telephone adapter for portable CTEL-Telecommunicationfor telematics services	●	●	●	●
SL	230	From 09/2003 to05/2006	CTEL-Mobile phone adapter with universal interface	●	●	●	●
SL	230	From 09/2003 to05/2006	AUDIO	●	●	●	●
SL	230	From 09/2003 to05/2006	NAVI-Navigation system	●	●	●	●
SL	230	From 09/2003 to05/2006	CDC-CD changer	●	●	●	●

SL	230	From 09/2003 to05/2006	VCS-Voice control system	●	●	●	●
SL	230	From 09/2003 to05/2006	SOUND-Bose sound system	●	●	●	●
SL	230	From 09/2003 to05/2006	TV-TV tuner	●	●	●	●
SL	230	From 09/2003 to05/2006	TV-TV tuner (AGW)	●	●	●	●
SL	230	From 09/2003 to05/2006	SDAR-Satellite radio	●	●	●	●
SL	230	From 09/2003 to05/2006	TELE AID-Control unit	●	●	●	●
SL	230	From 09/2003 to05/2006	TELE AID-Telematic services Emergency call	●	●	●	●
SL	230	From 09/2003 to05/2006	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
SL	230	From 09/2003 to05/2006	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
SL	230	From 09/2003 to05/2006	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
SL	230	From 09/2003 to05/2006	COMAND	●	●	●	●
SL	230	From 09/2003 to05/2006	D2B-COMAND, MCS or AUDIO	●	●	●	●
SL	230	From 09/2003 to05/2006	AUDIO	●	●	●	●
SL	230	From 09/2003 to05/2006	CDC-CD changer	●	●	●	●
SL	230	From 09/2003 to05/2006	VCS-Voice control system	●	●	●	●
SL	230	From 09/2003 to05/2006	SOUND- Sound system	●	●	●	●
SL	230	From 09/2003 to05/2006	SDAR-Satellite radio	●	●	●	●
SL	230	From 09/2003 to05/2006	CTEL- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
SL	230	From 09/2003 to05/2006	UHI- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
SL	230	From 09/2003 to05/2006	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
SL	230	From 09/2003 to05/2006	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
SL	230	From 09/2003 to05/2006	DCM-L-Door control module left	●	●	●	●
SL	230	From 09/2003 to05/2006	DCM-R-Door control module right	●	●	●	●
SL	230	From 09/2003 to05/2006	ESA-FL-Electric seat adjustment front left	●	●	●	●
SL	230	From 09/2003 to05/2006	ESA-FR-Electric seat adjustment front right	●	●	●	●
SL	230	From 09/2003 to05/2006	OSB-FL-Multicontour backrest front left	●	●	●	●
SL	230	From 09/2003 to05/2006	OSB-FR-Multicontour backrest front right	●	●	●	●
SL	230	From 09/2003 to05/2006	AAC-Automatic air conditioning	●	●	●	●
SL	230	From 09/2003 to05/2006	STH-Stationary heater	●	●	●	●
SL	230	From 09/2003 to05/2006	HSW-Heated steering wheel	●	●	●	●

SL	230	From 06/2006 to02/2008	ETC-Electronic transmission control	●	●	●	●
SL	230	From 06/2006 to02/2008	ETC-Electronic transmission control	●	●	●	●
SL	230	From 06/2006 to02/2008	SEQ-Sequentronic automated manual transmission	●	●	●	●
SL	230	From 06/2006 to02/2008	ETC-Electronic transmission control	●	●	●	●
SL	230	From 06/2006 to02/2008	ESM-Electronic selector module	●	●	●	●
SL	230	From 06/2006 to02/2008	DTR-Distrionic	●	●	●	●
SL	230	From 06/2006 to02/2008	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
SL	230	From 06/2006 to02/2008	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
SL	230	From 06/2006 to02/2008	DTR-Distrionic	●	●	●	●
SL	230	From 06/2006 to02/2008	ME 9.7-Motor electronics 9.7	●	●	●	●
SL	230	From 06/2006 to02/2008	ME-SFI 2.7.1-Motor electronics 2.7.1	●	●	●	●
SL	230	From 06/2006 to02/2008	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
SL	230	From 06/2006 to02/2008	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
SL	230	From 06/2006 to02/2008	SBC-Sensotronic Brake Control	●	●	●	●
SL	230	From 06/2006 to02/2008	SBC-Sensotronic Brake Control	●	●	●	●
SL	230	From 06/2006 to02/2008	ESP-Electronic stability program	●	●	●	●
SL	230	From 06/2006 to02/2008	ESP-Electronic stability program	●	●	●	●
SL	230	From 06/2006 to02/2008	ABC-ABC active body control	●	●	●	●
SL	230	From 06/2006 to02/2008	ABC-ABC active body control	●	●	●	●
SL	230	From 06/2006 to02/2008	TPM - Tire pressure monitor (N88)	●	●	●	●
SL	230	From 06/2006 to02/2008	TPC-Tire pressure monitor	●	●	●	●
SL	230	From 06/2006 to02/2008	CGW-Central gateway	●	●	●	●
SL	230	From 06/2006 to02/2008	EZS-Electronic ignition switch	●	●	●	●
SL	230	From 06/2006 to02/2008	System diagnosis (CAN)	●	●	●	●
SL	230	From 06/2006 to02/2008	AB-Airbag	●	●	●	●
SL	230	From 06/2006 to02/2008	WSS-Weight sensing system	●	●	●	●
SL	230	From 06/2006 to02/2008	OCP-Overhead control panel	●	●	●	●
SL	230	From 06/2006 to02/2008	LCP-Lower control panel	●	●	●	●
SL	230	From 06/2006 to02/2008	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
SL	230	From 06/2006 to02/2008	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●

SL	230	From 06/2006 to02/2008	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
SL	230	From 06/2006 to02/2008	BNS-Vehicle power supply control module	●	●	●	●
SL	230	From 06/2006 to02/2008	RVC-Rollover bar/vario roof control module	●	●	●	●
SL	230	From 06/2006 to02/2008	RVC-Rollover bar/vario roof control module	●	●	●	●
SL	230	From 06/2006 to02/2008	PSE-Pneumatic system equipment	●	●	●	●
SL	230	From 06/2006 to02/2008	KG-Keyless Go	●	●	●	●
SL	230	From 06/2006 to02/2008	KG-Keyless Go	●	●	●	●
SL	230	From 06/2006 to02/2008	HRA-FR-Front right headlamp range control	●	●	●	●
SL	230	From 06/2006 to02/2008	HRA-FL-Front left headlamp range control	●	●	●	●
SL	230	From 06/2006 to02/2008	System diagnosis (CAN)	●	●	●	●
SL	230	From 06/2006 to02/2008	PTS-Parktronic system	●	●	●	●
SL	230	From 06/2006 to02/2008	SCM [MRM]-Steering column module	●	●	●	●
SL	230	From 06/2006 to02/2008	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
SL	230	From 06/2006 to02/2008	TV-TV tuner	●	●	●	●
SL	230	From 06/2006 to02/2008	E-call [Japan]-Telematic system	●	●	●	●
SL	230	From 06/2006 to02/2008	E-call [USA]-Telematic system	●	●	●	●
SL	230	From 06/2006 to02/2008	TELE AID-Telematic system	●	●	●	●
SL	230	From 06/2006 to02/2008	CTEL over K-wire-Telematic system	●	●	●	●
SL	230	From 06/2006 to02/2008	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
SL	230	From 06/2006 to02/2008	CTEL-Telecommunication for telematics services	●	●	●	●
SL	230	From 06/2006 to02/2008	Telephone adapter for portable CTET-Telecommunicationfor telematics services	●	●	●	●
SL	230	From 06/2006 to02/2008	CTEL-Mobile phone adapter with universal interface	●	●	●	●
SL	230	From 06/2006 to02/2008	AUDIO	●	●	●	●
SL	230	From 06/2006 to02/2008	NAVI-Navigation system	●	●	●	●
SL	230	From 06/2006 to02/2008	CDC-CD changer	●	●	●	●
SL	230	From 06/2006 to02/2008	VCS-Voice control system	●	●	●	●
SL	230	From 06/2006 to02/2008	SOUND-Bose sound system	●	●	●	●
SL	230	From 06/2006 to02/2008	TV-TV tuner	●	●	●	●
SL	230	From 06/2006 to02/2008	TV-TV tuner (AGW)	●	●	●	●

SL	230	From 06/2006 to02/2008	SDAR-Satellite radio	●	●	●	●
SL	230	From 06/2006 to02/2008	TELE AID-Control unit	●	●	●	●
SL	230	From 06/2006 to02/2008	TELE AID-Telematic services Emergency call	●	●	●	●
SL	230	From 06/2006 to02/2008	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
SL	230	From 06/2006 to02/2008	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
SL	230	From 06/2006 to02/2008	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
SL	230	From 06/2006 to02/2008	COMAND	●	●	●	●
SL	230	From 06/2006 to02/2008	D2B-COMAND, MCS or AUDIO	●	●	●	●
SL	230	From 06/2006 to02/2008	AUDIO	●	●	●	●
SL	230	From 06/2006 to02/2008	CDC-CD changer	●	●	●	●
SL	230	From 06/2006 to02/2008	VCS-Voice control system	●	●	●	●
SL	230	From 06/2006 to02/2008	SOUND- Sound system	●	●	●	●
SL	230	From 06/2006 to02/2008	SDAR-Satellite radio	●	●	●	●
SL	230	From 06/2006 to02/2008	CTEL- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
SL	230	From 06/2006 to02/2008	UHI- Cellular telephone 1 (fixed installation orportable) (D2B)	●	●	●	●
SL	230	From 06/2006 to02/2008	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
SL	230	From 06/2006 to02/2008	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
SL	230	From 06/2006 to02/2008	DCM-L-Door control module left	●	●	●	●
SL	230	From 06/2006 to02/2008	DCM-R-Door control module right	●	●	●	●
SL	230	From 06/2006 to02/2008	ESA-FL-Electric seat adjustment front left	●	●	●	●
SL	230	From 06/2006 to02/2008	ESA-FR-Electric seat adjustment front right	●	●	●	●
SL	230	From 06/2006 to02/2008	OSB-FL-Multicontour backrest front left	●	●	●	●
SL	230	From 06/2006 to02/2008	OSB-FR-Multicontour backrest front right	●	●	●	●
SL	230	From 06/2006 to02/2008	AAC-Automatic air conditioning	●	●	●	●
SL	230	From 06/2006 to02/2008	STH-Stationary heater	●	●	●	●
SL	230	From 06/2006 to02/2008	HSW-Heated steering wheel	●	●	●	●
SL	230	As of 03/2008	ETC-Electronic transmission control	●	●	●	●
SL	230	As of 03/2008	ETC-Electronic transmission control	●	●	●	●
SL	230	As of 03/2008	ETC-Electronic transmission control	●	●	●	●
SL	230	As of 03/2008	ESM-Electronic selector module	●	●	●	●

SL	230	As of 03/2008	DTR-Distronic	●	●	●	●
SL	230	As of 03/2008	ME 9.7-Motor electronics 9.7	●	●	●	●
SL	230	As of 03/2008	TV-TV tuner	●	●	●	●
SL	230	As of 03/2008	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
SL	230	As of 03/2008	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
SL	230	As of 03/2008	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●
SL	230	As of 03/2008	SBC-Sensotronic Brake Control	●	●	●	●
SL	230	As of 03/2008	ESP-Electronic stability program	●	●	●	●
SL	230	As of 03/2008	ABC-ABC active body control	●	●	●	●
SL	230	As of 03/2008	TPC-Tire pressure monitor	●	●	●	●
SL	230	As of 03/2008	CGW-Central gateway	●	●	●	●
SL	230	As of 03/2008	EZS-Electronic ignition switch	●	●	●	●
SL	230	As of 03/2008	System diagnosis (CAN)	●	●	●	●
SL	230	As of 03/2008	AB-Airbag	●	●	●	●
SL	230	As of 03/2008	WSS-Weight sensing system	●	●	●	●
SL	230	As of 03/2008	OCP-Overhead control panel	●	●	●	●
SL	230	As of 03/2008	LCP-Lower control panel	●	●	●	●
SL	230	As of 03/2008	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
SL	230	As of 03/2008	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●
SL	230	As of 03/2008	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
SL	230	As of 03/2008	BNS-Vehicle power supply control module	●	●	●	●
SL	230	As of 03/2008	RVC-Rollover bar/vario roof control module	●	●	●	●
SL	230	As of 03/2008	PSE-Pneumatic system equipment	●	●	●	●
SL	230	As of 03/2008	KG-Keyless Go	●	●	●	●
SL	230	As of 03/2008	XALWA-L-Xenon headlamp, left	●	●	●	●
SL	230	As of 03/2008	XALWA-R-Xenon headlamp, right	●	●	●	●
SL	230	As of 03/2008	System diagnosis (CAN)	●	●	●	●
SL	230	As of 03/2008	AMG DRVU-AMG DRIVE UNIT (N145)	●	●	●	●
SL	230	As of 03/2008	PTS-Parktronic system	●	●	●	●
SL	230	As of 03/2008	SCM [MRM]-Steering column module	●	●	●	●
SL	230	As of 03/2008	ICM-Instrument cluster with maintenance interval display	●	●	●	●

SL	230	As of 03/2008	TV-TV tuner	●	●	●	●
SL	230	As of 03/2008	E-call [Japan]-Telematic system	●	●	●	●
SL	230	As of 03/2008	E-call [USA]-Telematic system	●	●	●	●
SL	230	As of 03/2008	TELE AID-Telematic system	●	●	●	●
SL	230	As of 03/2008	CTEL over K-wire-Telematic system	●	●	●	●
SL	230	As of 03/2008	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
SL	230	As of 03/2008	CTEL-Telecommunication for telematics services	●	●	●	●
SL	230	As of 03/2008	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●
SL	230	As of 03/2008	CTEL-Mobile phone adapter with universal interface	●	●	●	●
SL	230	As of 03/2008	AUDIO	●	●	●	●
SL	230	As of 03/2008	NAVI-Navigation system	●	●	●	●
SL	230	As of 03/2008	CDC-CD changer	●	●	●	●
SL	230	As of 03/2008	VCS-Voice control system	●	●	●	●
SL	230	As of 03/2008	SOUND-Bose sound system	●	●	●	●
SL	230	As of 03/2008	TV-TV tuner	●	●	●	●
SL	230	As of 03/2008	TV-TV tuner (AGW)	●	●	●	●
SL	230	As of 03/2008	SDAR-Satellite radio	●	●	●	●
SL	230	As of 03/2008	COMAND or AUDIO	●	●	●	●
SL	230	As of 03/2008	Sound system (Main amplifier)	●	●	●	●
SL	230	As of 03/2008	UCI-Media interface	●	●	●	●
SL	230	As of 03/2008	DAB-Digital radio	●	●	●	●
SL	230	As of 03/2008	SDAR-Satellite radio (Valid for USA)	●	●	●	●
SL	230	As of 03/2008	TV-TV tuner	●	●	●	●
SL	230	As of 03/2008	CTEL-Cellular telephone (JAPAN)	●	●	●	●
SL	230	As of 03/2008	TELE AID-Control unit	●	●	●	●
SL	230	As of 03/2008	TELE AID-Telematic services Emergency call	●	●	●	●
SL	230	As of 03/2008	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
SL	230	As of 03/2008	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
SL	230	As of 03/2008	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
SL	230	As of 03/2008	DCM-L-Door control module left	●	●	●	●



SL	230	As of 03/2008	DCM-R-Door control module right	●	●	●	●
SL	230	As of 03/2008	ESA-FL-Electric seat adjustment front left	●	●	●	●
SL	230	As of 03/2008	ESA-FR-Electric seat adjustment front right	●	●	●	●
SL	230	As of 03/2008	OSB-FL-Multicontour backrest front left	●	●	●	●
SL	230	As of 03/2008	OSB-FR-Multicontour backrest front right	●	●	●	●
SL	230	As of 03/2008	AIRSCARF	●	●	●	●
SL	230	As of 03/2008	AAC-Automatic air conditioning	●	●	●	●
SL	230	As of 03/2008	STH-Stationary heater	●	●	●	●
SL	230	As of 03/2008	HSW-Heated steering wheel	●	●	●	●
SL	231	ALL	ME-Motor electronics 'ME1778' for combustion engine' M277' (N3/10)	●	●	●	●
SL	231	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
SL	231	ALL	DTR-Distronic	●	●	●	●
SL	231	ALL	ISM-Shift module (A80)	●	●	●	●
SL	231	ALL	FSCU-Fuel pump	●	●	●	●
SL	231	ALL	mbrace-mbrace (N123/4)	●	●	●	●
SL	231	ALL	ABC-ABC (N51/2)	●	●	●	●
SL	231	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
SL	231	ALL	AIRSCARF-AIRSCARF system (N25/7)	●	●	●	●
SL	231	ALL	EPB-Electronic parking break (N128)	●	●	●	●
SL	231	ALL	TPM-Tire pressure monitor	●	●	●	●
SL	231	ALL	CGW[ZGW]-Central gateway (CGW[ZGW])	●	●	●	●
SL	231	ALL	CGW-Central gateway	●	●	●	●
SL	231	ALL	CGW-Central gateway	●	●	●	●
SL	231	ALL	EZS-Electronic ignition lock (N73)	●	●	●	●
SL	231	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●
SL	231	ALL	SGR-Radar sensors control unit	●	●	●	●
SL	231	ALL	VDS-Vario roof control (N52)	●	●	●	●
SL	231	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
SL	231	ALL	KG-KEYLESS GO	●	●	●	●
SL	231	ALL	KG-KEYLESS GO (N69/5)	●	●	●	●
SL	231	ALL	MSC-MAGIC SKY CONTROL (N53)	●	●	●	●
SL	231	ALL	RevETR-LF-Left front reversible emergency tensioningretractor (A76)	●	●	●	●
SL	231	ALL	RevETR-RF-Right front reversible emergency tensioningretractor (A76/1)	●	●	●	●
SL	231	ALL	Driver-side SAM-Driver signal acquisition andactuation module	●	●	●	●
SL	231	ALL	Dr-side SAM-Driver signal acquisition and actuationmodule	●	●	●	●
SL	231	ALL	Driver-side SAM-Driver signal acquisition andactuation module	●	●	●	●
SL	231	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
SL	231	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●

SL	231	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
SL	231	ALL	SCM-Steering column module(N80)	●	●	●	●
SL	231	ALL	SGR-Radar sensors control unit	●	●	●	●
SL	231	ALL	AMG PM-AMG Performance Media(N125/2)	●	●	●	●
SL	231	ALL	ES-Electrical power steering	●	●	●	●
SL	231	ALL	IC-Instrument cluster (A1)	●	●	●	●
SL	231	ALL	IC-Instrument cluster (A1)	●	●	●	●
SL	231	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
SL	231	ALL	COU [ZBE]-Central operating unit	●	●	●	●
SL	231	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
SL	231	ALL	DAB-Digital radio	●	●	●	●
SL	231	ALL	ZAN-Central display	●	●	●	●
SL	231	ALL	AMG DRVU-AMG DRIVE UNIT (N145)	●	●	●	●
SL	231	ALL	DSI-DIRECT SELECT interface (N150)	●	●	●	●
SL	231	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
SL	231	ALL	MFK-Multifunction camera	●	●	●	●
SL	231	ALL	NSA-Night View Assist(N101)	●	●	●	●
SL	231	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
SL	231	ALL	SDAR-Satellite radio(Valid for USA)	●	●	●	●
SL	231	ALL	SOUND - Sound system(N40/3)	●	●	●	●
SL	231	ALL	Sound system (Main amplifier)	●	●	●	●
SL	231	ALL	Sound system (Bass amplifier)	●	●	●	●
SL	231	ALL	TV-TV tuner(AGW)	●	●	●	●
SL	231	ALL	UCI-Media interface	●	●	●	●
SL	231	ALL	DCU-LF-Left front door (N69/1)	●	●	●	●
SL	231	ALL	DCU-RF-Right front door (N69/2)	●	●	●	●
SL	231	ALL	DS-LF-Left front dynamic seat	●	●	●	●
SL	231	ALL	DS-RF-Right front dynamic seat	●	●	●	●
SL	231	ALL	DSP-Pneumatic pump for dynamic seat	●	●	●	●
SL	231	ALL	ESA 'Driver'-Electrical seat adjustment 'Driver' withmemory function(N32/1)	●	●	●	●
SL	231	ALL	ESA' Front passenger'-Electric seat adjustment 'Frontpassenger' with memory function(N32/2)	●	●	●	●
SL	231	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
SL	231	ALL	AU-Analog clock (A70/1)	●	●	●	●
SL	231	ALL	BFS LSE-Lumbar support 'Front passenger seat' (N32/24)	●	●	●	●
SL	231	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
SL	231	ALL	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	●	●	●	●
SL	231	ALL	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	●	●	●	●
SL	231	ALL	OCP-Overhead control panel(N70)	●	●	●	●
SLK	170(OBD 16)	ALL	ETC-Electronic transmission control	●	●	●	●
SLK	170(OBD 16)	ALL	ETC-Electronic transmission control	●	●	●	●
SLK	170(OBD 16)	ALL	ESM-Electronic selector module	●	●	●	●
SLK	170(OBD 16)	ALL	ME-SFI-Motor electronics	●	●	●	●

SLK	170 (OBD 16)	ALL	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
SLK	170 (OBD 16)	ALL	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
SLK	170 (OBD 16)	ALL	ESP-Electronic stability program	●	●	●	●
SLK	170 (OBD 16)	ALL	ESP-Electronic stability program	●	●	●	●
SLK	170 (OBD 16)	ALL	BAS-Brake assist	●	●	●	●
SLK	170 (OBD 16)	ALL	VP-Vacuum pump brake booster	●	●	●	●
SLK	170 (OBD 16)	ALL	AB-Airbag	●	●	●	●
SLK	170 (OBD 16)	ALL	RFL-Radio frequency locking/electric central locking	●	●	●	●
SLK	170 (OBD 16)	ALL	PSE-Pneumatic system equipment	●	●	●	●
SLK	170 (OBD 16)	ALL	CCM-Multifunction control module	●	●	●	●
SLK	170 (OBD 16)	ALL	VR-Vario roof	●	●	●	●
SLK	170 (OBD 16)	ALL	HRA-Headlamp range adjustment	●	●	●	●
SLK	170 (OBD 16)	ALL	ICM-Instrument cluster with maintenance interval display	●	●	●	●
SLK	170 (OBD 16)	ALL	AUDIO	●	●	●	●
SLK	170 (OBD 16)	ALL	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●
SLK	170 (OBD 16)	ALL	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●
SLK	170 (OBD 16)	ALL	VCS-Voice control system	●	●	●	●
SLK	170 (OBD 16)	ALL	CDC-CD changer	●	●	●	●
SLK	170 (OBD 16)	ALL	E-call [Japan]-Emergency call system	●	●	●	●
SLK	170 (OBD 16)	ALL	E-call [USA]-Emergency call system	●	●	●	●
SLK	170 (OBD 16)	ALL	E-call [USA]-Telematic system	●	●	●	●
SLK	170 (OBD 16)	ALL	CTEL over K-wire-Telematic system	●	●	●	●
SLK	170 (OBD 16)	ALL	TAC-Automatic temperature control	●	●	●	●
SLK	170 (OBD 16)	ALL	AAC-Automatic air conditioning	●	●	●	●
SLK	170 (OBD 16)	ALL	STH-Stationary heater	●	●	●	●
SLK		171 Up to 05/2005	ETC-Electronic transmission control	●	●	●	●
SLK		171 Up to 05/2005	SEQ-Sequentronic automated manual transmission	●	●	●	●
SLK		171 Up to 05/2005	ETC-Electronic transmission control	●	●	●	●
SLK		171 Up to 05/2005	ESM-Electronic selector module	●	●	●	●
SLK		171 Up to 05/2005	ME-SFI-Motor electronics	●	●	●	●
SLK		171 Up to 05/2005	ME-SFI-Motor electronics	●	●	●	●
SLK		171 Up to 05/2005	TV-TV tuner	●	●	●	●

SLK	171	Up to 05/2005	ME 9.7-Motor electronics 9.7	●	●	●	●
SLK	171	Up to 05/2005	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
SLK	171	Up to 05/2005	ESP-Electronic stability program	●	●	●	●
SLK	171	Up to 05/2005	CGW-Central gateway	●	●	●	●
SLK	171	Up to 05/2005	EZS-Electronic ignition switch	●	●	●	●
SLK	171	Up to 05/2005	System diagnosis (CAN)	●	●	●	●
SLK	171	Up to 05/2005	AB-Airbag	●	●	●	●
SLK	171	Up to 05/2005	VR-Vario roof	●	●	●	●
SLK	171	Up to 05/2005	UCP-Upper control panel	●	●	●	●
SLK	171	Up to 05/2005	OCP-Overhead control panel	●	●	●	●
SLK	171	Up to 05/2005	SAM-F-Signal acquisition and actuation module front	●	●	●	●
SLK	171	Up to 05/2005	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
SLK	171	Up to 05/2005	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●
SLK	171	Up to 05/2005	PTS-Parktronic system	●	●	●	●
SLK	171	Up to 05/2005	SCM [MRM]-Steering column module	●	●	●	●
SLK	171	Up to 05/2005	IC-Instrument cluster	●	●	●	●
SLK	171	Up to 05/2005	ASSYST-Active Service System	●	●	●	●
SLK	171	Up to 05/2005	ASSYST PLUS-PLUS Active Service System	●	●	●	●
SLK	171	Up to 05/2005	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
SLK	171	Up to 05/2005	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●
SLK	171	Up to 05/2005	CTEL-Mobile phone adapter with universal interface	●	●	●	●
SLK	171	Up to 05/2005	AUDIO	●	●	●	●
SLK	171	Up to 05/2005	COMAND or AUDIO	●	●	●	●
SLK	171	Up to 05/2005	NAVI-Navigation system	●	●	●	●
SLK	171	Up to 05/2005	CDC-CD changer	●	●	●	●
SLK	171	Up to 05/2005	VCS-Voice control system	●	●	●	●
SLK	171	Up to 05/2005	SDAR-Satellite radio	●	●	●	●
SLK	171	Up to 05/2005	COMAND or AUDIO	●	●	●	●
SLK	171	Up to 05/2005	Sound system (Main amplifier)	●	●	●	●
SLK	171	Up to 05/2005	UCI-Media interface	●	●	●	●

SLK	171	Up to 05/2005	DAB-Digital radio	●	●	●	●
SLK	171	Up to 05/2005	SDAR-Satellite radio(Valid for USA)	●	●	●	●
SLK	171	Up to 05/2005	TV-TV tuner	●	●	●	●
SLK	171	Up to 05/2005	CTEL-Cellular telephone(JAPAN)	●	●	●	●
SLK	171	Up to 05/2005	GPS box	●	●	●	●
SLK	171	Up to 05/2005	TELE AID-Control unit	●	●	●	●
SLK	171	Up to 05/2005	TELE AID-Telematic services Emergency call	●	●	●	●
SLK	171	Up to 05/2005	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
SLK	171	Up to 05/2005	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
SLK	171	Up to 05/2005	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
SLK	171	Up to 05/2005	DCM-L-Door control module left	●	●	●	●
SLK	171	Up to 05/2005	DCM-R-Door control module right	●	●	●	●
SLK	171	Up to 05/2005	ESA driver-Electric seat adjustment driver (with	●	●	●	●
SLK	171	Up to 05/2005	ESA passenger-Electric seat adjustment passenger	●	●	●	●
SLK	171	Up to 05/2005	HS-Seat heater	●	●	●	●
SLK	171	Up to 05/2005	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●
SLK	171	As of 06/2005	ETC-Electronic transmission control	●	●	●	●
SLK	171	As of 06/2005	ETC-Electronic transmission control	●	●	●	●
SLK	171	As of 06/2005	SEQ-Sequentronic automated manual transmission	●	●	●	●
SLK	171	As of 06/2005	ETC-Electronic transmission control	●	●	●	●
SLK	171	As of 06/2005	ESM-Electronic selector module	●	●	●	●
SLK	171	As of 06/2005	ME-SFI-Motor electronics	●	●	●	●
SLK	171	As of 06/2005	ME-SFI-Motor electronics	●	●	●	●
SLK	171	As of 06/2005	TV-TV tuner	●	●	●	●
SLK	171	As of 06/2005	ME 9.7-Motor electronics 9.7	●	●	●	●
SLK	171	As of 06/2005	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
SLK	171	As of 06/2005	ESP-Electronic stability program	●	●	●	●
SLK	171	As of 06/2005	TPC-Tire pressure monitor	●	●	●	●
SLK	171	As of 06/2005	CGW-Central gateway	●	●	●	●
SLK	171	As of 06/2005	EZS-Electronic ignition switch	●	●	●	●

SLK	171	As of 06/2005	System diagnosis (CAN)	●	●	●	●
SLK	171	As of 06/2005	AB-Airbag	●	●	●	●
SLK	171	As of 06/2005	WSS-Weight sensing system	●	●	●	●
SLK	171	As of 06/2005	VR-Vario roof	●	●	●	●
SLK	171	As of 06/2005	UCP-Upper control panel	●	●	●	●
SLK	171	As of 06/2005	OCP-Overhead control panel	●	●	●	●
SLK	171	As of 06/2005	SAM-F-Signal acquisition and actuation module front	●	●	●	●
SLK	171	As of 06/2005	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
SLK	171	As of 06/2005	HRA-Automatic headlamp range adjustment and headlampcontrol	●	●	●	●
SLK	171	As of 06/2005	PTS-Parktronic system	●	●	●	●
SLK	171	As of 06/2005	PTS-Parktronic system	●	●	●	●
SLK	171	As of 06/2005	SCM [MRM]-Steering column module	●	●	●	●
SLK	171	As of 06/2005	IC-Instrument cluster	●	●	●	●
SLK	171	As of 06/2005	ASSYST-Active Service System	●	●	●	●
SLK	171	As of 06/2005	ASSYST PLUS-PLUS Active Service System	●	●	●	●
SLK	171	As of 06/2005	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
SLK	171	As of 06/2005	AGW-Audio gateway (MOST network management, diagnosisgateway, radio tuner)	●	●	●	●
SLK	171	As of 06/2005	CTEL-Mobile phone adapter with universal interface	●	●	●	●
SLK	171	As of 06/2005	AUDIO	●	●	●	●
SLK	171	As of 06/2005	COMAND or AUDIO	●	●	●	●
SLK	171	As of 06/2005	NAVI-Navigation system	●	●	●	●
SLK	171	As of 06/2005	CDC-CD changer	●	●	●	●
SLK	171	As of 06/2005	VCS-Voice control system	●	●	●	●
SLK	171	As of 06/2005	SDAR-Satellite radio	●	●	●	●
SLK	171	As of 06/2005	COMAND or AUDIO	●	●	●	●
SLK	171	As of 06/2005	Sound system (Main amplifier)	●	●	●	●
SLK	171	As of 06/2005	UCI-Media interface	●	●	●	●
SLK	171	As of 06/2005	DAB-Digital radio	●	●	●	●
SLK	171	As of 06/2005	SDAR-Satellite radio (Valid for USA)	●	●	●	●
SLK	171	As of 06/2005	TV-TV tuner	●	●	●	●

SLK	171	As of 06/2005	CTEL-Cellular telephone (JAPAN)	●	●	●	●
SLK	171	As of 06/2005	GPS box	●	●	●	●
SLK	171	As of 06/2005	TELE AID-Control unit	●	●	●	●
SLK	171	As of 06/2005	TELE AID-Telematic services Emergency call	●	●	●	●
SLK	171	As of 06/2005	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
SLK	171	As of 06/2005	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
SLK	171	As of 06/2005	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
SLK	171	As of 06/2005	DCM-L-Door control module left	●	●	●	●
SLK	171	As of 06/2005	DCM-R-Door control module right	●	●	●	●
SLK	171	As of 06/2005	ESA driver-Electric seat adjustment driver (with	●	●	●	●
SLK	171	As of 06/2005	ESA passenger-Electric seat adjustment passenger	●	●	●	●
SLK	171	As of 06/2005	HS-Seat heater	●	●	●	●
SLK	171	As of 06/2005	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●
SLK	172	ALL	DTR-Distronic	●	●	●	●
SLK	172	ALL	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●
SLK	172	ALL	ME-Motor electronics 'MED177AMG' for combustion engine' M152' (N3/10)	●	●	●	●
SLK	172	ALL	FSCU-Fuel pump	●	●	●	●
SLK	172	ALL	FSCU-Fuel pump	●	●	●	●
SLK	172	ALL	mbrace-mbrace (N123/4)	●	●	●	●
SLK	172	ALL	ESM-Electronic selector module	●	●	●	●
SLK	172	ALL	FSCU-Fuel pump	●	●	●	●
SLK	172	ALL	ETC-Electronic transmission control	●	●	●	●
SLK	172	ALL	CDI 3-Common Rail Diesel Injection3	●	●	●	●
SLK	172	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
SLK	172	ALL	AIRSCARF-AIRSCARF system (N25/7)	●	●	●	●
SLK	172	ALL	EHPS-Electrohydraulic Power Steering	●	●	●	●
SLK	172	ALL	EFB-Electronic parking break (N128)	●	●	●	●
SLK	172	ALL	TPM-Tire pressure monitor	●	●	●	●
SLK	172	ALL	CGW[ZGW]-Central gateway (CGW[ZGW])	●	●	●	●
SLK	172	ALL	CGW-Central gateway	●	●	●	●
SLK	172	ALL	CGW-Central gateway	●	●	●	●
SLK	172	ALL	EZS-Electronic ignition lock	●	●	●	●
SLK	172	ALL	VDS-Vario roof control (N52)	●	●	●	●
SLK	172	ALL	SGR-Radar sensors control unit	●	●	●	●
SLK	172	ALL	SG-SW-Control unit 'Headlamp' (N71/1)	●	●	●	●
SLK	172	ALL	KG-Keyless Go	●	●	●	●
SLK	172	ALL	MSC-MAGIC SKY CONTROL (N53)	●	●	●	●
SLK	172	ALL	SRS-Supplemental restraint system (N2/10)	●	●	●	●

SLK	172	ALL	RevETR-LF-Left front reversible emergency tensioning retractor (A76)	●	●	●	●
SLK	172	ALL	RevETR-RF-Right front reversible emergency tensioning retractor (A76/1)	●	●	●	●
SLK	172	ALL	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●
SLK	172	ALL	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
SLK	172	ALL	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●
SLK	172	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
SLK	172	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
SLK	172	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
SLK	172	ALL	SCM-Steering column module (N80)	●	●	●	●
SLK	172	ALL	SGR-Radar sensors control unit	●	●	●	●
SLK	172	ALL	COU [ZBE]-Central operating unit	●	●	●	●
SLK	172	ALL	IC-Instrument cluster (A1)	●	●	●	●
SLK	172	ALL	IC-Instrument cluster (A1)	●	●	●	●
SLK	172	ALL	ICM-Instrument cluster with maintenance interval display	●	●	●	●
SLK	172	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
SLK	172	ALL	DAB-Digital radio	●	●	●	●
SLK	172	ALL	ZAN-Central display	●	●	●	●
SLK	172	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
SLK	172	ALL	MPK-Multifunction camera	●	●	●	●
SLK	172	ALL	NAV-Navigation module (A2/30)	●	●	●	●
SLK	172	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
SLK	172	ALL	SCCM-Steering column module (N80)	●	●	●	●
SLK	172	ALL	SDAR-Satellite radio (Valid for USA)	●	●	●	●
SLK	172	ALL	Sound system (Main amplifier)	●	●	●	●
SLK	172	ALL	TV-TV tuner (AGW)	●	●	●	●
SLK	172	ALL	UCI-Media interface	●	●	●	●
SLK	172	ALL	NAVI20 - Navigation (N125/2)	●	●	●	●
SLK	172	ALL	TELE AID-Control unit	●	●	●	●
SLK	172	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
SLK	172	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
SLK	172	ALL	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
SLK	172	ALL	DCU-LF-Left front door	●	●	●	●
SLK	172	ALL	DCU-RF-Right front door	●	●	●	●
SLK	172	ALL	DCU-RF-Right front door	●	●	●	●
SLK	172	ALL	ESA 'Driver' -Electric seat adjustment 'Driver' (N32/1)	●	●	●	●
SLK	172	ALL	ESA' Front passenger' -Electric seat adjustment 'Frontpassenger' with memory function (N32/2)	●	●	●	●
SLK	172	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
SLK	172	ALL	AU-Analog clock (A70/1)	●	●	●	●
SLK	172	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
SLK	172	ALL	OCP-Overhead control panel (N70)	●	●	●	●



SLS	197	ALL	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●
SLS	197	ALL	ISM-Shift module (A80)	●	●	●	●
SLS	197	ALL	FSCU-Fuel pump	●	●	●	●
SLS	197	ALL	AIRSCARF-AIRSCARF system (N25/7)	●	●	●	●
SLS	197	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
SLS	197	ALL	ESP-Electronic stability program (N30/4)	●	●	●	●
SLS	197	ALL	Electronic parking brake-Electric parking brake	●	●	●	●
SLS	197	ALL	EHPS-Electrohydraulic Power Steering	●	●	●	●
SLS	197	ALL	EFB-Electronic parking break (N128)	●	●	●	●
SLS	197	ALL	TPM - Tire pressure monitor(N88)	●	●	●	●
SLS	197	ALL	CGW[ZGW]-Central gateway (CGW[ZGW])	●	●	●	●
SLS	197	ALL	CGW-Central gateway	●	●	●	●
SLS	197	ALL	CGW-Central gateway	●	●	●	●
SLS	197	ALL	EZS-Electronic ignition lock	●	●	●	●
SLS	197	ALL	BMS-Battery management system	●	●	●	●
SLS	197	ALL	BMS-Battery management system	●	●	●	●
SLS	197	ALL	BMS-Battery management system	●	●	●	●
SLS	197	ALL	VDS-Soft top control (N52)	●	●	●	●
SLS	197	ALL	SRS-Supplemental restraint system	●	●	●	●
SLS	197	ALL	DDW-DC/DC converter (N83/1)	●	●	●	●
SLS	197	ALL	IRS-HRA-Outer right rear intelligent radar sensor	●	●	●	●
SLS	197	ALL	IRS-HLA-Outer left rear intelligent radar sensorsystem (B29/4)	●	●	●	●
SLS	197	ALL	KG-Keyless Go	●	●	●	●
SLS	197	ALL	WSS-Weight sensing system	●	●	●	●
SLS	197	ALL	Driver-side SAM-Driver signal acquisition andactuation module	●	●	●	●
SLS	197	ALL	Dr-side SAM-Driver signal acquisition and actuationmodule	●	●	●	●
SLS	197	ALL	Driver-side SAM-Driver signal acquisition andactuation module	●	●	●	●
SLS	197	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
SLS	197	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
SLS	197	ALL	Rear SAM-Rear signal acquisition and actuation module	●	●	●	●
SLS	197	ALL	AMG PM-AMG Performance Media(N125/2)	●	●	●	●
SLS	197	ALL	COU [ZBE]-Central operating unit	●	●	●	●
SLS	197	ALL	IC-Instrument cluster (A1)	●	●	●	●
SLS	197	ALL	IC-Instrument cluster (A1)	●	●	●	●
SLS	197	ALL	ICM-Instrument cluster with maintenance intervaldisplay	●	●	●	●
SLS	197	ALL	DAB-Digital Audio Broadcasting (N87/3)	●	●	●	●
SLS	197	ALL	DAB-Digital radio	●	●	●	●
SLS	197	ALL	DKG-Electronic transmission control for double-plateclutch transmission (N15/13)	●	●	●	●
SLS	197	ALL	ZAN-Central display	●	●	●	●
SLS	197	ALL	AMG DRVU-AMG DRIVE UNIT (N145)	●	●	●	●
SLS	197	ALL	DSI-DIRECT SELECT interface (N150)	●	●	●	●

SLS	197	ALL	Audio-Audio or COMAND (A2-A40/3)	●	●	●	●
SLS	197	ALL	COMAND or AUDIO	●	●	●	●
SLS	197	ALL	PTS-PARKTRONIC (N62)	●	●	●	●
SLS	197	ALL	SCM [MRM]-Steering column module	●	●	●	●
SLS	197	ALL	SCCM-Steering column module (N80)	●	●	●	●
SLS	197	ALL	SDAR-Satellite radio (Valid for USA)	●	●	●	●
SLS	197	ALL	Sound system (Main amplifier)	●	●	●	●
SLS	197	ALL	Sound system (Main amplifier)	●	●	●	●
SLS	197	ALL	Sound system (Bass amplifier)	●	●	●	●
SLS	197	ALL	UCI-Media interface	●	●	●	●
SLS	197	ALL	TELE AID-Control unit	●	●	●	●
SLS	197	ALL	TELE AID-Telematic services Emergency call	●	●	●	●
SLS	197	ALL	TELE AID-Telematic services Remote doorunlocking, Remote door locking	●	●	●	●
SLS	197	ALL	TELE AID-Telematic services MB Info, Roadsideassistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●
SLS	197	ALL	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●
SLS	197	ALL	DCU-LF-Left front door	●	●	●	●
SLS	197	ALL	DCU-RF-Right front door	●	●	●	●
SLS	197	ALL	ESA 'Driver' -Electric seat adjustment 'Driver' (N32/1)	●	●	●	●
SLS	197	ALL	ESA driver	●	●	●	●
SLS	197	ALL	ESA' Front passenger' -Electric seat adjustment 'Frontpassenger' with memory function (N32/2)	●	●	●	●
SLS	197	ALL	ESA passenger	●	●	●	●
SLS	197	ALL	EKMK-Electric refrigerant compressor (A9/5)	●	●	●	●
SLS	197	ALL	AAC-Air conditioning (N22/7)	●	●	●	●
SLS	197	ALL	GTO-Garage door opener (A67n2)	●	●	●	●
SLS	197	ALL	BSN-Battery sensor (B95)	●	●	●	●
SLR	199	ALL	ETC-Electronic transmission control	●	●	●	●
SLR	199	ALL	ESM-Electronic selector module	●	●	●	●
SLR	199	ALL	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●
SLR	199	ALL	SBC-Sensotronic Brake Control	●	●	●	●
SLR	199	ALL	ESP-Electronic stability program	●	●	●	●
SLR	199	ALL	TPM - Tire pressure monitor (N88)	●	●	●	●
SLR	199	ALL	TPC-Tire pressure monitor	●	●	●	●
SLR	199	ALL	EZS-Electronic ignition switch	●	●	●	●
SLR	199	ALL	OCP-Overhead control panel	●	●	●	●
SLR	199	ALL	LCP-Lower control panel	●	●	●	●
SLR	199	ALL	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●
SLR	199	ALL	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●
SLR	199	ALL	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●
SLR	199	ALL	BNS-Vehicle power supply control module	●	●	●	●
SLR	199	ALL	HRA-FR-Front right headlamp range control	●	●	●	●
SLR	199	ALL	HRA-FL-Front left headlamp range control	●	●	●	●

SLR	199	ALL	RS-Roadster soft top	●	●	●	●
SLR	199	ALL	CGW-Central gateway	●	●	●	●
SLR	199	ALL	AB-Airbag	●	●	●	●
SLR	199	ALL	WSS-Weight sensing system	●	●	●	●
SLR	199	ALL	ACL [ZLB]-Air brake (spoiler) and central locking control unit	●	●	●	●
SLR	199	ALL	BKGS-Brake cooling and gearshift	●	●	●	●
SLR	199	ALL	System diagnosis (CAN)	●	●	●	●
SLR	199	ALL	SCM [MRM]-Steering column module	●	●	●	●
SLR	199	ALL	ICM-Instrument cluster with maintenance interval display	●	●	●	●
SLR	199	ALL	AUDIO	●	●	●	●
SLR	199	ALL	CDC-CD changer	●	●	●	●
SLR	199	ALL	SOUND- Sound system	●	●	●	●
SLR	199	ALL	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●
SLR	199	ALL	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●
SLR	199	ALL	E-call [Japan]-Telematic system	●	●	●	●
SLR	199	ALL	E-call [USA]-Telematic system	●	●	●	●
SLR	199	ALL	TELE AID-Telematic system	●	●	●	●
SLR	199	ALL	CTEL over K-wire-Telematic system	●	●	●	●
SLR	199	ALL	DCM-L-Door control module left	●	●	●	●
SLR	199	ALL	DCM-R-Door control module right	●	●	●	●
SLR	199	ALL	AAC-Automatic air conditioning	●	●	●	●

Benz\_V01.30 OIL Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Chassis	Model Year	OIL
A-Class	168	ALL	●
A-Class	169	As of 12/2005	●
A-Class	169	Up to 11/2005	●
A-Class	176	ALL	●
AMG	190	ALL	●
B-Class	245	As of 12/2005	●
B-Class	245	Up to 11/2005	●
B-Class	246	ALL	●
C-Class	202	As of 06/1997	●
C-Class	202	Up to 05/1997	●
C-Class	203	As of 01/2008	●
C-Class	203	From 09/2003 to 12/2007	●
C-Class	203	Up to 08/2003	●
C-Class	204	ALL	●
C-Class	205	ALL	●
CL	215	As of 09/2002	●
CL	215	Up to 08/2002	●
CL	216	ALL	●
CLA	117	ALL	●
CLC	203	ALL	●
CLK	208	ALL	●
CLK	209	As of 04/2004	●
CLK	209	Up to 03/2004	●
CLS	218	ALL	●
CLS	219	As of 06/2006	●
CLS	219	From 06/2005 to 05/2006	●
CLS	219	Up to 05/2005	●
E-Class	207	ALL	●
E-Class	210	As of 03/1997	●
E-Class	210	Up to 02/1997	●
E-Class	211	As of 06/2006	●
E-Class	211	From 06/2005 to 05/2006	●
E-Class	211	Up to 05/2005	●
E-Class	212	ALL	●
G-Class	461 (OBD 16)	ALL	●
G-Class	463 (OBD 16)	As of 03/2007	●
G-Class	463 (OBD 16)	From 09/2006 to 02/2007	●
G-Class	463 (OBD 16)	From 04/2004 to 08/2006	●
G-Class	463 (OBD 16)	Up to 03/2004	●
G-Class	463 (BENZ-38)	Up to 03/2004	●
GL-Class	164	ALL	●
GL-Class	166	ALL	●
GLA	156	ALL	●
GLC	253	ALL	●
GLE	292	ALL	●
GLK	204	ALL	●

ML	163	ALL	●
ML	164	ALL	●
ML	166	ALL	●
MayBach	240	As of 09/2006	●
MayBach	240	Up to 08/2006	●
R-Class	251	ALL	●
S-Class	140	ALL	●
S-Class	217	ALL	●
S-Class	220	As of 09/2002	●
S-Class	220	Up to 08/2002	●
S-Class	221	As of 07/2009	●
S-Class	221	Up to 06/2009	●
S-Class	222	All	●
SL	129	As of 09/1999	●
SL	129	Up to 08/1999	●
SL	230	As of 03/2008	●
SL	230	From 06/2006 to 02/2008	●
SL	230	From 09/2003 to 05/2006	●
SL	230	Up to 08/2003	●
SL	231	ALL	●
SLK	170(OBD 16)	ALL	●
SLK	170(BENZ-38)	ALL	●
SLK	171	As of 06/2005	●
SLK	171	Up to 05/2005	●
SLK	172	ALL	●
SLR	199	ALL	●
SLS	197	ALL	●