| VW_V01.15 Daig Function List (Note:For reference only) | |
|---|---|
| NOTES: | |
| ● This function is supported. | |
| ※ This function may be supported, which depends on the actual condition of the vehicle. | |
| ○ This function is not supported. | |
| ▲ This function is the new feature in this version. | |
| Vehicle | Model Year |
| 12 - Up/Cross up | 2014 - 2017 |
| 13 - Scirocco | 2009 - 2017 |
| 15 - New Bora | 2008 - |
| 16 - Jetta | 2011 - 2017 |
| 17 - Golf Citi | 1998 - 2009 |
| 18 - Lavida | 2008 - |
| 1C - New Beetle | 1998 - 2011 |
| 1E - Golf Cabrio | 1993 - 2002 |
| 1F - Eos | 2006 - 2017 |
| 1G - Golf Jetta II | 1989 - 1992 |
| 1H - Golf Vento III | 1992 - 1999 |
| 1J - Bora | 1999 - 2005 |
| 1J - Golf | 1998 - 2006 |
| 1K - Golf | 2004 - 2009 |
| 1K - Jetta | 2005 - 2010 |
| 1K - Rabbit | 2006 - 2009 |
| 1T - Touran | 2003 - 2017 |
| 1V - Golf Cabrio | 1997 - 2002 |
| 1Y - New Beetle Cab | 2003 - 2011 |
| 2C - CaddY | 2011 - 2015 |
| 2D - LT2 | 1996 - 2006 |
| 2E - Crafter LT3 | 2006 - 2015 |
| 2H - Amarok | 2010 - 2015 |
| 2K - CaddY | 2004 - 2010 |
| 35 - Passat CC | 2009 - 2017 |
| 36 - Passat B7 | 2011 - 2015 |
| 3A - Passat B4 | 1994 - 1997 |
| 3B - Passat B5 | 1997 - 2005 |
| 3C - Passat B6 | 2005 - 2011 |
| 3D - Phaeton D1 | 2003 - 2017 |
| 3G - Passat | 2015 - 2017 |
| 3X - Santana | 2001 - 2007 |
| 50 - Corrado | - 1995 |
| 51 - Golf Cabriolet | 2012 - 2017 |
| 52 - Golf Plus | 2009 - 2014 |
| 5C - Beetle | 2012 - 2015 |
| 5C - Beetle Cab | 2013 - |
| 5G - Golf/Jetta VII | 2013 - 2017 |
| 5K - Golf Jetta VI | 2009 - 2014 |
| 5M - Golf Plus | 2005 - 2009 |
| 5N - Tiguan | 2008 - 2017 |
| 5U - Gol/VoYage/Saveiro | 2009 - 2013 |
| 5U - Novo Gol/VoYage/Saveiro | 2013 - 2017 |
| 5W - Gol Par Sav Poi | 2006 - 2015 |

| | |
|---|---|
| 5X - Gol Par Sav Poi | 1999 - 2017 |
| 5Y - Gol Special | 1999 - 2005 |
| 5Z - Fox/CrossFox/Lupo | 2004 - 2017 |
| 5Z - SpaceFox/Space Cross/Suran/Sportvan | 2006 - 2017 |
| 60 - Polo | 2010 - 2017 |
| 61 - Polo | 2011 - 2017 |
| 6C - Polo | 2014 - 2017 |
| 6N - Polo | 1995 - 2002 |
| 6R - Polo | 2010 - 2015 |
| 6S - Polo Vivo | 2010 - 2015 |
| 6V - Polo Classic | 1996 - 2010 |
| 6X - Lupo | 1999 - 2006 |
| 6Z - XL1 | 2013 - 2017 |
| 70 - Transporter | 1991 - 1996 |
| 7D - T4 Caravelle | 2001 - 2003 |
| 7D - Transporter | 1996 - 2004 |
| 7E - Transporter | 2010 - 2015 |
| 7F - Transporter/Multivan | 2010 - 2015 |
| 7H - Transporter | 2004 - 2009 |
| 7J - Transporter/Multivan | 2004 - 2009 |
| 7L - Touareg | 2003 - 2010 |
| 7M - Sharan I | 2001 - 2010 |
| 7N - Sharan II | 2011 - 2017 |
| 7P - Touareg | 2010 - 2017 |
| 7X - Kombi | 2006 - 2015 |
| 9A - Polo | 2003 - 2015 |
| 9B - Golf | 1999 - 2015 |
| 9C - New Beetle | 1998 - 2011 |
| 9F - Passat B5 | |
| 9K - CaddY | 1996 - 2003 |
| 9M - Jetta IV | 1999 - 2015 |
| 9N - Polo | 2002 - 2010 |
| 9V - Polo | 2001 - 2003 |
| A3 - Passat | 2011 - 2017 |
| A9 - Touareg NAR | 2010 - 2011 |
| AA - Up | 2012 - 2017 |
| AG - New Beetle NAR | 2010 |
| AH - Eos NAR | 2010 - |
| AJ - Golf Jetta VI NAR | 2010 - 2014 |
| AL - New Beetle Cab NAR | 2010 |
| AM - Golf | 2014 - 2017 |
| AN - Passat | 2010 - |
| AT - Beetle Cab NAR | 2012 - |
| AU - Golf | 2013 - 2015 |
| AX - Tiguan NAR | 2010 - |
| BA - Golf Variant VII | 2014 - |
| BE - Golf | 2013 - 2015 |
| BK - Sagitar | 2006 - |
| BL - Up | 2012 - 2017 |
| BP - Touareg NAR | 2011 - |

| BS - Jetta CHN | 2013 - | | | |
|---|---|---|---|---|
| BS - Bora CHN | 2013 - | | | |
| Systemlist | EcuInfo. | ReadCodes | EraseCode | LiveData |
| 01 Engine Control Module 1 | ● | ● | ● | ● |
| 02 Transmission Control Module | ● | ● | ● | ● |
| 03 Brake Control Module | ● | ● | ● | ● |
| 04 Steering Angle Sender | ● | ● | ● | ● |
| 05 Kessy | ● | ● | ● | ● |
| 06 Seat Adjustment Passenger Side | ● | ● | ● | ● |
| 07 Display Control Unit | ● | ● | ● | ● |
| 08 Air Conditioning | ● | ● | ● | ● |
| 09 Central Electrics | ● | ● | ● | ● |
| 0B Auxiliary Air Heater | ● | ● | ● | ● |
| 0C Rear Axle Steering 2 | ● | ● | ● | ● |
| 0D Sliding Door Left | ● | ● | ● | ● |
| 0E Media Player Position 1 | ● | ● | ● | ● |
| 0F Radio Tuner - Digital | ● | ● | ● | ● |
| 10 Parking Assistance 2 | ● | ● | ● | ● |
| 11 Engine Control Module 2 | ● | ● | ● | ● |
| 12 Clutch Control Unit | ● | ● | ● | ● |
| 13 Adaptive Cruise Control | ● | ● | ● | ● |
| 14 Wheel Dampening Electronics | ● | ● | ● | ● |
| 15 Airbag | ● | ● | ● | ● |
| 16 Steering Column Electronics | ● | ● | ● | ● |
| 17 Dash Board | ● | ● | ● | ● |
| 18 Auxiliary Parking Heating | ● | ● | ● | ● |
| 19 Gateway | ● | ● | ● | ● |
| 1B Power-Assisted Steering | ● | ● | ● | ● |
| 1C Vehicle Position Detection | ● | ● | ● | ● |
| 1D Driver Identification | ● | ● | ● | ● |
| 1E Media Player Position 2 | ● | ● | ● | ● |
| 1F Radio Satellite | ● | ● | ● | ● |
| 20 High Beam Assistance | ● | ● | ● | ● |
| 21 Battery Energy Control Module 2 | ● | ● | ● | ● |
| 22 4WD Electronics | ● | ● | ● | ● |
| 23 Brake Boost | ● | ● | ● | ● |
| 24 Drive Slip Control | ● | ● | ● | ● |
| 25 Immobilizer | ● | ● | ● | ● |
| 26 Electric Roof Control | ● | ● | ● | ● |
| 27 Display Control Unit Rear | ● | ● | ● | ● |
| 28 Climate Control Unit Rear | ● | ● | ● | ● |
| 29 Light Control Left | ● | ● | ● | ● |
| 2B Steer Column Locking | ● | ● | ● | ● |
| 2D Voice Amplifier | ● | ● | ● | ● |
| 2E Media Player Position 3 | ● | ● | ● | ● |
| 2F TV Tuner - Digital | ● | ● | ● | ● |
| 30 Special Function 2 | ● | ● | ● | ● |
| 31 Engine Electronics Conjunction | ● | ● | ● | ● |
| 32 Locking Electroniscs | ● | ● | ● | ● |
| 34 Self Adjustment Suspension | ● | ● | ● | ● |
| 35 Central Locking Control Module | ● | ● | ● | ● |

| | | | | |
|---|---|---|---|---|
| 36 Seat Adjustment Driver Side | ● | ● | ● | ● |
| 37 Navigation | ● | ● | ● | ● |
| 38 Roof Electronics | ● | ● | ● | ● |
| 39 Light Control Right | ● | ● | ● | ● |
| 3A Special Vehicle Assistant | ● | ● | ● | ● |
| 3B Sensor Electronics | ● | ● | ● | ● |
| 3C Lane Change Assistance System | ● | ● | ● | ● |
| 3D Special Function | ● | ● | ● | ● |
| 3E Media Player Position 4 | ● | ● | ● | ● |
| 40 Air Conditioning Compressor | ● | ● | ● | ● |
| 41 Diesel Pump Electronics | ● | ● | ● | ● |
| 42 Driver-Door Electronics | ● | ● | ● | ● |
| 43 Braker Boost Assistance | ● | ● | ● | ● |
| 44 Steering Assistance | ● | ● | ● | ● |
| 45 Interior Monitoring | ● | ● | ● | ● |
| 46 Central Control Module | ● | ● | ● | ● |
| 47 Sound System | ● | ● | ● | ● |
| 48 Seat Adjustment Rear Driver Side | ● | ● | ● | ● |
| 49 Automatic Lighting Switch | ● | ● | ● | ● |
| 4B Multifunction Module | ● | ● | ● | ● |
| 4C Tyre Pressure Monitor II | ● | ● | ● | ● |
| 4E Control Head Rear Right | ● | ● | ● | ● |
| 4F Central Electronics II | ● | ● | ● | ● |
| 51 Drive Motor Control Module | ● | ● | ● | ● |
| 52 Passenger-Door Electronics | ● | ● | ● | ● |
| 53 Parking Brake | ● | ● | ● | ● |
| 54 Rear Spoiler | ● | ● | ● | ● |
| 55 Headlight Range Control | ● | ● | ● | ● |
| 56 Radio | ● | ● | ● | ● |
| 57 TV-Tuner | ● | ● | ● | ● |
| 58 Auxiliary Fuel Tank | ● | ● | ● | ● |
| 59 Towing Protection | ● | ● | ● | ● |
| 5B Seat Adjustment Rear Passenger Side | ● | ● | ● | ● |
| 5C Lane Keeping Assistance System | ● | ● | ● | ● |
| 5D Operation | ● | ● | ● | ● |
| 5E Control Head Left Rear | ● | ● | ● | ● |
| 5F Information Control Unit 1 | ● | ● | ● | ● |
| 61 Battery Regulation | ● | ● | ● | ● |
| 62 Door Electronics Left Rear | ● | ● | ● | ● |
| 63 Entry Assistance Driver Side | ● | ● | ● | ● |
| 64 Stabilizers | ● | ● | ● | ● |
| 65 Tyre Pressure Monitoring I | ● | ● | ● | ● |
| 66 Seat/Mirror Adjustment | ● | ● | ● | ● |
| 67 Voice Control | ● | ● | ● | ● |
| 68 Wiper Control Unit | ● | ● | ● | ● |
| 69 Trailer Function | ● | ● | ● | ● |
| 6B Aerodynamics Control Module | ● | ● | ● | ● |
| 6C Camera System Rear View | ● | ● | ● | ● |
| 6D Electronic Equipment of Trunk Lid | ● | ● | ● | ● |
| 6E Display Control Roof | ● | ● | ● | ● |
| 6F Central Control Module II | ● | ● | ● | ● |

| | | | | |
|---|---|---|---|---|
| 71 Battery Charger | ● | ● | ● | ● |
| 72 Door Electronics Right Rear | ● | ● | ● | ● |
| 73 Entry Assistance Passenger Side | ● | ● | ● | ● |
| 74 Vehicle Control System | ● | ● | ● | ● |
| 75 Telematics Communication Unit | ● | ● | ● | ● |
| 76 Parking Assistance | ● | ● | ● | ● |
| 77 Telephone | ● | ● | ● | ● |
| 78 Sliding Door | ● | ● | ● | ● |
| 7D Auxiliary Heater | ● | ● | ● | ● |
| 7E Dash Board Display Unit | ● | ● | ● | ● |
| 7F Information Control Unit 2 | ● | ● | ● | ● |
| 81 Gear Shift Control Module | ● | ● | ● | ● |
| 82 Head Up Display | ● | ● | ● | ● |
| 84 Night Vision | ● | ● | ● | ● |
| 85 On Board-Cammera | ● | ● | ● | ● |
| 88 Muiti Contour Seat Driver Side | ● | ● | ● | ● |
| 89 Multi Contour Seat Passenger Side | ● | ● | ● | ● |
| 8A Muiti Contour Seat Rear Driver Side | ● | ● | ● | ● |
| 8B Adaptive Cruise Control 2 | ● | ● | ● | ● |
| 8C Battery Energy Control Module | ● | ● | ● | ● |
| 8D Muiti Contour Seat Rear Passenger Side | ● | ● | ● | ● |
| 8E Image Processing Electronics | ● | ● | ● | ● |
| 8F Pretensioner Front Left | ● | ● | ● | ● |
| 90 Pretensioner Front Right | ● | ● | ● | ● |
| 91 Engine Control Moudle LT3 | ● | ● | ● | ● |
| 92 Transmission Electronics LT3 | ● | ● | ● | ● |
| 93 Immobilizer LT3 | ● | ● | ● | ● |
| 94 Airbag LT3 | ● | ● | ● | ● |
| 95 Electronic Stability Program LT3 | ● | ● | ● | ● |
| 96 Instruments Cluster LT3 | ● | ● | ● | ● |
| 97 Tachograph LT3 | ● | ● | ● | ● |
| 98 Tire Pressure Monitoring LT3 | ● | ● | ● | ● |
| 99 Electrical Ignition/Starter Switch LT3 | ● | ● | ● | ● |
| 9A Remote Control LT3 | ● | ● | ● | ● |
| 9B Driver's Door Electronics LT3 | ● | ● | ● | ● |
| 9C A/C Electronics LT3 | ● | ● | ● | ● |
| 9D Auxiliary Heater(Fuel)LT3 | ● | ● | ● | ● |
| 9E Auxiliary Heater(Electric)LT3 | ● | ● | ● | ● |
| 9F Additional Heater, Water LT3 | ● | ● | ● | ● |
| A0 Radio 'Audio 5' LT3 | ● | ● | ● | ● |
| A1 Navigation LT3 | ● | ● | ● | ● |
| A2 CD Changer LT3 | ● | ● | ● | ● |
| A3 Telephone LT3 | ● | ● | ● | ● |
| A5 Front Sensors Driver Assistance System | ● | ● | ● | ● |
| A6 Microphone Control Unit | ● | ● | ● | ● |
| A7 Infotainment Interface | ● | ● | ● | ● |
| A9 Actuator for Structure-Borne Sound | ● | ● | ● | ● |
| AC Reductant Control Module | ● | ● | ● | ● |
| AD Sensors Brake Systems | ● | ● | ● | ● |
| B0 Roof Display/Control Head (Roof Control Head) LT3 | ● | ● | ● | ● |
| B1 Upper Operating Field LT3 | ● | ● | ● | ● |

| | | | | |
|---|---|---|---|---|
| B2 Parking Aid LT3 | ● | ● | ● | ● |
| B3 Trailer Function LT3 | ● | ● | ● | ● |
| B4 Vehicle Electrical System Control Module LT3 | ● | ● | ● | ● |
| B5 Programmable Special Module LT3 | ● | ● | ● | ● |
| B6 Steering Column Jacket Switch Module LT3 | ● | ● | ● | ● |
| B7 Access Startsystem Interface | ● | ● | ● | ● |
| B8 Electronic Roof Control 2 | ● | ● | ● | ● |
| B9 Auxiliary Display Conrol Unit | ● | ● | ● | ● |
| BA Assembly Mounting | ● | ● | ● | ● |
| BB Door Electronics Rear Driver Side | ● | ● | ● | ● |
| BC Door Electronics Rear Passenger Side | ● | ● | ● | ● |
| BD High Voltage Battery Charge Management | ● | ● | ● | ● |
| BE Sliding Door Rear Left | ● | ● | ● | ● |
| BF Sliding Door Right | ● | ● | ● | ● |
| C0 Actuator For Exterior Noise | ● | ● | ● | ● |
| C1 Battery regulation LT3 | ● | ● | ● | ● |
| C2 Transmission Control Module 2 | ● | ● | ● | ● |
| C4 DC/DC Converter Control Module | ● | ● | ● | ● |
| C5 Thermal Management | ● | ● | ● | ● |
| C6 Battery Charger Control Module | ● | ● | ● | ● |
| C7 Pedestrian Protection | ● | ● | ● | ● |
| CB Rear Axle Steering | ● | ● | ● | ● |
| D0 Front Axle Lift System | ● | ● | ● | ● |

# VW_V01.35 OIL Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Vehicle | OIL |
|---|---|
| BEETLE | ● |
| BORA | ● |
| CC | ● |
| EOS | ● |
| GOLF | ● |
| JETTA | ● |
| LAVIDA | ● |
| MAGOTAN | ● |
| PASSAT | ● |
| POLO | ● |
| SAGITAR | ● |
| SCIROCCO | ● |
| SHARAN | ● |
| TIGUAN | ● |
| TOUAREG | ● |
| TOURAN | ● |