#### SEAT\_V01.15 Daig Function List (Note:For reference only)

- This function is supported.
- \* This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Model Year
Alhambra I	2001 - 2010
Alhambra II	2011 - 2015
Altea	2004 - 2015
Arosa	2001 - 2004
Cordoba	1999 - 2009
Exeo	2009 - 2014
Ibiza	1999 - 2017
Inca	2001 - 2003
Leon	2000 - 2015
Mii	2012 - 2015
Toledo	1995 - 2010
Toledo	2013 - 2015

Toledo	2013 - 2015				
Systemlist		EcuInfo.	ReadCodes	EraseCodes	LiveData
01 Engine Control Module 1		•	•	•	•
02 Transmission Control Module		•	•	•	•
03 Brake Control Module		•	•	•	•
04 Steering Angle Sender		•	•	•	•
05 Kessy		•	•	•	•
06 Seat Adjustment Passenger Sid	e	•	•	•	•
07 Display Control Unit		•	•	•	•
08 Air Conditioning		•	•	•	•
09 Central Electrics		•	•	•	•
OB Auxiliary Air Heater		•	•	•	•
OC Rear Axle Steering 2		•	•	•	•
OD Sliding Door Left		•	•	•	•
OE Media Player Position 1		•	•	•	•
OF Radio Tuner - Digital		•	•	•	•
10 Parking Assistance 2		•	•	•	•
11 Engine Control Module 2		•	•	•	•
12 Clutch Control Unit		•	•	•	•
13 Adaptive Cruise Control		•	•	•	•
14 Wheel Dampening Electronics		•	•	•	•
15 Airbag		•	•	•	•
16 Steering Column Electronics		•	•	•	•
17 Dash Board		•	•	•	•
18 Auxiliary Parking Heating		•	•	•	•
19 Gateway		•	•	•	•
1B Power-Assisted Steering		•	•	•	•
1C Vehicle Position Detection		•	•	•	•
1D Driver Identification		•	•	•	•
1E Media Player Position 2		•	•	•	•
1F Radio Satellite		•	•	•	•
20 High Beam Assistance		•	•	•	•
21 Battery Energy Control Module	2	•	•	•	•

22 4WD Electronics	•			
23 Brake Boost		•		
24 Drive Slip Control				
25 Immobilizer		•	•	•
26 Electric Roof Control	•	•	•	
27 Display Control Unit Rear		•	•	
28 Climate Control Unit Rear	•	•		
29 Light Control Left	•	•	•	
	•	•	•	
2B Steer Column Locking	•	•	•	
2D Voice Amplifier 2E Media Player Position 3	•			
2F TV Tuner - Digital	•			
30 Special Function 2	•		•	
	•	•	•	
31 Engine Electronics Conjunction	•	•	•	
32 Locking Electroniscs	•	•	•	
34 Self Adjustment Suspension	•	•	•	•
35 Central Locking Control Module	•	•	•	•
36 Seat Adjustment Driver Side	•	•	•	•
37 Navigation	•	•	•	•
38 Roof Electronics	•	•	•	•
39 Light Control Right	•	•	•	•
3A Special Vehicle Assistant	•	•	•	•
3B Sensor Electronics	•	•	•	•
3C Lane Change Assistance System	<u>•</u>	•	•	•
3D Special Function	•	•	•	•
3E Media Player Position 4	•	•	•	•
40 Air Conditioning Compressor	•	•	•	•
41 Diesel Pump Electronics	•	•	•	•
42 Driver-Door Electronics	<u>•</u>	•	•	-
43 Braker Boost Assistance	<u>•</u>	•	•	•
44 Steering Assistance	<u>•</u>	•	•	•
45 Interior Monitoring	•	•	•	•
46 Central Control Module	•	•	•	•
47 Sound System	•	•	•	•
48 Seat Adjustment Rear Driver Side	•	•	•	•
49 Automatic Lighting Switch	•	•	•	•
4B Multifunction Module	•	•	•	•
4C Tyre Pressure Monitor II	•	•	•	•
4E Control Head Rear Right	•	•	•	•
4F Central Electronics II	•	•	•	•
51 Drive Motor Control Module	•	•	•	•
52 Passenger-Door Electronics	•	•	•	•
53 Parking Brake	•	•	•	•
54 Rear Spoiler	•	•	•	•
55 Headlight Range Control	•	•	•	•
56 Radio	•	•	•	•
57 TV-Tuner	•	•	•	•
58 Auxiliary Fuel Tank	•	•	•	•
59 Towing Protection	•	•	•	•
5B Seat Adjustment Rear Passenger Side	•	•	•	•
5C Lane Keeping Assistance System	•	•	•	•

5D Operation	•	•		
5E Control Head Left Rear	•	•	•	•
5F Information Control Unit 1	•	•	•	•
61 Battery Regulation	•	•	•	•
62 Door Electronics Left Rear	•	•	•	•
63 Entry Assistance Driver Side	•	•	•	•
64 Stabilizers	•	•	•	•
65 Tyre Pressure Monitoring I	•	•	•	•
66 Seat/Mirror Adjustment	•	•	•	•
67 Voice Control	•	•	•	•
68 Wiper Control Unit	•	•	•	•
69 Trailer Function	•	•	•	•
6B Aerodynamics Control Module	•	•	•	•
6C Camera System Rear View	•	•	•	•
6D Electronic Equipment of Trunk Lid	•	•	•	•
6E Display Control Roof	•	•	•	•
6F Central Control Module II	•	•	•	•
71 Battery Charger	•	•	•	•
72 Door Electronics Right Rear	•	•	•	•
73 Entry Assistance Passenger Side	•	•	•	•
74 Vehicle Control System	•	•	•	•
75 Telematics Communication Unit	•	•	•	•
76 Parking Assistance	•	•	•	•
77 Telephone	•	•	•	•
78 Sliding Door	•	•		•
7D Auxiliary Heater	•	•	•	•
7E Dash Board Display Unit	•	•	•	•
7F Information Control Unit 2	•	•	•	•
81 Gear Shift Control Module	•	•	•	•
82 Head Up Display	•	•	•	•
84 Night Vision	•	•	•	•
85 On Board-Cammera	•	•	•	•
88 Muiti Contour Seat Driver Side	•	•	•	•
89 Multi Contour Seat Passenger Side	•	•	•	•
8A Muiti Contour Seat Rear Driver Side	•	•	•	•
8B Adaptive Cruise Control 2	•	•	•	•
8C Battery Energy Control Module	•	•	•	•
8D Muiti Contour Seat Rear Passenger Side	•	•	•	•
8E Image Processing Electronics	•	•	•	•
8F Pretensioner Front Left	•	•	•	•
90 Pretensioner Front Right	•	•	•	•
91 Engine Control Moudle LT3	•	•	•	•
92 Transmission Electronics LT3	•	•	•	•
93 Immobilizer LT3	•	•	•	•
94 Airbag LT3	•	•	•	•
95 Electronic Stability Program LT3	•	•	•	•
96 Instruments Cluster LT3	•	•	•	•
97 Tachograph LT3	•	•		•
98 Tire Pressure Monitoring LT3	•	•		•
99 Electrical Ignition/Starter Switch LT3	•	•		•
9A Remote Control LT3	•	•	•	•
OIL NOMOTO COULTED DIO			1 -	_

9B Driver's Door Electronics LT3				
9C A/C Electronics LT3	•	•	•	•
9D Auxiliary Heater(Fuel)LT3	•	•	•	•
9E Auxiliary Heater(Electric)LT3	•	•	•	•
9F Additional Heater, Water LT3	•	•	•	•
AO Radio 'Audio 5' LT3	•	•	•	•
Al Navigation LT3	•	•	•	•
A2 CD Changer LT3	•	•	•	•
A3 Telephone LT3	•	•	•	•
A5 Front Sensors Driver Assistance System	•	•	•	•
A6 Microphone Control Unit	•	•	•	•
A7 Infotainment Interface	•	•	•	•
A9 Actuator for Structure-Borne Sound	•	•	•	•
AC Reductant Control Module	•	•	•	•
AD Sensors Brake Systems	•	•	•	•
BO Roof Display/Control Head (Roof Control Head) LT3	•	•	•	•
B1 Upper Operating Field LT3	•	•	•	•
B2 Parking Aid LT3	•	•	•	•
B3 Trailer Function LT3	•	•	•	•
B4 Vehicle Electrical System Control Module LT3	•	•	•	•
B5 Programmable Special Module LT3	•	•	•	•
B6 Steering Column Jacket Switch Module LT3	•	•	•	•
B7 Access Startsystem Interface	•	•	•	•
B8 Electronic Roof Control 2	•	•	•	•
B9 Auxiliary Display Conrol Unit	•	•	•	•
BA Assembly Mounting	•	•	•	•
BB Door Electronics Rear Driver Side	•	•	•	•
BC Door Electronics Rear Passenger Side	•	•	•	•
BD High Voltage Battery Charge Management	•	•	•	•
BE Sliding Door Rear Left	•	•	•	•
BF Sliding Door Right	•	•	•	•
CO Actuator For Exterior Noise	•	•	•	•
C1 Battery regulation LT3	•	•	•	•
C2 Transmission Control Module 2	•	•	•	•
C4 DC/DC Converter Control Module	•	•	•	•
C5 Thermal Management	•	•	•	•
C6 Battery Charger Control Module	•	•	•	•
C7 Pedestrian Protection	•	•	•	•
CB Rear Axle Steering	•	•	•	•
DO Front Axle Lift System	•	•	•	•

### Seat\_V01.35 BMS Function List (Note:For reference only)

- ullet This function is supported.
- \* This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- lacktriangle This function is the new feature in this version.

Vehicle	BMS
ALHAMBRA	**
ALTEA	**
IBIZA	**
LEON	**
MII	**
TOLEDO	**

SEAT_VO1.35 DPF Function List (Note:For reference only)			
NOTES:			
• This function is suppo	• This function is supported.		
* This function may be supported, which depends on the actual condition of the vehicle.			
O This function is not supported.			
▲ This function is the new feature in this version.			
Vehicle	DPF		
LEON	•		

# SEAT\_V01.35 EPB Function List (Note:For reference only)

- ullet This function is supported.
- \* This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	EPB
ALHAMBRA	*
ALTEA	*
AROSA	*
CORDOBA	*
EXEO	*
IBIZA	*
INCA	*
LEON	*
MII	*
TOLEDO	<b>※</b>

SEAT_VO1.35 ETC Function List (Note:For reference only)		
NOTES:		
• This function is suppo	orted.	
※ This function may be s	supported, which depends on the actual condition of the vehicle.	
O This function is not s	supported.	
▲ This function is the m	new feature in this version.	
Vehicle	ETC	
ALHAMBRA		
ALTEA	•	
AROSA	•	
CORDOBA	•	
EXEO	•	
IBIZA	•	
INCA	•	
LEON	•	
MII	•	
TOLEDO	•	

SEAT_VO1.35 INJ Function List (Note:For reference only)			
NOTES:			
• This function is suppo	• This function is supported.		
* This function may be supported, which depends on the actual condition of the vehicle.			
O This function is not supported.			
▲ This function is the new feature in this version.			
Vehicle	INJ		
LEON	•		

SEAT_V01	.35 OIL Function List (Note:For reference only)
NOTES:	
• This function is suppo	orted.
※ This function may be s	supported, which depends on the actual condition of the vehicle.
O This function is not s	supported.
▲ This function is the m	new feature in this version.
Vehicle	0IL
ALHAMBRA	•
ALTEA	•
AROSA	•
CORDOBA	•
EXEO	•
IBIZA	•
INCA	•
LEON	•
MII	•
TOLEDO	•

# SEAT\_V01.35 SAS Function List (Note:For reference only)

- This function is supported.
- \* This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	SAS
ALHAMBRA	*
ALTEA	*
AROSA	*
CORDOBA	*
EXEO	*
IBIZA	*
INCA	*
LEON	*
MII	*
TOLEDO	*