

[illegible]

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																		
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
2013	P a s s e n g e r	C h e v r o l e t	B	Beat	1.0L(LEB)	CD	CD	CD	CD		CD																							
			C	Spark	1. 0L (LCP)	CD	CD	CD	CD	CD	CD																		CD					
					1. 0L (LMT)	CD	CD	CD	CD	CD	CD																		CD					
					1. 2L (LL0)	CD	CD	CD	CD	CD	CD																		CD					
					1. 2L (L2E)	CD	CD	CD	CD	CD	CD	CD																	CD					
					1. 2L (LKY)	CD	CD	CD	CD	CD	CD	CD																	CD					
					1. 2L (LMU)	CD	CD	CD	CD	CD	CD	CD																	CD					
			F	Camaro	3. 6L (LFX)	CD	CD	CD	CD	CD	CD	CD	CD																CD					
					6. 2L (L99)	CD	CD	CD	CD	CD	CD	CD	CD															CD						
					6. 2L (LS3)	CD	CD	CD	CD	CD	CD	CD	CD															CD						
					6. 2L (LSA)	CD	CD	CD	CD	CD	CD	CD	CD															CD						
			K		[4] 0.8L L3 LBF	CD	CD	CD	CD																									
					[0] 1.0L L4 LA2	CD		CD	CD																									
			J	Sonic	1.2L(LDC)	CD	CD	CD	CD	CD	CD	CD	CD	CD																CD				
					1.3L(LDV)	CD	CD	CD	CD	CD	CD	CD	CD	CD															CD					
					1.3L(LSF)	CD	CD	CD	CD	CD	CD	CD	CD	CD															CD					
					1.4L(LDD)	CD	CD	CD	CD	CD	CD	CD	CD	CD															CD					
					1.4L(LUV)	CD	CD	CD	CD	CD	CD	CD	CD	CD															CD					
					1.6L(LDE)	CD	CD	CD	CD	CD	CD	CD	CD	CD															CD					
					1.6L(LFJ)	CD	CD	CD	CD	CD	CD	CD	CD	CD															CD					
					1.8L(LUW)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD														CD					
					1.8L(LWE)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD														CD					
			M		[3] 3.6L V6 LFX	CD	CD	CD	CD	CD	CD	CD	CD			CD								CD					CD					
					[2] 6.0L V8 L77	CD	CD	CD	CD	CD	CD	CD	CD	CD			CD							CD					CD					
			P	Cruze	1.4L(LDD)	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD									CD				
					1.4L(LUJ)	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD								CD					
					1.4L(LUV)	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD								CD					
					1.6L(L2W)	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD								CD					
					1.6L(LDE)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD					
					1.6L(LXT)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD					
					1.7L(LUD)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD					
					1.8L(2HO)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD					
					1.8L(LFH)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD					
					1.8L(LUW)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD					
					1.8L(LWE)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD					
					2.0L(LNP)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD					
					R	Volt	ECM	CD	CD	CD	CD	CD	CD	CD	CD							CD								CD				
			S		[D] 1.2L L4 LMU	CD		CD	CD									CD																
					[7] 1.4L L4 L95	CD	CD	CD	CD									CD																
					[W] 1.4L L4 LDT	CD	CD	CD	CD	CD								CD																
	[Y] 1.5L L4 LV8	CD		CD	CD	CD	CD								CD																			
T	Aveo	1. 2L (LDC)	CD	CD	CD	CD	CD	CD	CD																		CD							
		1. 2L (LWD)	CD	CD	CD	CD	CD	CD	CD	CD																CD								
		1. 3L (LDV)	CD	CD	CD	CD	CD	CD	CD	CD																CD								
		1. 3L (LSF)	CD	CD	CD	CD	CD	CD	CD	CD																CD								
		1. 4L (L2N)	CD	CD	CD	CD	CD	CD	CD	CD	CD															CD								
		1. 4L (LDD)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD														CD								
		1. 6L (LDE)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD														CD								
		1. 6L (LFJ)	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD														CD								

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS				
	C a r			Other	[D] 1.2L L4 LMU	CD		CD	CD		CD				CD																					
					[7] 1.4L L4 L95	CD	CD	CD	CD		CD				CD																					
					[W] 1.4L L4 LDT	CD	CD	CD	CD		CD				CD																					
					[Y] 1.5L L4 LV8	CD	CD	CD	CD		CD				CD																					
			W		[3] 3.6L V6 LFX	CD	CD	CD	CD	CD	CD	CD		CD					CD						CD				CD							
					[W] 6.2L V8 LS3	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD	CD	CD	CD	CD				CD							
			Y		[T] 6.2L V8 LS9	CD		CD	CD	CD	CD	CD								CD	CD	CD	CD	CD	CD	CD				CD						
					[E] 7.0L V8 LS7	CD		CD	CD	CD	CD	CD								CD	CD	CD	CD	CD	CD	CD				CD						
			Z	Malibu	2.0L(LBN)	CD	CD	CD	CD	CD	CD	CD									CD										CD					
					2.0L(LBS)	CD	CD	CD	CD	CD	CD	CD									CD										CD					
					2.0L(LBY)	CD	CD	CD	CD	CD	CD	CD									CD										CD					
					2.0L(LTD)	CD	CD	CD	CD	CD	CD	CD									CD										CD					
					2.0L(LTG)	CD	CD	CD	CD	CD	CD	CD									CD										CD					
					2.4L(LE9)	CD	CD	CD	CD	CD	CD	CD									CD										CD					
					2.4L(LUK)	CD	CD	CD	CD	CD	CD	CD									CD										CD					
					2.5L(LCV)	CD	CD	CD	CD	CD	CD	CD									CD										CD					
					3.0L(LFW)	CD	CD	CD	CD	CD	CD	CD									CD										CD					
			Other	Onix	1.0L(LKL)	CD	CD	CD	CD	CD	CD	CD																			CD					
					1.4L(LKJ)	CD	CD	CD	CD	CD	CD	CD																			CD					
					1.4L(LKK)	CD	CD	CD	CD	CD	CD	CD																			CD					
				Spin	1.3L(LDV)	CD	CD	CD	CD	CD	CD	CD																				CD				
					1.3L(LSF)	CD	CD	CD	CD	CD	CD	CD																				CD				
					1.8L(LJ1)	CD	CD	CD	CD	CD	CD	CD																				CD				
					1.8L(LMD)	CD	CD	CD	CD	CD	CD	CD																				CD				
				Cobalt	1.3L(LDV)	CD		CD	CD	CD	CD	CD																				CD				
					1.4L(LKF)	CD		CD	CD	CD	CD	CD																				CD				
					1.5L(L2C)	CD	CD	CD	CD	CD	CD	CD	CD																			CD				
					1.8L(LJ1)	CD	CD	CD	CD	CD	CD	CD	CD																			CD				
					1.8L(LMD)	CD	CD	CD	CD	CD	CD	CD	CD																			CD				
				Sail	1.2L(LMU)	CD	CD	CD	CD																											
					1.3L(LDV)	CD	CD	CD	CD																											
					1.4L(LCU)	CD	CD	CD	CD																											
		Buick	Other	Encore	1.4L(LUJ)	CD	CD	CD	CD	CD	CD	CD																		CD						
					1.4L(LUV)	CD	CD	CD	CD	CD	CD	CD																			CD					
		Cad i				[5] 3.0L V6 LFW	CD	CD	CD	CD	CD	CD	CD					CD			CD		CD		CD					CD						
						[3] 3.6L V6 LFX	CD	CD	CD	CD	CD	CD	CD							CD			CD		CD		CD				CD					
						[P] 6.2L V8 LSA	CD	CD	CD	CD	CD	CD	CD							CD			CD		CD		CD				CD					
			Avalanche	[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD	CD	CD						
				[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD								CD					CD	CD				CD	CD	CD					
				[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD					CD	CD	CD			
				[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD										CD				CD	CD					CD	CD	CD			
				[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD										CD				CD	CD					CD	CD	CD			
				[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD										CD				CD	CD					CD	CD	CD			

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
		C 																														

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS						
2013	L D T r k , M P V , I n c o m p l e t e		K	Silverado	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD			CD	CD	CD								
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD								
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD								
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD								
					[8] 6.6L V8 LML Diesel	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD								
				Cheyenne	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD										CD						CD	CD					CD					
					[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD										CD						CD	CD					CD					
					[0]5.3L V8 LMG	CD	CD	CD	CD	CD	CD										CD						CD	CD					CD					
				Silverado Hybrid		CD	CD	CD	CD	CD	CD	CD									CD						CD	CD			CD	CD	CD					
				Suburban	[7]5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD									CD						CD	CD			CD	CD	CD					
					[0]5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD									CD						CD	CD			CD	CD	CD					
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD									CD						CD	CD			CD	CD	CD					
				Tahoe	[0]5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD								CD						CD	CD			CD	CD	CD					
				Tahoe Hybrid		CD	CD	CD	CD	CD	CD	CD	CD								CD						CD	CD			CD	CD	CD					
				L	Captiva	2.0L(LNP)	CD	CD	CD	CD	CD	CD	CD			CD																						
			2.2L(LNQ)			CD	CD	CD	CD	CD	CD	CD			CD																							
			2.4L(LE5)			CD	CD	CD	CD	CD	CD	CD			CD																							
			2.4L(LE9)			CD	CD	CD	CD	CD	CD	CD			CD																							
			3.0L(LFW)			CD	CD	CD	CD	CD	CD	CD			CD																							
			Captiva Sport		[K] 2.4L L4 LEA	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD	CD			CD							
					[5] 3.0L V6 LFW	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD	CD			CD							
			Equinox		2.4L(LEA)	CD	CD	CD	CD	CD	CD	CD	CD								CD										CD							
					3.6L(LFX)	CD	CD	CD	CD	CD	CD	CD	CD								CD										CD							
			P		Orlando	1.4L(LUJ)	CD	CD	CD	CD	CD	CD	CD	CD								CD										CD						
				1.8L(2H0)		CD	CD	CD	CD	CD	CD	CD	CD								CD									CD								
				2.0L(LBN)		CD	CD	CD	CD	CD	CD	CD	CD								CD									CD								
				2.0L(LNP)		CD	CD	CD	CD	CD	CD	CD	CD								CD									CD								
			R		2.4L(LEA)	CD	CD	CD	CD	CD	CD	CD	CD								CD									CD								
					[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD								CD					CD	CD			CD								
					2.4L(LE6)	CD	CD	CD	CD	CD	CD	CD	CD								CD									CD								
					2.5L(LVN)	CD	CD	CD	CD	CD	CD	CD	CD								CD									CD								
			S	Colorado	2.8L(LWH)	CD	CD	CD	CD	CD	CD	CD	CD								CD									CD								
					3.6L(LY7)	CD	CD	CD	CD	CD	CD	CD	CD								CD									CD								
					2.4L(LE6)	CD	CD	CD	CD	CD	CD	CD	CD								CD									CD								
					2.4L(LP8)	CD	CD	CD	CD	CD	CD	CD	CD								CD									CD								
				S10	2.5L(LVN)	CD	CD	CD	CD	CD	CD	CD	CD								CD										CD							
					2.8L(LWH)	CD	CD	CD	CD	CD	CD	CD	CD								CD										CD							
					2.5L(LVN)	CD	CD	CD	CD	CD	CD	CD	CD								CD										CD							
					2.8L(LWH)	CD	CD	CD	CD	CD	CD	CD	CD								CD										CD							
				Trailblazer	2.5L(LVN)	CD	CD	CD	CD	CD	CD	CD	CD								CD										CD							
					2.8L(LWH)	CD	CD	CD	CD	CD	CD	CD	CD								CD										CD							
			V			3.6L(LFX)	CD	CD	CD	CD	CD	CD	CD	CD						CD										CD								
						3.6L(LY7)	CD	CD	CD	CD	CD	CD	CD	CD								CD								CD								
							Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD							CD						CD	CD			CD	CD	CD					
								[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD								CD						CD	CD			CD	CD	CD			
								[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD								CD						CD	CD			CD	CD	CD		
								[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD								CD						CD	CD			CD	CD	CD		
								[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD	CD								CD						CD	CD			CD	CD	CD		
								[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD	CD								CD						CD	CD			CD	CD	CD		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
		G M C T r u c k	1		[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD			CD	CD	CD		
					[8] 6.6L V8 LML Diesel	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD			CD	CD	CD		
				Sierra Hybrid		CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
				Yukon	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
				Yukon Hybrid		CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD		CD		
				Yukon XL	[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
			2	Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[8] 6.6L V8 LML Diesel	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
				Sierra Hybrid		CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
				Yukon	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
				Yukon Hybrid		CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD		CD		
				Yukon XL	[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
			7	Express/Savana	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD				CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD				CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD				CD				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD				CD				
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
				Express Access/Savana Pro	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD				CD				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD				CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD				CD				
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
			8	Express/Savana	[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD				CD				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD				CD				
				Express Access/Savana Pro	[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD								
2013		Buick	R		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD								
			V		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD							
			R		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD							
			V		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD							
		C a d i l	3	Escalade	[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD					
				Escalade		CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD	CD	CD					
			4	Escalade	[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD				
				Escalade		CD	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD				
		Chevrolet MPV		Enjoy	1. 3L (LDV)	CD			CD	CD																										
					1. 4L (LCU)	CD			CD	CD																										
				N300	[A] 1. 2L L4	CD			CD	CD																										
			P	Cruze	2. 0L (LNP)	CD	CD	CD	CD	CD	CD	CD																	CD							
					1. 7L (LUD)	CD	CD	CD	CD	CD	CD	CD																			CD					
					1. 8L (LUW)	CD	CD	CD	CD	CD	CD	CD																				CD				
					1. 8L (LFH)	CD	CD	CD	CD	CD	CD	CD																				CD				
					1. 8L (2H0)	CD	CD	CD	CD	CD	CD	CD																				CD				
					1. 6L (LXV)	CD	CD	CD	CD	CD	CD	CD																				CD				
					1. 6L (LDE)	CD	CD	CD	CD	CD	CD	CD																				CD				
					1. 6L (LXT)	CD	CD	CD	CD	CD	CD	CD																				CD				
					1. 6L (L2W)	CD	CD	CD	CD	CD	CD	CD																				CD				
					1. 4L (LUJ)	CD	CD	CD	CD	CD	CD	CD																				CD				
				F	Camaro	3. 6L (LFX)	CD	CD	CD	CD	CD	CD	CD	CD																		CD				
						6. 2L (L99)	CD	CD	CD	CD	CD	CD	CD																			CD				
						6. 2L (LSA)	CD	CD	CD	CD	CD	CD	CD																			CD				
				C	Spark	1. 0L (LEB)	CD	CD	CD				CD																							
						1. 0L (LCP)	CD	CD	CD				CD																							
				R	Volt		CD	CD	CD	CD	CD	CD	CD	CD																	CD					
				J	Sonic	1. 4L (LDD)	CD	CD	CD	CD	CD	CD	CD																			CD				
						1. 4L (LUV)	CD	CD	CD	CD	CD	CD	CD																			CD				
			1. 6L (LDE)			CD	CD	CD	CD	CD	CD	CD																			CD					
			1. 8L (LUW)			CD	CD	CD	CD	CD	CD	CD																			CD					
			1. 3L (LDV)			CD	CD	CD	CD	CD	CD	CD																			CD					
			1. 3L (LSF)			CD	CD	CD	CD	CD	CD	CD																			CD					
			Other	[U] 2.0L L4 LMN	CD	CD	CD																													
				[7] 1.4L L4 L95	CD			CD																												
				[B]1.8L L4 LDA	CD	CD	CD																													
				[F]1.6L L4 LXT	CD	CD	CD																													
			K		[4] 0.8L L3 LBF	CD	CD	CD																												
					[0] 1.0L L4 LA2	CD			CD																											
			M		[3] 3.6L V6 LFX	CD	CD	CD	CD	CD	CD	CD	CD	CD			CD								CD						CD					
					[2] 6.0L V8 L77	CD	CD	CD	CD	CD	CD	CD	CD	CD			CD								CD						CD					
N		[U] 2.0L L4 LMN	CD	CD	CD																															
		[7] 1.4L L4 L95	CD			CD																														
		[B]1.8L L4 LDA	CD	CD	CD																															
		[F]1.6L L4 LXT	CD	CD	CD																															
	Chevy		[X] 1.6L L4 LLQ	CD	CD																					CD										
			[D] 1.2L L4 LMU	CD			CD	CD							CD																					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
2012	P a s s e n g e r C a r	C h e v r o l e t	S	Aveo	[7] 1.4L L4 L95	CD	CD	CD	CD						CD																	
					[W] 1.4L L4 LDT	CD	CD	CD	CD						CD																	
					[Y] 1.5L L4 LV8	CD	CD	CD	CD						CD																	
					[F] 1.6L L4 LXT	CD	CD	CD	CD						CD																	
			T	Aveo	1. 2L (LDC)	CD	CD	CD		CD	CD	CD																CD				
					1. 2L (LWD)	CD	CD	CD		CD	CD	CD																CD				
					1. 3L (LDV)	CD	CD	CD		CD	CD	CD																CD				
					1. 3L (LSF)	CD	CD	CD		CD	CD	CD																CD				
					1. 4L (LCU)	CD	CD	CD		CD	CD	CD																CD				
					1. 4L (LDD)	CD	CD	CD		CD	CD	CD																CD				
					1. 6L (LDE)	CD	CD	CD		CD	CD	CD																CD				
					1. 6L (LFJ)	CD	CD	CD		CD	CD	CD																CD				
					1. 8L (LUW)	CD	CD	CD		CD	CD	CD																CD				
				Other	[D] 1.2L L4 LMU	CD		CD	CD		CD				CD								CD									
					[7] 1.4L L4 L95	CD	CD	CD	CD		CD				CD								CD									
					[W] 1.4L L4 LDT	CD	CD	CD	CD		CD				CD								CD									
					[Y] 1.5L L4 LV8	CD	CD	CD	CD		CD				CD								CD									
					[F] 1.6L L4 LXT	CD	CD	CD	CD		CD				CD								CD									
			W		[3] 3.6L V6 LFX	CD	CD	CD	CD	CD	CD	CD		CD				CD					CD					CD				
			Y		[W] 6.2L V8 LS3	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD	CD	CD	CD	CD				CD				
					[T] 6.2L V8 LS9	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD	CD	CD	CD				CD				
					[E] 7.0L V8 LS7	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD	CD	CD	CD				CD				
			Z	Malibu	2. 0L (LBN)	CD	CD	CD	CD	CD	CD	CD																CD				
					2. 0L (LBS)	CD	CD	CD	CD	CD	CD	CD																CD				
					2. 0L (LTD)	CD	CD	CD	CD	CD	CD	CD																CD				
					2. 4L (LE9)	CD	CD	CD	CD	CD	CD	CD																CD				
					3. 0L (LFW)	CD	CD	CD	CD	CD	CD	CD																CD				
				Other	[0] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD		CD				CD					CD					CD				
					[1] 2.4L L4 LE5			CD	CD	CD	CD	CD		CD				CD					CD					CD				
					[U] 2.4L L4 LE9	CD	CD	CD	CD	CD	CD	CD		CD				CD					CD					CD				
					[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD		CD				CD					CD					CD				
				Cobalt	1.3L(LDV)	CD	CD	CD		CD	CD	CD																				
					1.3L(LSF)	CD	CD	CD		CD	CD	CD																				
					1.4L(LKF)	CD	CD	CD		CD	CD	CD																				
					1.8L(LJ1)	CD	CD	CD		CD	CD	CD																				
			Sail		1. 19L (LC5)	CD	CD	CD	CD																							
					1. 2L (LMU)	CD	CD	CD	CD																							
					1. 4L (LCU)	CD	CD	CD	CD																							
			Orlando		1.8L(2HO)	CD	CD	CD	CD	CD	CD	CD																CD				
					2.0L(LNP)	CD	CD	CD	CD	CD	CD	CD																CD				
					2.0L(LBN)	CD	CD	CD	CD	CD	CD	CD																CD				
					2.4L(LAF)	CD	CD	CD	CD	CD	CD	CD																CD				
		B u		LaCrosse	2.4L(LAF)	CD	CD	CD	CD	CD	CD	CD																CD				
					2. 4L (LUK)	CD	CD	CD	CD	CD	CD	CD																CD				
					3.0L(LFW)	CD	CD	CD	CD	CD	CD	CD																CD				
					3.6L(LFX)	CD	CD	CD	CD	CD	CD	CD																CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS				
		I c k	G	Regal	2. 4L (LUK)	CD	CD	CD	CD	CD	CD	CD																CD								
					2.0L(LHU)	CD	CD	CD	CD	CD	CD	CD																	CD							
					2.0L(LTD)	CD	CD	CD	CD	CD	CD	CD																		CD						
					2. 4L (LEA)	CD	CD	CD	CD	CD	CD	CD																		CD						
				Verano	2.4L(LEA)	CD	CD	CD	CD	CD	CD	CD																		CD						
		C a d i			[5] 3.0L V6 LFW	CD	CD	CD	CD	CD	CD	CD	CD								CD		CD		CD				CD		CD					
					[3] 3.6L V6 LFX	CD	CD	CD	CD	CD	CD	CD											CD		CD					CD		CD				
					[P] 6.2L V8 LSA	CD	CD	CD	CD	CD	CD	CD											CD		CD					CD		CD				
		Holden	S		[F] 1.6L L4 LXT	CD	CD		CD	CD							CD																			
		2012		C	Avalanche	[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD								CD					CD	CD			CD	CD	CD				
[0] 5.3L V8 LMG	CD					CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD				
Silverado	[X] 4.3L V6 LU3					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
	[A] 4.8L V8 L20					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
	[7] 5.3L V8 LC9					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
	[0] 5.3L V8 LMG					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
	[G] 6.0L V8 L96					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
	[2] 6.2L V8 L9H					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
	[L] 6.6L V8 LGH Diesel					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
	[8] 6.6L V8 LML Diesel					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
Cheyenne	[X] 4.3L V6 LU3					CD	CD	CD	CD	CD	CD											CD					CD	CD					CD			
	[7] 5.3L V8 LC9					CD	CD	CD	CD	CD	CD											CD					CD	CD					CD			
	[0] 5.3L V8 LMG					CD	CD	CD	CD	CD	CD											CD					CD	CD					CD			
Silverado Hybrid						CD	CD	CD	CD	CD	CD											CD					CD	CD			CD	CD	CD			
Suburban	[7] 5.3L V8 LC9					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
	[0] 5.3L V8 LMG					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
	[G] 6.0L V8 L96					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
Tahoe	[0] 5.3L V8 LMG					CD	CD	CD	CD	CD	CD	CD										CD					CD	CD			CD	CD	CD			
Tahoe Hybrid						CD	CD	CD	CD	CD	CD											CD					CD	CD			CD	CD	CD			
G	Express/Savana					[X] 4.3L V6 LU3	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD				
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD				
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD												CD					CD	CD	CD			CD				
	Express Access/Savana Pro				[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD				
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD			CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD			CD				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD			CD				
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD												CD					CD	CD	CD			CD				
	Express/Savana				[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD			CD				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD			CD				
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD			CD				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD			CD				
Express	[A] 4.8L V8 L20				CD	CD	CD	CD	CD	CD											CD					CD	CD	CD			CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
		n e v r o l e t T r u c k	K	Express Access/Sava na Pro	[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
				Avalanche	[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
				Silverado	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[8] 6.6L V8 LML Diesel	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
				Cheyenne	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD						CD		
					[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD							CD					CD	CD						CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD							CD					CD	CD						CD		
				Silverado Hybrid		CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
				Suburban	[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
				Tahoe	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
				Tahoe Hybrid		CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		
	L D T r u c k M P V I n c o		L	Captiva	2.0L(LNP)	CD	CD	CD	CD	CD	CD	CD																				
					2.2L(LNQ)	CD	CD	CD	CD	CD	CD	CD																				
					2.4L(LE5)	CD	CD	CD	CD	CD	CD	CD																				
					2.4L(LE9)	CD	CD	CD	CD	CD	CD	CD																				
					3.0L(LF1)	CD	CD	CD	CD	CD	CD	CD																				
					3.0L(LFW)	CD	CD	CD	CD	CD	CD	CD																				
				Equinox	2. 4L (LEA)	CD	CD	CD	CD	CD	CD	CD																CD				
					3. 0L (LFW)	CD	CD	CD	CD	CD	CD	CD																CD				
				Captiva Sport	[K] 2.4L L4 LEA	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD				CD				
					[5] 3.0L V6 LFW	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD				CD				
				R	[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
				S	Colorado	2.4L(LE6)	CD	CD		CD	CD	CD																				
						2.5L(LVN)	CD	CD		CD	CD	CD																				
						2.8L(LWH)	CD	CD		CD	CD	CD																				
						3.6L(LY7)	CD	CD		CD	CD	CD																				
					Other	[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
				T		[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
				V		[D] 3. 6L V6 LLT	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD	CD	CD		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
2012	m p l e t e	G M C T r u c k	1	Sierra	[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[8] 6.6L V8 LML Diesel	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
				Sierra Hybrid		CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
				Yukon	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
				Yukon Hybrid		CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD		CD		
				Yukon XL	[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
			2	Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[8] 6.6L V8 LML Diesel	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
				Sierra Hybrid		CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
				Yukon	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
				Yukon Hybrid		CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD		CD		
				Yukon XL	[7] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD	CD	CD		
			5		[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD				
					[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD				
					[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD				
			6		[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD				
					[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD				
					[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD				
			Express/Savana		[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD					CD					CD	CD	CD				CD				
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD					CD					CD	CD	CD				CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD					CD					CD	CD	CD				CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD					CD					CD	CD	CD				CD				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD					CD					CD	CD	CD				CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)									
---	--	--	--	--	--	--	--	--	--

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS					
2012			7	Express Access/Sav ana Pro	[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD							CD					CD	CD	CD				CD								
					[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD					
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
			8	Express/Sav ana	[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD					
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
				Express Access/Sava na Pro	[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD				CD				
	L	Terrain	2.4L(LAF)	CD	CD	CD	CD	CD	CD	CD																			CD								
			3.0L(LF1)	CD	CD	CD	CD	CD	CD	CD																			CD								
		R		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD				CD							
		V		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD				CD							
	Buick	R		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD				CD							
		V		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD				CD							
	C a d i l l a c	3	Escalade	[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD	CD								CD					CD	CD				CD	CD	CD					
				[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD				CD	CD	CD					
		Escalade		CD	CD	CD	CD	CD	CD	CD										CD					CD	CD				CD	CD	CD					
				CD	CD	CD	CD	CD	CD	CD										CD					CD	CD				CD	CD	CD					
4		Escalade	[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD				CD	CD	CD					
			[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD				CD	CD	CD					
Escalade			CD	CD	CD	CD	CD	CD	CD										CD					CD	CD				CD	CD	CD						
			CD	CD	CD	CD	CD	CD	CD										CD					CD	CD				CD	CD	CD						
N	SRX	3.0L(LFW)	CD	CD	CD	CD	CD	CD	CD	CD																		CD									
			3.6L(LFX)	CD	CD	CD	CD	CD	CD	CD																		CD									
Chevrolet MPV		N200	[A] 1.2L L4 LAQ	CD		CD																															
		N300	[A] 1.2L L4 LAQ	CD		CD																															
			C	Spark	1.0L (LEB)	CD	CD	CD			CD																										
						1.0L (LCP)	CD	CD	CD			CD																									
			B	Beat	1.0L(LEB)	CD	CD	CD			CD																										
			F	Camaro	3.6L (LLT)	CD	CD	CD	CD		CD																			CD							
						6.2L (L99)	CD	CD	CD	CD		CD																			CD						
						6.2L (LS3)	CD	CD	CD	CD		CD																			CD						
																															CD						
			J		[7] 1.4L L4 L95	CD		CD										CD																			
						[F] 1.6L L4 LXT	CD	CD	CD										CD																		
						[B] 1.8L L4 LDA	CD	CD	CD										CD																		
						[Z] 2.0L L4 L34	CD	CD	CD										CD																		
						[U] 2.0L L4 LMN	CD	CD	CD	CD									CD																		
																			CD																		
			K		[4] 0.8L L3 LBF	CD	CD	CD																													
						[0] 1.0L L4 LA2	CD		CD																												
			L		[F] 2.0L L4 LLU	CD	CD	CD	CD																			CD									
						[K] 2.0L L6 LBM	CD	CD	CD	CD	CD																		CD								
	[L] 2.5L L6 LBK	CD			CD	CD	CD	CD																		CD											
M		[2] 6.0L V8 L77	CD	CD	CD	CD	CD	CD	CD													CD	CD	CD				CD									

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
2011	P a s s e n g e r C a r	C h e v r o l e t	N		[B] 1.8L L4 LDA	CD	CD	CD							CD																	
					[Z] 2.0L L4 L34	CD	CD	CD							CD																	
					[U] 2.0L L4 LMN	CD	CD	CD							CD																	
			P	Cruze	2. 0L (LNP)	CD		CD	CD	CD	CD	CD															CD					
					2. 0L (LLW)	CD		CD	CD	CD	CD	CD															CD					
					1. 8L (LUW)	CD		CD	CD	CD	CD	CD															CD					
					1. 8L (2H0)	CD		CD	CD	CD	CD	CD															CD					
					1. 6L (LXV)	CD		CD	CD	CD	CD	CD															CD					
					1. 6L (LDE)	CD		CD	CD	CD	CD	CD															CD					
					1. 6L (LXT)	CD		CD	CD	CD	CD	CD															CD					
					1. 6L (L2W)	CD		CD	CD	CD	CD	CD															CD					
					1. 4L (LUJ)	CD		CD	CD	CD	CD	CD															CD					
			R	Volt		CD	CD	CD	CD	CD	CD	CD															CD					
			S	Chevy	[X] 1.6L L4 LLQ	CD	CD																			CD						
				Aveo	[D] 1.2L L4 LMU	CD		CD	CD						CD																	
					[7] 1.4L L4 L95	CD	CD	CD	CD						CD																	
					[W] 1.4L L4 LDT	CD	CD	CD	CD						CD																	
					[Y] 1.5L L4 LV8	CD	CD	CD	CD						CD																	
					[E] 1.6L L4 LXV	CD	CD	CD	CD						CD																	
			T		[W] 1. 4L L4 LDT	CD	CD	CD	CD						CD								CD									
					[6] 1.6L L4 LXT	CD	CD	CD	CD						CD								CD									
					[E] 1.6L L4 LXV	CD	CD	CD	CD						CD								CD									
			W		[K] 3.5L V6 LZE	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD				
					[M] 3.9L V6 LGD	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD				
2011			Y		[W] 6.2L V8 LS3	CD	CD	CD	CD	CD	CD	CD				CD		CD	CD	CD	CD	CD	CD					CD				
					[T] 6.2L V8 LS9	CD		CD	CD	CD	CD	CD				CD		CD	CD	CD	CD	CD	CD					CD				
					[E] 7.0L V8 LS7	CD		CD	CD	CD	CD	CD				CD		CD	CD	CD	CD	CD	CD					CD				
			Z		[1] 2. 4L L4 LE5	CD	CD	CD	CD	CD	CD	CD					CD					CD	CD	CD				CD				
					[0] 2. 4L L4 LE9	CD			CD	CD	CD	CD					CD					CD	CD	CD				CD				
					[U] 2. 4L L4 LE9	CD	CD	CD	CD	CD	CD	CD					CD					CD	CD	CD				CD				
					[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD					CD					CD	CD	CD				CD				
				Sail	1. 2L (LMU)	CD	CD	CD	CD																							
					1. 4L (LCU)	CD	CD	CD	CD																							
			B u i c		[M] 3. 9L V6 LGD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD				
					[S] 4.6L V8 L37	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD				
2011				Verano	2.4L(LEA)	CD	CD	CD	CD	CD	CD	CD															CD					
			D	CTS	[Y] 3.0L V6 LF1	CD	CD	CD	CD	CD	CD	CD				CD		CD					CD				CD			CD		
					[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD				CD		CD					CD				CD			CD		
					[P] 6.2L V8 LSA	CD	CD	CD	CD	CD	CD	CD				CD		CD					CD				CD			CD		
			K	STS	[D] 3. 6L V6 LLT	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD	CD	CD	CD	CD				CD			CD		
					[S] 4. 6L V8 L37	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD	CD	CD		CD	CD			CD			CD		CD
					[6] 4.6L V8 LD8	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD	CD	CD		CD	CD			CD			CD		CD
			L		[F] 2.0L L4 LLW	CD	CD	CD	CD																	CD						
					[K] 2.0L L6 LBM	CD	CD	CD	CD																	CD						
					[L] 2.5L L6 LBK	CD	CD	CD	CD																	CD						
			S		[F] 1.6L L4 LXT	CD	CD	CD	CD						CD																	
				HHP	[W] 2.2L L4 LE8	CD	CD	CD	CD	CD	CD				CD			CD					CD				CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS			
	2011	C h e v r o l e t T r u c k	A		[U] 2.4L L4 LE9	CD	CD	CD	CD	CD	CD				CD			CD					CD					CD							
HHR Panel				[W] 2.2L L4 LE8	CD	CD	CD	CD	CD	CD	CD					CD			CD					CD					CD						
C				[U] 2.4L L4 LE9	CD	CD	CD	CD	CD	CD						CD				CD					CD					CD					
			Avalanche	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD								CD	CD					CD	CD				CD		CD			
				[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD								CD	CD					CD	CD				CD		CD			
			Captiva	[R] 2.0L L4 LLW	CD	CD		CD	CD	CD	C	C														CD									
				[U] 2.0L L4 LMN	CD			CD	CD	CD	C	C														CD									
				[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	C	C														CD									
				[1] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	C	C														CD									
				[U] 2.4L L4 LE9	CD	CD	CD	CD	CD	CD	C	C														CD									
				[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	C	C														CD									
			Silverado	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD	CD						CD		
				[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD	CD						CD		
				[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD	CD						CD		
				[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD	CD						CD		
				[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD	CD						CD		
				[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD	CD						CD		
				[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD	CD						CD		
			[8] 6.6L V8 LML Diesel	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD	CD						CD			
			Cheyenne	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD										CD	CD	CD		CD		CD	CD					CD			
Silverado Hybrid				CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD	CD			CD		CD				
Suburban			[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD	CD				CD		CD			
			[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD	CD				CD		CD			
			[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD	CD				CD		CD			
2011			C h e v r o l e t T r u c k	Tahoe	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD	CD			CD		CD			
					Tahoe Hybrid		CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD	CD			CD		CD		
	G	Express/Savana		[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD								
				[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD							
				[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD							
				[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD							
				[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD							
		[L] 6.6L V8 LGH Diesel		CD	CD	CD	CD	CD	CD	CD										CD					CD	CD	CD								
		Express Access/Savana Pro		[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD							
				[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD							
[4] 5.3L V8 LMF				CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD								
[G] 6.0L V8 L96				CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD								
[B] 6.0L V8 LC8	CD			CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD									
H	Express/Savana	[A] 4.8L V8 L20		CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD									
		[4] 5.3L V8 LMF		CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD								
	Express Access/Savana Pro	[G] 6.0L V8 L96		CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD								
		[B] 6.0L V8 LC8		CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD	CD								
	Avalanche	[3] 5.3L V8 LC9		CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD				CD	CD				CD		CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS				
	LD Trk , MPV , Incomple te		K	Avaniche	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD	CD				CD		CD					
				Silverado	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD					
					[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD				
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD				
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD				
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD				
					[8] 6.6L V8 LML Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD				
				Cheyenne	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD	CD				
				Silverado Hybrid		CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD	CD				CD
				Suburban	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD	CD				CD
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD	CD				CD
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD				CD
				Tahoe	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD				CD
			Tahoe Hybrid		CD	CD	CD					CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD				CD	
			L	Captive Sport	[W] 2.4L L4 LAF	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD	CD				CD					
					[Y] 3.0L V6 LF1	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD	CD				CD				
				Equinox	2. 4L (LAF) 3. 0L (LF1)	CD CD	CD CD	CD CD	CD CD	CD CD	CD CD	CD CD	CD CD	CD CD	CD CD															CD CD						
			R		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD						
	S		[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD								
			[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD							
			[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD	CD	CD	CD								CD					CD	CD				CD						
	T		[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD	CD								CD					CD	CD				CD							
			[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD				CD						
			[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD				CD					
	V		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD								
		Tavera	2. 0L (LKM)	CD																																
	1	Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						CD					
			[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						CD				
			[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						CD				
			[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						CD				
			[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						CD				
			[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						CD				
			[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						CD				
			[8] 6.6L V8 LML Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						CD				
		Sierra Hybrid		CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD	CD						CD				
		Yukon	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						CD				
	[F] 6.2L V8 L94		CD	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD	CD						CD				
	Yukon Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						CD					
		[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD	CD						CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
2011		G M C T r u c k	2	Yukon XL	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
				Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[8] 6.6L V8 LML Diesel	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
				Sierra Hybrid		CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
				Yukon	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
				Yukon Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
				Yukon XL	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD	CD						CD		
			5		[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
					[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
					[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
			6		[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
					[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
					[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
			7	Express/Savana	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
				Express Access/Savana Pro	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
			8	Express Savana	[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
			I	Terrain	[B] 6.0L V8 LC8	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD								
					2.4L(LAF)	CD	CD	CD	CD	CD	CD	CD															CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
2011			L	Ferrari	3.0L(LF1)	CD	CD	CD	CD	CD	CD	CD															CD						
			R		[D] 3. 6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD						
			V		[D] 3. 6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD						
		B u i l c k	G	Regal	2.0L(LHU)	CD	CD	CD		CD	CD	CD																CD					
					2.4L(LAF)	CD	CD	CD		CD	CD	CD																CD					
					2.4L(LAF)	CD	CD	CD		CD	CD	CD																CD					
				LaCrosse	3.0L(LF1)	CD	CD	CD		CD	CD	CD																	CD				
					3.6L(LLT)	CD	CD	CD		CD	CD	CD																	CD				
					R		[D] 3. 6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD				
			V		[D] 3. 6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD						CD								CD						
		C a d i l l i a c	3	Escalade	[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD					CD			CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD					CD			CD		
				Escalade		CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD					CD			CD		
			4	Escalade	[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD					CD			CD	
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD					CD			CD	
				Escalade		CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD					CD			CD	
			N	SRX	2. 8L (LAU)	CD	CD	CD	CD	CD	CD	CD	CD																CD				
				3. 0L (LF1)	CD	CD	CD	CD	CD	CD	CD																	CD					
		2011		Chevrolet MPV	U	N200	[A] 1. 2L L4 LAQ	CD		CD																							
				V	N300	[A] 1. 2L L4 LAQ	CD		CD																								
				Opel			[R] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	C											CD		CD						
					[U] 2.0L L4 LMN	CD		CD	CD	CD	CD	C												CD		CD							
					[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	C												CD		CD							
		[1] 2.4L L4 LE5	CD		CD	CD	CD	CD	CD	C												CD		CD									
				[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	C											CD		CD										
2011	Workhors e			6 - W20		CD																											
				6 - W22		CD																											
				A - W24		CD																											
				D - W42	[D] 4.8L V8 L20	CD	CD																										
				G - W62	[E] 6.0L V8 L96	CD																											
2010		A		[X] 2.0L L4 LNF	CD		CD	CD	CD	CD							CD					CD	CD	CD				CD					
				[5] 2.2L L4 LAP	CD	CD	CD	CD	CD	CD								CD					CD	CD	CD				CD				
		F	Camaro	3. 6L (LLT)	CD	CD	CD	CD		CD																			CD				
				6. 2L (L99)	CD	CD	CD	CD		CD																			CD				
				6. 2L (LS3)	CD	CD	CD	CD		CD																			CD				
					[7] 1.4L L4 L95	CD		CD									CD												CD				
		J		[6] 1.6L L4 LXT	CD	CD	CD										CD																
				[B] 1.8L L4 LDA	CD	CD	CD										CD																
				[Z] 2.0L L4 L34	CD	CD	CD										CD																
				[U] 2.0L L4 LMN	CD	CD	CD										CD																
																	CD																
		K			[4] 0.8L L3 LBF	CD	CD	CD																									
					[0] 1.0L L4 LA2	CD		CD																									
L				[F] 2.0L L4 LLU	CD	CD	CD	CD																		CD							
			[K] 2.0L L6 LBM	CD	CD	CD	CD																			CD							
			[L] 2.5L L6 LBK	CD	CD	CD	CD	CD																			CD						
N			[7] 1.4L L4 L95	CD		CD									CD																		
			[6] 1.6L L4 LXT	CD	CD	CD									CD																		
			[B] 1.8L L4 LDA	CD	CD	CD									CD																		
			[Z] 2.0L L4 L34	CD	CD	CD	CD								CD																		
			[U] 2.0L L4 LMN	CD	CD	CD									CD																		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
2010	P a s s e n g e r C a r	C h e v r o l e t	S	Chevy	[X] 1.6L L4 LLQ	CD	CD																			CD								
				Aveo	[D] 1.2L L4 LMU	CD		CD	CD					CD																				
			[7] 1.4L L4 L95		CD	CD	CD	CD					CD																					
			[W] 1.4L L4 LDT		CD	CD	CD	CD						CD																				
			[Y] 1.5L L4 LV8		CD	CD	CD	CD						CD																				
			[6] 1.6L L4 LXT		CD	CD	CD	CD						CD																				
			[E] 1.6L L4 LXV		CD	CD	CD	CD						CD																				
			T		[W] 1.4L L4 LDT	CD	CD	CD	CD								CD								CD									
					[6] 1.6L L4 LXT	CD	CD	CD	CD								CD								CD									
					[E] 1.6L L4 LXV	CD	CD	CD	CD								CD								CD									
			W		[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD				
					[K] 3.5L V6 LZE	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD				
					[M] 3.9L V6 LGD	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD				
			Y			[W] 6.2L V8 LS3	CD	CD	CD	CD	CD	CD	CD						CD		CD	CD	CD	CD	CD	CD					CD	CD		
						[T] 6.2L V8 LS9	CD		CD	CD	CD	CD	CD						CD		CD	CD	CD	CD	CD	CD					CD	CD		
						[E] 7.0L V8 LS7	CD		CD	CD	CD	CD	CD						CD		CD	CD	CD	CD	CD	CD					CD	CD		
				Z	Malibu	[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD								CD					CD	CD				CD			
						[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD								CD					CD	CD				CD			
						[0] 2.4L L4 LE9	CD	CD		CD	CD	CD	CD								CD					CD	CD				CD			
						[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD								CD					CD	CD				CD			
		[K] 3.5L V6 LZE				CD	CD		CD	CD	CD	CD								CD					CD	CD				CD				
		[7] 3.6L V6 LY7			CD	CD	CD	CD	CD	CD	CD								CD					CD	CD				CD					
		Malibu Hybrid			CD	CD	CD	CD	CD	CD									CD					CD	CD				CD					
				Lacetti	1.6L(LXV)	CD	CD	CD	CD	CD	CD	CD																		CD				
					1.8L(2HO)	CD	CD	CD	CD	CD	CD	CD																		CD				
					2.0L(LLW)	CD	CD	CD	CD	CD	CD	CD																			CD			
		C r u z e			1.8L (2HO)	CD		CD	CD	CD	CD																			CD				
					2.0L (LLW)	CD		CD	CD	CD	CD																				CD			
					1.6L (LXV)	CD		CD	CD	CD	CD	CD																			CD			
					1.6L (LDE)	CD		CD	CD	CD	CD	CD																			CD			
					1.6L (LXT)	CD		CD	CD	CD	CD	CD																			CD			
		S a l i s p a b			1.2L (LMU)	CD	CD	CD	CD																									
					1.4L (LCU)	CD	CD	CD	CD																									
					1.0L (LEB)	CD	CD	CD				CD																						
					1.0L (LCP)	CD	CD	CD				CD																						
						1.0L(LEB)	CD	CD	CD			CD																						
		P	T	A		[X] 2.0L L4 LNF	CD		CD	CD	CD	CD	CD							CD				CD	CD	CD				CD				
						[5] 2.2L L4 LAP	CD	CD	CD	CD	CD	CD									CD				CD	CD	CD				CD			
				K		[0] 1.0L L4 LA2	CD			CD	CD																							
				M		[X] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD	CD									CD				CD	CD					CD		
						[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD													CD	CD					CD		
				S		[8] 1.8L L4 LAY	CD	CD	CD	CD	CD	CD	CD					CD				CD					D			CD	CD			
						[0] 2.4L L4 LAX	CD	CD	CD	CD	CD	CD	CD						CD			CD					D			CD	CD			
				G3		[E] 1.6L L4 LXV	CD	CD	CD	CD	CD							CD								CD					C			
						[W] 1.4L L4 LDT	CD	CD	CD	CD	CD								CD								CD				C			

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
2010	on t i a c	Z		Wave	[E] 1.6L L4 LXV	CD	CD	CD	CD						CD								CD									
					[W] 1.4L L4 LDT	CD	CD	CD	CD						CD								CD									
				6 Speed Automatic	[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
								CD	CD	CD	CD	CD						CD					CD	CD				CD				
					[0] 2.4L L4 LE9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
								CD	CD	CD	CD	CD						CD					CD	CD				CD				
					[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
	B u i c k	H			[M] 3.9L V6 LGD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
					[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
					[9] 4.6L V8 L37	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
		G		Allure	2.4L(LAF)	CD	CD	CD		CD	CD																CD					
					3.0L(LF1)	CD	CD	CD		CD	CD																CD					
					3.6L(LLT)	CD	CD	CD		CD	CD																CD					
					2.4L(LAF)	CD	CD	CD		CD	CD	CD															CD					
					3.0L(LF1)	CD	CD	CD		CD	CD	CD															CD					
					3.6L(LLT)	CD	CD	CD		CD	CD	CD															CD					
																											CD					
	C a d i l l i a c	D		CTS	[G] 3.0L V6 LF1	CD	CD	CD	CD	CD	CD	CD											CD				CD		CD	CD	CD	
					[V] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD											CD				CD		CD	CD	CD	
				STS	[P] 6.2L V8 LSA	CD	CD	CD	CD	CD	CD	CD											CD				CD		CD	CD	CD	
					[V] 3.6L V6 LLT	CD	CD	CD	CD		CD	CD						CD	CD	CD	CD	CD	CD				CD		CD	CD	CD	
		K			[A] 4.6L V8 LH2	CD	CD	CD	CD		CD	CD						CD	CD	CD	CD	CD	CD				CD		CD	CD	CD	
						CD	CD	CD	CD	CD	CD	CD						CD	CD	CD	CD		CD	CD			CD		CD	CD	CD	
	S a t u r n	M			[X] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD							CD					CD				CD					
					[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD							CD					CD				CD					
		Z		Aura	[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
					[0] 2.4L L4 LE9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
					[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
				Aura Hybrid	[5] 2.4L L4 LAT			CD	CD	CD	CD	CD						CD					CD	CD				CD				
	H o l d e n	L			[F] 2.0L L4 LLW	CD	CD	CD	CD																	CD						
					[K] 2.0L L6 LBM	CD	CD	CD	CD																	CD						
					[L] 2.5L L6 LBK	CD	CD	CD	CD																	CD						
		N			[B] 1.8L L4 LDA	CD	CD	CD							CD																	
		S			[6] 1.6L L4 LXT	CD	CD	CD	CD						CD																	
				A	HHR	[M] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						[B] 2.2L L4 LE8	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						[V] 2.4L L4 LE9	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
					HHR Panel	[M] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						[B] 2.2L L4 LE8	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
						[V] 2.4L L4 LE9	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
					Avalanche	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD						CD						CD			CD		CD			
						[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD						CD						CD			CD		CD			
					Captiva	[R] 2.0L L4 LLW	CD	CD	CD	CD	CD	C					CD					CD		CD								
						[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	C					CD					CD		CD								

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS			
2010	C	Chevrolet	C		[1] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	C					CD					CD		CD											
					[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	C								CD					CD		CD								
				Silverado	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		
					[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		
					[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		
					[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD								CD		
Silverado Hybrid				[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD			
Suburban				[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD							CD		CD			
				[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD							CD		CD			
				[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD							CD		CD			
				[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD							CD		CD			
Tahoe				[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD							CD		CD			
				[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD							CD		CD			
Tahoe Hybrid				[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD							CD		CD			
G				Express/Savana	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD															CD		CD				CD				
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD														CD		CD				CD				
	[4] 5.3L V8 LMF	CD	CD		CD	CD	CD	CD														CD		CD				CD							
	[G] 6.0L V8 L96	CD	CD		CD	CD	CD	CD														CD		CD				CD							
	[L] 6.6L V8 LGH Diesel	CD	CD		CD	CD	CD	CD														CD		CD				CD							
	[6] 6.6L V8 LMM Diesel	CD	CD		CD	CD	CD	CD														CD		CD				CD							
	Express Access/Savana Pro	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD														CD		CD				CD						
		[A] 4.8L V8 L20	CD		CD	CD	CD	CD	CD														CD		CD				CD						
		[4] 5.3L V8 LMF	CD		CD	CD	CD	CD	CD														CD		CD				CD						
		[G] 6.0L V8 L96	CD		CD	CD	CD	CD	CD														CD		CD				CD						
		[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD														CD		CD				CD							
		[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD														CD		CD				CD							
	Express/Savana	[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD														CD		CD				CD							
		[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD														CD		CD				CD							
		[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD														CD		CD				CD							
		[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD														CD		CD				CD							
	Express Access/Savana Pro	[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD														CD		CD				CD							
		[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD														CD		CD				CD							
	Avalanche	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD									CD										CD		CD					
		[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD									CD										CD		CD					
Silverado	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD									CD					
	[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD									CD					
	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD									CD					
	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD									CD					
	[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD									CD					
	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD									CD					
	[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD									CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
			K		[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD						CD		
				Silverado Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD						CD		
				Suburban	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
				Tahoe	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
				Tahoe Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
			L	Captiva Sport	[V] 2.4L L4 LE9	CD	CD	CD	CD	CD	CD	CD										CD		CD				CD				
					[7] 3.6L V6 LY7			CD	CD	CD	CD	CD										CD		CD				CD				
				Equinox	2. 4L (LAF) 3. 0L (LF1)	CD CD	CD CD	CD CD	CD CD	CD CD	CD CD	CD CD																CD CD				
			R		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD				
			S		[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD				
					[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD				
					[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD				
			T		[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD				
					[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD				
					[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD				
			V		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD				
			C	Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
				Sierra Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
				Yukon	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
				Yukon Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
				Yukon XL	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[F] 6.0L V8 L94	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD			CD				CD		CD		
			D	5 Speed Automatic	[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	C										CD										
						CD		CD	CD	CD	CD	C										CD										
				6 Speed Automatic	[1] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	C										CD										
				5 Speed Automatic	[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	C										CD										

L
D

T
r
i
e

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS						
2010	K M P V · I n c o m p l e t e	G M C T r u c k		Manual		CD	CD	CD	CD	CD	CD	C										CD																
			G	Express/Savana	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD													CD		CD												
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD													CD		CD												
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD													CD		CD												
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD													CD		CD												
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD													CD		CD												
					[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD														CD		CD											
				Express Access/Savana Pro	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD														CD		CD											
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD														CD		CD											
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD														CD		CD											
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD														CD		CD											
					[L] 6.6L V8 LGH Diesel	CD	CD	CD	CD	CD	CD														CD		CD											
					[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD															CD		CD										
			H	Express/Savana	[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD														CD		CD											
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD														CD		CD											
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD														CD		CD											
				Express Access/Savana Pro	[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD														CD		CD										
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD														CD		CD										
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD														CD		CD										
			K	Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD						CD		CD						
					[A] 4.8L V8 L20	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD						CD		CD						
					[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD							CD		CD					
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD								CD		CD				
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD								CD		CD				
					[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		CD			
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		CD			
					[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		CD			
				Sierra Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD								CD		CD				
				Yukon	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		CD			
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD										CD		CD		
					Yukon Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		CD		
			Yukon XL		[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD									CD		CD			
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD										CD		CD		
					[G] 6.0L V8 L96	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD										CD		CD		
[F] 6.0L V8 L94	CD	CD			CD	CD	CD	CD	CD								CD	CD	CD		CD										CD		CD					
[2] 6.2L V8 L9H	CD	CD			CD	CD	CD	CD	CD								CD	CD	CD		CD										CD		CD					
L	Terrain	2.4L(LAF)	CD		CD	CD	CD	CD	CD	CD																					CD							
		3.0L(LF1)	CD		CD	CD	CD	CD	CD	CD																					CD							
R		[D] 3.6L V6 LLT	CD		CD	CD	CD	CD	CD	CD	CD								CD	CD		CD		CD	CD						CD							
S		[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD						CD								
		[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD						CD								
		[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD	CD									CD						CD	CD					CD								
T		[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD									CD					CD	CD						CD								
		[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD									CD						CD	CD					CD								
		[P] 5.3L V8 LH9	CD	CD	CD	CD	CD	CD	CD									CD						CD	CD					CD								
V		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD	CD					CD									

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS				
2010		Buick	R		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD		CD	CD				CD									
			V		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD		CD	CD				CD								
		Cadillac	C	Escalade	[X] 4.3L V6 LU3			CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD						
					[A] 4.8L V8 L20			CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD			
					[3] 5.3L V8 LC9			CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[0] 5.3L V8 LMG			CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[G] 6.0L V8 L96			CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[K] 6.0L V8 LY6			CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[6] 6.6L V8 LMM Diesel			CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
			Escalade		CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD				
			K	Escalade	[X] 4.3L V6 LU3			CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD			
					[A] 4.8L V8 L20			CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD			
					[3] 5.3L V8 LC9			CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[0] 5.3L V8 LMG			CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[G] 6.0L V8 L96			CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[K] 6.0L V8 LY6			CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[F] 6.2L V8 L94	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
					[6] 6.6L V8 LMM Diesel			CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD		
			Escalade		CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD						CD			CD		CD		CD				
			N	SRX	2. 8L (LAU)	CD	CD	CD	CD	CD	CD	CD	CD																CD							
					3. 0L (LF1)	CD	CD	CD	CD	CD	CD	CD	CD	CD															CD							
			Saturn	L		[1] 2.4L L4 LE5	CD	CD	CD		CD	CD	CD							CD						CD	CD			CD						
						CD	CD	CD		CD	CD	CD								CD						CD	CD			CD						
						[7] 3.6L V6 LY7					CD	CD	CD									CD						CD	CD			CD				
						CD	CD	CD		CD	CD	CD										CD						CD	CD			CD				
				R		[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD	CD			CD					
						[D] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD	CD			CD				
		Cadillac Incomplete	Hearse			CD	CD	CD	CD	CD	CD	CD	CD							CD		CD							CD		CD					
					Limousine		CD	CD	CD	CD	CD	CD	CD	CD							CD		CD							CD		CD				
		Chevrolet			[A] 1.2L L4 LAQ	CD																														
		Hummer		Hummer H2	[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD			CD		CD					
								CD	CD	CD	CD	CD	CD	CD							CD	CD		CD		CD	CD			CD		CD				
						CD		CD	CD	CD	CD	CD	CD							CD	CD		CD		CD	CD			CD		CD					
						CD	CD	CD	CD	CD	CD	CD	CD							CD	CD		CD		CD	CD			CD		CD					
Holden		Captiva		CD	CD	CD	CD	CD	CD	CD	CD											CD		CD												
						CD	CD	CD	CD	CD	CD	CD											CD		CD											
						CD	CD	CD	CD	CD	CD	CD											CD		CD											
						CD	CD	CD	CD	CD	CD	CD											CD		CD											
						CD	CD	CD	CD	CD	CD	CD											CD		CD											
						CD	CD	CD	CD	CD	CD	CD											CD		CD											
						CD	CD	CD	CD	CD	CD	CD											CD		CD											
						CD	CD	CD	CD	CD	CD	CD											CD		CD											
			CD	CD	CD	CD	CD	CD	CD											CD		CD														

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
2010					[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD											CD		CD									
						CD		CD	CD	CD	CD	CD												CD		CD								
		Opel			[R] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
						CD		CD	CD	CD	CD	CD	CD											CD		CD								
					[U] 2.0L L4 LMN	CD		CD	CD	CD	CD	CD	CD											CD		CD								
						CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
					[F] 2.4L L4 LD9	CD		CD	CD	CD	CD	CD	CD											CD		CD								
						CD		CD	CD	CD	CD	CD	CD											CD		CD								
					[1] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
						CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
				[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD									
					CD		CD	CD	CD	CD	CD	CD											CD		CD									
		Vauxhall			[R] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
						CD		CD	CD	CD	CD	CD	CD											CD		CD								
					[U] 2.0L L4 LMN	CD		CD	CD	CD	CD	CD	CD											CD		CD								
						CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
					[F] 2.4L L4 LD9	CD		CD	CD	CD	CD	CD	CD											CD		CD								
						CD		CD	CD	CD	CD	CD	CD											CD		CD								
					[1] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
						CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
		[G] 3.2L V6 LU1	CD		CD	CD	CD	CD	CD	CD											CD		CD											
			CD		CD	CD	CD	CD	CD	CD											CD		CD											
2010	Workhorse		6 - W20 Series	[G] 6.0L V8 L96	CD	CD																												
		[G] 8.1L V8 L18		CD	CD																													
			6 - W22 Series	[G] 6.0L V8 L96	CD	CD																												
		[G] 8.1L V8 L18		CD	CD																													
			A - W24 Series	[G] 6.0L V8 L96	CD	CD																												
		[G] 8.1L V8 L18		CD	CD																													
			D - W42 Series	[A] 4.8L V8 L20	CD	CD																												
		[K] 6.0L V8 LY6		CD																														
			E - W16 Series	[G] 6.0L V8 L96		CD																												
		[G] 8.1L V8 L18		CD	CD																													
			E - W18 Series	[G] 6.0L V8 L96		CD																												
		[G] 8.1L V8 L18		CD	CD																													
			F - R26 Series	[G] 6.0L V8 L96	CD	CD																												
		[G] 8.1L V8 L18		CD	CD																													
			G - W62 Series	[G] 6.0L V8 L96	CD	CD																												
		[G] 8.1L V8 L18		CD	CD																													
				A			[X] 2.0L L4 LNF	CD		CD	CD	CD	CD													CD				CD				
							[H] 2.2L L4 LAP	CD	CD	CD	CD	CD	CD	CD												CD				CD				
				J			[7] 1.4L L4 L95	CD		CD	CD							CD										D						
							[6] 1.6L L4 L91	CD	CD	CD	CD							CD										D						
					[6] 1.6L L4 LXT	CD	CD	CD	CD							CD										D								
					[3] 1.8L L4 L79	CD	CD	CD	CD							CD										D								
					[B] 1.8L L4 LDA	CD	CD	CD	CD							CD										D								
					[Z] 2.0L L4 L34	CD	CD	CD	CD							CD										D								
					[U] 2.0L L4 LMN	CD	CD	CD	CD							CD										D								
K	Joy			[4] 0.8L L3 LBF	CD	CD	CD	CD																		D								
				[0] 1.0L L4 LA2	CD		CD	CD																		D								
	Spark			[4] 0.8L L3 LBF	CD	CD	CD	CD																			D							
		[0] 1.0L L4 LA2	CD		CD	CD																			D									

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
2009		C h e v r o l e t	L		[R] 2.0L L4 LLU	CD	CD	CD	CD																D	CD							
					[K] 2.0L L6 LBM	CD	CD	CD	CD																	D	CD						
					[L] 2.5L L6 LBK	CD	CD	CD	CD																		D	CD					
			N		[7] 1.4L L4 L95	CD		CD	CD								CD									D							
					[6] 1.6L L4 L91	CD	CD	CD	CD								CD									D							
					[6] 1.6L L4 LXT	CD	CD	CD	CD								CD									D							
					[3] 1.8L L4 L79	CD	CD	CD	CD								CD									D							
					[B] 1.8L L4 LDA	CD	CD	CD	CD								CD									D							
					[Z] 2.0L L4 L34	CD	CD	CD	CD								CD									D							
					[U] 2.0L L4 LMN	CD	CD	CD	CD								CD									D							
			S	Chevy	[X] 1.6L L4 LLQ	CD	CD																						CD				
				Aveo	[D] 1.2L L4 LMU	CD		CD									CD										D						
					[7] 1.4L L4 L95 India	CD		CD									CD																
					[7] 1.4L L4 L95	CD	CD	CD									CD																
					[W] 1.4L L4 LDT	CD	CD	CD									CD																
					[Y] 1.5L L4 LV8	CD	CD	CD									CD																
			[E] 1.6L L4 LXV	CD	CD	CD									CD																		
			T	Aveo	[7] 1.4L L4 L95 India	CD		CD								CD																	
					[6] 1.6L L4 LXT	CD	CD	CD	CD							CD										D							
					[E] 1.6L L4 LXV	CD	CD	CD	CD		CD					CD										CD	D			C			
W		[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD														CD				CD						
			CD	CD	CD	CD	CD	CD	CD														CD				CD						
		[K] 3.5L V6 LZE	CD	CD	CD	CD	CD	CD	CD															CD				CD					
		[M] 3.9L V6 LGD	CD	CD	CD	CD	CD	CD	CD															CD				CD					
		[C] 5.3L V8 LS4	CD	CD	CD	CD	CD	CD	CD															CD				CD					
Y		[W] 6.2L V8 LS3	CD	CD	CD	CD	CD	CD	CD							CD		CD	CD	CD	CD	CD					CD	CD					
		[W] 6.2L V8 LS3	CD		CD	CD	CD	CD	CD								CD		CD	CD	CD	CD					CD	CD					
		[R] 6.2L V8 LS9	CD		CD	CD	CD	CD	CD								CD		CD	CD	CD	CD					CD	CD					
		[E] 7.0L V8 LS7	CD		CD	CD	CD	CD	CD								CD		CD	CD	CD	CD					CD	CD					
Z	Malibu	[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD														CD				CD						
		CD	CD	CD	CD	CD	CD	CD															CD				CD						
		[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD															CD				CD					
		[K] 3.5L V6 LZE	CD	CD		CD	CD	CD	CD															CD				CD					
	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD															CD				CD						
Malibu Hybrid	[5] 2.4L L4 LAT	CD	CD	CD	CD	CD	CD	CD															CD				CD						
	Lacetti	1.6L(LXV)	CD	CD	CD	CD	CD	CD	CD																		CD						
		1.8L(2HO)	CD	CD	CD	CD	CD	CD	CD																		CD						
		2.0L(LLW)	CD	CD	CD	CD	CD	CD	CD																		CD						
2009	P a s s e n g e r C a r	P o n t i a c	A		[H] 2.2L L4 LAP	CD	CD	CD	CD	CD													CD				CD						
			E		[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD													CD				CD					
					[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD														CD				CD				
					[W] 6.2L V8 LS3	CD	CD	CD	CD	CD	CD														CD				CD				
			K		[4] 0.8L L3 LBF	CD	CD	CD	CD																D								
					[0] 1.0L L4 LA2	CD		CD	CD																	D							
			M		[X] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD	CD												CD				CD					
					[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD														CD				CD				
			S		[8] 1.8L L4 LAY	CD		CD	CD	CD	CD						CD												CD				
					[0] 2.4L L4 LAX	CD	CD	CD	CD	CD	CD							CD											CD				
					[8] 1.8L L4 LV6	CD		CD	CD	CD	CD			CD												CD							

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
2009	S e n t r a l	G e n e r a l	T		[O] 2.4L L4 LAX	CD		CD	CD	CD	CD				CD													CD						
				G3	[E] 1.6L L4 LXV	CD	CD	CD			CD			CD											CD	D			C					
					Wave	[E] 1.6L L4 LXV	CD	CD	CD			CD			CD											CD	D			C				
			Z		[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD	CD																CD					
				With Tap Shift	[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD															CD			CD				
						Without Tap Shift	CD	CD	CD	CD	CD	CD	CD														CD			CD				
						With Tap Shift	CD	CD	CD	CD	CD	CD	CD														CD			CD				
						Without Tap Shift	CD	CD	CD	CD	CD	CD	CD														CD			CD				
					[K] 3.5L V6 LZE	CD	CD	CD	CD	CD	CD	CD	CD																CD					
					[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD																CD					
					[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD																CD					
				H		[M] 3.9L V6 LGD	CD	CD	CD	CD	CD	CD	CD	CD										CD						CD				
			[1] 3.9L V6 LZ9			CD	CD	CD	CD	CD	CD	CD	CD										CD						CD					
			[9] 4.6L V8 L37			CD	CD	CD	CD	CD	CD	CD	CD										CD						CD					
			J			[6] 1.6L L4 L91	CD		CD	CD							CD										D							
	[U] 2.0L L4LMN	CD					CD	CD								CD									D									
	W	Allure			[2] 3.8L V6 L26	CD			CD	CD	CD	CD												CD					CD					
			[C] 5.3L V8 LS4	CD	CD		CD	CD	CD	CD												CD					CD							
		LaCrosse	[2] 3.8L V6 L26	CD			CD	CD	CD	CD	CD												CD					CD						
			[C] 5.3L V8 LS4	CD	CD		CD	CD	CD	CD	CD												CD					CD						
	C a d i l l a c	D	CTS	[T] 2.8L V6 LP1	CD	CD	CD	CD	CD	CD	CD	CD						CD										CD		CD				
				[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD							CD									CD		CD				
				[V] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD	CD	CD							CD										CD		CD			
				[P] 6.2L V8 LSA	CD	CD	CD	CD	CD	CD	CD	CD							CD										CD		CD			
			SLS	[T] 2.8L V6 LP1	CD	CD	CD	CD			CD	CD							CD			CD	CD		CD	CD			CD		CD			
				[7] 3.6L V6 LY7	CD	CD	CD	CD			CD	CD							CD			CD	CD		CD	CD			CD		CD			
				[A] 4.6L V8 LH2	CD	CD	CD	CD				CD	CD						CD			CD	CD		CD	CD			CD		CD			
				STS	[V] 3.6L V6 LLT	CD	CD	CD	CD				CD	CD						CD			CD	CD		CD				CD	CD	CD		
			[D] 4.4L V8 LC3		CD	CD	CD	CD	CD				CD	CD					CD			CD	CD		CD				CD	CD	CD			
			[A] 4.6L V8 LH2		CD	CD	CD	CD				CD	CD						CD			CD	CD		CD				CD	CD	CD			
			K				CD	CD	CD	CD		CD	CD								CD	CD	CD						CD		CD			
			Y		[D] 4.4L V8 LC3	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD	CD		CD					CD		CD		
		[A] 4.6L V8 LH2			CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD	CD		CD					CD		CD			
		S a t u r n	M		[X] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD	CD												CD				CD						
	[B] 2.4L L4 LE5				CD	CD	CD	CD	CD	CD														CD			CD							
	Z		Aura	[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD								CD								CD							
				[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD															CD							
			Aura Hybrid	[5] 2.4L L4 LAT	CD	CD	CD	CD	CD	CD	CD																	CD						
	H o l d e n	L		[R] 2.0L L4 LLW	CD	CD	CD	CD																		CD								
				[K] 2.0L L6 LBM	CD	CD	CD	CD																			CD							
				[L] 2.5L L6 LBK	CD	CD	CD	CD																				CD						
N			[B] 1.8L L4 LDA	CD	CD	CD	CD																D											
S			[6] 1.6L L4 LXT	CD	CD	CD	CD																	D										
			HHR	[X] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD							CD									CD								
				[B] 2.2L L4 LE8	CD	CD	CD	CD	CD	CD																	CD							
				[V] 2.4L L4 LE9	CD	CD	CD	CD	CD	CD																		CD						

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
2009			A	HHR Panel	[X] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD						CD						CD				CD					
					[B] 2.2L L4 LE8	CD	CD	CD	CD	CD	CD						CD						CD				CD					
					[V] 2.4L L4 LE9	CD	CD	CD	CD	CD	CD						CD						CD				CD					
				HHR (Europe)		CD	CD	CD	CD	CD	CD																CD					
			C	Avalanche	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
						CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
						CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
					[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
						CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
					[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
						CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
				Captiva	[R] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	C										CD		CD								
					[U] 2.0L L4 LMN	CD		CD	CD	CD	CD	C										CD		CD								
					[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	C										CD		CD								
					[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	C										CD		CD								
				Silverado	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
					[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
					[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
					[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
						CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
					[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
						CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
					[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
				Silverado Hybrid	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
					[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD						CD			
					[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
					[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
					[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
				Suburban	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
					[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
					[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
						CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
				Tahoe	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
						CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
						CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
				Tahoe Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD				CD		CD			
				Express/Savana	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD											CD		CD			CD					
					[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD											CD		CD			CD					
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD											CD		CD			CD					
					[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD											CD		CD			CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS				
2009		Chevrolet Truck	G		[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD											CD		CD				CD								
					Express Access/Savana Pro	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD													CD		CD				CD					
						[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD														CD		CD				CD				
						[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD														CD		CD				CD				
						[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD														CD		CD				CD				
				[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD															CD		CD				CD					
				H	Express/Savana	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD													CD		CD				CD				
						[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD													CD		CD				CD				
						[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD													CD		CD				CD				
						[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD														CD		CD				CD				
Express Access/Savana Pro			[X] 4.3L V6 LU3		CD	CD	CD	CD	CD	CD	CD	CD													CD		CD				CD					
[C] 4.8L V8 LY2			CD	CD	CD	CD	CD	CD	CD	CD													CD		CD				CD							
[4] 5.3L V8 LMF			CD	CD	CD	CD	CD	CD	CD	CD													CD		CD				CD							
[K] 6.0L V8 LY6			CD	CD	CD	CD	CD	CD	CD														CD		CD				CD							
K			Avalanche		[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD							CD				CD		CD				CD			CD			
						CD	CD	CD	CD	CD	CD	CD	CD								CD				CD		CD				CD			CD		
					[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD									CD				CD		CD				CD			CD	
						CD	CD	CD	CD	CD	CD	CD	CD									CD				CD		CD				CD			CD	
				[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD								CD				CD		CD				CD			CD		
					CD	CD	CD	CD	CD	CD	CD	CD	CD								CD				CD		CD				CD			CD		
	[Y] 6.0L V8 L76	CD			CD	CD	CD	CD	CD	CD	CD	CD								CD				CD		CD				CD			CD			
		CD			CD	CD	CD	CD	CD	CD	CD	CD								CD				CD		CD				CD			CD			
		Silverado	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD		CD		CD		CD						CD				
				CD	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD	CD		CD		CD						CD				
	CD			CD	CD	CD	CD	CD	CD	CD								CD	CD	CD	CD		CD		CD						CD					
	CD			CD	CD	CD	CD	CD	CD	CD								CD	CD	CD	CD		CD		CD						CD					
	[3] 5.3L V8 LC9		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD						CD				
			CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD	CD		CD		CD						CD				
			[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD						CD			
				CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD	CD		CD		CD						CD			
	[J] 5.3L V8 LY5	CD		CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD						CD				
		CD		CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD						CD				
		[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD						CD				
			CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD	CD		CD		CD						CD				
[K] 6.0L V8 LY6	CD		CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD						CD					
	CD		CD	CD	CD	CD	CD	CD	CD									CD	CD	CD	CD		CD		CD						CD					
	[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD						CD					
		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD						CD					
[6] 6.6L V8 LMM Diesel		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD						CD					
		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD						CD					
	Silverado Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD					
			CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD					
CD			CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
CD			CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
[3] 5.3L V8 LC9		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
		[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD					
			CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD					
[J] 5.3L V8 LY5	CD		CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
	CD		CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
[K] 6.0L V8 LY6		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
	[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
[6] 6.6L V8 LMM Diesel		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
	Tahoe	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
			CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
CD			CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD							
CD			CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD							
[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD							
	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD							
	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
[J] 5.3L V8 LY5		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						
		CD	CD	CD	CD	CD	CD	CD	CD									CD	CD		CD		CD		CD					CD						

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS						
2009	LD Trk · MPV · Inc omple te			Equinox	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD						CD				CD		CD				CD										
			R			CD	CD	CD	CD	CD	CD	CD							CD	CD		CD		CD				CD										
			S	Colorado	[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD								CD						CD				CD									
					[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD									CD						CD				CD								
					[L] 5.3L V8 LH8	CD	CD	CD	CD	CD	CD									CD						CD				CD								
				TrailBlazer	[S] 4.2L L6 LL8	CD	CD	CD	CD	CD	CD	CD								CD	CD		CD			CD				CD	CD							
					[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD								CD	CD		CD			CD				CD	CD							
					[H] 6.0L V8 LS2	CD	CD	CD	CD	CD	CD	CD								CD	CD		CD			CD				CD	CD							
			T	Colorado	[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD									CD						CD				CD							
					[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD										CD						CD				CD							
					[L] 5.3L V8 LH8	CD	CD	CD	CD	CD	CD										CD						CD				CD							
				TrailBlazer	[S] 4.2L L6 LL8	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD		CD			CD				CD	CD						
					[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD		CD			CD				CD	CD						
					[H] 6.0L V8 LS2	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD		CD			CD				CD	CD						
			V				CD	CD	CD	CD	CD	CD	CD							CD	CD		CD			CD				CD								
2009	LD Trk · MPV · Inc omple te	C	Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD						CD								
				[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD						CD						
				[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD										CD	CD	CD		CD		CD						CD					
				[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD						CD					
				[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD						CD					
					CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD				
				[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD						CD					
					CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD				
					CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD				
				[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD				
				[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD				
				[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD				
			[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD					
			Sierra Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD	CD								CD	CD	CD		CD		CD							CD					
			Yukon	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD					CD		CD				
				[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD					CD		CD				
				[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD						CD		CD			
					CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD		CD		
				[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD		CD		
					CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD		CD		
			[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD		CD			
			Yukon Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD						CD		CD			
			Yukon XL	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD						CD		CD			
				[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD		CD		
				[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD		CD		
				[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD		CD		
				[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD		CD		
				[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD									CD	CD	CD		CD		CD							CD		CD		
D	5 Speed Automatic	[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	CD	CD												CD		CD														
	Manual		CD		CD	CD	CD	CD	CD	CD												CD		CD														

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
2009		G M C T r u c k	C	5 Speed Automatic	[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD										CD		CD										
				Manual		CD		CD	CD	CD	CD	CD											CD		CD									
			G	Express/Savana	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
					[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
					[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
					[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
				Express Access/Savana Pro	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
					[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
			H	Express/Savana	[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
					[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
									CD	CD	CD	CD	CD	CD											CD		CD							
				Express Access/Savana Pro	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
					[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
					[4] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD										CD		CD							
					[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD										CD		CD							
			K	Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD							CD	
					[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD							CD	
[3] 5.3L V8 LC9	CD	CD			CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD							CD				
[M] 5.3L V8 LH6	CD	CD			CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD							CD				
	CD	CD			CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD							CD				
	CD	CD			CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD						CD				
[J] 5.3L V8 LY5	CD	CD			CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD					CD					
	CD	CD			CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD					CD					
[Y] 6.0L V8 L76	CD	CD			CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD						CD				
[K] 6.0L V8 LY6	CD	CD		CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD						CD					
[2] 6.2L V8 L9H	CD	CD		CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD						CD					
[6] 6.6L V8 LMM Diesel	CD	CD		CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD						CD					
Sierra Hybrid	[5] 6.0L V8 LFA	CD		CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD						CD					
Yukon	[C] 4.8L V8 LY2	CD		CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD				CD		CD				
	[3] 5.3L V8 LC9	CD		CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD				CD		CD				
	[0] 5.3L V8 LMG	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD				CD		CD				
		CD		CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD				CD		CD				
	[J] 5.3L V8 LY5	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD				CD		CD				
		CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD				CD		CD					
[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD				CD		CD						
Yukon Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD				CD		CD					
	Yukon XL	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD				CD		CD				
		[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD		CD				CD		CD				
		[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD				CD		CD				
		[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD		CD				CD		CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
2009					[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD				CD		CD					
					[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD		CD		CD				CD		CD				
			R			CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD						CD		CD				
			S	Canyon	[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD							CD						CD				CD					
					[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD							CD						CD				CD					
					[L] 5.3L V8 LH8	CD	CD	CD	CD	CD	CD	CD							CD						CD				CD					
				Envoy	[S] 4.2L L6 LL8	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD			CD	CD				
					[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD			CD	CD				
			T	Canyon	[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD	CD							CD										CD				
					[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD								CD										CD				
					[L] 5.3L V8 LH8	CD	CD	CD	CD	CD	CD	CD								CD										CD				
				Envoy	[S] 4.2L L6 LL8	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD		CD			CD			CD				
			[M] 5.3L V8 LH6		CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD		CD			CD			CD					
			V					CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD			CD					
			B u t	R				CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD			CD					
			V					CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD			CD					
		C a d i l l a c	C	Escalade	[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD			CD			CD		CD			
				Escalade Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD					CD		CD			
				Powertrain	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD	CD				CD		CD			
					[A] 4.6L V8 LH2	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD	CD				CD		CD		
			K	Escalade	[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD			CD			CD		CD		
				Escalade Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD	CD		CD			CD			CD		CD		
		S a t u r n	L	VUE	[P] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD				CD					
					[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD	CD								CD					CD				CD				
					[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD								CD					CD				CD				
						CD	CD	CD	CD	CD	CD	CD	CD								CD					CD				CD				
				VUE Hybrid	[Z] 2.4L L4 LAT				CD	CD	CD	CD	CD								CD					CD				CD				
					[B] 3.6L V6 LCS	CD	CD	CD	CD	CD	CD	CD	CD	CD								CD					CD				CD			
			R				CD	CD	CD	CD	CD	CD	CD							CD	CD		CD			CD			CD					
			V				CD	CD	CD	CD	CD	CD	CD							CD	CD		CD			CD			CD					
Cadillac Incompleta	Hearse				CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD					CD		CD						
	Limousine				CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD					CD		CD						
P o n t i a c	L		[F] 3.4L V6 LN3	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD				CD							
				CD	CD	CD	CD	CD	CD	CD								CD					CD				CD							
			[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD								CD					CD				CD						
				CD	CD	CD	CD	CD	CD	CD									CD					CD				CD						
	U		[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD							CD				CD					CD							
V		[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD							CD				CD					CD								
Chevrolet MPV	U		[1] 3.9L V6 LZ9	CD		CD	CD	CD	CD	CD							CD				CD						CD							
	V		[1] 3.9L V6 LZ9	CD		CD	CD	CD	CD	CD								CD				CD					CD							
Hummer		Hummer H2	[2] 6.2L V8 L9H	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD		CD			CD			CD							
		Hummer H3	[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD								CD						CD				CD	CD					
				CD		CD	CD	CD	CD								CD						CD				CD	CD						
			[L] 5.3L V8 LH8	CD	CD	CD	CD	CD	CD									CD						CD				CD						
					CD	CD	CD	CD	CD								CD						CD				CD							
				[S] 4.2L L6 LL8	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD				CD	CD						

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS			
2009		SAAB			[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD				CD	CD						
					[H] 6.0L V8 LS2	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD				CD	CD					
		Holden	Captiva		[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	C											CD		CD										
						CD		CD	CD	CD	CD	C												CD		CD									
						CD	CD	CD	CD	CD	CD	C												CD		CD									
						CD		CD	CD	CD	CD	C												CD		CD									
				Captiva Maxx	[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	C												CD		CD									
						CD		CD	CD	CD	CD	C												CD		CD									
		Opel			[R] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	CD	C											CD		CD									
						CD		CD	CD	CD	CD	C												CD		CD									
					[U] 2.0L L4 LMN	CD		CD	CD	CD	CD	CD	C											CD		CD									
						CD	CD	CD	CD	CD	CD	CD	C											CD		CD									
					[F] 2.4L L4 LD9	CD		CD	CD	CD	CD	CD	C											CD		CD									
						CD		CD	CD	CD	CD	CD	C											CD		CD									
					[P] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	C											CD		CD									
						CD		CD	CD	CD	CD	CD	C											CD		CD									
		Vauxhall				[R] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	CD	C										CD		CD									
							CD		CD	CD	CD	CD	CD	C										CD		CD									
					[U] 2.0L L4 LMN	CD		CD	CD	CD	CD	CD	C											CD		CD									
						CD	CD	CD	CD	CD	CD	CD	C											CD		CD									
						CD		CD	CD	CD	CD	CD	C											CD		CD									
						CD	CD	CD	CD	CD	CD	CD	CD	C										CD		CD									
					[P] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	CD	C										CD		CD									
					CD		CD	CD	CD	CD	CD	CD	C										CD		CD										
		Medium Dut	Chevrolet Truck				[k] 6.0L V8 LY6	CD	CD																										
					C-WT5500	[9] 6.6L V8 LMM Diesel	CD	CD																											
							CD																												
							[G] 8.1L V8 L18	CD	CD																										
						CD																													
				T-B7 Chassis	[k] 6.0L V8 LY6	CD	CD	CD																											
						[9] 6.6L V8 LMM Diesel	CD	CD	CD																										
						[G] 8.1L V8 L18	CD	CD	CD																										
						CD		CD																											
				D-C Series	[k] 6.0L V8 LY6	CD	CD	CD	CD				CD																	CD					
						[9] 6.6L V8 LMM Diesel	CD	CD	CD	CD				CD																	CD				
						[G] 8.1L V8 L18	CD	CD	CD	CD				CD																	CD				
					CD		CD	CD				CD																	CD						
	C-T Series			[k] 6.0L V8 LY6	CD	CD	CD					CD																							
					[9] 6.6L V8 LMM Diesel	CD	CD	CD					CD																						
					[G] 8.1L V8 L18	CD	CD	CD					CD																						
					CD		CD					CD																							
	B-W4 Series			[k] 6.0L V8 LY6	CD	CD	CD																												
				[9] 6.6L V8 LMM Diesel	CD	CD	CD																												
				[G] 8.1L V8 L18	CD	CD	CD																												
				CD		CD																													
						[k] 6.0L V8 LY6	CD	CD																											

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
2009	y T r u c k	G M C T r u c k		C-WT5500	[9] 6.6L V8 LMM Diesel	CD	CD																											
					[G] 8.1L V8 L18	CD	CD																											
							CD																											
				T-B7 Chassis	[k] 6.0L V8 LY6	CD	CD	CD																										
					[9] 6.6L V8 LMM Diesel	CD	CD	CD																										
						CD	CD	CD																										
					[G] 8.1L V8 L18	CD		CD																										
						CD		CD																										
								CD			CD																							
				D-C Series	[k] 6.0L V8 LY6	CD		CD	CD		CD																			CD				
					[9] 6.6L V8 LMM Diesel	CD	CD	CD	CD		CD																			CD				
						CD	CD	CD	CD		CD																			CD				
					[G] 8.1L V8 L18	CD		CD	CD		CD																			CD				
				C-T Series	[k] 6.0L V8 LY6	CD	CD	CD				CD																						
					[9] 6.6L V8 LMM Diesel	CD	CD	CD				CD																						
						CD	CD	CD				CD																						
					[G] 8.1L V8 L18	CD		CD				CD																			CD			
				B-W4 Series	[k] 6.0L V8 LY6	CD	CD	CD																										
					[9] 6.6L V8 LMM Diesel	CD	CD	CD																										
						CD	CD	CD																										
					[G] 8.1L V8 L18	CD		CD																							CD			
	W o r k h o r s e			6-W20 Series	[G] 8.1L V8 L18	CD	CD																											
				6-W22 Series	[G] 8.1L V8 L18	CD	CD																											
				A-W24 Series	[G] 8.1L V8 L18	CD	CD																											
				D-W42 Series	[8] 4.8L V8 LY2	CD	CD																											
					[7] 6.0L V8 LY6	CD	CD																											
				E-W16 Series	[G] 8.1L V8 L18	CD																												
				E-W18 Series	[G] 8.1L V8 L18	CD																												
				F-R26 Series	[G] 8.1L V8 L18	CD	CD																											
				G-W62 Series	[G] 8.1L V8 L18	CD	CD																											
2008			A (VIN 4th)	COBALTA	[X]2.0L L4 LNF	CD		CD	CD	CD		CD					CD					CD	CD				CD							
2008					[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD		CD					CD					CD	CD				CD						
2008					[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD		CD					CD					CD	CD				CD						
2008			J (VIN 4th)		[Z] 2.0L L4 L34	CD	CD	CD	CD						CD												S16							
			K (VIN 4th)		[4] 0.8L L3 LBF	CD	CD	CD	CD																			S16						
					[0] 1.0L L4 L11	CD		CD	CD																			S16						
			L (VIN 4th)		[R] 2.0L L4 LLW	CD	CD	CD	CD																		CD							
					[K] 2.0L L6 LBM	CD	CD	CD	CD																		CD							
					[L] 2.5L L6 LBK	CD	CD	CD	CD																		CD							
						CD	CD	CD	CD																									
						[7] 1.4L L4 L95	CD	CD	CD	CD						CD												S16						
						[6] 1.6L L4 L91	CD	CD	CD	CD						CD												S16						

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS					
	P a s s e n g e r	C h e v r o l e t	N (VIN 4th)		[6] 1.6L L4 LXT	CD	CD	CD	CD						CD												S16										
					[3] 1.8L L4 L79	CD	CD	CD	CD								CD												S16								
					[B] 1.8L L4 LDA	CD	CD	CD	CD								CD													S16							
					[Z] 2.0L L4 L34	CD	CD	CD	CD								CD													S16							
					[D] 2.0L L4 LMN	CD	CD	CD	CD	CD							CD													S16							
					[U] 2.0L L4 LMN	CD	CD	CD	CD	CD							CD													S16							
				S (VIN 4th)	Chevy	[X] 1.6L L4 LLQ	CD	CD																					S16								
						[D] 1.2L L4 LMU	CD			CD	CD							CD													S16						
					Aveo	[T] 1.2L L4 LY4	CD	CD	CD	CD	CD							CD													S16						
						[7] 1.4L L4 L95 India	CD	CD	CD	CD	CD							CD													S16						
						[7] 1.4L L4 L95	CD	CD	CD	CD	CD							CD													S16						
						[W] 1.4L L4 LDT	CD	CD	CD	CD	CD							CD													S16						
						[Y] 1.5L L4 LV8	CD	CD	CD	CD	CD							CD													S16						
						[6] 1.6L L4 L91 India	CD	CD	CD	CD	CD							CD													S16						
						[D] 1.2L L4 LMU	CD			CD	CD							CD													S16						
						[T] 1.2L L4 LY4	CD	CD		CD	CD							CD													S16						
				T (VIN 4th)	[7] 1.4L L4 L95 India	CD	CD	CD	CD								CD													S16							
					[W] 1.4L L4 LDT	CD	CD	CD	CD	CD							CD													S16							
					[6] 1.6L L4 L91	CD	CD	CD	CD	CD							CD													S16							
					[6] 1.6L L4 L91 India	CD	CD	CD	CD	CD							CD													S16							
					[6] 1.6L L4 LXT	CD	CD	CD	CD	CD							CD													S16							
					[6] 1.6L L4 L91	CD			CD	CD																				S16							
				U (VIN 4th)		[6] 1.6L L4 L91	CD			CD	CD																			S16							
						[6] 1.6L L4 LXT	CD			CD	CD																			S16							
					[Z] 2.0L L4 L34	CD	CD	CD	CD	CD																			S16								
					[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD						CD			CD								
			W (VIN 4th)		[K] 3.5L V6 LZE	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD						CD				CD								
					[3] 3.9L V6 LZG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD					CD				CD								
					[C] 5.3L V8 LS4	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD					CD				CD								
			Y (VIN 4th)			CD	CD	CD	CD	CD	CD	CD	CD	CD				CD	CD	CD	CD	CD	CD	CD	CD				CD	CD							
			Z (VIN 4th)	Classic	[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD						CD				CD								
					[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD			CD							
				Malibu	[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD			CD							
						[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD			CD						
						[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD			CD						
					Malibu Hybrid	[5] 2.4L L4 LAT	CD	CD		CD	CD	CD	CD	CD						CD						CD	CD			CD							
2008			P o n t i a c	A (VIN 4th)		[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD							CD						CD	CD			CD								
						[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD	CD						CD							CD	CD			CD						
					E (VIN 4th)	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	CD												CD	CD			CD						
						[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD												CD	CD			CD					
				M (VIN 4th)	[X] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD							
						[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD						
				S (VIN 4th)		[8] 1.8L L4 LV6	CD			CD	CD						CD			CD						CD				D	CD						
					G3	[T] 1.2L L4 LY4	CD	CD	CD	CD	CD							CD													S16						
							[W] 1.4L L4 LDT	CD	CD	CD	CD	CD							CD													S16					
							[6] 1.6L L4 L91	CD	CD	CD	CD	CD							CD													S16					
							[6] 1.6L L4 LXT	CD	CD	CD	CD	CD							CD													S16					
							Wave	[T] 1.2L L4 LY4	CD	CD	CD	CD	CD						CD													S16					
						Wave	[6] 1.6L L4 L91	CD	CD	CD	CD	CD						CD													S16						
						Wave	[6] 1.6L L4 LXT	CD	CD	CD	CD	CD						CD													S16						
		W (VIN 4th)			[2] 3.8L V6 L26	CD	D		CD	CD	CD	CD	CD	CD					CD					CD	CD				CD	CD							

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
			Z (VIN 4th)		[C] 5.3L V8 LS4	CD	CD	CD	CD	CD	CD	CD						CD				CD	CD				CD	CD				
					[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD			CD					
					[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD			CD					
					[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD			CD					
					[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD			CD					
2008			B U I C K	H (VIN 4th)		[2] 3.8L V6 L26	CD	D	CD	CD	CD	CD						CD						CD			CD					
						[9] 4.6L V8 L37	CD	CD	CD	CD	CD	CD						CD						CD			CD					
						[Y] 4.6L V8 LD8	CD	CD	CD	CD	CD	CD						CD						CD			CD					
				J (VIN 4th)		[6] 1.6L L4 L91	CD	CD	CD	CD					CD											S16						
						[3] 1.8L L4 LDA	CD	CD	CD	CD					CD											S16						
						[U] 2.0L L4 LMN	CD	CD	CD	CD					CD											S16						
				W (VIN 4th)	Allure	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD						CD				CD	CD				CD					
					Allure	[2] 3.8L V6 L26	CD	D	CD	CD	CD	CD						CD				CD	CD				CD					
					Allure	[C] 5.3L V8 LS4	CD	CD	CD	CD	CD	CD						CD				CD	CD				CD					
					LaCrosse	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD						CD				CD	CD				CD					
					LaCrosse	[2] 3.8L V6 L26	CD	D	CD	CD	CD	CD						CD				CD	CD				CD					
					LaCrosse	[C] 5.3L V8 LS4	CD	CD	CD	CD	CD	CD						CD				CD	CD				CD					
			C a d i l l a c	D (VIN 4th)	CTS	[T] 2.8L V6 LP1	CD	CD	CD	CD	CD	CD															CD					
					CTS	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD															CD					
					CTS	[V] 3.6L V6 LLT	CD	CD	CD	CD	CD	CD															CD					
					SLS	[T] 2.8L V6 LP1	CD	CD	CD	CD		CD	CD				CD	CD	CD	CD	CD	CD					CD			CD		
					SLS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD	CD				CD	CD	CD	CD	CD	CD					CD			CD		
					SLS	[A] 4.6L V8 LH2	CD	CD	CD	CD		CD	CD				CD	CD	CD	CD	CD	CD					CD			CD		
					STS	[V] 3.6L V6 LLT	CD	CD	CD	CD		CD	CD				CD	CD	CD	CD	CD	CD	CD				CD	CD	CD			
					STS	[D] 4.4L V8 LC3	CD	CD	CD	CD		CD	CD				CD	CD	CD	CD	CD	CD	CD				CD	CD	CD			
				K (VIN 4th)			CD	CD	CD	CD	CD	CD						CD	CD	CD	CD			CD			CD			CD		
				Y (VIN 4th)		[D] 4.4L V8 LC3	CD	CD	CD	CD	CD	CD					CD	CD	CD	CD	CD	CD	CD				CD	CD	CD			
						[A] 4.6L V8 LH2	CD	CD	CD	CD	CD	CD					CD	CD	CD	CD	CD	CD	CD				CD	CD	CD			
			S a t u r n	M (VIN 4th)		[X] 2.0L L4 LNF	CD	CD	CD	CD	CD							CD				CD	CD	CD			CD					
						[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD						CD				CD	CD	CD			CD					
				Z (VIN 4th)	Aura	[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD						CD					CD	CD			CD					
					Aura	[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD						CD					CD	CD			CD					
					Aura	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD						CD					CD	CD			CD					
			H o l d e n	L (VIN 4th)	Teves/Mando	[R] 2.0L L4 LLW	CD	CD	CD	CD															CD							
					Teves/Mando	[K] 2.0L L6 LBM	CD	CD	CD	CD															CD							
					Teves/Mando	[L] 2.5L L6 LBK	CD	CD	CD	CD															CD							
				N (VIN 4th)		[7] 1.4L L4 L95	CD		CD	CD					CD											S16						
						[6] 1.6L L4 L91	CD	CD	CD	CD					CD											S16						
						[6] 1.6L L4 LXT	CD	CD	CD	CD					CD											S16						
						[B] 1.8L L4 LDA	CD	CD	CD	CD					CD											S16						
				S (VIN 4th)		[T] 1.2L L4 LY4	CD	CD	CD	CD					CD											S16						
						[W] 1.4L L4 LDT	CD	CD	CD	CD					CD											S16						
						[6] 1.6L L4 L91	CD	CD	CD	CD					CD											S16						
						[6] 1.6L L4 LXT	CD	CD	CD	CD					CD											S16						
2008			A (VIN 5th)	HHR	[X] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD							CD					CD	CD			CD					
				HHR	[D] 2.2L L4 L61	CD	CD	CD	CD	CD	CD							CD					CD	CD			CD					
				HHR	[P] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD							CD					CD	CD			CD					
				HHR Panel	[X] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD							CD					CD	CD			CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	C	hevrolet	C (VIN 5th)	HHR Panel	[D] 2.2L L4 L61	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD					
				HHR Panel	[P] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD								CD					CD	CD				CD				
				HHR (Europe)			CD	CD	CD	CD	CD	CD																	CD				
				Tracker	[J] 2.0L L4 L34	CD		CD	C																					CD			
				Avalanche	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Avalanche	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Avalanche	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Avalanche	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Captiva	[R] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	CD	CD	CD	C						CD				CD		CD			CD		CD	
				Captiva	[U] 2.0L L4 LMN	CD			CD	CD	CD	CD	CD	CD	C						CD				CD		CD			CD		CD	
				Captiva	[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	CD	CD	CD	C						CD				CD		CD			CD		CD	
				Captiva	[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	CD	CD	C						CD				CD		CD			CD		CD	
				Silverado	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Silverado	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Silverado	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Silverado	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Silverado	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Silverado	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Silverado	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Silverado	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Silverado	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Suburban	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Suburban	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Suburban	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Suburban	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Suburban	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Tahoe	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Tahoe	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Tahoe	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Tahoe Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD		CD	
				Tracker	[J] 2.0L L4 L34	CD			CD	C																							
			G (VIN 5th)	Express/Savana	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
				Express/Savana	[C] 4.8 V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD												CD		CD						
				Express/Savana	[5] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD						
				Express/Savana	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD						
				Express/Savana	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD						
				Express Access/Savana Pro	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD						
				Express Access/Savana Pro	[C] 4.8 V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD						
				Express Access/Savana Pro	[5] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD						
				Express Access/Savana Pro	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD						

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
	Truck	rollet		Express Access/Savana Pro	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD											CD		CD								
			H (VIN 5th)	Express/Savana	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD											CD		CD								
				Express/Savana	[C] 4.8 V8 LY2	CD	CD	CD	CD	CD	CD											CD		CD								
				Express/Savana	[5] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD											CD		CD								
				Express/Savana	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD											CD		CD								
				Express Access/Savana Pro	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD											CD		CD								
				Express Access/Savana Pro	[C] 4.8 V8 LY2	CD	CD	CD	CD	CD	CD											CD		CD								
				Express Access/Savana Pro	[5] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD											CD		CD								
				Express Access/Savana Pro	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD											CD		CD								
			K (VIN 5th)	Avalanche	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Avalanche	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Avalanche	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Avalanche	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Silverado	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Silverado	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Silverado	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Silverado	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Silverado	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Silverado	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Silverado	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Silverado	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Silverado	[6] 6.6L V8 LMM Diesel(With AT Case)	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Silverado	[6] 6.6L V8 LMM Diesel(Without AT Case)	CD		CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Suburban	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Suburban	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Suburban	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Suburban	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Suburban	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Tahoe	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Tahoe	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Tahoe	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
				Tahoe Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD		
			L (VIN 5th)	Captiva Sport	[P] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD						CD					CD		CD			CD					
				Captiva Sport	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD						CD					CD		CD			CD					
				Equinox	[F] 3.4L V6 LNJ	CD	CD	CD	CD	CD	CD	CD					CD						CD	CD				CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																		
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
	L D T r k · M P V · I n c o m p l e t e		S (VIN 5th)	Equinox	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD						
				Colorado	[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD							CD						CD				CD					
				Colorado	[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD							CD						CD				CD					
				TrailBlazer	[S] 4.2L L6 LL8	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD			CD			CD	CD				
				TrailBlazer	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD			CD			CD	CD				
				TrailBlazer	[H] 6.0L V8 LS2	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD				CD		CD	CD				
			T (VIN 5th)	Colorado	[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD				CD					
				Colorado	[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD				CD					
				TrailBlazer	[S] 4.2L L6 LL8	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD			CD			CD	CD				
				TrailBlazer	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD			CD			CD	CD				
				TrailBlazer	[H] 6.0L V8 LS2	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD				CD		CD	CD				
				TrailBlazer	[H] 6.0L V8 LS2	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD				CD		CD	CD				
2008			C (VIN 5th)	Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD			CD			
				Sierra	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD			CD		
				Sierra	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD	CD			CD			CD	
				Sierra	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD	CD			CD			CD	
				Sierra	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD	CD			CD			CD	
				Sierra	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD	CD			CD			CD	
				Sierra	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD	CD			CD			CD	
				Sierra	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD	CD			CD			CD	
				Sierra	[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD	CD			CD			CD	
				Sierra	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD					CD	CD			CD			CD	
				Typhoon	[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD	CD			CD			CD	
				Yukon	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD			CD	
				Yukon	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD			CD	
				Yukon	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD			CD	
				Yukon	[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD			CD	
				Yukon Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD			CD	
				Yukon XL	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD			CD	
				Yukon XL	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD			CD	
				Yukon XL	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD			CD	
				Yukon XL	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD			CD			CD	
	Yukon XL			[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD				CD		CD			CD			CD		
	Yukon XL			[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD				CD		CD			CD			CD		
	G (VIN 5th)			Express/Savana	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
				Express/Savana	[C] 4.8 V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD												CD		CD							
				Express/Savana	[5] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
				Express/Savana	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
				Express/Savana	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
				Express Access/Savana Pro	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD							
			Express Access/Savana Pro	[C] 4.8 V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
			Express Access/Savana Pro	[5] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD								
			Express Access/Savana Pro	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD									

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS			
		G M C T r u c k		Express Access/Sava na Pro	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD											CD		CD											
			H (VIN 5th)	Express/Sav ana	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD											CD		CD										
				Express/Sav ana	[C] 4.8 V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD									
				Express/Sav ana	[5] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD									
				Express/Sav ana	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD									
				Express Access/Sava na Pro	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD									
				Express Access/Sava na Pro	[C] 4.8 V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD									
				Express Access/Sava na Pro	[5] 5.3L V8 LMF	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD									
				Express Access/Sava na Pro	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD											CD		CD									
			K (VIN 5th)	Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Sierra	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Sierra	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Sierra	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Sierra	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Sierra	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Sierra	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Sierra	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Sierra	[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Sierra	[6] 6.6L V8 LMM Diesel(With AT Case)	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Sierra	[6] 6.6L V8 LMM Diesel(Without AT Case)	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Yukon	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Yukon	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Yukon	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Yukon	[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Yukon Hybrid	[5] 6.0L V8 LFA	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Yukon XL	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Yukon XL	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Yukon XL	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Yukon XL	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD				CD		CD			
				Yukon XL	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD		CD			CD		CD			
				Yukon XL	[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD		CD			CD		CD			
			L (VIN 5th)		[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	CD	CD	C																					
			R(VIN 5th)					CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD					
			S (VIN 5th)	Canyon	[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD				CD					
				Canyon	[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD				CD					
				Envoy	[S] 4.2L L6 LL8	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD			CD	CD				CD	CD				
				Envoy	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD	CD				CD	CD			
				Canyon	[9] 2.9L L4 LLV	CD	CD	CD	CD	CD	CD							CD						CD	CD				CD						

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
			T (VIN 5th)	Canyon	[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD							CD						CD				CD						
				Envoy	[S] 4.2L L6 LL8	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD				CD	CD			
				Envoy	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD						CD	CD			
				V (VIN 5th)			CD	CD	CD	CD	CD	CD	CD	CD	CD						CD			CD						CD				
2008		B u	R(VIN 5th)			CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD					
			V (VIN 5th)			CD	CD	CD	CD	CD	CD	CD	CD											CD	CD				CD					
2008		C a d i l	C (VIN 5th)		[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD					CD	CD					CD		CD		
			E (VIN 5th)		[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD				CD	CD					CD		CD		
					[A] 4.6L V8 LH2	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD				CD	CD					CD		CD	
			K (VIN 5th)		[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD	CD					CD		CD	
2008		S a t u r n	L (VIN 5th)	VUE	[P] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD				CD				
				VUE	[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD				CD			
				VUE	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD	CD				CD		
				VUE Hybrid			CD	CD	CD	CD	CD	CD	CD	CD	CD												CD	CD				CD		
				R(VIN 5th)			CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD			
			V (VIN 5th)			CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD				
2008		C a		Hearse		CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD	CD				CD				CD		CD		
				Limousine		CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD		
2008		P o n t i a c	L (VIN 5th)		[F] 3.4L V6 LNJ	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD				CD				
					[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD				CD			
				U (VIN 5th)		[W] 3.9L V6 LCD	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD				CD	CD		
						[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD											CD	CD					CD	CD		
				V (VIN 5th)		[W] 3.9L V6 LCD	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD	CD		
						[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD				CD	CD		
2008		C h e v	U (VIN 5th)		[W] 3.9L V6 LCD	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD				CD	CD			
					[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD	CD				CD	CD		
				V (VIN 5th)		[W] 3.9L V6 LCD	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD				CD	CD		
						[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD	CD				CD	CD	
2008		H u m m e		H2	[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD						CD						CD	CD					CD		CD	
				H3/5GT	[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD								CD						CD				CD	CD			
				H3/5GT	[L] 5.3L V8 LH8	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD				CD	CD			
				H3/ADM	[E] 3.7L L5 LLR	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD				CD	CD			
				H3/ADM	[L] 5.3L V8 LH8	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD				CD	CD			
2008		S A A B			[S] 4.2L L6 LL8	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD					CD	CD			
					[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD							CD	CD		CD							CD	CD			
					[H] 6.0L V8 LS2	CD			CD	CD	CD	CD	CD	CD						CD	CD		CD							CD	CD			
2008		H o i		Captiva	[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	C											CD		CD								
				Captiva Maxx	[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	CD	C											CD		CD							
2008		O p e l			[R] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	CD	C											CD		CD								
						[U] 2.0L L4 LMN	CD	CD	CD	CD	CD	CD	CD	C											CD		CD							
						[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	CD	C												CD		CD						
						[P] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	C												CD		CD						
2008		V a u x h			[R] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	CD	C												CD		CD							
						[U] 2.0L L4 LMN	CD	CD	CD	CD	CD	CD	CD	C												CD		CD						
						[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	CD	C												CD		CD						
						[P] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	C												CD		CD						
2008																																		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS			
	Medium Duty Truck	Chevrolet Truck		T-B7 Chassis	[9] 6.6L V8 LMM Diesel	CD	CD	CD																											
				T-B7 Chassis	[B] 7.8L L6 LF8	CD		CD																											
				T-B7 Chassis	[G] 8.1L V8 L18	CD	CD	CD																											
				D-C Series	[6] 5.2L L4 Diesel	CD	CD	CD	CD			CD																							
				D-C Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD	CD			CD																							
				D-C Series	[B] 7.8L L6 LF8	CD		CD	CD			CD																							
				D-C Series	[G] 8.1L V8 L18	CD	CD	CD	CD			CD																							
				C-T Series	[6] 5.2L L4 Diesel	CD	CD	CD				CD																							
				C-T Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD				CD																							
				C-T Series	[B] 7.8L L6 LF8	CD		CD				CD																							
				C-T Series	[G] 8.1L V8 L18	CD	CD	CD				CD																							
				B-W4 Series	[6] 5.2L L4 Diesel	CD	CD	CD																											
				B-W4 Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD																											
				B-W4 Series	[B] 7.8L L6 LF8	CD		CD																											
				B-W4 Series	[G] 8.1L V8 L18	CD	CD	CD																											
2008				GMC Truck		C-WT5500	[6] 5.2L L4 Diesel	CD	CD																										
					C-WT5500	[9] 6.6L V8 LMM Diesel	CD	CD																											
					C-WT5500	[B] 7.8L L6 LF8	CD																												
					C-WT5500	[G] 8.1L V8 L18	CD	CD																											
					T-B7 Chassis	[6] 5.2L L4 Diesel	CD	CD	CD																										
					T-B7 Chassis	[9] 6.6L V8 LMM Diesel	CD	CD	CD																										
					T-B7 Chassis	[B] 7.8L L6 LF8	CD		CD																										
					T-B7 Chassis	[G] 8.1L V8 L18	CD	CD	CD																										
					D-C Series	[6] 5.2L L4 Diesel	CD	CD	CD	CD			CD																						
					D-C Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD	CD			CD																						
					D-C Series	[B] 7.8L L6 LF8	CD		CD	CD			CD																						
					D-C Series	[G] 8.1L V8 L18	CD	CD	CD	CD			CD																						
			C-T Series	[6] 5.2L L4 Diesel	CD	CD	CD				CD																								
		C-T Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD				CD																									
		C-T Series	[B] 7.8L L6 LF8	CD		CD				CD																									
		C-T Series	[G] 8.1L V8 L18	CD	CD	CD				CD																									
		B-W4 Series	[6] 5.2L L4 Diesel	CD	CD	CD																													
		B-W4 Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD																													

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
				B-W4 Series	[B] 7.8L L6 LF8	CD		CD																								
				B-W4 Series	[G] 8.1L V8 L18	CD	CD	CD																								
2008	W o r k h o r s e			6-W20 Series	[G] 8.1L V8 L18	CD	CD																									
				6-W22 Series	[G] 8.1L V8 L18	CD	CD																									
				A - W24 Series	[G] 8.1L V8 L18	CD	CD																									
				D-W42 Series	[C] 4.8L V8 LY2	CD	CD																									
					[K] 6.0L V8 LY6	CD	CD																									
				E-W16 Series	[G] 8.1L V8 L18	CD																										
				E-W18 Series	[G] 8.1L V8 L18	CD																										
					F-R26 Series	[G] 8.1L V8 L18	CD	CD																								
					G-W62 Series	[G] 8.1L V8 L18	CD	CD																								
2007		C h e v r o l e t		A (VIN 4th)	COBALTA	[X]2.0L L4 LNF	CD		CD	CD	CD	CD							CD						CD			CD				
			A (VIN 4th)	COBALTA	[F] 2.2L L4 L61	CD	CD	CD										CD						CD			CD					
			A (VIN 4th)	COBALTA	[B] 2.4L L4 LE5	CD	CD	CD										CD						CD			CD					
			J (VIN 4th)		[Z] 2.0L L4 L34	CD		CD	CD							CD											S16					
			K (VIN 4th)		[4] 0.8L L3 LBF	CD		CD	CD																		S16					
			K (VIN 4th)		[0] 1.0L L4 L11	CD		CD	CD																		S16					
			L (VIN 4th)		[R] 2.0L L4 LLW	CD		CD	CD																							
			L (VIN 4th)		[K] 2.0L L6 LBM	CD	CD	CD	CD																		CD					
			L (VIN 4th)		[L] 2.5L L6 LBK	CD	CD	CD	CD																		CD					
			L (VIN 4th)		[R] 2.0L L4 LLW	CD	CD	CD	CD																		CD					
			N (VIN 4th)		[7] 1.4L L4 L95	CD		CD	CD							CD											S16					
			N (VIN 4th)		[6] 1.6L L4 L91	CD	CD	CD	CD							CD											S16					
			N (VIN 4th)		[6] 1.6L L4 L91 India	CD	CD	CD	CD							CD											S16					
			N (VIN 4th)		[3] 1.8L L4 L79	CD		CD	CD							CD											S16					
			N (VIN 4th)		[B] 1.8L L4 LDA	CD		CD	CD							CD											S16					
			N (VIN 4th)		[Z] 2.0L L4 L34	CD		CD	CD							CD											S16					
			N (VIN 4th)		[R] 2.0L L4 L34	CD	CD	CD	CD							CD											S16					
			N (VIN 4th)		[U] 2.0L L4 LMN	CD	CD	CD	CD							CD											S16					
			S (VIN 4th)	Chevy	[X] 1.6L L4 LLQ	CD		CD	CD																		CD					
			S (VIN 4th)	Aveo	[T] 1.2L L4 LY4	CD	CD	CD	CD																		S16					
			S (VIN 4th)	Aveo	[7] 1.4L L4 L95 India	CD		CD	CD																		S16					
			S (VIN 4th)	Aveo	[7] 1.4L L4 L95	CD		CD	CD																		S16					
			S (VIN 4th)	Aveo	[A] 1.4L L4 LBJ	CD		CD	CD																		S16					
			S (VIN 4th)	Aveo	[Y] 1.5L L4 LV8	CD		CD	CD																		S16					
			S (VIN 4th)	Aveo	[6] 1.6L L4 L91	CD		CD	CD																		S16					
			S (VIN 4th)	Aveo	[6] 1.6L L4 L91 India	CD		CD	CD																		S16					
			T (VIN 4th)		[T] 1.2L L4 LY4	CD	CD	CD	CD																		S16					
					[7] 1.4L L4 L95 India	CD		CD	CD																		S16					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																		
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
	P a s s e n g e r				[7] 1.4L L4 L95	CD		CD	CD																	S16								
				[A] 1.4L L4 LBJ	CD		CD	CD																			S16							
				[Y] 1.5L L4 LV8	CD		CD	CD																			S16							
				[6] 1.6L L4 L91	CD		CD	CD																			S16							
				[6] 1.6L L4 L91 India	CD		CD	CD																			S16							
				U (VIN 4th)	[6] 1.6L L4 L91	CD		CD	CD																		S16							
				U (VIN 4th)	[Z] 2.0L L4 L34	CD	CD	CD	CD																		S16							
				V (VIN 4th)	[B] 1.8L L4 LDA	CD		CD	CD																		CD							
					[K] 2.0L L6 LBM	CD	CD	CD	CD	CD																	CD							
					[L] 2.5L L6 LBK	CD	CD	CD	CD	CD																	CD							
					[R] 2.0L L4 LLW	CD	CD	CD	CD	CD																	CD							
				W (VIN 4th)	[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD				CD		CD			CD					
					[K] 3.5L V6 LZE	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD				CD		CD			CD					
					[R] 3.9L V6 LZ8	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD				CD		CD			CD					
					[C] 5.3L V8 LS4	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD				CD		CD			CD					
				Y (VIN 4th)			CD	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD	CD	CD	CD		CD			CD					
				Z (VIN 4th)	[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD				CD		CD			CD					
				Z (VIN 4th)	[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD				CD		CD			CD					
			Z (VIN 4th)	[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD				CD		CD			CD						
2007			P o n t i a c	A (VIN 4th)		[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD							CD						CD			CD						
				A (VIN 4th)		[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD							CD						CD			CD					
				M (VIN 4th)		[X] 2.0L L4 LNF	CD	CD	CD	CD	CD	CD	CD							CD				CD		CD			CD					
				M (VIN 4th)		[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD								CD				CD		CD			CD				
				S (VIN 4th)		[8] 1.8L L4 LV6	CD		CD	CD											CD								CD					
				T (VIN 4th)	G3	[6] 1.6L L4 L91	CD	CD	CD	CD																			S16					
					Wave	[6] 1.6L L4 L91	CD	CD	CD	CD																			S16					
				W (VIN 4th)		[2] 3.8L V6 L26	CD		CD	CD	CD	CD	CD	CD	CD						CD				CD					CD	CD			
						[4] 3.8L V6 L32	CD		CD	CD	CD	CD	CD	CD	CD						CD				CD					CD	CD			
						[C] 5.3L V8 LS4	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD				CD					CD	CD			
				Z (VIN 4th)		[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD			CD				
					[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD			CD					
			[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD			CD							
			[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD			CD							
2007		B U I C K	H (VIN 4th)		[2] 3.8L V6 L26	CD		CD	CD	CD	CD	CD						CD						CD			CD							
				[Y] 4.6L V8 LD8	CD	CD	CD	CD	CD	CD	CD	CD							CD						CD			CD						
			W (VIN 4th)	Allure	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD							CD				CD				CD						
				Allure	[2] 3.8ILV6 L26	CD		CD	CD	CD	CD	CD	CD							CD				CD				CD						
			W (VIN 4th)	LaCrosse	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD							CD				CD				CD						
				LaCrosse	[2] 3.8ILV6 L26	CD		CD	CD	CD	CD	CD	CD							CD				CD				CD						
2007		C a d i l l	D (VIN 4th)	[DM] CTS	[T] 2.8L V6 LP1	CD	CD	CD	CD		CD							CD	CD	CD	CD			CD			CD		CD					
				[DM] CTS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD								CD	CD	CD	CD			CD			CD		CD				
			D (VIN 4th)	[DP] CTS	[T] 2.8L V6 LP1	CD	CD	CD	CD		CD								CD	CD	CD	CD			CD			CD		CD				
				[DP] CTS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD									CD	CD	CD	CD			CD			CD		CD			
			D (VIN 4th)	[DR] CTS	[T] 2.8L V6 LP1	CD	CD	CD	CD		CD									CD	CD	CD	CD			CD			CD		CD			
				[DR] CTS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD									CD	CD	CD	CD			CD			CD		CD			
			D (VIN 4th)	[DN] CTS-V	[U] 6.0L V8 LS2	CD		CD	CD		CD						CD	CD	CD	CD	CD			CD			CD		CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																			
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS			
		I a c	D (VIN 4th)	[DC] STS-V8		CD	CD	CD	CD		CD	CD					CD	CD	CD	CD	CD							CD	CD	CD					
			D (VIN 4th)	[DW] STS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD	CD						CD	CD	CD	CD	CD							CD	CD	CD				
			D (VIN 4th)	[DX] STS-V		CD	CD	CD	CD		CD	CD						CD	CD	CD	CD	CD							CD	CD	CD				
			K (VIN 4th)			CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD	CD	CD		CD				CD		CD				
			Y (VIN 4th)	[YV] XLR		CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD	CD	CD						CD	CD	CD				
				[YX] XLR-V		CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD	CD	CD	CD						CD	CD	CD				
		S a t u r n	A (VIN 4th)		[P] 2.0L L4 LSJ	CD		CD	CD	CD	CD													CD					CD						
					[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD														CD					CD					
						CD		CD	CD	CD	CD														CD					CD					
					[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD														CD					CD					
						CD		CD	CD	CD	CD														CD					CD					
2007			M (VIN 4th)		[X] 2.0L L4 LNF	CD	CD	CD	CD		CD	CD							CD					CD					CD						
					[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD									CD					CD				CD						
			Z (VIN 4th)	Aura	[N] 3.5L V6 LZ4	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD			CD						
				Aura	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD							CD					CD	CD			CD						
			Z (VIN 4th)	Aura Hybrid	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD				CD						
2007	H o l d e					[B] 1.8L L4 LDA	CD		CD	CD																	CD								
						[K] 2.0L L6 LBM	CD	CD	CD	CD																		CD							
						[L] 2.5L L6 LBK	CD	CD	CD	CD																			CD						
						[R] 2.0L L4 LLW	CD	CD	CD	CD																			CD						
2007				A (VIN 5th)		[D] 2.2L L4 L61	CD	CD	CD	CD	CD	CD						CD						CD				CD							
						[P] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD								CD						CD			CD						
				C (VIN 5th)	Avalanche	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD				CD		CD			
					Avalanche	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD				CD		CD		
					Avalanche	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD				CD		CD		
					Avalanche	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD					CD				CD		CD		
				C (VIN 5th)	Captiva	[R] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	CD	CD	C										CD		CD								
					Captiva	[U] 2.0L L4 LMN	CD	CD	CD	CD	CD	CD	CD	CD	C										CD		CD								
					Captiva	[F] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	CD	CD	C										CD		CD								
					Captiva	[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	CD	C										CD		CD								
				C (VIN 5th)	Silverado	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
					Silverado	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
					Silverado	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
					Silverado	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
					Silverado	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
					Silverado	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
					Silverado	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
					Silverado	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
					Silverado	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
						Silverado Classic	[X] 4.3L V6 LU3	CD			CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
						Silverado Classic	[V] 4.8L V8 LR4	CD			CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
						Silverado Classic	[B] 5.3L V8 L33	CD			CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
						Silverado Classic	[Z] 5.3L V8 L59	CD			CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																	
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
		C h e v r o l e t		Silverado Classic	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD			
				Silverado Classic	[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	CD					CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	CD	CD					CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD					CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[U] 6.0L V8 LQ4 Dedicated GNG	CD		CD	CD	CD	CD	CD	CD	CD					CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD					CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[D] 6.6L V8 LBZ Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[G] 8.1L V8 L18	CD	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD		CD	CD				CD	CD	CD		
				Suburban	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD	CD		CD		CD	CD				CD			
				Suburban	[O] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD	CD		CD		CD	CD				CD			
				Suburban	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD	CD		CD		CD	CD				CD			
				Suburban	[Y] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD	CD		CD		CD	CD				CD			
				Suburban	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD	CD		CD		CD	CD				CD			
				Tahoe	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD			CD		CD	CD				CD			
				Tahoe	[O] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD			CD		CD	CD				CD			
				Tahoe	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD			CD		CD	CD				CD			
				E (VIN 5th)		[C] 2.0L L4 L34	CD			CD	C																						
				G (VIN 5th)	Express/Savana	[X] 4.3L V6 LU3	CD			CD	CD	CD	CD										CD	CD						CD			
					Express/Savana	[V] 4.8L V8 LR4	CD			CD	CD	CD	CD										CD	CD						CD			
					Express/Savana	[Z] 5.3L V8 L59	CD			CD	CD	CD	CD										CD	CD						CD			
					Express/Savana	[T] 5.3L V8 LM7	CD			CD	CD	CD	CD										CD	CD						CD			
					Express/Savana	[U] 6.0L V8 LQ4	CD			CD	CD	CD	CD										CD	CD						CD			
					Express/Savana	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD	CD	CD	CD										CD	CD						CD			
					Express/Savana	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD										CD	CD						CD			
				G (VIN 5th)	Express Access/Savana Pro	[X] 4.3L V6 LU3	CD			CD	CD	CD	CD										CD	CD						CD			
					Express Access/Savana Pro	[V] 4.8L V8 LR4	CD			CD	CD	CD	CD										CD	CD						CD			
					Express Access/Savana Pro	[Z] 5.3L V8 L59	CD			CD	CD	CD	CD										CD	CD						CD			
					Express Access/Savana Pro	[T] 5.3L V8 LM7	CD			CD	CD	CD	CD										CD	CD						CD			
					Express Access/Savana Pro	[U] 6.0L V8 LQ4	CD			CD	CD	CD	CD										CD	CD						CD			

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																		
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
	Truck	Truck		Express Access/Savana Pro	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD	CD	CD											CD	CD					CD						
				Express Access/Savana Pro	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD												CD	CD					CD				
			H (VIN 5th)	Express/Savana	[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD												CD	CD					CD				
				Express/Savana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD												CD	CD					CD				
			H (VIN 5th)	Express Access/Savana Pro	[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD												CD	CD					CD				
				Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD												CD	CD					CD				
			J (VIN 5th)		[C] 2.0L L4 L34	CD		CD	C																									
			K (VIN 5th)	Avalanche	[3] 5.3L V8 LC9	CD		CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Avalanche	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Avalanche	[J] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Avalanche	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Silverado	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Silverado	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Silverado	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Silverado	[M] 5.3L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Silverado	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Silverado	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Silverado	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Silverado	[K] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Silverado	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD				CD		CD			
				Silverado Classic	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[B] 5.3L V8 L33	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[U] 6.0L V8 LQ4 Dedicated GNG	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[D] 6.6L V8 LBZ Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		
				Silverado Classic	[6] 6.6L V8 LMM Diesel			CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
	L D T r k : M P V : I n c o m p l e			Silverado Classic	[G] 8.1L V8 L18	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD	CD				CD	CD	CD				
				Suburban	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD			
				Suburban	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
				Suburban	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
				Suburban	[Y] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
				Suburban	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
				Tahoe	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
				Tahoe	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
				Tahoe	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD					CD				CD		CD		
				L (VIN 5th)		[F] 3.4L V6 LNJ	CD	CD	CD	CD	CD	CD	CD	CD						CD					CD	CD				CD				
				P (VIN 5th)		[R] 5.7L V8 L31	CD				CD														CD									
				S (VIN 5th)	Colorado	[9] 2.9L L4 LLV	CD			CD	CD	CD	CD							CD										CD				
					Colorado	[E] 3.7L L5 LLR	CD			CD	CD	CD	CD							CD										CD				
					TrailBlazer	[S] 4.2L L6 LL8	CD			CD	CD	CD	CD	CD						CD	CD		CD		CD					CD	CD			
					TrailBlazer	[S] 4.2L L6 LL8 Japan	CD			CD	CD	CD	CD	CD						CD	CD		CD		CD					CD	CD			
					TrailBlazer	[M] 5.3L V8 LH6	CD	CD		CD	CD	CD	CD	CD						CD	CD		CD		CD					CD	CD			
					TrailBlazer	[H] 6.0L V8 LS2	CD	CD		CD	CD	CD	CD	CD						CD	CD		CD		CD					CD	CD			
				T (VIN 5th)	Colorado	[9] 2.9L L4 LLV	CD			CD	CD	CD	CD							CD										CD				
					Colorado	[E] 3.7L L5 LLR	CD			CD	CD	CD	CD							CD										CD				
					TrailBlazer	[S] 4.2L L6 LL8	CD			CD	CD	CD	CD	CD						CD	CD		CD		CD					CD	CD			
					TrailBlazer	[S] 4.2L L6 LL8 Japan	CD			CD	CD	CD	CD	CD						CD	CD		CD		CD					CD	CD			
					TrailBlazer	[M] 5.3L V8 LH6	CD	CD		CD	CD	CD	CD	CD						CD	CD		CD		CD					CD	CD			
					TrailBlazer	[H] 6.0L V8 LS2	CD	CD		CD	CD	CD	CD	CD						CD	CD		CD		CD					CD	CD			
2007				C (VIN 5th)	Sierra	[X] 4.3L V6 LU3	CD	CD		CD	CD	CD	CD	CD		C				CD	CD					CD						CD		
		Sierra			[C] 4.8L V8 LY2	CD	CD		CD	CD	CD	CD	CD	CD		C				CD	CD					CD						CD		
		Sierra			[3] 5.3L V8 LC9	CD	CD		CD	CD	CD	CD	CD	CD		C				CD	CD					CD						CD		
		Sierra			[M] 5.3L V8 LH6	CD	CD		CD	CD	CD	CD	CD	CD		C				CD	CD					CD						CD		
		Sierra			[0] 5.3L V8 LMG	CD	CD		CD	CD	CD	CD	CD	CD	CD		C				CD	CD				CD						CD		
		Sierra			[J] 5.3L V8 LY5	CD	CD		CD	CD	CD	CD	CD	CD	CD		C				CD	CD				CD						CD		
		Sierra			[Y] 6.0L V8 L76	CD	CD		CD	CD	CD	CD	CD	CD	CD		C				CD	CD				CD						CD		
		Sierra			[K] 6.0L V8 LY6	CD	CD		CD	CD	CD	CD	CD	CD	CD		C				CD	CD				CD						CD		
		Sierra			[8] 6.2L V8 L92	CD	CD		CD	CD	CD	CD	CD	CD	CD		C				CD	CD				CD						CD		
	Sierra	[6] 6.6L V8 LMM Diesel			CD	CD		CD	CD	CD	CD	CD	CD	CD		C				CD	CD				CD						CD			
	Sierra Classic	[X] 4.3L V6 LU3			CD			CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD						CD			
	Sierra Classic	[V] 4.8L V8 LR4			CD			CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD						CD			
	Sierra Classic	[B] 5.3L V8 L33			CD			CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD						CD			
	Sierra Classic	[Z] 5.3L V8 L59			CD			CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD						CD			
	Sierra Classic	[T] 5.3L V8 LM7			CD			CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD						CD			
	Sierra Classic	[T] 5.3L V8 LM7 Parallel Hybrid			CD			CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD						CD			
	Sierra Classic	[R] 5.7L V8 L31	CD			CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD						CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
	te	G M C T r u c		Sierra Classic	[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[U] 6.0L V8 LQ4 Dedicated GNG	CD		CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[D] 6.6L V8 LBZ Diesel	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[G] 8.1L V8 L18	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Yukon	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon	[O] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon	[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon XL	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon XL	[O] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon XL	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon XL	[Y] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon XL	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon XL	[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
			G (VIN 5th)	Express/Sav ana	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD						CD	CD						CD				CD		CD		
				Express/Sav ana	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD						CD	CD						CD	CD			CD		CD		
				Express/Sav ana	[Z] 5.3L V8 L59	CD		CD	CD	CD	CD						CD	CD						CD	CD			CD		CD		
				Express/Sav ana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD						CD	CD						CD	CD			CD		CD		
				Express/Sav ana	[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD						CD	CD						CD	CD			CD		CD		
				Express/Sav ana	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD	CD	CD						CD	CD						CD	CD			CD		CD		
				Express/Sav ana	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD						CD	CD						CD	CD			CD		CD		
				Express Access/Sava na Pro	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD											CD	CD					CD				
				Express Access/Sava na Pro	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD											CD	CD					CD				
				Express Access/Sava na Pro	[Z] 5.3L V8 L59	CD		CD	CD	CD	CD											CD	CD					CD				
				Express Access/Sava na Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD											CD	CD					CD				
				Express Access/Sava na Pro	[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD											CD	CD					CD				
				Express Access/Sava na Pro	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD	CD	CD											CD	CD					CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																		
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
		k		Express Access/Savana Pro	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD											CD	CD					CD						
			H (VIN 5th)	Express/Savana	[Z] 5.3L V8 L59	CD		CD	CD	CD	CD												CD	CD					CD					
				Express/Savana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD												CD	CD					CD					
				Express Access/Savana Pro	[Z] 5.3L V8 L59	CD		CD	CD	CD	CD													CD	CD					CD				
				Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD													CD	CD					CD				
			K (VIN 5th)	Sierra	[X] 4.3L V6 LU3	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD							CD		
				Sierra	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD							CD		
				Sierra	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD							CD		
				Sierra	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD							CD		
				Sierra	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD							CD		
				Sierra	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD							CD		
				Sierra	[Y] 6.0L V8 L76	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD							CD		
				Sierra	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD							CD		
				Sierra	[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD							CD		
				Sierra	[6] 6.6L V8 LMM Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD					CD							CD		
				Sierra Classic	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[B] 5.3L V8 L33	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[U] 6.0L V8 LQ4 Dedicated GNG	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[D] 6.6L V8 LBZ Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Sierra Classic	[G] 8.1L V8 L18	CD	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD		CD							CD		
				Yukon	[C] 4.8L V8 LY2	CD	CD	CD	CD	CD	CD	CD	CD	CD		C				CD						CD				CD		CD		
				Yukon	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon	[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		
				Yukon XL	[3] 5.3L V8 LC9	CD	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD				CD		CD		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
				Yukon XL	[0] 5.3L V8 LMG	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD			CD		CD			
				Yukon XL	[J] 5.3L V8 LY5	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD			CD		CD			
				Yukon XL	[Y] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD			CD		CD			
				Yukon XL	[K] 6.0L V8 LY6	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD			CD		CD			
				Yukon XL	[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD		C			CD	CD						CD			CD		CD			
			P (VIN 5th)		[R] 5.7L V8 L31	CD			CD																							
			R(VIN 5th)		[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD		C				CD						CD			CD					
			S (VIN 5th)	Canyon	[9] 2.9L L4 LLV	CD		CD	CD	CD	CD	CD						CD									CD					
				Canyon	[E] 3.7L L5 LLR	CD		CD	CD	CD	CD	CD						CD									CD					
				Envoy	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD						CD		CD											
				Envoy	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD						CD		CD											
			T (VIN 5th)	Canyon	[9] 2.9L L4 LLV	CD		CD	CD	CD	CD	CD						CD									CD					
				Canyon	[E] 3.7L L5 LLR	CD		CD	CD	CD	CD	CD						CD									CD					
				Envoy	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD					CD	CD		CD						CD	CD				
				Envoy	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD						CD	CD				
			V (VIN 5th)		[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	C				CD						CD			CD					
2007		B u c k	A (VIN 5th)		[L] 3.5L V6 LX9	CD		CD	CD	CD	CD	CD	CD					CD						CD			CD	CD				
			S (VIN 5th)		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD					CD	CD		CD						CD	CD				
					[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD						CD	CD				
			T (VIN 5th)		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD					CD	CD		CD						CD	CD				
					[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD					CD	CD		CD						CD	CD				
			V (VIN 5th)		[W] 3.9L V6 LGD	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
					[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
2007	C a d i l		C (VIN 5th)		[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD	C			CD	CD						CD			CD		CD			
			E (VIN 5th)		[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	C			CD	CD				CD		CD			CD		CD			
					[A] 4.6L V8 LH2	CD	CD	CD	CD	CD	CD	CD	CD	C			CD	CD				CD		CD			CD		CD			
			K (VIN 5th)		[8] 6.2L V8 L92	CD	CD	CD	CD	CD	CD	CD	CD	C			CD	CD						CD			CD		CD			
2007	S a t u r n		R(VIN 5th)		[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	C				CD						CD			CD					
			V (VIN 5th)	Outlook	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	C				CD									CD					
				Relay	[W] 3.9L V6 LGD	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
				Relay	[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
			Z (VIN 5th)	VUE	[D] 2.2L L4 L61	CD	CD	CD	CD	CD	CD	CD	CD					CD					CD				CD					
				VUE	[4] 3.5L V6 L66	CD		CD	CD	CD	CD	CD	CD					CD					CD				CD					
				VUE Hybrid		CD	CD	CD	CD	CD	CD	CD	CD					CD					CD				CD					
2007	C a d			Hearse		CD	CD	CD	CD	CD	CD	CD	CD					CD		CD				CD			CD		CD			
				Limousine		CD	CD	CD	CD	CD	CD	CD	CD					CD		CD				CD			CD		CD			
2007	P o n t i a c		L (VIN 5th)		[F] 3.4L V6 LNJ	CD	CD	CD	CD	CD	CD	CD	CD					CD					CD	CD			CD					
			U (VIN 5th)		[W] 3.9L V6 LGD	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
					[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
			V (VIN 5th)		[W] 3.9L V6 LGD	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
					[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
2007	C h e v r		U (VIN 5th)		[W] 3.9L V6 LGD	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
					[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
			V (VIN 5th)		[W] 3.9L V6 LGD	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
					[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD					CD									CD	CD				
2007	H u m			H2	[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD					CD	CD		CD						CD	CD	CD			
				H3/5GT	[E] 3.7L L5 LLR	CD		CD	CD	CD	CD	CD	CD					CD									CD	CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
		m m e r		H3/5GT	[E] 3.7L L5 LLR Japan	CD		CD	CD	CD	CD							CD									CD	CD				
				H3/ADM	[E] 3.7L L5 LLR	CD		CD	CD	CD	CD	CD							CD									CD	CD			
2007		S A A			[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD		CD			CD			CD	CD				
					[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD						CD	CD		CD			CD			CD	CD			
2007		H o l		Captiva Maxx	[K] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	C										CD		CD								
				Captiva	[G] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	C										CD		CD							
2007		O p e l			[F] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	C											CD		CD							
					[U] 2.0L L4 LMN	CD	CD	CD	CD	CD	CD	CD	C										CD		CD							
					[T] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	CD	C											CD		CD						
					[K] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	C											CD		CD						
2007		V a u x h			[F] 2.0L L4 LLW	CD	CD	CD	CD	CD	CD	C											CD		CD							
					[U] 2.0L L4 LMN	CD	CD	CD	CD	CD	CD	C											CD		CD							
					[T] 2.4L L4 LD9	CD	CD	CD	CD	CD	CD	CD	C											CD		CD						
					[K] 3.2L V6 LU1	CD	CD	CD	CD	CD	CD	CD	C											CD		CD						
2007		C h e v r o l e t T r u c k		C-WT5500	[6] 5.2L L4 Diesel	CD	CD																									
				C-WT5500	[U] 6.0L V8 LQ4	CD																										
				C-WT5500	[2] 6.6L V8 LLY Diesel	CD	CD																									
				C-WT5500	[9] 6.6L V8 LMM Diesel	CD	CD																									
				C-WT5500	[3] 7.8L L6 LG4	CD	CD																									
				C-WT5500	[B] 7.8L L6 LF8	CD																										
				C-WT5500	[G] 8.1L V8 L18	CD	CD																									
				T-B7 Chassis	[6] 5.2L L4 Diesel	CD	CD	CD																								
				T-B7 Chassis	[U] 6.0L V8 LQ4	CD		CD																								
				T-B7 Chassis	[2] 6.6L V8 LLY Diesel	CD	CD	CD																								
				T-B7 Chassis	[9] 6.6L V8 LMM Diesel	CD	CD	CD																								
				T-B7 Chassis	[3] 7.8L L6 LG4	CD	CD	CD																								
				T-B7 Chassis	[B] 7.8L L6 LF8	CD		CD																								
				T-B7 Chassis	[G] 8.1L V8 L18	CD	CD	CD																								
				D-C Series	[6] 5.2L L4 Diesel	CD	CD	CD	CD		CD		CD																CD			
				D-C Series	[U] 6.0L V8 LQ4	CD		CD	CD		CD		CD																CD			
				D-C Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD		CD		CD																CD			
				D-C Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD	CD		CD		CD																CD			
				D-C Series	[3] 7.8L L6 LG4	CD	CD	CD	CD		CD		CD																CD			
				D-C Series	[B] 7.8L L6 LF8	CD		CD	CD		CD		CD																CD			
				D-C Series	[G] 8.1L V8 L18	CD	CD	CD	CD		CD		CD																CD			
				C-T Series	[6] 5.2L L4 Diesel	CD	CD	CD	CD		CD		CD																CD			
				C-T Series	[U] 6.0L V8 LQ4	CD		CD	CD		CD		CD																CD			

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
	M e d i u m D u t y T r u c k			C-T Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD		CD																CD					
				C-T Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD	CD		CD																	CD				
				C-T Series	[3] 7.8L L6 LG4	CD	CD	CD	CD		CD																	CD				
				C-T Series	[B] 7.8L L6 LF8	CD		CD	CD		CD																	CD				
				C-T Series	[G] 8.1L V8 L18	CD	CD	CD	CD		CD																	CD				
				B-W4 Series	[6] 5.2L L4 Diesel	CD	CD	CD																								
				B-W4 Series	[U] 6.0L V8 LQ4	CD		CD																								
				B-W4 Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD																								
				B-W4 Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD																								
				B-W4 Series	[3] 7.8L L6 LG4	CD	CD	CD																								
				B-W4 Series	[B] 7.8L L6 LF8	CD		CD																								
				B-W4 Series	[G] 8.1L V8 L18	CD	CD	CD																								
2007		G M C T r u c k		C-WT5500	[6] 5.2L L4 Diesel	CD	CD																									
				C-WT5500	[U] 6.0L V8 LQ4	CD																										
				C-WT5500	[2] 6.6L V8 LLY Diesel	CD	CD																									
				C-WT5500	[9] 6.6L V8 LMM Diesel	CD	CD																									
				C-WT5501	[3] 7.8L L6 LG4	CD	CD																									
				C-WT5502	[B] 7.8L L6 LF8	CD																										
				C-WT5503	[G] 8.1L V8 L18	CD	CD																									
				T-B7 Chassis	[6] 5.2L L4 Diesel	CD	CD	CD																								
				T-B7 Chassis	[U] 6.0L V8 LQ4	CD		CD																								
				T-B7 Chassis	[2] 6.6L V8 LLY Diesel	CD	CD	CD																								
				T-B7 Chassis	[9] 6.6L V8 LMM Diesel	CD	CD	CD																								
				T-B7 Chassis	[3] 7.8L L6 LG4	CD	CD	CD																								
				T-B7 Chassis	[B] 7.8L L6 LF8	CD		CD																								
				T-B7 Chassis	[G] 8.1L V8 L18	CD	CD	CD																								
				D-C Series	[6] 5.2L L4 Diesel	CD	CD	CD	CD		CD																		CD			
				D-C Series	[U] 6.0L V8 LQ4	CD		CD	CD		CD																		CD			
		D-C Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD		CD																		CD					
		D-C Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD	CD		CD																		CD					
		D-C Series	[3] 7.8L L6 LG4	CD	CD	CD	CD		CD																		CD					
		D-C Series	[B] 7.8L L6 LF8	CD		CD	CD		CD																		CD					
		D-C Series	[G] 8.1L V8 L18	CD	CD	CD	CD		CD																		CD					
		C-T Series	[6] 5.2L L4 Diesel	CD	CD	CD	CD		CD																		CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
				C-T Series	[U] 6.0L V8 LQ4	CD		CD	CD		CD																CD					
				C-T Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD		CD																	CD				
				C-T Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD	CD		CD																	CD				
				C-T Series	[3] 7.8L L6 LG4	CD	CD	CD	CD		CD																	CD				
				C-T Series	[B] 7.8L L6 LF8	CD		CD	CD		CD																	CD				
				C-T Series	[G] 8.1L V8 L18	CD	CD	CD	CD		CD																	CD				
				B-W4 Series	[6] 5.2L L4 Diesel	CD	CD	CD																								
				B-W4 Series	[U] 6.0L V8 LQ4	CD		CD																								
				B-W4 Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD																								
				B-W4 Series	[9] 6.6L V8 LMM Diesel	CD	CD	CD																								
				B-W4 Series	[3] 7.8L L6 LG4	CD	CD	CD																								
				B-W4 Series	[B] 7.8L L6 LF8	CD		CD																								
				B-W4 Series	[G] 8.1L V8 L18	CD	CD	CD																								
2007	W o r k h o r s e			6-W22 Series	[G] 8.1L V8 L18	CD	CD	CD																								
				A - W24 Series	[G] 8.1L V8 L18	CD	CD																									
				A - W25 Series	[G] 8.1L V8 L18	CD	CD																									
				D-W42 Series	[V] 4.8L V8 LR4	CD																										
					[U] 6.0L V8 LQ4	CD																										
				E-W16 Series	[G] 8.1L V8 L18	CD																										
				E-W18 Series	[U] 6.0L V8 LQ4	CD																										
					[G] 8.1L V8 L18	CD																										
				F-R26 Series	[G] 8.1L V8 L18	CD	CD																									
				G-W62 Series	[G] 8.1L V8 L18	CD	CD																									
2006			A (VIN 4th)		[P] 2.0L L4 LSJ	CD	CD	CD		CD	CD						CD						CD				CD					
			A (VIN 4th)		[F] 2.2L L4 L61	CD	CD	CD		CD	CD																CD					
			A (VIN 4th)		[B] 2.4L L4 LE5	CD	CD	CD		CD	CD																CD					
			J (VIN 4th)		[7] 1.4L L4 L95	CD		CS9	CD																		S16					
					[6] 1.6L L4 L91	CD		CS9	CD																		S16					
					[6] 1.6L L4 L91 India	CD		CS9	CD																		S16					
					[3] 1.8L L4 L79	CD		CS9	CD																		S16					
					[8] 1.8L L4 L79	CD		CS9	CD																		S16					
					[B] 1.8L L4 LDA	CD		CS9	CD																		S16					
					[Z] 2.0L L4 L34	CD		CS9	CD																		S16					
			K (VIN 4th)		[4] 0.8L L3 LBF	CD		CS9	CD																		S16					
			K (VIN 4th)		[0] 1.0L L4 L11	CD		CS9	CD																		S16					
			L (VIN 4th)		[Z] 2.0L L4 L34	CD		CD	CD																		CD					
			L (VIN 4th)		[L] 2.5L L6 LBK	CD		CD	CD																		CD					
			N (VIN 4th)		[7] 1.4L L4 L95	CD		CS9	CD																		S16					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	P a s s e n g e r	C h e v r o l e t	N (VIN 4th)		[6] 1.6L L4 L91	CD		CS9	CD																	S16							
			N (VIN 4th)		[6] 1.6L L4 L91 India	CD		CS9	CD																	S16							
			N (VIN 4th)		[3] 1.8L L4 L79	CD		CS9	CD																	S16							
			N (VIN 4th)		[8] 1.8L L4 L79	CD		CS9	CD																	S16							
			N (VIN 4th)		[B] 1.8L L4 LDA	CD		CS9	CD																	S16							
			N (VIN 4th)		[Z] 2.0L L4 L34	CD		CS9	CD																	S16							
			S (VIN 4th)	Chevy	[6] 1.6L L4 L01		CD	CD	CD																								
				Chevy	[X] 1.6L L4 LLQ		CD	CD	CD																								
			S (VIN 4th)	Aveo	[T] 1.2L L4 LY4	CD		CD	CD																		S16						
				Aveo	[7] 1.4L L4 L95 India	CD		CD	CD																		S16						
				Aveo	[7] 1.4L L4 L95	CD		CD	CD																		S16						
				Aveo	[A] 1.4L L4 LBJ	CD		CD	CD																		S16						
				Aveo	[Y] 1.5L L4 LV8	CD		CD	CD																		S16						
				Aveo	[6] 1.6L L4 L91	CD		CD	CD																		S16						
				Aveo	[6] 1.6L L4 L91 India	CD		CD	CD																		S16						
			T (VIN 4th)		[T] 1.2L L4 LY4	CD		CD	CD																		S16						
					[7] 1.4L L4 L95 India	CD		CD	CD																		S16						
					[7] 1.4L L4 L95	CD		CD	CD																		S16						
					[A] 1.4L L4 LBJ	CD		CD	CD																		S16						
					[Y] 1.5L L4 LV8	CD		CD	CD																		S16						
					[6] 1.6L L4 L91	CD		CD	CD																		S16						
					[6] 1.6L L4 L91 India	CD		CD	CD																		S16						
			U (VIN 4th)		[6] 1.6L L4 L91	CD		CD	CD																		S16						
			U (VIN 4th)		[Z]2.0L L4 L34	CD	CD	CD	CD																		S16						
			V (VIN 4th)		[Z] 2.0L L4 L34	CD	CD	CD	CD																		CD						
					[L] 2.5L L6 LBJ	CD		CD	CD																		CD						
			W (VIN 4th)		[N]3.5L V6 LZ4	CD	CD	CD	CD	CD	CD								CD					CD		CD			CD				
					[K]3.5L V6 LZE	CD	CD	CD	CD	CD	CD								CD					CD		CD			CD				
					[1]3.9L V6 LZ9	CD	CD	CD	CD	CD	CD								CD					CD		CD			CD				
					[C]5.3L V8 LS4	CD	CD	CD	CD	CD	CD								CD					CD		CD			CD				
			Y (VIN 4th)			CD	CD	CD	CD	CD	CD								CD	CD	CD	CD	CD						CD	CD			
			Z (VIN 4th)		[F] 2.2L L4 L61	CD	CD	CD	CD		CD								CD							CD			CD				
			Z (VIN 4th)		[8] 3.5L V6 LX9	CD	CD	CD	CD				CD						CD							CD			CD				
			Z (VIN 4th)		[1] 3.9L V6 LZ9	CD	CD	CD	CD				CD						CD							CD			CD				
2006	P o n t i a	A (VIN 4th)		[P] 2.0L L4 LSJ		CD	CD	CD	CD	CD							CD							CD			CD						
				[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD								CD						CD			CD						
				[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD								CD						CD			CD						
		K (VIN 4th)		[4] 0.8L L3 LBF	CD		CD	CD																		S16							
				[0] 1.0L L4 L11	CD		CD	CD																		S16							
		M (VIN 4th)		[B] 2.4L L4 LE5	CD	CD	CD	CD				CD						CD						CD	CD			CD					
		V (VIN 4th)		[U] 6.0L V8 LS2	CD	CD	CD																										
		S (VIN 4th)		[L] 1.8L L4 LNK	CD		CD	CD											C									CD					
				[8] 1.8L L4 LV6	CD		CD	CD											C									CD					
		T (VIN 4th)		[6] 1.6L L4 L91	CD		CD	CD																			S16						

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
		C	W (VIN 4th)		[2] 3.8L V6 L26	CD		CD	CD	CD	CD																CD	CD				
						[4] 3.8L V6 L32			CD	CD	CD	CD															CD	CD				
						[C] 5.3L V8 LS4	CD	CD	CD	CD	CD	CD															CD	CD				
			Z (VIN 4th)		[B] 2.4L L4 LE5	CD	CD	CD	CD		CD	CD							CD					CD	CD			CD				
						[8] 3.5L V6 LX9	CD	CD	CD	CD	CD		CD	CD					CD					CD	CD			CD				
						[1] 3.9L V6 LZ9	CD	CD	CD	CD		CD	CD						CD					CD	CD			CD				
2006		B U I C K	J(VIN 4th)		[6] 1.6L L4 L91	CD		CD	CD																							
						[3] 1.8L L4 LDA	CD		CD	CD																						
			H (VIN 4th)		[2] 3.8L V6 L26	CD	CD	CD	CD		CD								CD	CD		CD	CD		CD			CD				
					[Y] 4.6L V8 LD8	CD	CD	CD	CD		CD								CD	CD		CD	CD		CD			CD				
			W (VIN 4th)	Allure	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD															CD				
				Allure	[2] 3.8L V6 L26	CD		CD	CD	CD	CD	CD	CD															CD				
		W (VIN 4th)	LaCrosse		[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD																CD					
				LaCrosse		[2] 3.8L V6 L26	CD		CD	CD	CD	CD																CD				
2006				C a d i l l a c	D (VIN 4th)	[DM] CTS	[T] 2.8L V6 LP1	CD	CD	CD	CD		CD			CD			C	CD	CD	CD			CD			CD		CD		
						[DM] CTS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD				CD			CD	CD	CD	CD			CD			CD		CD	
					D (VIN 4th)	[DP] CTS	[T] 2.8L V6 LP1	CD	CD	CD	CD		CD				CD			CD	CD	CD	CD			CD			CD		CD	
						[DP] CTS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD				CD			CD	CD	CD	CD			CD			CD		CD	
	D (VIN 4th)	[DR] CTS			[T] 2.8L V6 LP1	CD	CD	CD	CD		CD				CD			CD	CD	CD	CD			CD			CD		CD			
		[DR] CTS			[7] 3.6L V6 LY7	CD	CD	CD	CD		CD				CD			CD	CD	CD	CD			CD			CD		CD			
	D (VIN 4th)	[DN] CTS-V				CD	CD	CD	CD		CD				CD			CD	CD	CD	CD			CD			CD		CD			
	D (VIN 4th)	[DC] STS-V8			[A] 4.6L V8 LH2	CD	CD	CD	CD		CD								CD	CD	CD	CD	CD		CD			CD	CD	CD		
	D (VIN 4th)	[DW] STS			[7] 3.6L V6 LY7	CD	CD	CD	CD										CD	CD	CD	CD	CD		CD			CD	CD	CD		
		[DW] STS			[A] 4.6L V8 LH2			CD	CD		CD								CD	CD	CD	CD	CD		CD			CD	CD	CD		
	D (VIN 4th)	[DX] STS-V			[D] 4.4L V8 LC3	CD	CD	CD	CD										CD	CD	CD	CD	CD		CD			CD	CD	CD		
		[DX] STS-V			[A] 4.6L V8 LH2	CD		CD	CD		CD								CD	CD	CD	CD	CD		CD			CD	CD	CD		
	K (VIN 4th)			CD	CD	CD	CD		CD								CD	CD	CD	CD	CD		CD			CD		CD				
	Y (VIN 4th)	[YV] XLR		CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD	CD	CD	CD		CD		CD		CD				
		[YX] XLR-V		CD	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD	CD	CD	CD		CD		CD		CD				
2006		S a t u			[P] 2.0L L4 LSJ	CD		CD	CD	CD	CD							CD									CD					
						[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD							CD									CD				
						[B] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD	CD						CD									CD				
2006			A (VIN 5th)		[D] 2.2L L4 L61	CD	CD	CD	CD	CD	CD							CD					CD	CD			CD					
						[P] 2.4L L4 LE5	CD	CD	CD	CD	CD	CD							CD					CD	CD			CD				
			C (VIN 5th)	Alternative Fuels	[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
				Alternative Fuels	[U] 6.0L V8 LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
				Alternative Fuels	[U] 6.0L V8 LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
					[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
					[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
					[B] 5.3L V8 L33	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
					[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
					[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
					[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
					[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
							[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																		
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
	C h e v r o l e t T r u c k				[D] 6.6L V8 LBZ Diesel	CD	CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C			
					[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C		
						[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C		
				E (VIN 5th)		[C] 2.0L L4 L34	CD		CD	C																								
				G (VIN 5th)	Express/Savana	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD		C									C						CD				
					Express/Savana	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD		C									C						CD				
					Express/Savana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD		C									C						CD				
					Express/Savana	[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD		C									C						CD				
					Express/Savana	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD	CD	CD	CD		C									C						CD				
					Express Access/Savana Pro	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD		C									C						CD				
					Express Access/Savana Pro	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD		C									C						CD				
					Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD		C									C						CD				
					Express Access/Savana Pro	[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD		C									C						CD				
					Express Access/Savana Pro	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD	CD	CD	CD		C									C						CD				
				H (VIN 5th)	Express/Savana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD											C						CD				
					Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD											C						C				
				K (VIN 5th)	Alternative Fuels	[T] 5.3L V8 LM7 Parallel Hybrid			CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
					Alternative Fuels	[U] 6.0L V8 LQ4 Dedicated CNG			CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
					Alternative Fuels	[U] 6.0L V8 LQ4 Bi-Fuel			CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
						[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
						[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
						[B] 5.3L V8 L33	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
						[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
						[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
						[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
						[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
						[D] 6.6L V8 LBZ Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
						[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
						[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
	L D T r k · M P V · I n c o m p l e t e		L (VIN 5th)		[F] 3.4L V6 LNJ	CD	CD	CD	CD	CD								CD									CD							
			P (VIN 5th)		[R] 5.7L V8 L31	CD					CD	CD							C									C						
			S (VIN 5th)	Colorado	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD	CD							C									C						
				Colorado	[6] 3.5L L5 L52	CD		CD	CD	CD	CD	CD							C									C						
				TrailBlazer	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD		C	CD			C	CD		CD						CD	CD					
				TrailBlazer	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD	CD		C	CD			C	CD		CD					CD	CD					
				TrailBlazer	[H] 6.0L V8 LS2	CD	CD	CD	CD	CD	CD	CD	CD	CD		C	CD			C	CD		CD					CD	CD					
				TrailBlazer EXT	[S] 4.2L L6 LL8	CD		CD			CD	CD	CD	CD		C				C	CD		CD					CD	CD					
				TrailBlazer EXT	[M] 5.3L V8 LH6	CD	CD	CD			CD	CD	CD	CD		C				C	CD		CD					CD	CD					
				SSR			CD	CD	CD	CD	CD	CD	CD																					
				T (VIN 5th)	Colorado	[8] 2.8L L4 LK5	CD			CD	CD	CD	CD							C	CD		CD						C					
					Colorado	[6] 3.5L L5 L52	CD			CD	CD	CD	CD							C	CD		CD						C					
					TrailBlazer	[S] 4.2L L6 LL8	CD			CD	CD	CD	CD	CD		C	CD			C	CD		CD						CD	CD				
					TrailBlazer	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD		C	CD			C	CD		CD						CD	CD				
					TrailBlazer	[H] 6.0L V8 LS2	CD	CD	CD	CD	CD	CD	CD	CD		C	CD			C	CD		CD						CD	CD				
					TrailBlazer EXT	[S] 4.2L L6 LL8	CD			CD		CD	CD	CD		C				C	CD		CD						CD	CD				
					TrailBlazer EXT	[M] 5.3L V8 LH6	CD	CD	CD	CD		CD	CD	CD		C				C	CD		CD						CD	CD				
					SSR			CD	CD	CD	CD	CD	CD																CD		CD	CD		
2006				C (VIN 5th)	Alternative Fuels	[T] 5.3L V8 LM7 Parallel Hybrid	CD			CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
					Alternative Fuels	[U] 6.0L V8 LQ4 Dedicated CNG	CD			CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C	
					Alternative Fuels	[U] 6.0L V8 LQ4 Bi-Fuel	CD			CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
						[X] 4.3L V6 LU3	CD			CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
						[V] 4.8L V8 LR4	CD			CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
						[B] 5.3L V8 L33	CD			CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
						[Z] 5.3L V8 L59	CD			CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
						[T] 5.3L V8 LM7	CD			CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
						[R] 5.7L V8 L31	CD			CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
						[U] 6.0L V8 LQ4	CD			CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
						[N] 6.0L V8 LQ9	CD			CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
							[D] 6.6L V8 LBZ Diesel	CD	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
							[2] 6.6L V8 LLY Diesel	CD	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
							[G] 8.1L V8 L18	CD			CD	CD	CD	CD	CD	C	C	CD		CD	CD	CD	C	CD						CD	CD	CD	C	
					G (VIN 5th)	Express/Sav ana	[X] 4.3L V6 LU3	CD			CD	CD	CD	CD		C														CD				
						Express/Sav ana	[V] 4.8L V8 LR4	CD			CD	CD	CD	CD		C														CD				
						Express/Sav ana	[T] 5.3L V8 LM7	CD			CD	CD	CD	CD		C														CD				
						Express/Sav ana	[U] 6.0L V8 LQ4	CD			CD	CD	CD	CD		C														CD				
				Express/Sav ana	[2] 6.6L V8 LLY Diesel	CD	CD		CD	CD	CD	CD		C														CD						

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
		G M C T r u c k		Express Access/Sava na Pro	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		C														CD					
				Express Access/Sava na Pro	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		C															CD				
				Express Access/Sava na Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		C															CD				
				Express Access/Sava na Pro	[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD		C															CD				
				Express Access/Sava na Pro	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD	CD	CD		C															CD				
				H (VIN 5th)	Express/Sav ana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD																CD				
					Express Access/Sava na Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD																CD				
				K (VIN 5th)	Alternative Fuels	[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
					Alternative Fuels	[U] 6.0L V8 LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
					Alternative Fuels	[U] 6.0L V8 LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
						[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
						[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
						[B] 5.3L V8 L33	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
						[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
						[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
						[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
						[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
						[D] 6.6L V8 LBZ Diesel	CD	CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
						[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
						[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD						CD	CD	CD		
				P (VIN 5th)		[R] 5.7L V8 L31	CD																									
				S (VIN 5th)	Canyon	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD	CD						C									CD				
					Canyon	[6] 3.5L L5 L52	CD		CD	CD	CD	CD	CD						C									CD				
					Envoy	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD		C			CD	CD	C	CD						CD	CD			
					Envoy	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD	C	CD						CD	CD			
					Envoy XL	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD		C			CD	CD	C	CD						CD	CD			
					Envoy XL	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD	C	CD						CD	CD			
				T (VIN 5th)	Canyon	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD	CD															CD				
					Canyon	[6] 3.5L L5 L52	CD		CD	CD	CD	CD	CD															CD				
					Envoy	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD		C			CD	CD	C	CD						CD	CD			
					Envoy	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD	C	CD						CD	CD			
					Envoy XL	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD		C			CD	CD	C	CD						CD	CD			
					Envoy XL	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD		C			CD	CD	C	CD						CD	CD			
2006			A (VIN 5th)		[L] 3.5L V6 LX9	CD		CD	CD	CD	CD	CD		CD			CD										CD	CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
		B u l c k			[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD		CD				CD										CD	CD					
			B (VIN 5th)		[L] 3.5L V6 LX9	CD		CD	CD	CD	CD	CD	CD		CD				CD										CD	CD				
					[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD		CD				CD										CD	CD				
			S (VIN 5th)		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD		C				CD	CD		CD							CD	CD				
					[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD		CD							CD	CD				
			T (VIN 5th)		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD		C				CD	CD		CD							CD	CD				
					[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD		C				CD	CD		CD							CD	CD				
			V (VIN 5th)		[L] 3.5L V6 LX9	CD		CD	CD	CD	CD	CD	CD						CD										CD	CD				
					[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD	CD	CD						CD										CD	CD				
				[L] 3.5L V6 LX9	CD		CD	CD	CD	CD	CD	CD						CD										CD	CD					
2006			C a d i l	C (VIN 5th)		[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD	C		
				E (VIN 5th)		[7] 3.6L V6 LY7	CD	CD	CD	CD		CD			CD	CD		CD	CD	CD		CD							CD	CD				
						[A] 4.6L V8 LH2	CD	CD	CD	CD		CD			CD	CD		CD	CD	CD		CD							CD	CD				
					K (VIN 5th)		[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	CD	C	CD							CD	CD	CD		
2006			C a d		Hearse		CD	CD	CD	CD		CD	CD						CD	CD	CD	CD	CD	CD	CD				CD	CD	CD			
						Limousine		CD	CD	CD	CD		CD	CD						CD	CD	CD	CD	CD	CD	CD				CD	CD			
2006			P o n t i a c	L (VIN 5th)		[F] 3.4L V6 LNJ	CD	CD	CD	CD	CD								CD										CD					
					U (VIN 5th)		[L] 3.5L V6 LX9	CD		CD	CD	CD	CD						CD										CD	CD				
							[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD						CD											CD	CD			
					V (VIN 5th)			CD		CD	CD	CD	CD							CD										CD	CD			
								CD	CD	CD	CD	CD	CD							CD										CD	CD			
					X (VIN 5th)		[L] 3.5L V6 LX9	CD		CD	CD	CD	CD							CD										CD	CD			
2006			C h e v r o l	U (VIN 5th)		[L] 3.5L V6 LX9	CD		CD	CD	CD	CD							CD										CD	CD				
							[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD							CD										CD	CD			
					V (VIN 5th)		[L] 3.5L V6 LX9	CD		CD	CD	CD	CD							CD										CD	CD			
							[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD							CD										CD	CD			
					X (VIN 5th)		[L] 3.5L V6 LX9	CD		CD	CD	CD	CD							CD										CD	CD			
2006			H u m		H2	[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD						CD	CD	C	CD							CD	CD				
						H3		CD		CD	CD	CD	CD																CD	CD				
2006			S A A			[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		C				CD	CD	C	CD							CD	CD				
						[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD		C				CD	CD	C	CD							CD	CD				
2006		S a t u r n	V (VIN 5th)		[L] 3.5L V6 LX9	CD		CD	CD	CD	CD							CD										CD	CD					
						[1] 3.9L V6 LZ9	CD	CD	CD	CD	CD	CD							CD										CD	CD				
				X (VIN 5th)		[L] 3.5L V6 LX9	CD		CD	CD	CD	CD							CD										CD	CD				
				Z (VIN 5th)		[D] 2.2L L4 L61	CD		CD	CD	CD								CD										CD	CD				
						[4] 3.5L V6 L66	CD		CD	CD	CD								CD										CD	CD				
2006		C h		C-WT5500	[6] 5.2L L4 Diesel	CD																												
					C-WT5500	[2] 6.6L V8 LLY Diesel	CD	CD																										
					C-WT5500	[3] 7.8L L6 LG4	CD																											
					C-WT5500	[G] 8.1L V8 L18	CD																											
					T-B7 Chassis	[6] 5.2L L4 Diesel	CD		CD																									
					T-B7 Chassis	[2] 6.6L V8 LLY Diesel	CD	CD	CD																									
					T-B7 Chassis	[3] 7.8L L6 LG4	CD		CD																									

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	Medium Duty Truck	e v r o l e t T r u c k		T-B7 Chassis	[G] 8.1L V8 L18	CD		CD																									
				D-C Series	[6] 5.2L L4 Diesel	CD		CD	CD		CD			C														C					
				D-C Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD		CD			C														C					
				D-C Series	[3] 7.8L L6 LG4	CD		CD	CD		CD			C														C					
				D-C Series	[G] 8.1L V8 L18	CD		CD	CD		CD			C														C					
				C-T Series	[6] 5.2L L4 Diesel	CD		CD	C		CD			C														C					
				C-T Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD	C		CD			C														C					
				C-T Series	[3] 7.8L L6 LG4	CD		CD	C		CD			C														C					
				C-T Series	[G] 8.1L V8 L18	CD		CD	C		CD			C														C					
				B-W4 Series	[6] 5.2L L4 Diesel	CD		CD																									
				B-W4 Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD																									
				B-W4 Series	[U] 6.0L V8 LQ4	CD		CD																									
				B-W4 Series	[3] 7.8L L6 LG4	CD		CD																									
				B-W4 Series	[G] 8.1L V8 L18	CD		CD																									
2006		Duty Truck	G M C T r u c k		C-WT5500	[6] 5.2L L4 Diesel	CD																										
					C-WT5500	[2] 6.6L V8 LLY Diesel	CD	CD																									
					C-WT5500	[3] 7.8L L6 LG4	CD																										
					C-WT5500	[G] 8.1L V8 L18	CD																										
					T-B7 Chassis	[6] 5.2L L4 Diesel	CD		CD																								
					T-B7 Chassis	[2] 6.6L V8 LLY Diesel	CD	CD	CD																								
					T-B7 Chassis	[3] 7.8L L6 LG4	CD		CD																								
					T-B7 Chassis	[G] 8.1L V8 L18	CD		CD																								
					D-C Series	[6] 5.2L L4 Diesel	CD		CD	CD		CD			C															C			
					D-C Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD	CD		CD			C															C			
					D-C Series	[3] 7.8L L6 LG4	CD		CD	CD		CD			C															C			
					D-C Series	[G] 8.1L V8 L18	CD		CD	CD		CD			C															C			
					C-T Series	[6] 5.2L L4 Diesel	CD		CD	C		CD			C															C			
					C-T Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD	C		CD			C															C			
				C-T Series	[3] 7.8L L6 LG4	CD		CD	C		CD			C															C				
				C-T Series	[G] 8.1L V8 L18	CD		CD	C		CD			C															C				
				B-W4 Series	[6] 5.2L L4 Diesel	CD		CD																									
				B-W4 Series	[2] 6.6L V8 LLY Diesel	CD	CD	CD																									
				B-W4 Series	[U] 6.0L V8 LQ4	CD		CD																									
				B-W4 Series	[3] 7.8L L6 LG4	CD		CD																									

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
	2006	H u m e r		B-W4 Series	[G] 8.1L V8 L18	CD		CD																								
					[F] 6.5L V8 L65	CD																					CD					
					[P] 6.6L V8 LLY Diesel	CD	CD																					CD				
2006	W o r k h o r s e			1 - LF72 Series		CD	CD																									
				1 - LF72 Series		CD		CD																								
				A - W24 Series		CD																										
				7 - W52 Series		CD		CD																								
				C - FE20 Series		CD																										
				D - W42 Series	[3] 4.5L V6 L61 Diesel	CD	CD																									
				D - W42 Series	[V] 4.8L V8 LR4	CD																										
				D - W42 Series	[U] 6.0L V8 LQ4	CD																										
				E - W18 Series	[U] 6.0L V8 LQ4	CD																										
2005	C h e v		A (VIN 4th)		[P] 2.0L L4 LSJ	CD		CD	CD	CD	CD																CD					
			A (VIN 4th)		[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD																CD					
			J (VIN 4th)	Cavalier	[F] 2.2L L4 L61	CD		CD	CD	CD	CD								C									CD				
				Optra	[7] 1.4L L4 L95	CD		CD	CD																							
				Optra	[6] 1.6L L4 L91	CD		CD	CD																							
				Optra	[U] 1.6L L4 L91			CD	CD																							
				Optra	[3] 1.8L L4 L79	CD		CD	CD																							
				Optra	[8] 1.8L L4 L79	CD		CD	CD																							
				Optra	[P] 1.8L L4 L79	CD		CD	CD																							
				Optra	[Z] 2.0 L L4 L34			CD	CD																							
				L (VIN 4th)		[6] 1.6L L4 L91 India	CD		CD	CD																						
						[Z] 2.0L L4 L34(Euro II,ECE 83)	CD	CD	CD	CD																						
						[L] 2.5L L6 LBK Automatic	CD		CD	CD																						
						[L] 2.5L L6 LBK Manual	CD		CD	CD																						
				M (VIN 4th)		[4] 0.8L L3 LBF	CD		CD	CD																						
						[0] 1.0L L4 LA2	CD		CD	CD																						
						[J] 1.0L L4 LA2	CD		CD	CD																						
				N (VIN 4th)	Optra	[7] 1.4L L4 L95	CD		CD	CD																						
					Optra	[6] 1.6L L4 L91	CD		CD	CD																						
					Optra	[U] 1.6L L4 L91			CD	CD																						
					Optra	[3] 1.8L L4 L79	CD		CD	CD																						
					Optra	[8] 1.8L L4 L79	CD		CD	CD																						
					Optra	[P] 1.8L L4 L79	CD		CD	CD																						
			Optra	[Z] 2.0 L L4 L34			CD	CD																								

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	P a s s e n g e r	r o l e t		Classic	[F] 2.2L L4 L61	CD			CD	CD												C						CD					
			S (VIN 4th)	Monza	[X] 1.6L L4 LLQ	CD																											
				Monza	[6] 1.6L L4 L01	CD	CD																										
				Aveo	[T] 1.2L L4 LY4	CD		CD	CD																								
				Aveo	[7] 1.4L L4 L95	CD		CD	CD																								
				Aveo	[A] 1.4L L4 LBJ	CD		CD	CD																								
				Aveo	[Y] 1.5L L4 LV8	CD		CD	CD																								
				Aveo	[6] 1.6L L4 L91	C S3		CD	CD																								
				Chevy	[X] 1.6L L4 LLQ	CD																											
				Chevy	[6] 1.6L L4 L01	CD	CD																										
				T (VIN 4th)		[T] 1.2L L4 LY4	CD			CD	CD																						
						[7] 1.4L L4 L95	CD			CD	CD																						
						[A] 1.4L L4 LBJ	CD			CD	CD																						
						[Y] 1.5L L4 LV8	CD			CD	CD																						
						[6] 1.6L L4 L91	CD			CD	CD																						
				U (VIN 4th)		[6] 1.6L L4 L91	CD			CD	CD																						
						[U] 1.6L L4 L91	CD			CD	CD																						
							[Z] 2.0L L4 L34(Euro II,ECE 83)	CD	CD	CD	CD																						
				V (VIN 4th)		[Z] 2.0L L4 L34	CD	CD	CD	CD	CD																						
						[L] 2.5L L6 LBK	CD			CD	CD																						
			W (VIN 4th)		[E] 3.4L V6 LA1	CD			CD	CD	CD	CD	C						C										CD				
					[1] 3.8L V6 L67	CD			CD	CD	CD	CD	C						C										CD				
					[K] 3.8L V6 L36	CD			CD	CD	CD	CD	C						C										CD				
			Y (VIN 4th)				CD	CD	CD	CD		CD																	CD	CD			
			Z (VIN 4th)			[F] 2.2L L4 L61	CD		CD	CD		CD																	CD				
						[8] 3.5L V6 LX9	CD	CD	CD	CD		CD																	CD				
2005			A v e o	A (VIN 4th)		[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD																	CD				
						[P] 2.0L L4 LSJ	CD	CD	CD	CD	CD	CD																	CD				
				H (VIN 4th)	[HX] Bonneville SE		CD			CD	CD		CD			C				C	C			C					CD				
					[HY] Bonneville SLE		CD			CD	CD		CD			C				C	C			C					CD				
				[HZ] Bonneville GXP		CD			CD	CD		CD			C				C	C			C					CD					
		J (VIN 4th)				[F] 2.2L L4 L61 Automatic	CD		CD	CD	CD	CD							C									CD					
						[F] 2.2L L4 L61 Manual	CD		CD	CD	CD	CD							C									CD					
		M (VIN 4th)				[4] 0.8L L3 LBF	CD		CD	CD																							
						[K] 0.8L L3 LBF	CD		CD	CD																							
						[0] 1.0L L4 LA2	CD		CD	CD																							
					[J] 1.0L L4 LA2	CD		CD	CD																								
		N (VIN 4th)			[F] 2.2L L4 L61	CD		CD	CD	CD	CD											C					CD						
					[E] 3.4L V6 LA1	CD		CD	CD	CD	CD											C					CD						

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS			
			S (VIN 4th)		[L] 1.8L L4 LNK	CD		CD	CD									C									CD								
					[8] 1.8L L4 LV6	CD		CD	CD										C									CD							
			T (VIN 4th)		[6] 1.6L L4 L91	CD		CD	CD																				CD						
			W (VIN 4th)		[2] 3.8L V6 L26	CD		CD	CD	CD	CD	CD	CD	CD															CD	CD					
					[4] 3.8L V6 L32	CD		CD	CD	CD	CD	CD	CD	CD															CD	CD					
					[C] 5.3L V8 LS4	CD	CD	CD	CD	CD	CD	CD	CD	CD															CD	CD					
			V (VIN 4th)		[U] 6.0L V8 LS2	CD	CD	CD																											
		Z (VIN 4th)				CD		CD	CD	CD	CD	CD																CD							
2005		B U I C K	C (VIN 5th)		[1] 3.8L V6 L67	CD		CD		CD	CD	CD	CD		C					C			C												
					[K] 3.8L V6 L36	CD		CD		CD	CD	CD	CD		C					C			C												
			H (VIN 4th)	[HP] LeSabre Custom	[K] 3.8L V6 L36	CD		CD	CD		CD					C				C	CD			C					CD						
				[HR] LeSabre Limited	[K] 3.8L V6 L36	CD		CD	CD		CD					C				C	CD			CD					CD						
			W (VIN 4th)	Century	[J] 3.1L V6 LG8	CD		CD	CD	CD	CD	CD	CD	CD															C						
				Allure	[2] 3.8L V6 L26	CD		CD	CD	CD	CD	CD	CD	CD															CD						
				Allure	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	CD															CD						
				Lacrosse	[2] 3.8L V6 L26	CD		CD	CD	CD	CD	CD	CD	CD															CD						
				Lacrosse	[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD	CD	CD															CD						
			C a d i l l a c	D (VIN 4th)	[DM] CTS	[T] 2.8L V6 LP1	CD	CD	CD	CD	CD		CD			C				CD	C		C	C						CD		C			
				[DM] CTS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD				C				CD	C		C	C						CD		C				
				[DP] CTS	[T] 2.8L V6 LP1	CD	CD	CD	CD		CD				C				CD	C		C	C						CD		C				
				[DP] CTS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD				C				CD	C		C	C						CD		C				
				[DR] CTS	[T] 2.8L V6 LP1	CD	CD	CD	CD		CD				C				CD	C		C	C						CD		C				
				[DR] CTS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD				C				CD	C		C	C						CD		C				
				[DN] CTS-V	[S] 5.7L V8 LS6	CD		CD	CD		CD		CD			C				CD	C		C	C					CD		C				
				[DN] CTS-V	[U] 6.0L V8 LS2	CD		CD	CD		CD		CD			C				CD	C		C	C					CD		C				
				[DC] STS-V8	[4] 4.6L V8 LH2	CD	CD	CD	CD		CD	CD	CD																CD	CD					
				[DW] STS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD	CD	CD																CD	CD					
				[DW] STS	[A] 4.6L V8 LH2	CD	CD	CD	CD		CD	CD	CD																CD	CD					
		K (VIN 4th)		[KD] Deville	[9] 4.6L V8 L37	CD		CD	CD		CD		CD			C				CD	C		C	C					C	CD	C				
				[KD] Deville	[Y] 4.6L V8 LD8	CD		CD	CD		CD		CD			C				CD	C		C	C					C	CD	C				
				[KE] DHS	[9] 4.6L V8 L37	CD		CD	CD		CD		CD			C				CD	C		C	C					C	CD	C				
				[KE] DHS	[Y] 4.6L V8 LD8	CD		CD	CD		CD		CD			C				CD	C		C	C					C	CD	C				
				[KF] DTS	[9] 4.6L V8 L37	CD		CD	CD		CD		CD			C				CD	C		C	C					C	CD	C				
				[KF] DTS	[Y] 4.6L V8 LD8	CD		CD	CD		CD		CD			C				CD	C		C	C					C	CD	C				
		Y (VIN 4th)				CD	CD	CD	CD		CD																		CD						
2005		S a t u	A (VIN 4th)		[P] 2.0L L4 LSJ	CD		CD	CD	CD	CD	CD							CD										CD						
					[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD	CD								CD										CD					
2005			J (VIN 4th)		[R] 3.0L V6 L81	CD		CD	CD	CD		CD																							
			C (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C							CD	CD	CD	CD	CD		
					[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C								CD	CD	CD	CD	CD	
					[B] 5.3L V8 L33	CD		CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C									CD	CD	CD	CD	CD
					[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C									CD	CD	CD	CD	CD
					[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C									CD	CD	CD	CD	CD
					[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C								CD	CD	CD	CD	CD		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																	
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	Chevrolet Truck				[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C						CD	CD	CD	CD	CD		
					[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C						CD	CD	CD	CD	CD		
							[Z] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C						CD	CD	CD	CD	CD	
							[G] 8.1L V8 L18	C S10S1S3		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C						CD	CD	CD	CD	CD
							[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C						CD	CD	CD	CD	CD
							[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C						CD	CD	CD	CD	CD
							[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C						CD	CD	CD	CD	CD
					E (VIN 5th)		[C] 2.0L L4 L34	CD		CD																							
					G (VIN 5th)	Express/Savana	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		CD								CD						CD				
						Express/Savana	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		CD								CD						CD				
						Express/Savana	[B] 5.3L V8 L33	CD		CD	CD	CD	CD		CD								CD						CD				
						Express/Savana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD								CD						CD				
						Express/Savana	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		CD								CD						CD				
						Express/Savana	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		CD								CD						CD				
						Express Access/Savana Pro	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		CD								CD						CD				
						Express Access/Savana Pro	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		CD								CD						CD				
						Express Access/Savana Pro	[B] 5.3L V8 L33	CD		CD	CD	CD	CD		CD								CD						CD				
						Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD								CD						CD				
						Express Access/Savana Pro	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		CD								CD						CD				
						Express Access/Savana Pro	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		CD								CD						CD				
					H (VIN 5th)	Express/Savana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD								CD						CD				
						Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD								CD						CD				
					J (VIN 5th)		[C] 2.0L L4 L34	CD																									
					K (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C						CD	CD	CD	CD	CD
							[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C						CD	CD	CD	CD	CD
							[B] 5.3L V8 L33	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C						CD	CD	CD	CD	CD
							[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C						CD	CD	CD	CD	CD

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS			
					[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C							CD	CD	CD	CD	CD			
					[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C							CD	CD	CD	CD	CD		
					[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C							CD	CD	CD	CD	CD	
							[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C								CD	CD	CD	CD	CD
							[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	C	C	CD		CD	CD	C	C	C								CD	CD	CD	CD	CD
						Alternative Fuels	[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	C	C	CD		CD	C	C	C	C								CD	CD	CD	CD	CD
						Alternative Fuels	[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD	C	C	CD		CD	C	C	C	C								CD	CD	CD	CD	CD
						Alternative Fuels	[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	C	C	CD		CD	C	C	C	C								CD	CD	CD	CD	CD
					L (VIN 5th)	Astro	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																						
						Equinox	[F] 3.4L V6 LNJ	CD	CD	CD	CD	CD								CD										CD					
					M (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																						
					P (VIN 5th)		[R] 5.7L V8 L31	CD																											
					S (VIN 5th)	Colorado	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD							CD										CD					
						Colorado	[6] 3.5L L5 L52	CD		CD	CD	CD	CD							CD											CD				
						TrailBlazer	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		C				CD	CD	CD	CD								CD	CD		CD	
						TrailBlazer EXT	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		C				CD	CD	CD	CD								CD	CD		CD	
						TrailBlazer EXT	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD		C				CD	CD	CD	CD								CD	CD		CD	
						TrailBlazer EXT	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD		C				CD	CD	CD	CD								CD	CD		CD	
						Blazer	[X] 4.3L V6 LU3(4 Speed Automatic)	CD		CD	CD	CD	CD	CD																	CD			CD	
						Blazer	[X] 4.3L V6 LU3(Manual)	CD		CD	CD	CD	CD	CD																	CD			CD	
						SSR		CD	CD	CD	CD	CD	CD									CD		CD							CD		CD	CD	
					T (VIN 5th)	Colorado	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD							CD											CD				
						Colorado	[6] 3.5L L5 L52	CD		CD	CD	CD	CD							CD											CD				
						TrailBlazer	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		CD				CD	CD	CD	CD								CD	CD			
						TrailBlazer EXT	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		CD				CD	CD	CD	CD								CD	CD			
						TrailBlazer EXT	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD		CD				CD	CD	CD	CD								CD	CD			
						Blazer	[X] 4.3L V6 LU3(4 Speed Automatic)	CD		CD	CD	CD	CD	CD																	CD				
						Blazer	[X] 4.3L V6 LU3(Manual)	CD		CD	CD	CD	CD	CD																	CD				
2005					C (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD								CD	CD	CD	CD	CD
							[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD								CD	CD	CD	CD	CD
							[B] 5.3L V8 L33	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD								CD	CD	CD	CD	CD
							[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD								CD	CD	CD	CD	CD
					[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD								CD	CD	CD	CD	CD		
					[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD								CD	CD	CD	CD	CD		
					[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD								CD	CD	CD	CD	CD		
					[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD								CD	CD	CD	CD	CD		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																	
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	L D T r k · M P V · I n c o m p l e t e	G M C T r u c k			[1] 6.6L V8 LB7 Diesel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD						CD	CD	CD	CD	CD		
					[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD						CD	CD	CD	CD	CD		
					[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD						CD	CD	CD	CD	CD		
				Alternative Fuels	[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD						CD	CD	CD	CD	CD		
				Alternative Fuels	[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD						CD	CD	CD	CD	CD		
				Alternative Fuels	[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	C	CD						CD	CD	CD	CD	CD		
				G (VIN 5th)	Express/Savana	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		CD									CD					CD					
					Express/Savana	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		CD									CD					CD					
					Express/Savana	[B] 5.3L V8 L33	CD		CD	CD	CD	CD		CD									CD					CD					
					Express/Savana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD									CD					CD					
					Express/Savana	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		CD									CD					CD					
					Express/Savana	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		CD									CD					CD					
					Express Access/Savana Pro	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		CD									CD					CD					
					Express Access/Savana Pro	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		CD									CD					CD					
					Express Access/Savana Pro	[B] 5.3L V8 L33	CD		CD	CD	CD	CD		CD									CD					CD					
					Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD									CD					CD					
					Express Access/Savana Pro	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		CD									CD					CD					
					Express Access/Savana Pro	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		CD									CD					CD					
				H (VIN 5th)	Express/Savana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD									CD					CD					
					Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD									CD					CD					
				K (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD						CD	CD	CD		CD
						[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD						CD	CD	CD		CD
						[B] 5.3L V8 L33	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD						CD	CD	CD		CD
						[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD						CD	CD	CD		CD
						[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD						CD	CD	CD		CD
						[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD						CD	CD	CD		CD
						[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD						CD	CD	CD		CD

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																			
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS			
					[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD							CD	CD	CD		CD			
					[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD							CD	CD	CD		CD		
					[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD							CD	CD	CD		CD		
						[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD							CD	CD	CD		CD		
						[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD		C	C	CD							CD	CD	CD		CD		
					L (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																						
					M (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																						
					P (VIN 5th)		[R] 5.7L V8 L31	CD																											
					S (VIN 5th)	Canyon	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD							CD										CD					
						Canyon	[6] 3.5L L5 L52	CD		CD	CD	CD	CD							CD											CD				
						Envoy	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD		C				CD	CD	CD	CD								CD	CD		CD	
						Envoy	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		C				CD	CD	CD	CD								CD	CD		CD	
						Envoy XL	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		CD				CD	CD	CD	CD								CD	CD		CD	
						Envoy XL	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD		CD				CD	CD	CD	CD								CD	CD		CD	
						Envoy XUV	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		CD				CD	CD	CD	CD								CD	CD		CD	
						Envoy XUV	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD		CD				CD	CD	CD	CD								CD	CD		CD	
						Jimmy	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD																	CD			CD	
						Sonoma	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																		CD			CD	
					T (VIN 5th)	Canyon	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD							CD											CD				
						Canyon	[6] 3.5L L5 L52	CD		CD	CD	CD	CD							CD											CD				
						Envoy	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD		CD				CD	CD	CD	CD								CD	CD			
						Envoy	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		CD				CD	CD	CD	CD								CD	CD			
						Envoy XL	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		CD				CD	CD	CD	CD								CD	CD			
						Envoy XL	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD		CD				CD	CD	CD	CD								CD	CD			
						Envoy XUV	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD								CD	CD			
						Envoy XUV	[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD						CD	CD	CD	CD								CD	CD			
						Jimmy	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD																	CD				
						Sonoma	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																		CD				
2005			B u i c k		A (VIN 5th)		[E] 3.4L V6 LA1	CD		CD	CD	CD	CD	CD		C				C										CD	CD				
								[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD		C				C										CD	CD			
		B (VIN 5th)				[E] 3.4L V6 LA1	CD		CD	CD	CD	CD			C				C											CD	CD				
						[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD			C				C												CD	CD			
		S (VIN 5th)				[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD						C	C	C	C								CD	CD		C	
						[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD						C	C	C	C								CD	CD		C	
		T (VIN 5th)				[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD	CD		C				C	C	C	C								CD	CD			
						[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD	CD		C				C	C	C	C								CD	CD			
		V (VIN 5th)						CD		CD	CD	CD	CD	CD																CD	CD				
		X (VIN 5th)						CD		CD	CD	CD	CD	CD																	CD	CD			
2005	C a d i l l		C (VIN 5th)		[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	C	C	C	C	C							CD	CD	C	C	CD		
				E (VIN 5th)		[7] 3.6L V6 LY7	CD	CD	CD	CD		CD			C	CD		CD	C	C		C	C							CD	CD	C			
						[A] 4.6L V8 LH2	CD	CD	CD	CD		CD			C	CD		CD	C	C		C	C								CD	CD	C		
				K (VIN 5th)		[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	C	C	C	C	C							CD	CD	C	C	CD
2005	S		V (VIN 5th)		[8] 3.5L V6 LX9	CD		CD	CD	CD	CD	CD																	CD	CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																	
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
		a t u r n	X (VIN 5th)		[8] 3.5L V6 LX9	CD		CD	CD	CD	CD	CD															CD	CD					
			Z (VIN 5th)		[D] 2.2L L4 L61	CD		CD	CD	CD									CD									CD					
					[4] 3.5L V6 L66	CD		CD	CD	CD									CD									CD					
2005		C a d i l		Hearse	[9] 4.6L V8 L37	CD		CD	CD		CD			C	CD			C	C		C	C						C					
				Hearse	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C	CD			C	C		C	C						C					
				Limousine	[9] 4.6L V8 L37	CD		CD	CD		CD			C	CD			C	C		C	C						C	CD	C			
				Limousine	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C	CD			C	C		C	C						C	CD	C			
2005		P o n t i a c	A (VIN 5th)			CD		CD	CD	CD	CD			C				C										CD					
			B (VIN 5th)			CD		CD	CD	CD	CD			C				C										CD					
			U (VIN 5th)			CD		CD	CD	CD	CD	CD	CD						C									CD	CD				
			V (VIN 5th)	Montana SV6		CD		CD	CD	CD	CD	CD	CD															CD	CD				
				Montana		CD		CD	CD		CD									CD									CD				
			X (VIN 5th)			CD		CD	CD	CD	CD	CD	CD	CD															CD	CD			
2005			U (VIN 5th)			CD		CD	CD	CD	CD	CD	CD																CD	CD			
			V (VIN 5th)	Venture		CD		CD	CD		CD									CD									CD				
		A C h e v r		Uplander		CD		CD	CD	CD	CD	CD	CD																CD	CD			
			X (VIN 5th)			CD		CD	CD	CD	CD	CD	CD																CD	CD			
2005		H u m m			[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD						C	C	C	C							CD	CD			
2005			S A A			[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		C					C	C	C	C						CD	CD			
						[M] 5.3L V8 LH6	CD	CD	CD	CD	CD	CD	CD		C					C	C	C	C						CD	CD			
2005	C h e v r o l e t T r u c k			C-WT5500	[6] 5.2L L4 Diesel	CD																											
				C-WT5500	[2] 6.6L V8 LLY Diesel	CD																											
				C-WT5500	[3] 7.8L L6 LG4	CD																											
				C-WT5500	[E] 8.1L V8 L18	CD																											
				T-B7 Chassis	[6] 5.2L L4 Diesel	CD		CD																									
				T-B7 Chassis	[2] 6.6L V8 LLY Diesel	CD		CD																									
				T-B7 Chassis	[3] 7.8L L6 LG4	CD		CD																									
				T-B7 Chassis	[E] 8.1L V8 L18	CD		CD																									
				D-C Series	[6] 5.2L L4 Diesel	CD		CD	CD		CD				C															CD			
				D-C Series	[2] 6.6L V8 LLY Diesel	CD		CD	CD		CD				C															CD			
				D-C Series	[3] 7.8L L6 LG4	CD		CD	CD		CD				C															CD			
				D-C Series	[E] 8.1L V8 L18	CD		CD	CD		CD				C															CD			
				C-T Series	[6] 5.2L L4 Diesel	CD		CD	CD		CD				C															CD			
				C-T Series	[2] 6.6L V8 LLY Diesel	CD		CD	CD		CD				C															CD			
				C-T Series	[3] 7.8L L6 LG4	CD		CD	CD		CD				C															CD			
				C-T Series	[E] 8.1L V8 L18	CD		CD	CD		CD				C															CD			

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS			
	Medium Duty Truck			B-W4 Series	[6] 5.2L L4 Diesel	CD		CD																											
				B-W4 Series	[U] 6.0L V8 LQ4	CD		CD																											
				B-W4 Series	[2] 6.6L V8 LLY Diesel	CD		CD																											
				B-W4 Series	[3] 7.8L L6 LG4	CD		CD																											
				B-W4 Series	[E] 8.1L V8 L18	CD		CD																											
2005			GMC Truck		C-WT5500	[6] 5.2L L4 Diesel	CD																												
					C-WT5500	[2] 6.6L V8 LLY Diesel	CD																												
					C-WT5500	[3] 7.8L L6 LG4	CD																												
					C-WT5500	[E] 8.1L V8 L18	CD																												
					T-B7 Chassis	[6] 5.2L L4 Diesel	CD		CD																										
					T-B7 Chassis	[2] 6.6L V8 LLY Diesel	CD		CD																										
					T-B7 Chassis	[3] 7.8L L6 LG4	CD		CD																										
					T-B7 Chassis	[E] 8.1L V8 L18	CD		CD																										
					D-C Series	[6] 5.2L L4 Diesel	CD		CD	CD			CD				CD														CD				
					D-C Series	[2] 6.6L V8 LLY Diesel	CD		CD	CD			CD				CD														CD				
					D-C Series	[3] 7.8L L6 LG4	CD		CD	CD			CD				CD														CD				
					D-C Series	[E] 8.1L V8 L18	CD		CD	CD			CD				CD														CD				
					C-T Series	[6] 5.2L L4 Diesel	CD		CD	CD			CD				CD														CD				
					C-T Series	[2] 6.6L V8 LLY Diesel	CD		CD	CD			CD				CD														CD				
					C-T Series	[3] 7.8L L6 LG4	CD		CD	CD			CD				CD														CD				
					C-T Series	[E] 8.1L V8 L18	CD		CD	CD			CD				CD														CD				
					B-W4 Series	[6] 5.2L L4 Diesel	CD		CD																										
					B-W4 Series	[U] 6.0L V8 LQ4	CD		CD																										
					B-W4 Series	[2] 6.6L V8 LLY Diesel	CD		CD																										
					B-W4 Series	[3] 7.8L L6 LG4	CD		CD																										
					B-W4 Series	[E] 8.1L V8 L18	CD		CD																										
2005				Work horse			5 - P32 Series		CD		CD																								
							4 - P42 Series	[P] 3.9L L4 L4B Diesel	C S1		CD																								
		4 - P42 Series	[X] 4.3L V6 LU3			CD		CD																											
		4 - P42 Series	[V] 4.8L V8 LR4			CD		CD																											
		4 - P42 Series	[U] 6.0L V8 LQ4			CD		CD																											
		4 - P42 Series	[Y] 6.5L V8 L57			CD		CD																											
			6 - W22 Series			[G] 8.1L V8 L18	CD		CD																										

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

[illegible]

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
	P a s s e n g e r				[6] 1.6L L4 L91	CD		CD	CD																							
			U (VIN 4th)		[6] 1.6L L4 L91	CD		CD	CD																							
					[U] 1.6L L4 L91	CD		CD	CD																							
					[Z] 2.0L L4 L34	CD	CD	CD	CD																							
			V (VIN 4th)		[Z]2.0L L4 L34	CD	CD	CD	CD																							
					[L]2.5L L6 LBK	CD		CD	CD																							
			W (VIN 4th)		[E] 3.4L V6 LA1	CD		CD	CD	CD	CD	CD	C						C									CD				
					[1] 3.8L V6 L67	CD		CD	CD	CD	CD	CD	C						C									CD				
					[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD	C						C									CD				
			Y (VIN 4th)		[G] 5.7L V8 LS1	CD		CD	CD	CD	CD	CD	D					CD										C				
					[S] 5.7L V8 LS6	CD		CD	CD	CD	CD	CD	D					CD										C				
			Z (VIN 4th)		[F] 2.2L L4 L61	CD		CD	CD	CD	CD	CD																CD				
					[8] 3.5L V6 LX9	CD		CD	CD	CD	CD	CD																CD				
2004		P o n t i a c	H (VIN 4th)	[HX] Bonneville SE		CD		CD	CD		CD				C				C	C			C					CD				
				[HY] Bonneville SLE		CD		CD	CD		CD				C				C	C			C					CD				
				[HZ] Bonneville GXP		CD		CD	CD		CD				C				C	C			C					CD				
			J (VIN 4th)		[F] 2.2L L4 L61 Automatic	CD		CD	CD	CD	CD								CD									CD				
					[F] 2.2L L4 L61 Manual	CD		CD	CD	CD	CD								CD									CD				
			M (VIN 4th)		[4] 0.8L L3 LBF	CD		CD	CD																							
					[K] 0.8L L3 LBF	CD		CD	CD																							
					[0] 1.0L L4 LA2	CD		CD	CD																							
					[J] 1.0L L4 LA2	CD		CD	CD																							
			N (VIN 4th)		[F] 2.2L L4 L61	CD		CD	CD	CD	CD	CD											C					CD				
					[E] 3.4L V6 LA1	CD		CD	CD	CD	CD	CD											C					CD				
			S (VIN 4th)		[L] 1.8L L4 LNK	CD		CD	C											C								CD				
				[8] 1.8L L4 LV6	CD		CD	C											C								CD					
	V (VIN 4th)			[G] 5.7L V8 LS1	CD																						CD					
				[G] 5.7L V8 LS1	CD																						CD					
	W (VIN 4th)			[2] 3.8L V6 L26	CD		CD	CD	CD	CD	CD	CD			C				C								CD					
				[4] 3.8L V6 L32	CD		CD	CD	CD	CD	CD	CD			C				C								CD					
2004	O l d				[F] 2.2L L4 L61	CD		CD	CD	CD	CD												C					CD				
					[E] 3.4L V6 LA1	CD		CD	CD	CD	CD												C					CD				
2004	B U I C K		C (VIN 5th)		[1] 3.8L V6 L67	CD		CD	CD	CD	CD	CD			CD					CD			D									
				[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD			CD					CD			D										
		H (VIN 4th)	[HP] LeSabre Custom	[K] 3.8L V6 L36	CD		CD	CD		CD				C				CD	CD			C					CD					
			[HR] LeSabre Limited	[K] 3.8L V6 L36	CD		CD	CD		CD				CD				CD	CD			C					CD					
		W (VIN 4th)		[J] 3.1L V6 LG8	CD		CD	CD	CD	CD	CD	CD															CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
	2004	C a d i l l a c			[I] 3.8L V6 L67	CD		CD	CD	CD	CD	CD															CD					
					[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD															CD					
2004			D (VIN 4th)	[DM] CTS	[M] 2.6L V6 LY9	CD		CD	CD		CD			C				C	C		C	C					CD		C			
				[DM] CTS	[N] 3.2L V6 LA3	CD		CD	CD		CD			C				C	C		C	C					CD		C			
				[DM] CTS	[7] 3.6L V6 LY7	CD	CD	CD	CD		CD			C				C	C		C	C					CD		C			
				[DR] CTS	[M] 2.6L V6 LY9	CD		CD	CD					C				C	C		C	C					CD		C			
				[DR] CTS	[N] 3.2L V6 LA3	CD		CD	CD					C				C	C		C	C					CD		C			
				[DN] CTS-V	[S] 5.7L V8 LS6	CD		CD			CD			C				C	C			C					CD		C			
			K (VIN 4th)	[KD] Deville	[9] 4.6L V8 L37	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
				[KD] Deville	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
				[KE] DHS	[9] 4.6L V8 L37	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
				[KE] DHS	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
				[KF] DTS	[9] 4.6L V8 L37	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
				[KF] DTS	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
				[KS] Seville SLS	[9] 4.6L V8 L37	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
				[KS] Seville SLS	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
				[KY] Seville STS	[9] 4.6L V8 L37	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
				[KY] Seville STS	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
			Y (VIN 4th)			CD	CD	CD	CD		CD																	CD				
2004			C (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[1] 6.6L V8 LB7 Diesel	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
					[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C			CD
			E (VIN 5th)		[C] 2.0L L4 L34	CD		CD	CD																							
					[4] 2.5L V6 LE8	CD		CD	CD																							
			G (VIN 5th)	Express/Sav ana	[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD		CD									C					CD					
				Express/Sav ana	[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD		CD									C					CD					
				Express/Sav ana	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		CD									C					CD					
				Express/Sav ana	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		CD									C					CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
		C h e v r o l e t T r u c k		Express/Savana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD									C					CD						
				Express/Savana	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD	CD		CD									C						CD				
				Express/Savana	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD	CD		CD									C						CD				
				Express Access/Savana Pro	[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD		CD									C						CD				
				Express Access/Savana Pro	[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD		CD									C						CD				
				Express Access/Savana Pro	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD		CD									C						CD				
				Express Access/Savana Pro	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD		CD									C						CD				
				Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD		CD									C						CD				
				Express Access/Savana Pro	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD	CD		CD									C						CD				
				Express Access/Savana Pro	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD	CD		CD									C						CD				
				H (VIN 5th)	Express/Savana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD										C						CD				
					Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD										C						CD				
				J (VIN 5th)		[C] 2.0L L4 L34	CD		CD	CD																							
						[4] 2.5L V6 LE8	CD		CD	CD																							
				K (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
						[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
						[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
						[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
						[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
						[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
						[1] 6.6L V8 LB7 Diesel	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
						[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
						[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
						[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
						[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
						[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD			CD
					L (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																				
					M(VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																		
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
	L D T r k · M P V · I n c o m p l e t e		S (VIN 5th)	S10	[X] 4.3L V6 LU3(4 Speed Automatic)	CD		CD	CD	CD	CD																CD			C				
				S10	[X] 4.3L V6 LU3(Manual)	CD		CD	CD	CD	CD																	CD			C			
				Colorado	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD								C										CD					
				Colorado	[6] 3.5L L5 L52	CD		CD	CD	CD	CD	CD							C										CD					
				TrailBlazer	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		CD		C			C	C	C	C							CD	CD	C	C		
				TrailBlazer EXT	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		CD		C			C	C	C	C							CD	CD	C	C		
				TrailBlazer EXT	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD		CD		C			C	C	C	C							CD	CD	C	C		
				Blazer	[X] 4.3L V6 LU3(4 Speed Automatic)	CD		CD	CD	CD	CD	CD		CD															CD			C		
				Blazer	[X] 4.3L V6 LU3(Manual)	CD		CD	CD	CD	CD	CD		CD															CD			C		
				SSR	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD										C		C					CD		C	C		
				T (VIN 5th)	S10	[X] 4.3L V6 LU3(4 Speed Automatic)	CD		CD	CD	CD	CD																	CD			C		
					S10	[X] 4.3L V6 LU3(Manual)	CD		CD	CD	CD	CD																	CD			C		
					Colorado	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD							C										CD					
					Colorado	[6] 3.5L L5 L52	CD		CD	CD	CD	CD							C										CD					
					TrailBlazer	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD		CD		C			C	C	C	C							CD	CD	C	C		
					TrailBlazer EXT	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD		CD		C			C	C	C	C							CD	CD	C	C		
					TrailBlazer EXT	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD		CD		C			C	C	C	C							CD	CD	C	C		
					Blazer	[X] 4.3L V6 LU3(4 Speed Automatic)	CD		CD	CD	CD	CD		CD															CD			C		
					Blazer	[X] 4.3L V6 LU3(Manual)	CD		CD	CD	CD	CD		CD															CD			C		
2004			C T r k · M P V · I n c o m p l e t e		C (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD	
							[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD
							[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD
							[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD
								[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD
								[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD
								[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD
									[1] 6.6L V8 LB7 Diesel	CD		CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD
									[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD
									[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD
									[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD
									[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD
							[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD	CD	CD		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																		
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
		G M C T r u c k	G (VIN 5th)	Express/Sav ana	[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD		CD									CD						CD						
				Express/Sav ana	[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD		CD										CD						CD					
				Express/Sav ana	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		CD											CD						CD				
				Express/Sav ana	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		CD											CD						CD				
				Express/Sav ana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD											CD						CD				
				Express/Sav ana	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		CD											CD						CD				
				Express/Sav ana	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		CD											CD						CD				
				Express Access/Sava na Pro	[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD		CD											CD						CD				
				Express Access/Sava na Pro	[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD		CD											CD						CD				
				Express Access/Sava na Pro	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		CD											CD						CD				
				Express Access/Sava na Pro	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		CD											CD						CD				
				Express Access/Sava na Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD											CD						CD				
				Express Access/Sava na Pro	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		CD											CD						CD				
				Express Access/Sava na Pro	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		CD											CD						CD				
				H (VIN 5th)	Express/Sav ana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD												CD						CD				
				Express Access/Sava na Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD													CD						CD				
				K (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD	CD	CD		CD
						[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD	CD	CD		CD
						[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD	CD	CD		CD
						[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD	CD	CD		CD
						[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD	CD	CD		CD
						[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD	CD	CD		CD
						[1] 6.6L V8 LB7 Diesel	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD	CD	CD		CD
						[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD	CD	CD		CD
						[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD	CD	CD		CD
						[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD	CD	CD		CD

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
					[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD		CD	
					[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD	CD	CD		CD	
			L (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																					
			M (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																					
			S (VIN 5th)	Canyon	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD	CD						CD									CD					
				Canyon	[6] 3.5L L5 L52	CD		CD	CD	CD	CD	CD						CD									CD					
				Envoy	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD						CD	CD	CD	CD		
				Envoy XL	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD						CD	CD	CD	CD		
				Envoy XL	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD						CD	CD	CD	CD		
				Envoy XUV	[S] 4.2L L6 LL8	CD		CD	CD		CD	CD						CD	CD	CD	CD						CD	CD	CD	CD		
				Envoy XUV	[P] 5.3L V8 LM4	CD		CD	CD		CD	CD						CD	CD	CD	CD						CD	CD	CD	CD		
				Jimmy	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD															CD			CD		
				Sonoma	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																CD			CD		
			T (VIN 5th)	Canyon	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD							CD									CD			CD		
				Canyon	[6] 3.5L L5 L52	CD		CD	CD	CD	CD							CD									CD					
				Envoy	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD						CD	CD	CD			
				Envoy XL	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD						CD	CD	CD			
				Envoy XL	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD						CD	CD	CD			
				Envoy XUV	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD						CD	CD	CD			
				Envoy XUV	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD						CD	CD	CD			
				Jimmy	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD															CD					
				Sonoma	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																CD					
2004			A (VIN 5th)		[E] 3.4L V6 LA1	CD		CD	CD	CD	CD	CD		C				CD									CD	CD				
					[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD		C				CD									CD	CD				
			B (VIN 5th)		[E] 3.4L V6 LA1	CD		CD	CD	CD	CD	CD		C				CD									CD	CD				
					[7] 3.6L V6 LY7	CD	CD	CD	CD	CD	CD	CD		C				CD									CD	CD				
			S (VIN 5th)		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						C	C	C	C						CD	CD	C	C		
					[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD						C	C	C	C						CD	CD	C	C		
			T (VIN 5th)		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						C	C	C	C						CD	CD	C			
					[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD						C	C	C	C						CD	CD	C			
2004			C (VIN 5th)		[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C	C	CD	
			E (VIN 5th)		[A] 4.6L V8 LH2	CD	CD	CD	CD		CD			C	CD		CD	CD	C		C	C					CD	CD	C			
					[7] 3.6L V6 LY7	CD	CD	CD			CD			C	CD		CD	CD	C		C	C					CD	CD	C			
			K (VIN 5th)		[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	C	CD		CD	CD	C	C	C						CD	CD	C		CD	
2004				Hearse	[9] 4.6L V8 L37	CD		CD	CD		CD			C	CD				C		C						C		C			
				Hearse	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C	CD				C		C						C		C			
				Limousine	[9] 4.6L V8 L37	CD		CD	CD		CD			C	CD				C		C	C					C	CD	C			
				Limousine	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C	CD				C		C	C					C	CD	C			
2004			S (VIN 5th)		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						C	C	C	C						CD		C	C		
			T (VIN 5th)		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						C	C	C	C						CD		C			
			V (VIN 5th)			CD		CD	CD		CD			C				CD									CD					
			X (VIN 5th)			CD		CD	CD		CD			C				CD									CD					
2004			A (VIN 5th)			CD		CD	CD	CD	CD	C		C				CD									CD					
			B (VIN 5th)			CD		CD	CD	CD	CD			C				CD									CD					
			U (VIN 5th)			CD		CD	CD		CD			C				CD									CD					
			V (VIN 5th)			CD		CD	CD		CD			C				CD									CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	2004	a c c h e v	X (VIN 5th)			CD		CD	CD		CD			C				CD									CD						
		C h e v	U (VIN 5th)			CD		CD	CD		CD			C				CD									CD						
			V (VIN 5th)			CD		CD	CD		CD			C				CD									CD						
			X (VIN 5th)			CD		CD	CD		CD			C				CD									CD						
	2004	H u m m e r			[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD							CD	C	C	C						CD	CD	C				
2004	M e d i u m	C h e v r o l e t T r u c k		C-WT5500	[4] 4.8L L4	CD																											
				C-WT5500	[1] 6.6L V8 LB7 Diesel	CD																											
				C-WT5500	[2] 6.6L V8 LLY Diesel	CD																											
				C-WT5500	[3] 7.8L L6 LG4	CD																											
				C-WT5500	[E] 8.1L V8 L18	CD																											
				T-B7 Chassis	[4] 4.8L L4 Diesel	CD		CD																									
				T-B7 Chassis	[1] 6.6L V8 LB7 Diesel	CD		CD																									
				T-B7 Chassis	[2] 6.6L V8 LLY Diesel	CD		CD																									
				T-B7 Chassis	[3] 7.8L L6 LG4	CD		CD																									
				T-B7 Chassis	[E] 8.1L V8 L18	CD		CD																									
				D-C Series	[4] 4.8L L4 Diesel	CD		CD	CD			CD				C													CD				
				D-C Series	[1] 6.6L V8 LB7 Diesel	CD		CD	CD			CD				C													CD				
				D-C Series	[2] 6.6L V8 LLY Diesel	CD		CD	CD			CD				C													CD				
				D-C Series	[3] 7.8L L6 LG4	CD		CD	CD			CD				C													CD				
				D-C Series	[E] 8.1L V8 L18	CD		CD	CD			CD				C													CD				
				C-T Series	[4] 4.8L L4 Diesel	CD		CD	CD			CD				C													CD				
				C-T Series	[1] 6.6L V8 LB7 Diesel	CD		CD	CD			CD				C													CD				
				C-T Series	[2] 6.6L V8 LLY Diesel	CD		CD	CD			CD				C													CD				
				C-T Series	[3] 7.8L L6 LG4	CD		CD	CD			CD				C													CD				
				C-T Series	[E] 8.1L V8 L18	CD		CD	CD			CD				C													CD				
				B-W4 Series	[4] 4.8L L4 Diesel	CD		CD																									
				B-W4 Series	[U] 6.0L V8 LQ4	CD		CD																									
				B-W4 Series	[1] 6.6L V8 LB7 Diesel	CD		CD																									
				B-W4 Series	[2] 6.6L V8 LLY Diesel	CD		CD																									
				B-W4 Series	[3] 7.8L L6 LG4	CD		CD																									
				B-W4 Series	[E] 8.1L V8 L18	CD		CD																									
2004						C-WT5500	[4] 4.8L L4	CD																									

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																	
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	D u t y T r u c k	G M C T r u c k		C-WT5500	[1] 6.6L V8 LB7 Diesel	CD																											
				C-WT5500	[2] 6.6L V8 LLY Diesel	CD																											
				C-WT5500	[3] 7.8L L6 LG4	CD																											
				C-WT5500	[E] 8.1L V8 L18	CD																											
				T-B7 Chassis	[4] 4.8L L4 Diesel	CD		CD																									
				T-B7 Chassis	[1] 6.6L V8 LB7 Diesel	CD		CD																									
				T-B7 Chassis	[2] 6.6L V8 LLY Diesel	CD		CD																									
				T-B7 Chassis	[3] 7.8L L6 LG4	CD		CD																									
				T-B7 Chassis	[E] 8.1L V8 L18	CD		CD																									
				D-C Series	[4] 4.8L L4 Diesel	CD		CD	CD		CD					CD													CD				
				D-C Series	[1] 6.6L V8 LB7 Diesel	CD		CD	CD		CD					CD													CD				
				D-C Series	[2] 6.6L V8 LLY Diesel	CD		CD	CD		CD					CD													CD				
				D-C Series	[3] 7.8L L6 LG4	CD		CD	CD		CD					CD													CD				
				D-C Series	[E] 8.1L V8 L18	CD		CD	CD		CD					CD													CD				
				C-T Series	[4] 4.8L L4 Diesel	CD		CD	CD		CD					CD													CD				
				C-T Series	[1] 6.6L V8 LB7 Diesel	CD		CD	CD		CD					CD													CD				
				C-T Series	[2] 6.6L V8 LLY Diesel	CD		CD	CD		CD					CD													CD				
				C-T Series	[3] 7.8L L6 LG4	CD		CD	CD		CD					CD													CD				
				C-T Series	[E] 8.1L V8 L18	CD		CD	CD		CD					CD													CD				
				B-W4 Series	[4] 4.8L L4 Diesel	CD		CD																									
				B-W4 Series	[U] 6.0L V8 LQ4	CD		CD																									
				B-W4 Series	[1] 6.6L V8 LB7 Diesel	CD		CD																									
				B-W4 Series	[2] 6.6L V8 LLY Diesel	CD		CD																									
				B-W4 Series	[3] 7.8L L6 LG4	CD		CD																									
				B-W4 Series	[E] 8.1L V8 L18	CD		CD																									
2004			H u m m e r				CD	CD																					CD				
2004	S a t u r n		A (VIN 4th)		[P] 2.0L L4 LSJ	CD		CD	CD	CD	CD						CD											CD					
					[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD						CD											CD					
				J (VIN 4th)		[F] 2.2L L4 L61	CD		CD	CD	CD	CD	CD																				
						[R] 3.0L V6 L81	CD		CD	CD	CD	CD	CD																				
				Z (VIN 5th)		[D] 2.2L L4 L61	CD		CD	CD	CD	CD							CD										CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
					[4] 3.5L V6 L66	CD		CD	CD	CD								CD									CD						
2004	W o r k h o r s e			5 - P32 Series	[G] 8.1L V8 L18	C S10S1S3		CD																									
				4 - P42 Series	[P] 3.9L L4 L4B Diesel	C		CD																									
				4 - P42 Series	[X] 4.3L V6 LU3	CD		CD																									
				4 - P42 Series	[V] 4.8L V8 LR4	CD		CD																									
				4 - P42 Series	[R] 5.7L V8 L31	CD		CD																									
				4 - P42 Series	[U] 6.0L V8 LQ4	CD		CD																									
				4 - P42 Series	[Y] 6.5L V8 L57	CD		CD																									
				6 - W22 Series	[G] 8.1L V8 L18	CD		CD																									
				A - W24 Series	[G] 8.1L V8 L18	CD																											
				7 - W52 Series	[G] 8.1L V8 L18	CD																											
2003	P a s s e n g e r	Chevrolet	J (VIN 4th)		[F] 2.2L L4 L61	CD		CD	CD	CD	CD							CD									CD						
2003		Chevrolet	J (VIN 4th)	Cavalier	[6] 2.2L L4 L42 Alternative Fuel	C S1S3		CD	CD	CD	CD							CD									CD						
2003		Chevrolet	J,L (VIN 4th)	Optra	[7] 1.4L L4 L95	CD		CD	CD																								
2003		Chevrolet		Optra	[6] 1.6L L4 L91	CD		CD	CD																								
2003		Chevrolet		Optra	[U] 1.6L L4 L91	CD		CD	CD																								
2003		Chevrolet		Optra	[3] 1.8L L4 L79	CD		CD	CD																								
2003		Chevrolet		Optra	[8] 1.8L L4 L79	CD		CD	CD																								
2003		Chevrolet		Optra	[P] 1.8L L4 L79	CD		CD	CD																								
2003		Chevrolet	K (VIN 4th)						CD	CD		CD			C				C	C		C	C					C		C			
2003		Chevrolet	L (VIN 4th)			[Z] 2.0L L4 L34	CD		CD	C																							
2003		Chevrolet	L (VIN 4th)			[LJ]2.5L L6 LBK	CD		CD	C																							
2003		Chevrolet	M (VIN 4th)			[4] 0.8L L3 LBF	CD		CD	CD																							
2003		Chevrolet				[0] 1.0L L4 LA2	CD		CD	CD																							
2003		Chevrolet				[J] 1.0L L4 LA2	CD		CD	CD																							
2003		Chevrolet	N (VIN 4th)	Classic		[F] 2.2L L4 L61	CD		CD	CD	CD	CD										C						C					
2003		Chevrolet	N (VIN 4th)	Classic		[J] 3.1L V6 LG8	CD		CD	CD	CD	CD										C						C					
2003		Chevrolet	N (VIN 4th)	Alero[Export]		[E] 3.4L V6 LA1	CD		CD	CD	CD	CD										C						CD					
2003		Chevrolet	S(VIN 4th)	Monza		[6] 1.6L L4 L01	CD	CD																									
2003		Chevrolet	S(VIN 4th)	Aveo		[T] 1.2L L4 LY4	CD		CD	CD																							
2003		Chevrolet		Aveo		[7] 1.4L L4 L95	CD		CD	CD																							
2003		Chevrolet		Aveo		[A] 1.4L L4 LBJ	CD		CD	CD																							
2003		Chevrolet		Aveo		[Y] 1.5L L4 LV8	CD		CD	CD																							
2003		Chevrolet		Aveo		[6] 1.6L L4 L91	C S3		CD	CD																							
2003		Chevrolet	T (VIN 4th)			[7] 1.4L L4 L95	CD		CD	CD																							
2003		Chevrolet				[A] 1.4L L4 LBJ	CD		CD	CD																							
2003		Chevrolet				[Y] 1.5L L4 LV8	CD		CD	CD																							

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
2003	P a s s e n g e r	Chevrolet			[6] 1.6L L4 L91	CD		CD	CD																							
2003		Chevrolet	U (VIN 4th)		[6] 1.6L L4 L91	CD		CD	CD																							
2003		Chevrolet			[U] 1.6L L4 L91	CD		CD	CD																							
2003		Chevrolet			[Z] 2.0L L4 L34	CD	CD		CD	CD																						
2003		Chevrolet	V (VIN 4th)		[Z] 2.0L L4 L34	CD			CD	C																						
2003		Chevrolet	V (VIN 4th)		[L]2.5L L6 LBK	CD			CD	C																						
2003		Chevrolet	W (VIN 4th)		[J] 3.1L V6 LG8	CD			CD	CD	CD	CD	CD		C				CD									CD				
2003		Chevrolet	W (VIN 4th)		[E] 3.4L V6 LA1	CD			CD	CD	CD	CD	CD		C				CD									CD				
2003		Chevrolet	W (VIN 4th)		[1] 3.8L V6 L67	CD			CD	CD	CD	CD	CD		C				CD									CD				
2003		Chevrolet	W (VIN 4th)		[K] 3.8L V6 L36	CD			CD	CD	CD	CD	CD		C				CD									CD				
2003		Chevrolet	Y (VIN 4th)		[G] 5.7L V8 LS1	CD			CD	CD	CD	CD	CD	D																		
2003		Chevrolet	Y (VIN 4th)		[S] 5.7L V8 LS6	CD			CD	CD	CD	CD	CD	D																		
2003		pontiac	M (VIN 4th)		[4] 0.8L L3 LBF	CD			CD	CD																						
2003		pontiac			[K] 0.8L L3 LBF	CD			CD	CD																						
2003		pontiac			[O] 1.0L L4 LA2	CD			CD	CD																						
2003		pontiac			[J] 1.0L L4 LA2	CD			CD	CD																						
2003		pontiac	J (VIN 4th)		[F] 2.2L L4 L61	CD			CD	CD	CD	CD							CD									CD				
2003		pontiac	M (VIN 4th)		[4] 0.8L L3 LBF	CD			CD	CD																						
2003		pontiac			[K] 0.8L L3 LBF	CD			CD	CD																						
2003		pontiac			[O] 1.0L L4 LA2	CD			CD	CD																						
2003		pontiac			[J] 1.0L L4 LA2	CD			CD	CD																						
2003		pontiac	N (VIN 4th)		[F] 2.2L L4 L61	CD			CD	CD	CD	CD										C						CD				
2003		pontiac			[E] 3.4L V6 LA1	CD			CD	CD	CD	CD										C						CD				
2003		pontiac	S (VIN 4th)		[L] 1.8L L4 LNK	CD			CD	C									C									C				
2003		pontiac			[8] 1.8L L4 LV6	CD			CD	C									C									C				
2003		pontiac	H (VIN 4th)	[HX] Bonneville SE						CD		CD			CD					CD						CD			CD			
2003		pontiac		[HY] Bonneville SLE						CD		CD			CD					CD						CD			CD			
2003		pontiac		[HZ] Bonneville SSEi						CD		CD			CD					CD						CD			CD			
2003		pontiac	W (VIN 4th)		[J] 3.1L V6 LG8	CD			CD	CD									CD													
2003		pontiac	W (VIN 4th)		[1] 3.8L V6 L67	CD			CD	CD			CD						CD									C				
2003		pontiac	W (VIN 4th)		[K] 3.8L V6 L36	CD			CD	CD									CD													
2003		Oldsmobil e				[E] 3.4L V6 LA1	CD		CD	CD	CD	CD										C						C				
2003		Buick	C (VIN 4th)			[1] 3.8L V6 L67	CD		CD	CD	CD	CD	CD		C					C												
2003		Buick	C (VIN 4th)			[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD		C					C												
2003		Buick	H (VIN 4th)			[1] 3.8L V6 L67	CD		CD	CD		CD			C				CD	C								CD				
2003		Buick	H (VIN 4th)			[K] 3.8L V6 L36	CD		CD	CD		CD			C				CD	C								CD				
2003		Buick	W (VIN 4th)			[J] 3.1L V6 LG8	CD		CD	CD	CD	CD	CD						CD									C				
2003		Buick				[1] 3.8L V6 L67	CD		CD	CD	CD	CD	CD															C				
2003		Buick				[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD															C				
2003		cadillac	D (VIN 4th)	CTS		[M] 2.6L V6 LY9	CD			CD		CD			C				C	C		C	C					CD		C		
2003		cadillac		CTS		[N] 3.2L V6 LA3	CD			CD		CD			C				C	C		C	C					C		C		
2003		cadillac		CTS-V		[S] 5.7L V8 LS6	CD			CD		CD			C				C	C		C	C					C		C		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
2003	P a s s e n g e r	cadillac	K (VIN 4th)	[KD] Deville	[9] 4.6L V8 L37	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
2003		cadillac		[KD] Deville	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
2003		cadillac		[KE] DHS	[9] 4.6L V8 L37	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
2003		cadillac		[KE] DHS	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
2003		cadillac		[KF] DTS	[9] 4.6L V8 L37	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
2003		cadillac		[KF] DTS	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
2003		cadillac		[KS] Seville SLS	[9] 4.6L V8 L37	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
2003		cadillac		[KS] Seville SLS	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
2003		cadillac		[KY] Seville STS	[9] 4.6L V8 L37	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
2003		cadillac		[KY] Seville STS	[Y] 4.6L V8 LD8	CD		CD	CD		CD			C				CD	C		C	C					C	CD	C			
2003			C (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[1] 6.6L V8 LB7 Diesel	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
					[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	C	C		CD	CD	C	C	C						C		C		CD	
			E (VIN 5th)		[C] 2.0L L4 L34	CD		CD	CD																							
					[4] 2.5L V6 LE8	CD		CD	CD																							
			G (VIN 5th)	Express/Sav ana	[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD		C									C					C					
					[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD		C									C					C					
					[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		C									C					C					
					[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		C									C					C					
					[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		C									C					C					
					[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		C									C					C					
					[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		C									C					C					
			G (VIN 5th)	Express Access/Sava na Pro	[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD		C									C					C					
					[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD		C									C					C					
					[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		C									C					C					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																		
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
		C h e v r o l e t T r u c k			[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		C									C					C							
					[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		C										C					C						
					[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		C										C					C						
					[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		C										C					C						
				H (VIN 5th)	Express/Savana/Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD											C						C					
				J (VIN 5th)		[C] 2.0L L4 L34	CD		CD	CD																								
						[4] 2.5L V6 LE8	CD		CD	CD																								
				K (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
						[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
						[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
						[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
						[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
						[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
						[1] 6.6L V8 LB7 Diesel	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
						[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
						[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
						[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
						[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
						[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C							C					C
				L (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																						
				M(VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																						
				S (VIN 5th)	S10	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																	C					C
					Colorado	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD							C										C					
					Colorado	[6] 3.5L L5 L52	CD		CD	CD	CD	CD							C										C					
					TrailBlazer	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		C				C	C	C	C							C			C	C	
					TrailBlazer EXT	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		C				C	C	C	C							C			C	C	
					TrailBlazer EXT	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD		C				C	C	C	C							C			C	C	
					Blazer	[X] 4.3L V6 LU3(4 Speed Automatic)	CD		CD	CD	CD	CD	CD																C					C
					Blazer	[X] 4.3L V6 LU3(Manual)	CD		CD	CD	CD	CD	CD																C					C
					SSR	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD									C		C						CD			C	C	
				T (VIN 5th)	S10	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																	C					C
					Colorado	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD							C										C					
					Colorado	[6] 3.5L L5 L52	CD		CD	CD	CD	CD							C										C					
					TrailBlazer	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		C				C	C	C	C							C			C	C	
					TrailBlazer EXT	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		C				C	C	C	C							C			C	C	

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
				TrailBlazer EXT	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD		C				C	C	C	C						C		C	C		
					Blazer	[X] 4.3L V6 LU3(4 Speed Automatic)	CD		CD	CD	CD	CD	CD														C			C		
					Blazer	[X] 4.3L V6 LU3(Manual)	CD		CD	CD	CD	CD	CD														C			C		
2003		G M C	C (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD	
						[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
						[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
						[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
						[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
						[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
						[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
						[1] 6.6L V8 LB7 Diesel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
						[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
						[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
						[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
						[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
						[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD					CD		CD	CD	CD	
				G (VIN 5th)	Express/Sav ana	[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD		CD								CD					CD					
					Express/Sav ana	[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD		CD								CD					CD					
					Express/Sav ana	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		CD								CD					CD					
					Express/Sav ana	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		CD								CD					CD					
					Express/Sav ana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD								CD					CD					
					Express/Sav ana	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		CD								CD					CD					
					Express/Sav ana	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		CD								CD					CD					
					Express Access/Sava na Pro	[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD		CD								CD					CD					
					Express Access/Sava na Pro	[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD		CD								CD					CD					
					Express Access/Sava na Pro	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		CD								CD					CD					
					Express Access/Sava na Pro	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		CD								CD					CD					
					Express Access/Sava na Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD								CD					CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																	
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
		T r u c k		Express Access/Sava na Pro	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		CD									CD						CD					
					Express Access/Sava na Pro	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		CD									CD						CD				
			H (VIN 5th)		Express/Sav ana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD											CD						CD				
					Express Access/Sava na Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD											CD						CD				
			K (VIN 5th)			[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
						[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
						[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
						[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
						[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
						[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
						[1] 6.6L V8 LB7 Diesel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
						[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
						[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
						[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
						[U] 6.0L LQ4 Bi- Fuel	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
						[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD							CD		CD		CD
			L (VIN 5th)			[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																					
			M (VIN 5th)			[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																					
			S (VIN 5th)	Canyon		[8] 2.8L L4 LK5	CD		CD	CD	CD	CD							CD										CD				
				Canyon		[6] 3.5L L5 L52	CD		CD	CD	CD	CD							CD										CD				
				Envoy		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD	CD	
				Envoy XL		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD	CD	
				Envoy XL		[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD	CD	
				Envoy XUV		[S] 4.2L L6 LL8	CD		CD	CD		CD	CD						CD	CD	CD	CD							CD		CD	CD	
				Envoy XUV		[P] 5.3L V8 LM4	CD		CD	CD		CD	CD						CD	CD	CD	CD							CD		CD	CD	
				Jimmy		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD																CD			CD	
				Sonoma		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																	CD			CD	
			T (VIN 5th)	Canyon		[8] 2.8L L4 LK5	CD		CD	CD	CD	CD							CD										CD				
				Canyon		[6] 3.5L L5 L52	CD		CD	CD	CD	CD							CD										CD				
				Envoy		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD		
				Envoy XL		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD		
				Envoy XL		[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD		
				Envoy XUV		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD		
				Envoy XUV		[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD		
				Jimmy		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD																CD				
				Sonoma		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																	CD				
2003		B	A (VIN 5th)		[E] 3.4L V6 LA1	CD		CD	CD	CD	CD	CD		C				CD										CD					
			B (VIN 5th)			[E] 3.4L V6 LA1	CD		CD	CD	CD	CD	CD		C				CD										CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
		U i c k	S (VIN 5th)		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						C	C	C	C						C		C	C		
						[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD						C	C	C	C						C		C	C	
			T (VIN 5th)			[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						C	C	C	C						C		C		
						[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD						C	C	C	C						C		C		
2003		C a d	C (VIN 5th)		[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C						C	CD	C	C	C	
			K (VIN 5th)			[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	C	C	C		C	CD	C	C	C						C		C		C
2003		O l d s m	S (VIN 5th)		[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						C	C	C	C						C		C	C		
			T (VIN 5th)			[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD						C	C	C	C						C		C		
			V (VIN 5th)				CD		CD	CD		CD			C				C									CD				
			X (VIN 5th)				CD		CD	CD		CD			C				C									CD				
2003		P o n t i a c	A (VIN 5th)			CD		CD	CD	CD	CD	C		C				CD									CD					
			B (VIN 5th)				CD		CD	CD	CD	CD			C				CD								CD					
			U (VIN 5th)				CD		CD	CD		CD			C				C									CD				
			V (VIN 5th)				CD		CD	CD		CD			C				C									CD				
			X (VIN 5th)				CD		CD	CD		CD			C				C									CD				
2003		C h e v	U (VIN 5th)			CD		CD	CD		CD			C				C									CD					
			V (VIN 5th)				CD		CD	CD		CD			C				C								CD					
			X (VIN 5th)				CD		CD	CD		CD			C				C								CD					
2003		M e d i u m		T-B7 Chassis	[4] 4.8L L4 Diesel	CD		CD																								
				T-B7 Chassis		[1] 6.6L V8 LB7 Diesel	CD		CD																							
					T-B7 Chassis		[2] 6.6L V8 LLY Diesel		CD																							
					T-B7 Chassis		[3] 7.8L L6 LG4		CD																							
					T-B7 Chassis		[E] 8.1L V8 L18		CD																							
					D-C Series		[4] 4.8L L4 Diesel		CD		CD				CD													CD				
					D-C Series		[1] 6.6L V8 LB7 Diesel		CD		CD				CD													CD				
					D-C Series		[2] 6.6L V8 LLY Diesel		CD		CD				CD													CD				
					D-C Series		[3] 7.8L L6 LG4		CD		CD				CD													CD				
					D-C Series		[E] 8.1L V8 L18		CD		CD				CD													CD				
					C-T Series		[4] 4.8L L4 Diesel		CD																							
					C-T Series		[1] 6.6L V8 LB7 Diesel		CD		CD																					
					C-T Series		[2] 6.6L V8 LLY Diesel		CD		CD																					
					C-T Series		[3] 7.8L L6 LG4		CD		CD																					
					C-T Series		[E] 8.1L V8 L18		CD		CD																					
					B-W4 Series		[4] 4.8L L4 Diesel		CD																							
					B-W4 Series		[U] 6.0L V8 LQ4		CD		CD																					
					B-W4 Series		[1] 6.6L V8 LB7 Diesel		CD		CD																					
					B-W4 Series		[2] 6.6L V8 LLY Diesel		CD		CD																					
					B-W4 Series		[3] 7.8L L6 LG4		CD		CD																					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
	D u t y T r u c k			B-W4 Series	[E] 8.1L V8 L18	CD		CD																								
				6 - W22 Series	[4] 4.8L L4 Diesel	CD		CD																								
				6 - W22 Series	[U] 6.0L V8 LQ4	CD		CD																								
				6 - W22 Series	[1] 6.6L V8 LB7 Diesel	CD		CD																								
				6 - W22 Series	[2] 6.6L V8 LLY Diesel	CD		CD																								
				6 - W22 Series	[3] 7.8L L6 LG4	CD		CD																								
				6 - W22 Series	[E] 8.1L V8 L18	CD		CD																								
				7 - W52 Series	[4] 4.8L L4 Diesel	CD		CD																								
				7 - W52 Series	[U] 6.0L V8 LQ4	CD		CD																								
				7 - W52 Series	[1] 6.6L V8 LB7 Diesel	CD		CD																								
				7 - W52 Series	[2] 6.6L V8 LLY Diesel	CD		CD																								
				7 - W52 Series	[3] 7.8L L6 LG4	CD		CD																								
				7 - W52 Series	[E] 8.1L V8 L18	CD		CD																								
				Hummer H-1	[4] 4.8L L4 Diesel	CD								C													CD					
				Hummer H-1	[U] 6.0L V8 LQ4	CD								C													CD					
				Hummer H-1	[1] 6.6L V8 LB7 Diesel	CD								C													CD					
				Hummer H-1	[2] 6.6L V8 LLY Diesel	CD								C													CD					
				Hummer H-1	[3] 7.8L L6 LG4	CD								C													CD					
				Hummer H-1	[E] 8.1L V8 L18	CD								C													CD					
2003	S a t u r n		A (VIN 4th)		[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD																					
			J (VIN 4th)		[F] 2.2L L4 L61	CD	CD	CD	CD	CD	CD	CD																				
			Z (VIN 5th)					CD	CD	CD	CD																					
					[D] 2.2L L4 L61	CD				CD																						
					[B] 3.0L V6 L81	CD				CD																						
					[R] 3.0L V6 L81	CD				CD																						
2002	P	Chevrolet	J (VIN 4th)	2002	[F] 2.2L L4 L61	CD		CD	CD	CD	CD						C										CD					
2002		Chevrolet	J (VIN 4th)	Cavalier	[4] 2.2L L4 LN2	CD		CD	CD	CD	CD																CD					
2002		Chevrolet	J (VIN 4th)		[T] 2.4L L4 LD9	CD		CD	CD	CD	CD																CD					
2002		Chevrolet	N (VIN 4th)	Classic	[F] 2.2L L4 L61	CD		CD	CD	CD	CD											C					C					
2002		Chevrolet	N (VIN 4th)	Classic	[T] 2.4L L4 LD9	CD		CD	CD	CD	CD																					
2002		Chevrolet	N (VIN 4th)	Classic	[J] 3.1L V6 LG8	CD		CD	CD	CD	CD											C					C					
2002		Chevrolet	N (VIN 4th)	Alero[Export]	[E] 3.4L V6 LA1	CD		CD	CD	CD	CD										C						CD					
2002		Chevrolet	S(VIN 4th)	Monza	[6] 1.6L L4 L01	CD	CD	CD	C																							
2002		Chevrolet	S(VIN 4th)	Prizm	[3] 1.6L L4 L73	CD	CD	CD	C																							
2002		Chevrolet	W (VIN 4th)		[J] 3.1L V6 LG8	CD		CD	CD	CD	CD	CD		C				C									CD					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																	
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
2002	a s s e n g e r	Chevrolet	W (VIN 4th)		[E] 3.4L V6 LA1	CD		CD	CD	CD	CD	CD		C				C										CD					
2002		Chevrolet	W (VIN 4th)		[1] 3.8L V6 L67	CD		CD	CD	CD	CD	CD		C				C										CD					
2002		Chevrolet	W (VIN 4th)		[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD	CD		C				C									CD					
2002		Chevrolet	Y (VIN 4th)		[G] 5.7L V8 LS1	CD		CD	CD	CD	CD	CD	CD	D														C					
2002		Chevrolet	Y (VIN 4th)		[S] 5.7L V8 LS6	CD		CD	CD	CD	CD	CD	CD	D														C					
2002		pontiac	H (VIN 4th)	[HX] Bonneville SE	[C] 4.0L V8 L47	CD			CD	CD		CD			C				C	C			C						CD				
2002		pontiac		[HY] Bonneville SLE	ENGING	CD			CD	CD		CD			C				C	C			C						CD				
2002		pontiac		[HZ] Bonneville GXP	ENGING	CD			CD	CD		CD			C				C	C			C						CD				
2002		pontiac	J (VIN 4th)		[F] 2.2L L4 L61	CD			CD	CD	CD	CD							C										C				
2002		pontiac	M(VIN 4th)		[2] 1.4L L4 LC0	CD				CD																							
2002		pontiac	N (VIN 4th)		[F] 2.2L L4 L61	CD			CD	CD	CD	CD											C						CD				
2002	P a s s e n g e r	pontiac			[E] 3.4L V6 LA1	CD		CD	CD	CD	CD											C						CD					
2002		pontiac	S (VIN 4th)		[8] 1.8L L4 LV6	CD		CD	C									C										C					
2002		pontiac	W (VIN 4th)		[J] 3.1L V6 LG8	CD		CD	CD																								
2002		pontiac	W (VIN 4th)		[1] 3.8L V6 L67	CD		CD	CD				CD						C										C				
2002		pontiac	W (VIN 4th)		[K] 3.8L V6 L36	CD		CD	CD																								
2002		Oldsmobile	N (VIN 4th)		[E] 3.4L V6 LA1	CD			CD	CD	CD	CD											C						CD				
2002		Buick	C (VIN 4th)		[1] 3.8L V6 L67	CD			CD	CD	CD	CD	CD		C					C													
2002		Buick	C (VIN 4th)		[K] 3.8L V6 L36	CD			CD	CD	CD	CD	CD		C					C													
2002		Buick	H (VIN 4th)		[1] 3.8L V6 L67	CD			CD	CD		CD			C					C									CD				
2002		Buick	H (VIN 4th)		[K] 3.8L V6 L36	CD			CD	CD		CD			C					C									CD				
2002		Buick	W (VIN 4th)		[J] 3.1L V6 LG8	CD			CD	CD	CD	CD	CD																C				
2002		Buick	W (VIN 4th)		[H] 3.5L V6 LX5	CD			CD	CD	CD	CD																					
2002		Buick				[1] 3.8L V6 L67	CD		CD	CD	CD	CD	CD																C				
2002		Buick				[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD																C				
2002		cadillac	K (VIN 4th)	[KD] Deville	[9] 4.6L V8 L37	CD			CD	CD		CD			C				C	C		C	C						C	CD	C		
2002		cadillac		[KD] Deville	[Y] 4.6L V8 LD8	CD			CD	CD		CD			C				C	C		C	C						C	CD	C		
2002		cadillac		[KE] DHS	[9] 4.6L V8 L37	CD			CD	CD		CD			C				C	C		C	C						C	CD	C		
2002		cadillac		[KE] DHS	[Y] 4.6L V8 LD8	CD			CD	CD		CD			C				C	C		C	C						C	CD	C		
2002		cadillac		[KF] DTS	[9] 4.6L V8 L37	CD			CD	CD		CD			C				C	C		C	C						C	CD	C		
2002		cadillac		[KF] DTS	[Y] 4.6L V8 LD8	CD			CD	CD		CD			C				C	C		C	C						C	CD	C		
2002		cadillac		[KS] Seville SLS	[9] 4.6L V8 L37	CD			CD	CD		CD			C				C	C		C	C						C	CD	C		
2002		cadillac		[KS] Seville SLS	[Y] 4.6L V8 LD8	CD			CD	CD		CD			C				C	C		C	C						C	CD	C		
2002		cadillac		[KY] Seville STS	[9] 4.6L V8 L37	CD			CD	CD		CD			C				C	C		C	C						C	CD	C		
2002		cadillac		[KY] Seville STS	[Y] 4.6L V8 LD8	CD			CD	CD		CD			C				C	C		C	C						C	CD	C		
2002			C (VIN 5th)/K (VIN 5th)		[X] 4.3L V6 LU3	CD			CD	CD	CD	CD	C	C	C		C	C	C	C	C							C	CD	C		C	
					[V] 4.8L V8 LR4	CD			CD	CD	CD	CD	C	C	C		C	C	C	C	C							C	CD	C		C	
					[T] 5.3L V8 LM7	CD			CD	CD	CD	CD	C	C	C		C	C	C	C	C							C	CD	C		C	

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																		
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
		Chevrolet Truck			[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	C	C	C		C	C	C	C	C						C	CD	C			C		
					[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	CD	C	C	C		C	C	C	C	C						C	CD	C			C	
					[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	C	C	C		C	C	C	C	C						C	CD	C			C	
					[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	C	C	C		C	C	C	C	C						C	CD	C			C	
					[1] 6.6L V8 LB7 Diesel	CD		CD	CD	CD	CD	CD	CD	C	C	C		C	C	C	C	C						C	CD	C			C	
					[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	CD	C	C	C		C	C	C	C	C						C	CD	C			C	
					[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	C	C	C		C	C	C	C	C						C	CD	C			C	
					[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	C	C	C		C	C	C	C	C						C	CD	C			C	
					[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD	CD	C	C	C		C	C	C	C	C						C	CD	C			C	
					[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	C	C	C		C	C	C	C	C						C	CD	C			C	
				E (VIN 5th)		[C] 2.0L L4 L34	CD		CD	CD																		C						
						[4] 2.5L V6 LE8	CD		CD	CD																								
				G (VIN 5th)	Express/Savana/Express Access/Savana Pro	[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD		C									C						CD					
						[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD		C									C						C					
						[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		C									C						C					
						[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		C									C						C					
						[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		C									C						C					
						[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		C									C						C					
						[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		C									C						C					
				H (VIN 5th)	Express/Savana/Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD											C						C					
				J (VIN 5th)		[C] 2.0L L4 L34	CD		CD	CD																								
						[4] 2.5L V6 LE8	CD		CD	CD																								
				L (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																						
				M(VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																						
				S (VIN 5th)	S10	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD																	C				C	
					Colorado	[8] 2.8L L4 LK5	CD		CD	CD	CD	CD							C										C					
					Colorado	[6] 3.5L L5 L52	CD		CD	CD	CD	CD							C										C					
					TrailBlazer	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		C				C	C	C	C							C		C	C		
					TrailBlazer EXT	[S] 4.2L L6 LL8	CD		CD	CD	CD	CD	CD		C				C	C	C	C							C		C	C		
					TrailBlazer EXT	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD	CD		C				C	C	C	C							C		C	C		
					Blazer	[X] 4.3L V6 LU3(4 Speed Automatic)	CD		CD	CD	CD	CD	CD																C			C		
					Blazer	[X] 4.3L V6 LU3(Manual)	CD		CD	CD	CD	CD	CD																C			C		
					SSR	[P] 5.3L V8 LM4	CD		CD	CD	CD	CD									C		C						C		C	C		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)																																
Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
2002		G M C T r u c k	C (VIN 5th)/K (VIN 5th)		[X] 4.3L V6 LU3	CD		CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD	
					[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
					[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
					[Z] 5.3L V8 L59	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
					[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
					[N] 6.0L V8 LQ9	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
					[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
					[1] 6.6L V8 LB7 Diesel	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
					[2] 6.6L V8 LLY Diesel	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
					[G] 8.1L V8 L18	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
					[T] 5.3L V8 LM7 Parallel Hybrid	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
					[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
					[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD	CD	CD	CD	CD	CD		CD	CD	C	CD	CD						CD		CD	CD	CD
				G (VIN 5th)	Express/Savana	[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD		CD									CD					CD				
					Express/Savana	[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD		CD									CD					CD				
					Express/Savana	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		CD									CD					CD				
					Express/Savana	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		CD									CD					CD				
					Express/Savana	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD									CD					CD				
					Express/Savana	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		CD									CD					CD				
					Express/Savana	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		CD									CD					CD				
					Express Access/Savana Pro	[U] 6.0L LQ4 Bi-Fuel	CD		CD	CD	CD	CD		CD									CD					CD				
					Express Access/Savana Pro	[U] 6.0L LQ4 Dedicated CNG	CD		CD	CD	CD	CD		CD									CD					CD				
					Express Access/Savana Pro	[X] 4.3L V6 LU3	CD		CD	CD	CD	CD		CD									CD					CD				
					Express Access/Savana Pro	[V] 4.8L V8 LR4	CD		CD	CD	CD	CD		CD									CD					CD				
					Express Access/Savana Pro	[T] 5.3L V8 LM7	CD		CD	CD	CD	CD		CD									CD					CD				
					Express Access/Savana Pro	[U] 6.0L V8 LQ4(without TAC)	CD		CD	CD	CD	CD		CD									CD					CD				

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
				Express Access/Savana Pro	[U] 6.0L V8 LQ4(with TAC)	CD		CD	CD	CD	CD		CD									CD						CD					
			H (VIN 5th)	Express/Savana	[T] 5.3L V8 LM7	CD			CD	CD	CD	CD											CD						CD				
				Express Access/Savana Pro	[T] 5.3L V8 LM7	CD			CD	CD	CD	CD											CD						CD				
			L (VIN 5th)		[X] 4.3L V6 LU3	CD			CD	CD	CD	CD																					
			M (VIN 5th)		[X] 4.3L V6 LU3	CD			CD	CD	CD	CD																					
			S (VIN 5th)/T (VIN 5th)	Canyon	[6] 3.5L L5 L52	CD			CD	CD	CD	CD							CD										CD				
				Envoy	[S] 4.2L L6 LL8	CD			CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD	CD	
				Envoy XL	[S] 4.2L L6 LL8	CD			CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD	CD	
				Envoy XL	[P] 5.3L V8 LM4	CD			CD	CD	CD	CD	CD						CD	CD	CD	CD							CD		CD	CD	
				Envoy XUV	[S] 4.2L L6 LL8	CD			CD	CD		CD	CD						CD	CD	CD	CD							CD		CD	CD	
				Envoy XUV	[P] 5.3L V8 LM4	CD			CD	CD		CD	CD						CD	CD	CD	CD							CD		CD	CD	
				Jimmy	[X] 4.3L V6 LU3	CD			CD	CD	CD	CD	CD						CD	CD	CD	CD							CD			CD	
			Sonoma	[X] 4.3L V6 LU3	CD			CD	CD	CD	CD	CD																CD			CD		
2002		B u i c k	A (VIN 5th)		[E] 3.4L V6 LA1	CD			CD	CD	CD	CD		C				C										CD					
			B (VIN 5th)		[E] 3.4L V6 LA1	CD			CD	CD	CD	CD	CD		C				C										CD				
			S (VIN 5th)			[S] 4.2L L6 LL8	CD			CD	CD	CD	CD						C	C	C	C							C		C	C	
						[P] 5.3L V8 LM4	CD			CD	CD	CD	CD						C	C	C	C							C		C	C	
			T (VIN 5th)			[S] 4.2L L6 LL8	CD			CD	CD	CD	CD						C	C	C	C							C		C		
						[P] 5.3L V8 LM4	CD			CD	CD	CD	CD						C	C	C	C							C		C		
2002		C a d i l l a d	C (VIN 5th)		[N] 6.0L V8 LQ9	CD			CD	CD	CD	CD	C	C	C		C	C	C	C	C							C		C	C	C	
			K (VIN 5th)		[N] 6.0L V8 LQ9	CD			CD	CD	CD	CD	CD	C	C	C		C	C	C	C	C						C		C		C	
2002		O l d s m	S (VIN 5th)		[S] 4.2L L6 LL8	CD			CD	CD	CD	CD						C	C	C	C							C		C	C		
			T (VIN 5th)			[S] 4.2L L6 LL8	CD			CD	CD	CD	CD						C	C	C	C						C		C			
			V (VIN 5th)				CD			CD	CD		CD		C				C									C					
			X (VIN 5th)				CD			CD	CD		CD		C				C									C					
2002		P o n t i a c	A (VIN 5th)			CD			CD	CD	CD		C					C										C					
			B (VIN 5th)				CD			CD	CD	CD							C									C					
			U (VIN 5th)				CD			CD	CD		CD		C				C									C		CD			
			V (VIN 5th)				CD			CD	CD		CD		C				C									C		CD			
			X (VIN 5th)				CD			CD	CD		CD		C				C									C		CD			
2002		C h e v	U (VIN 5th)			CD			CD	CD		CD		C				C										C					
			V (VIN 5th)				CD			CD	CD		CD		C				C									C					
			X (VIN 5th)				CD			CD	CD		CD		C				C									C					
2002				B-W4 Series	[4] 4.8L L4 Diesel	CD			CD																								
					B-W4 Series	[R] 5.7L V8 L31	CD			CD																							
					B-W4 Series	[F] 6.5L V8 L65	CD			CD																							
					B-W4 Series	[Z] 6.5L V8 L65	CD			CD																							
					B-W4 Series	[C] 7.2L L6 LG5	C			CD																							
					B-W4 Series	[E] 8.1L V8 L18	CD			CD																							
					B-W4 Series	[E] 8.1L V8 L18 Dedicated LPG	CD			CD																							

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
	M e d i u m D u t y T r u c k			6 - W22 Series	[4] 4.8L L4 Diesel	CD		CD																								
				6 - W22 Series	[R] 5.7L V8 L31	CD		CD																								
				6 - W22 Series	[F] 6.5L V8 L65	CD		CD																								
				6 - W22 Series	[Z] 6.5L V8 L65	CD		CD																								
				6 - W22 Series	[C] 7.2L L6 LG5	C		CD																								
				6 - W22 Series	[E] 8.1L V8 L18	CD		CD																								
				6 - W22 Series	[E] 8.1L V8 L18 Dedicated LPG	CD		CD																								
				7 - W52 Series	[4] 4.8L L4 Diesel	CD		CD																								
				7 - W52 Series	[R] 5.7L V8 L31	CD		CD																								
				7 - W52 Series	[F] 6.5L V8 L65	CD		CD																								
				7 - W52 Series	[Z] 6.5L V8 L65	CD		CD																								
				7 - W52 Series	[C] 7.2L L6 LG5	C		CD																								
				7 - W52 Series	[E] 8.1L V8 L18	CD		CD																								
				7 - W52 Series	[E] 8.1L V8 L18 Dedicated LPG	CD		CD																								
				T-B7 Chassis	[4] 4.8L L4 Diesel	CD		CD																								
				T-B7 Chassis	[R] 5.7L V8 L31	CD		CD																								
				T-B7 Chassis	[F] 6.5L V8 L65	CD		CD																								
				T-B7 Chassis	[Z] 6.5L V8 L65	CD		CD																								
				T-B7 Chassis	[C] 7.2L L6 LG5	C		CD																								
				T-B7 Chassis	[E] 8.1L V8 L18	CD		CD																								
				T-B7 Chassis	[E] 8.1L V8 L18 Dedicated LPG	CD		CD																								
				D-C Series	[4] 4.8L L4 Diesel	CD		CD																								
				D-C Series	[R] 5.7L V8 L31	CD		CD																								
				D-C Series	[F] 6.5L V8 L65	CD		CD																								
				D-C Series	[Z] 6.5L V8 L65	CD		CD																								
				D-C Series	[C] 7.2L L6 LG5	C		CD																								
				D-C Series	[E] 8.1L V8 L18	CD		CD																								
				D-C Series	[E] 8.1L V8 L18 Dedicated LPG	CD		CD																								
				C-T Series	[4] 4.8L L4 Diesel	CD		CD																								
				C-T Series	[R] 5.7L V8 L31	CD		CD																								

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
				C-T Series	[F] 6.5L V8 L65	CD		CD																								
				C-T Series	[Z] 6.5L V8 L65	CD		CD																								
				C-T Series	[C] 7.2L L6 LG5	C		CD																								
				C-T Series	[E] 8.1L V8 L18	CD		CD																								
				C-T Series	[E] 8.1L V8 L18 Dedicated LPG	CD		CD																								
2002	S a t u r n				[7] 1.9L L4 LL0	CD																										
					[8] 1.9L L4 L24	CD																										
					[D] 2.2L L4 L61	CD																										
					[F] 2.2L L4 L61	CD																										
					[B] 3.0L V6 L81	CD																										
					[R] 3.0L V6 L81	CD																										
			J (VIN 4th)						CD	CD	CD		CD																			
			Z (VIN 5th)						CD	CD	CD																					
2001	P a s s e n g e r		C (VIN 4th)		[1] 3.8L V6 L67	CD		CD	CD	CD	CD	CD		C				C														
			C (VIN 4th)		[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD		C				C														
			E (VIN 4th)							CD	CD	CD	CD									C					C					
			F (VIN 4th)		[K] 3.8L V6 L36	CD			CD	CD		CD																				
			F (VIN 4th)		[G] 5.7L V8 LS1	CD			CD	CD		CD																				
			G (VIN 4th)		[H] 3.5L V6 LX5	CD			CD	CD		CD			C				C				C					CD				
			H (VIN 4th)		[1] 3.8L V6 L67	CD			CD	CD		CD			C				C				C					CD				
			H (VIN 4th)		[K] 3.8L V6 L36	CD			CD	CD		CD			C				C				C					CD				
			J (VIN 4th)		[4] 2.2L L4 LN2	CD			CD	CD	CD	CD	CD						C									CD				
			J (VIN 4th)		[T] 2.4L L4 LD9	CD			CD	CD	CD	CD	CD															CD				
			J (VIN 4th)		[T] 2.4L L4 LD9 Supercharged	CD			CD	CD	CD	CD																CD				
			K (VIN 4th)						CD	CD		CD			C				C		C	C						C	C	C		
			M (VIN 4th)						CD	CD																						
			N (VIN 4th)			[T] 2.4L L4 LD9	CD		CD	CD	CD	CD			C								C					CD				
			N (VIN 4th)			[T] 2.4L L4 LD9 Supercharged	CD		CD	CD	CD	CD			C								C					CD				
			N (VIN 4th)			[J] 3.1L V6 LG8	CD		CD	CD	CD	CD			C								C					CD				
			N (VIN 4th)			[E] 3.4L V6 LA1	CD		CD	CD	CD	CD			C								C					CD				
			S (VIN 4th)							C																						
			V (VIN 4th)						CD	CD	CD	CD	CD															CD				
			W (VIN 4th)			[J] 3.1L V6 LG8	CD		CD	CD	CD	CD	CD		C													CD				
			W (VIN 4th)			[E] 3.4L V6 LA1	CD		CD	CD	CD	CD	CD		C													CD				
			W (VIN 4th)			[H] 3.5L V6 LX5	CD		CD	CD	CD	CD	CD		C													CD				
			W (VIN 4th)			[1] 3.8L V6 L67	CD		CD	CD	CD	CD	CD		C													CD				
			W (VIN 4th)			[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD		C													CD				
			Y (VIN 4th)			[G] 5.7L V8 LS1	CD		CD	CD	CD	CD	CD	D														C				
			Y (VIN 4th)			[S] 5.7L V8 LS6	CD		CD	CD	CD	CD	CD	D														C				
						[2] 1.3L L4 LY8	CD																									
						[2] 1.4L L4 LC0	CD																									
						[6] 1.6L L4 L01	CD	CD																								
						[3] 1.6L L4 L73	CD	CD																								
						[8] 1.8L L4 LV6	CD																									

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS
					[4] 2.2L L4 LN2 Alternative Fules	CD																										
					[R] 3.0L V6 L81	CD																										
					[C] 4.0L V8 L47	CD																										
					[9] 4.6L V8 L37	CD																										
					[Y] 4.6L V8 LD8	CD																										
2001	L D T r k · M P V · I n c o m p l e t e		A (VIN 5th)					CD	CD	CD	CD			C														CD				
			B (VIN 5th)					CD	CD	CD	CD			C														CD				
			C (VIN 5th)		[V] 4.8L V8 LR4	CD			CD	CD	CD	CD	CD					CD														C
					[F] 6.5L V8 L65	CD			CD	CD	CD	CD	CD					CD														C
					E (VIN 5th)					CD	CD																					
					G (VIN 5th)		[F] 6.5L V8 L65	CD			CD	CD												C						CD		
					H (VIN 5th)					CD	CD		CD			C					C			C						CD		C
					J (VIN 5th)					CD	CD																					
					K (VIN 5th)		[F] 6.5L V8 L65	CD			CD	CD	CD	CD	CD			CD														
					L (VIN 5th)					CD	CD	CD	CD																			
					M (VIN 5th)					CD	CD	CD	CD																			
					N (VIN 5th)					CD	C																					
					P (VIN 5th)		[F] 6.5L V8 L65	CD			CD																					
					P (VIN 5th)		[Y] 6.5L V8 L57	CD	CD		CD																					
					S (VIN 5th)					CD	CD	CD	CD	CD																		
					T (VIN 5th)					CD	CD	CD	CD	CD																		
					U (VIN 5th)					CD	CD		CD			C														CD		
					X (VIN 5th)					CD	CD		CD			C														CD		
							[6] 1.6L L4 L01 Without TZ2	CD																								
							[R] 5.7L L31 Bi- Fuel	CD																								
							[C] 2.0L L4 L34(Without TZ2)	CD																								
							[C] 2.0L L4 L34(With TZ2)	CD																								
							[5] 2.2L L4 L43	CD																								
							[4] 2.5L V6 LE8	CD																								
							[E] 3.4L V6 LA1	CD																								
							[W] 4.3L V6 L35	CD																								
							[W] 4.3L V6 L35(C/K pickup only)	CD																								
							[M] 5.0L V8 L30	CD																								
							[T] 5.3L V8 LM7	CD																								
							[R] 5.7L V8 L31	CD																								
							[U] 6.0L V8 LQ4	CD																								
							[1] 6.6L V8 LB7 Diesel	CD																								
							[G] 8.1L V8 L18	CD																								

L
D

T
r
k
,
M
P
V
,

I
n
c
o
m
p
l
e
t
e

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)									
---	--	--	--	--	--	--	--	--	--

[illegible]

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
				C-T Series	[D] 7.4L V8 LP4	CD		CD																									
				C-T Series	[E] 8.1L V8 L18	CD		CD																									
				C-T Series	[E] 8.1L V8 L18 Dedicated LPG	CD		CD																									
2001	S a t u r n				[7] 1.9L L4 LL0	CD																											
					[8] 1.9L L4 L24	CD																											
					[F] 2.2L L4 L61	CD																											
					[R] 3.0L V6 L81	CD																											
			J (VIN 4th)						CD	CD	CD																						
			Z (VIN 5th)						CD	CD	CD																						
2000	P a s s e n g e r				[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD		C					C														
					[1] 3.8L V6 L67	CD		CD	CD	CD	CD	CD		C					C														
										CD	CD	CD	CD										C					C					
						[K] 3.8L V6 L36	CD		CD	CD		CD																					
						[G] 5.7L V8 LS1	CD		CD	CD		CD																					
						[1] 3.8L V6 L67	CD		CD	CD		CD			C					C				C					CD				
						[K] 3.8L V6 L36	CD		CD	CD		CD			C					C				C					CD				
						[4] 2.2L L4 LN2	CD		CD	CD	CD	CD																	CD				
						[T] 2.4L L4 LD9	CD		CD	CD	CD	CD																	CD				
					J (VIN 4th)	Supercharge d	CD		CD	CD	CD	CD																	CD				
					K (VIN 4th)				CD	CD		CD			C					C			C	C					C	C	C		
					M (VIN 4th)				CD	CD																							
					N (VIN 4th)	[T] 2.4L L4 LD9	CD		CD	CD	CD	CD			C																		
					N (VIN 4th)	Supercharge d	CD		CD	CD	CD	CD			C																		
						[J] 3.1L V6 LG8	CD		CD	CD	CD	CD			C																		
						[E] 3.4L V6 LA1	CD		CD	CD	CD	CD			C																		
					S (VIN 4th)					C																							
					V (VIN 4th)				CD	CD	CD		CD																CD				
						[J] 3.1L V6 LG8	CD		CD	CD	CD	CD	CD		C														CD				
						[E] 3.4L V6 LA1	CD		CD	CD	CD	CD	CD		C														CD				
						[1] 3.8L V6 L67	CD		CD	CD	CD	CD	CD		C														CD				
						[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD		C														CD				
						[G] 5.7L V8 LS1	CD		CD	CD	CD	CD	CD	D															C				
						[6] 1.0L L3 LP2	CD																										
						[2] 1.3L L4 LY8	CD																										
						[2] 1.4L L4 LC0	CD																										
						[6] 1.6L L4 L01	CD	CD																									
						[3] 1.6L L4 L73	CD	CD																									
						[8] 1.8L L4 LV6	CD																										
					Alternative Fules		CD																										
						[R] 3.0L V6 L81	CD																										
						[H] 3.5L V6 LX5	CD																										
						[9] 4.6L V8 L37	CD																										
					[Y] 4.6L V8 LD8	CD																											
2000			C (VIN 5th)		[W] 4.3L V6 L35	CD		CD	CD	CD	CD	CD				CD															C		

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	L D T r k · M P V · I n c o m p l e t e		C (VIN 5th)		[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD				CD															C		
			C (VIN 5th)		[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD	CD				CD														C		
			C (VIN 5th)		[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD	CD	CD				CD													C		
			C (VIN 5th)		[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD	CD	CD				CD													C		
			C (VIN 5th)		[F] 6.5L V8 L65	CD		CD	CD	CD	CD	CD	CD	CD				CD													C		
			C (VIN 5th)		[J] 7.4L V8 L29	CD		CD	CD	CD	CD	CD	CD	CD				CD													C		
			E (VIN 5th)							CD	CD	CD	CD																				
			G (VIN 5th)				[W] 4.3L V6 L35	CD		CD	CD													C									
			G (VIN 5th)				[R] 5.7L V8 L31	CD		CD	CD													C									
			G (VIN 5th)				[F] 6.5L V8 L65	CD		CD	CD													C									
			G (VIN 5th)				[J] 7.4L V8 L29	CD		CD	CD													C									
			H (VIN 5th)							CD	CD		CD			C					C		C	C	C				CD		C		
			J (VIN 4th)							CD	CD																						
			K (VIN 5th)				[W] 4.3L V6 L35	CD		CD	CD	CD	CD	CD				CD															
			K (VIN 5th)				[V] 4.8L V8 LR4	CD		CD	CD	CD	CD	CD				CD															
			K (VIN 5th)				[T] 5.3L V8 LM7	CD		CD	CD	CD	CD	CD				CD															
			K (VIN 5th)				[R] 5.7L V8 L31	CD		CD	CD	CD	CD	CD				CD															
			K (VIN 5th)				[U] 6.0L V8 LQ4	CD		CD	CD	CD	CD	CD				CD															
			K (VIN 5th)				[F] 6.5L V8 L65	CD		CD	CD	CD	CD	CD				CD															
			K (VIN 5th)				[J] 7.4L V8 L29	CD		CD	CD	CD	CD	CD				CD															
			L (VIN 5th)				[W] 4.3L V6 L35	CD		CD	CD	CD	CD																				
			M (VIN 5th)				[W] 4.3L V6 L35	CD		CD	CD	CD	CD																				
			P (VIN 5th)				[W] 4.3L V6 L35	CD		CD																							
			P (VIN 5th)				[R] 5.7L V8 L31	CD		CD																							
			P (VIN 5th)				[F] 6.5L V8 L65	CD		CD																							
			P (VIN 5th)				[Y] 6.5L V8 L57	CD	CD	CD																							
			P (VIN 5th)				[J] 7.4L V8 L29	CD		CD																							
			S (VIN 5th)				[4] 2.2L L4 LN2	CD		CD	CD	CD	CD	CD																			
			S (VIN 5th)				[5] 2.2L L4 L43	CD		CD	CD	CD	CD	CD																			
			S (VIN 5th)				[W] 4.3L V6 L35	CD		CD	CD	CD	CD	CD																			
			S (VIN 5th)				[X] 4.3L V6 LF6	CD		CD	CD	CD	CD	CD																			
			T (VIN 5th)				[W] 4.3L V6 L35	CD		CD	CD	CD	CD	CD																			
			T (VIN 5th)				[X] 4.3L V6 LF6	CD		CD	CD	CD	CD	CD																			
			U (VIN 5th)							CD	CD		CD			C														CD			
			V (VIN 5th)										CD			C														CD			
			X (VIN 5th)							CD	CD		CD			C														CD			
							[6] 1.6L L4 L01	CD																									
							[C] 2.0L L4 L34	CD																									
							[E] 3.4L V6 LA1	CD																									
							[L] 4.1L L6 LH3	CD																									
					[M] 5.0L V8 L30	CD																											
					[R] 5.7L V8 L31 Alternative Fuel	CD																											
					[C] 7.2L L6 LG5	C																											
					[B] 7.4L V8 L21	CD																											
2000				B-W4 Series	[4] 4.8L L4 Diesel	CD		CD																									
				B-W4 Series	[R] 5.7L V8 L31	CD		CD																									

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

[illegible]

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
	P a s s e n g e r		N (VIN 4th)		[T] 2.4L L4 LD9	CD		CD	CD	CD	CD																							
			N (VIN 4th)		[M] 3.1L V6 L82	CD			CD	CD	CD	CD																						
			P (VIN 4th)							CD																								
			S (VIN 4th)							C	C																							
			V (VIN 4th)							CD	CD	CD	CD	CD															CD					
			W (VIN 4th)				[M] 3.1L V6 L82	CD		CD	CD	CD	CD	CD																				
			W (VIN 4th)				[K] 3.8L V6 L36	CD		CD	CD	CD	CD	CD																				
			W (VIN 4th)				[1] 3.8L V6 L67	CD		CD	CD	CD	CD	CD																				
			Y (VIN 4th)				[G] 5.7L V8 LS1	CD			CD	CD	CD	CD				CD											C					
							[6] 1.0L L3 LP2	CD																										
							[2] 1.3L L4 LY8	CD																										
							[2] 1.4L L4 LC0	CD																										
							[6] 1.6L L4 L01	CD	CD																									
							[3] 1.6L L4 L73	CD	CD																									
							[8] 1.8L L4 LV6	CD																										
							[4] 2.2L L4 LN2 Alternative Fuel	CD																										
							[R] 3.0L V6 L81	CD																										
							[J] 3.1L V6 LG8	CD																										
							[E] 3.4L V6 LA1	CD																										
							[H] 3.5L V6 LX5	CD																										
					[C] 4.0L V8 L47	CD																												
					[8] 4.0L V8 - Shelby	CD																												
					[9] 4.6L V8 L37	CD																												
					[Y] 4.6L V8 LD8	CD																												
1999	L D T r k · M P		C (VIN 5th)		[W] 4.3L V6 L35	CD		CD	CD	CD	CD																							
			C (VIN 5th)		[V] 4.8L V8 LR4	CD			CD	CD	CD	CD																						
			C (VIN 5th)		[M] 5.0L V8 L30	CD			CD	CD	CD	CD																						
			C (VIN 5th)		[T] 5.3L V8 LM7	CD			CD	CD	CD	CD																						
			C (VIN 5th)		[R] 5.7L V8 L31	CD			CD	CD	CD	CD																						
			C (VIN 5th)		[U] 6.0L V8 LQ4	CD			CD	CD	CD	CD																						
			C (VIN 5th)		[S] 6.5L V8 L56	CD			CD	CD	CD	CD																						
			C (VIN 5th)		[F] 6.5L V8 L65	CD			CD	CD	CD	CD																						
			C (VIN 5th)		[J] 7.4L V8 L29	CD			CD	CD	CD	CD																						
			E (VIN 5th)							CD	CD																							
			G (VIN 5th)				[W] 4.3L V6 L35	CD		CD	CD																							
			G (VIN 5th)				[M] 5.0L V8 L30	CD		CD	CD																							
			G (VIN 5th)				[R] 5.7L V8 L31	CD		CD	CD																							
			G (VIN 5th)				[F] 6.5L V8 L65	CD		CD	CD																							
			G (VIN 5th)				[J] 7.4L V8 L29	CD		CD	CD																							
			H (VIN 5th)							CD	CD	CD	CD	CD															CD					
			J (VIN 5th)							CD	CD																							
			K (VIN 5th)				[W] 4.3L V6 L35	CD		CD	CD	CD	CD																					
			K (VIN 5th)				[V] 4.8L V8 LR4	CD		CD	CD	CD	CD																					
			K (VIN 5th)				[M] 5.0L V8 L30	CD		CD	CD	CD	CD																					
	K (VIN 5th)				[T] 5.3L V8 LM7	CD		CD	CD	CD	CD																							
	K (VIN 5th)				[R] 5.7L V8 L31	CD		CD	CD	CD	CD																							

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

[illegible]

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

[illegible]

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

[illegible]

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

[illegible]

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS		
	r k , M P V , I n c o m p l e t e		K (VIN 5th)		[W] 4.3L V6 L35	CD		CD	CD																									
			K (VIN 5th)		[M] 5.0L V8 L30	CD		CD	CD																									
			K (VIN 5th)		[R] 5.7L V8 L31	CD		CD	CD																									
			K (VIN 5th)		[S] 6.5L V8 L56	CD		CD	CD																									
			K (VIN 5th)		[F] 6.5L V8 L65	CD		CD	CD																									
			K (VIN 5th)		[J] 7.4L V8 L29	CD		CD	CD																									
			L (VIN 5th)		[W] 4.3L V6 L35	CD		CD	CD																									
			M (VIN 5th)		[W] 4.3L V6 L35	CD		CD	CD																									
			P (VIN 5th)		[W] 4.3L V6 L35	CD		CD																										
			P (VIN 5th)		[R] 5.7L V8 L31	CD		CD																										
			P (VIN 5th)		[F] 6.5L V8 L65	CD		CD																										
			P (VIN 5th)		[J] 7.4L V8 L29	CD		CD																										
			S (VIN 5th)		[4] 2.2L L4 LN2	CD		CD	CD																									
			S (VIN 5th)		[W] 4.3L V6 L35	CD		CD	CD																									
			S (VIN 5th)		[X] 4.3L V6 LF6	CD		CD	CD																									
			T (VIN 5th)		[W] 4.3L V6 L35	CD		CD	CD																									
			T (VIN 5th)		[X] 4.3L V6 LF6	CD		CD	CD																									
			U (VIN 5th)							CD	CD																							
			X (VIN 5th)							CD	CD																							
							[6] 1.6L L4 L01	CD																										
					[E] 3.4L V6 LA1	CD																												
					[R] 5.7L V8 L31 Alternative Fuel	CD																												
					[Y] 6.5L V8 L57		CD																											
					[N] 7.4L V8 L19	CD	CD																											
1997	M e d i u m D u t y T r u c k			T-B7 Chassis	[A] 5.7L V8 L31	CD		CD																										
				T-B7 Chassis	[F] 6.5L V8 L65	CD		CD																										
				T-B7 Chassis	[Z] 6.5L V8 L65	CD		CD																										
				T-B7 Chassis	[Y] 6.5L V8 L57	CD		CD																										
				D-C Series	[A] 5.7L V8 L31	CD		CD																										
				D-C Series	[F] 6.5L V8 L65	CD		CD																										
				D-C Series	[Z] 6.5L V8 L65	CD		CD																										
				D-C Series	[Y] 6.5L V8 L57	CD		CD																										
				C-T Series	[A] 5.7L V8 L31	CD		CD																										
				C-T Series	[F] 6.5L V8 L65	CD		CD																										
				C-T Series	[Z] 6.5L V8 L65	CD		CD																										
				C-T Series	[Y] 6.5L V8 L57	CD		CD																										
1997	S a t u r				[8] 1.9L L4 L24	CD		CD																										
						[7] 1.9L L4 LL0	CD		CD																									
1996			A (VIN 4th)		[4] 2.2L L4 LN2	CD		CD	C																									
			A (VIN 4th)		[M] 3.1L V6 L82	CD		CD	C																									
			B (VIN 4th)		[P] 5.7L V8 LT1	CD			CD				CD																					
			C (VIN 4th)		[1] 3.8L V6 L67	CD			CD			CD	CD																					

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	P a s s e n g e r		C (VIN 4th)		[K] 3.8L V6 L67	CD			CD		CD	CD													D								
			D (VIN 4th)		[P] 5.7L V8 LT1	CD			CD	CD			CD																				
			E (VIN 4th)							CD	CD	CD	CD														CD						
			F (VIN 4th)				[K] 3.8L V6 L67	CD			CD	CD																					
			F (VIN 4th)				[P] 5.7L V8 LT1	CD			CD	CD																					
			G (VIN 4th)				[1] 3.8L V6 L67	CD			CD		CD																				
			G (VIN 4th)				[K] 3.8L V6 L67	CD			CD		CD																				
			H (VIN 4th)				[1] 3.8L V6 L67	CD			CD		CD																				
			H (VIN 4th)				[K] 3.8L V6 L67	CD			CD		CD																				
			J (VIN 4th)				[4] 2.2L L4 LN2	CD			CD																						
			J (VIN 4th)				[T] 2.4L L4 LD9	CD			CD																						
			K (VIN 4th)								CD	CD	CD	CD																			
			L (VIN 4th)				[4] 2.2L L4 LN2	CD			CD	C																					
			L (VIN 4th)				[M] 3.1L V6 L82	CD			CD	C																					
			M (VIN 4th)								CD	CD																					
			N (VIN 4th)				[T] 2.4L L4 LD9	CD			CD																						
			N (VIN 4th)				[M] 3.1L V6 L82	CD			CD																						
			S (VIN 4th)								CD																						
			W (VIN 4th)				[M] 3.1L V6 L82	CD			CD	CD																					
			W (VIN 4th)				[K] 3.8L V6 L67	CD			CD	CD																					
			Y (VIN 4th)				[P] 5.7L V8 LT1	CD			CD							CD															
							[6] 1.0L L3 LP2	CD																									
							[9] 1.3L L4 L72	CD																									
							[6] 1.6L L4 L01	CD																									
							[8] 1.8L L4 LV6	CD																									
							[X] 3.4L V6 LQ1	CD																									
							[C] 4.0L V8 L47	CD																									
							[W] 4.3L V8 L99	CD																									
							[9] 4.6L V8 L37	CD																									
							[Y] 4.6L V8 LD8	CD																									
					[5] 5.7L V8 LT4	CD																											
1996	L D T r k ,		C (VIN 5th)		[W] 4.3L V6 L35	CD			CD	CD																							
			C (VIN 5th)		[M] 5.0L V8 L30	CD				CD	CD																						
			C (VIN 5th)		[R] 5.7L V8 L31	CD				CD	CD																						
			C (VIN 5th)		[S] 6.5L V8 L56	CD				CD	CD																						
			C (VIN 5th)		[F] 6.5L V8 L65	CD				CD	CD																						
			C (VIN 5th)		[J] 7.4L V8 L29	CD				CD	CD																						
			E (VIN 5th)								CD																						
			G (VIN 5th)				[W] 4.3L V6 L35	CD			CD	CD																					
			G (VIN 5th)				[Z] 4.3L V6 LB4	CD	CD		CD	CD																					
			G (VIN 5th)				[M] 5.0L V8 L30	CD			CD	CD																					
			G (VIN 5th)				[K] 5.7L V8 L05	CD	CD		CD	CD																					
			G (VIN 5th)				[R] 5.7L V8 L31	CD			CD	CD																					
			G (VIN 5th)				[F] 6.5L V8 L65	CD			CD	CD																					
			G (VIN 5th)				[J] 7.4L V8 L29	CD			CD	CD																					
			H (VIN 5th)				[K] 5.7L V8 L05	CD	CD																								
			J (VIN 5th)						CD	CD																							

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	M P V , I n c o m p l e t e		K (VIN 5th)		[W] 4.3L V6 L35	CD		CD	CD																								
			K (VIN 5th)		[M] 5.0L V8 L30	CD		CD	CD																								
			K (VIN 5th)		[R] 5.7L V8 L31	CD		CD	CD																								
			K (VIN 5th)		[S] 6.5L V8 L56	CD		CD	CD																								
			K (VIN 5th)		[F] 6.5L V8 L65	CD		CD	CD																								
			K (VIN 5th)		[J] 7.4L V8 L29	CD		CD	CD																								
			L (VIN 5th)		[W] 4.3L V6 L35	CD		CD	CD																								
			M (VIN 5th)		[W] 4.3L V6 L35	CD		CD	CD																								
			P (VIN 5th)		[W] 4.3L V6 L35	CD																											
			P (VIN 5th)		[R] 5.7L V8 L31	CD																											
			P (VIN 5th)		[F] 6.5L V8 L65	CD																											
			P (VIN 5th)		[J] 7.4L V8 L29	CD																											
			S (VIN 5th)		[4] 2.2L L4 LN2	CD		CD	CD																								
			S (VIN 5th)		[W] 4.3L V6 L35	CD		CD	CD																								
			S (VIN 5th)		[X] 4.3L V6 LF6	CD		CD	CD																								
			T (VIN 5th)		[W] 4.3L V6 L35	CD			CD																								
			T (VIN 5th)		[X] 4.3L V6 LF6	CD			CD																								
			U (VIN 5th)					CD	CD																								
							[6] 1.6L L4 L01	CD																									
							[E] 3.4L V6 LA1	CD																									
					[Y] 6.5L V8 L57		CD																										
					[N] 7.4L V8 L19	CD	CD																										
1996	M e d i u				[A] 5.7L V8 L31	CD																											
					[D] 5.7L V8 L05	CD	CD																										
					[Z] 6.5L V8 L65	CD																											
					[Y] 6.5L V8 L57		CD																										
1996	S a r				[8] 1.9L L4 L24	CD		CD																									
					[7] 1.9L L4 LL0	CD		CD																									
1995	P a s s e n g e r		A (VIN 4th)		[4] 2.2L L4 LN2	CD		CD																									
			A (VIN 4th)		[D] 2.3L L4 LD2	CD		CD																									
			A (VIN 4th)		[M] 3.1L V6 L82	CD		CD																									
			B (VIN 4th)		[W] 4.3L V8 L99	CD		CD	CD																								
			B (VIN 4th)		[P] 5.7L V8 LT1	CD		CD	CD																								
			C (VIN 4th)		[1] 3.8L V6 L67	CD			CD																								
			C (VIN 4th)		[K] 3.8L V6 L36	CD			CD																								
			D (VIN 4th)		[P] 5.7L V8 LT1	CD		CD	CD																								
			E (VIN 4th)					CD																									
			F (VIN 4th)		[P] 5.7L V8 LT1	CD		CD	CD																								
			G (VIN 4th)		[1] 3.8L V6 L67	CD																											
			G (VIN 4th)		[K] 3.8L V6 L36	CD																											
			H (VIN 4th)		[L] 3.8L V6 L27	CD			CD																								
			H (VIN 4th)		[1] 3.8L V6 L67	CD			CD																								
			H (VIN 4th)		[K] 3.8L V6 L36	CD			CD																								
			J (VIN 4th)					CD																									
			L (VIN 4th)				[4] 2.2L L4 LN2	CD		CD	C																						
			M (VIN 4th)							CD																							
			N (VIN 4th)				[D] 2.3L L4 LD2	CD		CD	C																						

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

[illegible]

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
	L D T r k , M P V , I n c o m p l e t e		G (VIN 5th)		[Z] 4.3L V6 LB4	CD			CD																								
			K (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			L (VIN 5th)		[Z] 4.3L V6 LB4	CD				CD																							
			M (VIN 5th)		[Z] 4.3L V6 LB4	CD				CD																							
			P (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			S (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			T (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			U (VIN 5th)		[L]3.8L V6 L27	CD			CD	CD																							
					[4] 2.2L L4 LN2	CD																											
					[G] 2.3L L4 LD2	CD																											
					[W] 4.3L V6 L35	CD																											
					[W] 4.3L V6 L35 with CTF	CD																											
					[H] 5.0L V8 L03	CD																											
					[K] 5.7L V8 L05	CD																											
					[P] 6.5L V8 L49	D																											
					[S] 6.5L V8 L56	D																											
					[F] 6.5L V8 L65	D																											
					[Y] 6.5L V8 L57	D																											
					[N] 7.4L V8 L19	CD																											
1994			M e d S a				[A] 5.7L V8 L05	CD																									
					[Y] 6.5L V8 L57	D																											
1994						CD		CD																									
1993	P a s s e n g e r		A (VIN 4th)					C																									
			B (VIN 4th)						C																								
			C (VIN 4th)		[L] 3.8L V6 L27	D				CD																							
			D (VIN 4th)						CD	C																							
			E (VIN 4th)						CD	C																							
			F (VIN 4th)						CD																								
			H (VIN 4th)		[L] 3.8L V6 L27	D				CD																							
			J (VIN 4th)		[T] 3.1L V6 LH0	CD			CD																								
			K (VIN 4th)						CD	CD																							
			L (VIN 4th)		[A] 2.3L L4 LG0	CD			CD	C																							
			L (VIN 4th)		[T] 3.1L V6 LH0	CD			CD	C																							
			M (VIN 4th)							C																							
			N (VIN 4th)		[A] 2.3L L4 LG0	CD			CD																								
			R (VIN 4th)							C																							
			S (VIN 4th)							CD																							
			V (VIN 4th)								C																						
			W (VIN 4th)		[T] 3.1L V6 LH0	CD			CD																								
			W (VIN 4th)		[L] 3.8L V6 L27	D			CD																								
			Y (VIN 4th)								C																						
							[6] 1.6L L4 L01	CD																									
					[8] 1.8L L4 LV6	CD																											
					[H] 2.0L L4 LE4	CD																											
					[4] 2.2L L4 LN4	CD																											
					[3] 2.3L L4 L40	CD																											

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

Year	Type	Make	VIN	Model	ENG TYPE	ENG	AT	ABS	SIR	BCM	IPC	HVAC	VSES	VT D	TPM	RTD /CV RTD	ESC	DRR	DDM	DPM	PDM	RCD	VCIM	TDM	RFA	ISU	IMM O	Radi o	Navi gatio n Radi o	Amplifie r(Bose)	TA	RWS	
					[D] 2.3L L4 LD2	CD																											
					[W] 3.1L V6 L64	CD																											
					[X] 3.4L V6 LQ1	CD																											
					[1] 3.8L V6 L67	D																											
1993	L D T r k , M P V , I n c o m p l e t e		C (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			G (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			K (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			L (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			M (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			P (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			S (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			T (VIN 5th)		[Z] 4.3L V6 LB4	CD																											
			U (VIN 5th)							CD																							
							[G] 2.3L L4 LD2	CD																									
							[L] 3.8L V6 L27	D																									
							[W] 4.3L V6 L35	CD																									
							[H] 5.0L V8 L03	CD																									
							[K] 5.7L V8 L05	CD																									
							[J] 6.2L V8 LL4	D																									
							[F] 6.5L V8 L65	D																									
					[N] 7.4L V8 L19	CD																											
1993	M				[A] 5.7L V8 L05	CD																											
1993	S a t					CD		CD																									
1992	P a s s e n g e r		A (VIN 4th)		[T] 3.1L V6 LH0	CD																											
			B (VIN 4th)						CD	C																							
			C (VIN 4th)		[L] 3.8L V6 L27	D				CD																							
			D (VIN 4th)							CD																							
			E (VIN 4th)							CD	C																						
			F (VIN 4th)								C																						
			H (VIN 4th)		[L] 3.8L V6 L27	D					CD																						
			J (VIN 4th)		[T] 3.1L V6 LH0	CD				CD																							
			K (VIN 4th)							CD	C																						
			L (VIN 4th)		[T] 3.1L V6 LH0	CD				CD	C																						
			M (VIN 4th)								C																						
			N (VIN 4th)								CD																						
			R (VIN 4th)								C																						
			V (VIN 4th)								C																						
			W (VIN 4th)		[T] 3.1L V6 LH0	CD				CD																							
			W (VIN 4th)		[L] 3.8L V6 L27	D				CD																							
			Y (VIN 4th)								C																						
							[6] 1.6L L4 L01	CD																									
							[8] 1.8L L4 LV6	CD																									
							[H] 2.0L L4 LE4	CD																									
					[4] 2.2L L4 LN4	CD																											
					[3] 2.3L L4 L40	CD																											
					[D] 2.3L L4 LD2	CD																											

GM_DBSCar V12.10 Diagnostics List (Note:For reference only)

[illegible]