

AUDI_V01.10 Daig Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Model Year				
A1	2011 - 2017				
A2	2001 - 2006				
A3	1997 - 2017				
A4	1998 - 2017				
A5	2008 - 2017				
A6	1998 - 2017				
A7	2011 - 2017				
A8	1999 - 2017				
Cabriolet	2003 - 2009				
Q3	2012 - 2017				
Q5	2009 - 2017				
Q7	2007 - 2017				
R8	2007 - 2017				
TT	1999 - 2006				
Systemlist		EcuInfo.	ReadCodes	EraseCode	LiveData
01 Engine Control Module 1		●	●	●	●
02 Transmission Control Module		●	●	●	●
03 Brake Control Module		●	●	●	●
04 Steering Angle Sender		●	●	●	●
05 Kessy		●	●	●	●
06 Seat Adjustment Passenger Side		●	●	●	●
07 Display Control Unit		●	●	●	●
08 Air Conditioning		●	●	●	●
09 Central Electrics		●	●	●	●
0B Auxiliary Air Heater		●	●	●	●
0C Rear Axle Steering 2		●	●	●	●
0D Sliding Door Left		●	●	●	●
0E Media Player Position 1		●	●	●	●
0F Radio Tuner - Digital		●	●	●	●
10 Parking Assistance 2		●	●	●	●
11 Engine Control Module 2		●	●	●	●
12 Clutch Control Unit		●	●	●	●
13 Adaptive Cruise Control		●	●	●	●
14 Wheel Dampening Electronics		●	●	●	●
15 Airbag		●	●	●	●
16 Steering Column Electronics		●	●	●	●
17 Dash Board		●	●	●	●
18 Auxiliary Parking Heating		●	●	●	●
19 Gateway		●	●	●	●
1B Power-Assisted Steering		●	●	●	●
1C Vehicle Position Detection		●	●	●	●
1D Driver Identification		●	●	●	●
1E Media Player Position 2		●	●	●	●
1F Radio Satellite		●	●	●	●

20 High Beam Assistance	●	●	●	●
21 Battery Energy Control Module 2	●	●	●	●
22 4WD Electronics	●	●	●	●
23 Brake Boost	●	●	●	●
24 Drive Slip Control	●	●	●	●
25 Immobilizer	●	●	●	●
26 Electric Roof Control	●	●	●	●
27 Display Control Unit Rear	●	●	●	●
28 Climate Control Unit Rear	●	●	●	●
29 Light Control Left	●	●	●	●
2B Steer Column Locking	●	●	●	●
2D Voice Amplifier	●	●	●	●
2E Media Player Position 3	●	●	●	●
2F TV Tuner - Digital	●	●	●	●
30 Special Function 2	●	●	●	●
31 Engine Electronics Conjunction	●	●	●	●
32 Locking Electronics	●	●	●	●
34 Self Adjustment Suspension	●	●	●	●
35 Central Locking Control Module	●	●	●	●
36 Seat Adjustment Driver Side	●	●	●	●
37 Navigation	●	●	●	●
38 Roof Electronics	●	●	●	●
39 Light Control Right	●	●	●	●
3A Special Vehicle Assistant	●	●	●	●
3B Sensor Electronics	●	●	●	●
3C Lane Change Assistance System	●	●	●	●
3D Special Function	●	●	●	●
3E Media Player Position 4	●	●	●	●
40 Air Conditioning Compressor	●	●	●	●
41 Diesel Pump Electronics	●	●	●	●
42 Driver-Door Electronics	●	●	●	●
43 Braker Boost Assistance	●	●	●	●
44 Steering Assistance	●	●	●	●
45 Interior Monitoring	●	●	●	●
46 Central Control Module	●	●	●	●
47 Sound System	●	●	●	●
48 Seat Adjustment Rear Driver Side	●	●	●	●
49 Automatic Lighting Switch	●	●	●	●
4B Multifunction Module	●	●	●	●
4C Tyre Pressure Monitor II	●	●	●	●
4E Control Head Rear Right	●	●	●	●
4F Central Electronics II	●	●	●	●
51 Drive Motor Control Module	●	●	●	●
52 Passenger-Door Electronics	●	●	●	●
53 Parking Brake	●	●	●	●
54 Rear Spoiler	●	●	●	●
55 Headlight Range Control	●	●	●	●
56 Radio	●	●	●	●
57 TV-Tuner	●	●	●	●
58 Auxiliary Fuel Tank	●	●	●	●
59 Towing Protection	●	●	●	●

5B Seat Adjustment Rear Passenger Side	●	●	●	●
5C Lane Keeping Assistance System	●	●	●	●
5D Operation	●	●	●	●
5E Control Head Left Rear	●	●	●	●
5F Information Control Unit 1	●	●	●	●
61 Battery Regulation	●	●	●	●
62 Door Electronics Left Rear	●	●	●	●
63 Entry Assistance Driver Side	●	●	●	●
64 Stabilizers	●	●	●	●
65 Tyre Pressure Monitoring I	●	●	●	●
66 Seat/Mirror Adjustment	●	●	●	●
67 Voice Control	●	●	●	●
68 Wiper Control Unit	●	●	●	●
69 Trailer Function	●	●	●	●
6B Aerodynamics Control Module	●	●	●	●
6C Camera System Rear View	●	●	●	●
6D Electronic Equipment of Trunk Lid	●	●	●	●
6E Display Control Roof	●	●	●	●
6F Central Control Module II	●	●	●	●
71 Battery Charger	●	●	●	●
72 Door Electronics Right Rear	●	●	●	●
73 Entry Assistance Passenger Side	●	●	●	●
74 Vehicle Control System	●	●	●	●
75 Telematics Communication Unit	●	●	●	●
76 Parking Assistance	●	●	●	●
77 Telephone	●	●	●	●
78 Sliding Door	●	●	●	●
7D Auxiliary Heater	●	●	●	●
7E Dash Board Display Unit	●	●	●	●
7F Information Control Unit 2	●	●	●	●
81 Gear Shift Control Module	●	●	●	●
82 Head Up Display	●	●	●	●
84 Night Vision	●	●	●	●
85 On Board-Camera	●	●	●	●
88 Multi Contour Seat Driver Side	●	●	●	●
89 Multi Contour Seat Passenger Side	●	●	●	●
8A Multi Contour Seat Rear Driver Side	●	●	●	●
8B Adaptive Cruise Control 2	●	●	●	●
8C Battery Energy Control Module	●	●	●	●
8D Multi Contour Seat Rear Passenger Side	●	●	●	●
8E Image Processing Electronics	●	●	●	●
8F Pretensioner Front Left	●	●	●	●
90 Pretensioner Front Right	●	●	●	●
91 Engine Control Module LT3	●	●	●	●
92 Transmission Electronics LT3	●	●	●	●
93 Immobilizer LT3	●	●	●	●
94 Airbag LT3	●	●	●	●
95 Electronic Stability Program LT3	●	●	●	●
96 Instruments Cluster LT3	●	●	●	●
97 Tachograph LT3	●	●	●	●
98 Tire Pressure Monitoring LT3	●	●	●	●

	99 Electrical Ignition/Starter Switch LT3	●	●	●	●
	9A Remote Control LT3	●	●	●	●
	9B Driver' s Door Electronics LT3	●	●	●	●
	9C A/C Electronics LT3	●	●	●	●
	9D Auxiliary Heater(Fuel)LT3	●	●	●	●
	9E Auxiliary Heater(Electric)LT3	●	●	●	●
	9F Additional Heater, Water LT3	●	●	●	●
	A0 Radio 'Audio 5' LT3	●	●	●	●
	A1 Navigation LT3	●	●	●	●
	A2 CD Changer LT3	●	●	●	●
	A3 Telephone LT3	●	●	●	●
	A5 Front Sensors Driver Assistance System	●	●	●	●
	A6 Microphone Control Unit	●	●	●	●
	A7 Infotainment Interface	●	●	●	●
	A9 Actuator for Structure-Borne Sound	●	●	●	●
	AC Reductant Control Module	●	●	●	●
	AD Sensors Brake Systems	●	●	●	●
	B0 Roof Display/Control Head (Roof Control Head) LT3	●	●	●	●
	B1 Upper Operating Field LT3	●	●	●	●
	B2 Parking Aid LT3	●	●	●	●
	B3 Trailer Function LT3	●	●	●	●
	B4 Vehicle Electrical System Control Module LT3	●	●	●	●
	B5 Programmable Special Module LT3	●	●	●	●
	B6 Steering Column Jacket Switch Module LT3	●	●	●	●
	B7 Access Startsystem Interface	●	●	●	●
	B8 Electronic Roof Control 2	●	●	●	●
	B9 Auxiliary Display Conrol Unit	●	●	●	●
	BA Assembly Mounting	●	●	●	●
	BB Door Electronics Rear Driver Side	●	●	●	●
	BC Door Electronics Rear Passenger Side	●	●	●	●
	BD High Voltage Battery Charge Management	●	●	●	●
	BE Sliding Door Rear Left	●	●	●	●
	BF Sliding Door Right	●	●	●	●
	C0 Actuator For Exterior Noise	●	●	●	●
	C1 Battery regulation LT3	●	●	●	●
	C2 Transmission Control Module 2	●	●	●	●
	C4 DC/DC Converter Control Module	●	●	●	●
	C5 Thermal Management	●	●	●	●
	C6 Battery Charger Control Module	●	●	●	●
	C7 Pedestrian Protection	●	●	●	●
	CB Rear Axle Steering	●	●	●	●
	D0 Front Axle Lift System	●	●	●	●

AUDI_V01.10 Reset Function List (Note:For reference only)

Vehicle	Year	OIL	EPB	ETC	BMS	SAS	DPF
A1	2011 - 2014	●	●	●	●	●	●
A2	2000 - 2005	●	●	●	○	●	●
A3	1997 - 2014	●	●	●	●	●	●
A4	1995 - 2014	●	●	●	●	●	●
A5	2008 - 2014	●	●	●	●	●	●
A6	1992 - 2014	※	※	※	※	※	※
A7	2011 - 2014	●	●	●	●	●	●
A8	1994 - 2014	※	※	※	※	※	※
CABRIO	1992 - 2000	※	※	※	※	※	※

Q3	2012 - 2014	●	●	●	●	●	●
Q5	2009 - 2014	●	●	●	●	●	●
Q7	2007 - 2014	●	●	●	●	●	●
R8	2007 - 2014	●	●	●	●	●	●
RS3	2004 - 2013	●	●	●	●	●	●
RS4		○	○	○	●	○	○
RS5	2008 - 2014	●	●	●	●	●	●
S2	1992 - 1996	※	※	※	○	※	※
S3	1997 - 2014	●	●	●	●	●	●
S4		○	○	○	●	○	○
S5	2008 - 2014	●	●	●	●	●	●
TT	1999 - 2014	●	●	●	●	●	●
TTRS	2007 - 2014	●	●	●	●	●	●
TTS	2007 - 2014	●	●	●	●	●	●