

Renault\_V01.10 Daig Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	System Name	EcuInfo.	Read Codes	Erase Codes	LiveData
ALASKAN	Injection	●	●	●	●
ALASKAN	Transmission Control Module	●	●	●	●
ALASKAN	ABS	●	●	●	●
ALASKAN	Airbag/Pretensioners	●	●	●	●
ALASKAN	Instrument Panel	●	●	●	●
ALASKAN	UCH	●	●	●	●
ALASKAN	4 Wheels Drive	●	●	●	●
ALASKAN	UPC	●	●	●	●
ALASKAN	Parking Prox CAN	●	●	●	●
ALASKAN	Air Conditioning	●	●	●	●
ALASKAN	Distance Regulator	●	●	●	●
AVANTIME	Injection	●	●	●	●
AVANTIME	Transmission Control Module	●	●	●	●
AVANTIME	ABS	●	●	●	●
AVANTIME	Airbag/Pretensioners	●	●	●	●
AVANTIME	Interconnection Unit	●	●	●	●
AVANTIME	Engine Immobiliser	●	●	●	●
CAPTUR	Injection	●	●	●	●
CAPTUR	Transmission Control Module	●	●	●	●
CAPTUR	ABS	●	●	●	●
CAPTUR	Airbag/Pretensioners	●	●	●	●
CAPTUR	Instrument Panel	●	●	●	●
CAPTUR	UCH	●	●	●	●
CAPTUR	Communications Unit	●	●	●	●
CAPTUR	Variable P.A.S	●	●	●	●
CAPTUR	Parking Prox CAN	●	●	●	●
CAPTUR	UPC	●	●	●	●
CAPTUR	Air Conditioning	●	●	●	○
CAPTUR	Telematic Control Unit	●	●	●	●
CAPTUR	Radio	●	●	●	●
CAPTUR	Multimedia Interface	●	●	●	●
CAPTUR	Hands Free Kit	●	●	●	●
CLIO 2	Injection	●	●	●	●
CLIO 2	Transmission Control Module	●	●	●	●
CLIO 2	ABS	●	●	●	●
CLIO 2	Airbag/Pretensioners	●	●	●	●
CLIO 2	Gasoline Injection	●	●	●	●
CLIO 2	Interconnection Unit	●	●	●	●
CLIO 2	Engine Immobiliser	●	●	●	●
CLIO 2	Air Conditioning	●	●	●	●
CLIO II PH2/3/4	Injection	●	●	●	●

CLIO II PH2/3/4	Transmission Control Module	●	●	●	●
CLIO II PH2/3/4	ABS	●	●	●	●
CLIO II PH2/3/4	Airbag/Pretensioners	●	●	●	●
CLIO II PH2/3/4	Gasoline Injection	●	●	●	●
CLIO II PH2/3/4	Interconnection Unit	●	●	●	●
CLIO II PH2/3/4	Variable P.A.S	●	●	●	●
CLIO II PH2/3/4	Engine Immobiliser	●	●	●	●
CLIO II PH2/3/4	Air Conditioning	●	●	●	●
CLIO II PH2/3/4	Discharge Lamp	●	●	●	●
CLIO II PH6	Injection	●	●	●	●
CLIO II PH6	Airbag/Pretensioners	●	●	●	●
CLIO II PH6	UCH	●	●	●	●
CLIO II PH6	Tracker	●	●	●	●
CLIO III	Injection	●	●	●	●
CLIO III	Transmission Control Module	●	●	●	●
CLIO III	ABS	●	●	●	●
CLIO III	Airbag/Pretensioners	●	●	●	●
CLIO III	Instrument Panel	●	●	●	●
CLIO III	UCH	●	●	●	●
CLIO III	Communications Unit	●	●	●	●
CLIO III	Variable P.A.S	●	●	●	●
CLIO III	UPC	●	●	●	●
CLIO III	Tire Pressure Monitoring System	●	●	●	●
CLIO III	Air Conditioning	●	●	●	●
CLIO III	Lighting	●	●	●	●
CLIO III	Radio	●	●	●	●
CLIO III	Multimedia Connection	●	●	●	●
CLIO III	Multimedia Interface	●	●	●	●
CLIO III	Parking Assistance	●	●	●	●
CLIO IV	Injection	●	●	●	●
CLIO IV	Transmission Control Module	●	●	●	●
CLIO IV	ABS	●	●	●	●
CLIO IV	Airbag/Pretensioners	●	●	●	●
CLIO IV	Instrument Panel	●	●	●	●
CLIO IV	UCH	●	●	●	●
CLIO IV	Communications Unit	●	●	●	●
CLIO IV	Variable P.A.S	●	●	●	●
CLIO IV	Parking Prox CAN	●	●	●	●
CLIO IV	UPC	●	●	●	●
CLIO IV	Air Conditioning	●	●	●	●
CLIO IV	Telematic Control Unit	●	●	●	●
CLIO IV	Radio	●	●	●	●
CLIO IV	Multimedia Interface	●	●	●	●
CLIO IV	Hands Free Kit	●	●	●	●
CLIO IV	Amplifier	●	●	●	●
CLIO V6	Injection	●	●	●	●
CLIO V6 PH 2	Injection	●	●	●	●
DOKKER	Injection	●	●	●	●
DOKKER	ABS	●	●	●	●
DOKKER	Airbag/Pretensioners	●	●	●	●
DOKKER	Instrument Panel	●	●	●	●
DOKKER	UCH	●	●	●	●

DOKKER	Variable P.A.S	●	●	●	●
DOKKER	Radio	●	●	●	●
DUSTER	Injection	●	●	●	●
DUSTER	Transmission Control Module	●	●	●	●
DUSTER	ABS	●	●	●	●
DUSTER	Airbag/Pretensioners	●	○	●	●
DUSTER	UCH	●	●	●	●
DUSTER	4 Wheels Drive	●	●	●	●
DUSTER	Variable P.A.S	●	●	●	●
DUSTER	Radio	●	●	●	●
DUSTER	Tracker	●	●	●	●
DUSTER PH2	Injection	●	●	●	●
DUSTER PH2	ABS	●	●	●	●
DUSTER PH2	Airbag/Pretensioners	●	●	●	●
DUSTER PH2	Instrument Panel	●	●	●	●
DUSTER PH2	UCH	●	●	●	●
DUSTER PH2	Variable P.A.S	●	●	●	●
DUSTER PH2	4 Wheels Drive	●	●	●	●
DUSTER PH2	Radio	●	●	●	●
ESPACE	Injection	●	●	●	●
ESPACE	Transmission Control Module	●	●	●	●
ESPACE	ABS	●	●	●	●
ESPACE	Airbag/Pretensioners	●	●	●	●
ESPACE	Instrument Panel	●	※	※	●
ESPACE	Interconnection Unit	●	●	●	●
ESPACE	Engine Immobiliser	●	●	●	●
ESPACE	Air Conditioning	●	●	●	●
ESPACE	Heater	●	●	●	●
ESPACE	Lighting	●	●	●	●
ESPACE IV	Injection	●	●	●	●
ESPACE IV	Transmission Control Module	●	●	●	●
ESPACE IV	ABS	●	●	●	●
ESPACE IV	Airbag/Pretensioners	●	●	●	●
ESPACE IV	Instrument Panel	●	●	●	●
ESPACE IV	UCH	●	●	●	●
ESPACE IV	Air Conditioning	●	●	●	●
ESPACE IV	Parking Brake	●	●	●	●
ESPACE IV	Parking Assistance	●	●	●	●
ESPACE IV	Heater	●	●	●	●
ESPACE IV	Discharge Lamp	●	●	●	●
ESPACE IV	Radio	●	●	●	●
ESPACE IV	Hands Free Kit	●	●	●	●
ESPACE IV PH2	Injection	●	●	●	●
ESPACE IV PH2	Transmission Control Module	●	●	●	●
ESPACE IV PH2	ABS	●	●	●	●
ESPACE IV PH2	Airbag/Pretensioners	●	●	●	●
ESPACE IV PH2	Instrument Panel	●	●	●	●
ESPACE IV PH2	UCH	●	●	●	●
ESPACE IV PH2	Communications Unit	●	●	●	●
ESPACE IV PH2	Variable P.A.S	●	●	●	●
ESPACE IV PH2	Parking Brake	●	●	●	●
ESPACE IV PH2	Parking Prox CAN	●	●	●	●

ESPACE IV PH2	Air Conditioning	●	●	●	●
ESPACE IV PH2	Parking Assistance	●	●	●	●
ESPACE IV PH2	Heater	●	●	●	●
ESPACE IV PH2	Lighting	●	●	●	●
ESPACE IV PH2	Radio	●	●	●	●
ESPACE IV PH2	Multimedia Interface	●	●	●	●
ESPACE IV PH2	Multimedia Connection	●	●	●	●
ESPACE V	Injection	●	●	●	●
ESPACE V	Transmission Control Module	●	●	●	●
ESPACE V	ABS	●	●	●	●
ESPACE V	Airbag/Pretensioners	●	●	●	●
ESPACE V	Instrument Panel	●	●	●	●
ESPACE V	UCH	●	●	●	●
ESPACE V	4 Wheels Steering	●	●	●	●
ESPACE V	Variable P. A. S	●	●	●	●
ESPACE V	Parking Brake	●	●	●	●
ESPACE V	Parking Prox CAN	●	●	●	●
ESPACE V	UPC	●	●	●	●
ESPACE V	Air Conditioning	●	●	●	●
ESPACE V	Seat Management	●	●	●	●
ESPACE V	Front Camera	●	●	●	●
ESPACE V	Radio	●	●	●	●
ESPACE V	Multimedia Interface	●	●	●	○
ESPACE V	Amplifier	●	●	●	●
ESPACE V	Telematic Control Unit	●	●	●	●
ESPACE V	Left-Hand Door	●	●	●	●
ESPACE V	Right-Hand Door	●	●	●	●
ESPACE V	Distance Regulator	●	●	●	●
ESPACE V	Power Back Door	●	●	●	●
ESPACE V	Piloted Suspension	●	●	●	●
KADJAR	Injection	●	●	●	●
KADJAR	Transmission Control Module	●	●	●	●
KADJAR	ABS	●	●	●	●
KADJAR	Airbag/Pretensioners	●	●	●	●
KADJAR	Instrument Panel	●	●	●	●
KADJAR	UCH	●	●	●	●
KADJAR	4 Wheels Drive	●	●	●	●
KADJAR	Variable P. A. S	●	●	●	●
KADJAR	Parking Brake	●	●	●	●
KADJAR	Parking Prox CAN	●	●	●	●
KADJAR	UPC	●	●	●	●
KADJAR	Air Conditioning	●	●	●	●
KADJAR	Front Camera	●	●	●	●
KADJAR	Radio	●	●	●	●
KADJAR	Multimedia Interface	●	●	●	○
KADJAR	Amplifier	●	●	●	●
KADJAR	Telematic Control Unit	●	●	●	●
KADJAR	Distance Regulator	●	●	●	○
KADJAR CN	Injection	●	●	●	●
KADJAR CN	Transmission Control Module	●	●	●	●
KADJAR CN	ABS	●	●	●	●
KADJAR CN	Airbag/Pretensioners	●	●	●	●

KADJAR CN	Instrument Panel	●	●	●	●
KADJAR CN	UCH	●	●	●	●
KADJAR CN	4 Wheels Drive	●	●	●	●
KADJAR CN	Variable P.A.S	●	●	●	●
KADJAR CN	Parking Brake	●	●	●	●
KADJAR CN	Parking Prox CAN	●	●	●	●
KADJAR CN	UPC	●	●	●	●
KADJAR CN	Air Conditioning	●	●	●	●
KADJAR CN	Radio	●	●	●	●
KADJAR CN	Multimedia Interface	●	●	●	●
KADJAR CN	Amplifier	●	●	●	●
KADJAR CN	Telematic Control Unit	●	●	●	●
KANGOO	Injection	●	●	●	●
KANGOO	Transmission Control Module	●	●	●	●
KANGOO	ABS	●	●	●	●
KANGOO	Airbag/Pretensioners	●	●	●	●
KANGOO	Interconnection Unit	●	●	●	●
KANGOO	Air Conditioning	●	●	●	●
KANGOO	Gasoline Injection	●	●	●	●
KANGOO	Engine Immobiliser	●	●	●	●
KANGOO II	Injection	●	●	●	●
KANGOO II	Transmission Control Module	●	●	●	●
KANGOO II	ABS	●	●	●	●
KANGOO II	Airbag/Pretensioners	●	●	●	●
KANGOO II	Instrument Panel	●	●	●	●
KANGOO II	UCH	●	●	●	●
KANGOO II	Communications Unit	●	●	●	●
KANGOO II	UPC	●	●	●	●
KANGOO II	Variable P.A.S	●	●	●	●
KANGOO II	Air Conditioning	●	●	●	●
KANGOO II	Tire Pressure Monitoring System	●	●	●	○
KANGOO II	Parking Assistance	●	●	●	●
KANGOO II	Radio	●	●	●	●
KANGOO II	Multimedia Interface	●	●	●	●
KANGOO II	Multimedia Connection	●	●	●	●
KANGOO II	Telematic Control Unit	●	●	●	●
KANGOO II	Adaptation Unit	●	●	●	●
KANGOO MUX	Petrol Injection	●	●	●	●
KANGOO MUX	Diesel Injection	●	●	●	●
KANGOO MUX	Transmission Control Module	●	●	●	●
KANGOO MUX	ABS	●	●	●	●
KANGOO MUX	Airbag/Pretensioners	●	●	●	●
KANGOO MUX	Interconnection Unit	●	●	●	●
KANGOO MUX	Engine Immobiliser	●	●	●	●
KANGOO VLL	Injection	●	●	●	●
KANGOO VLL	ABS	●	●	●	●
KANGOO VLL	Airbag/Pretensioners	●	●	●	●
KANGOO VLL	UCH	●	●	●	●
KANGOO VLL	Variable P.A.S	●	●	●	●
KANGOO VLL	Tracker	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Injection	●	●	●	●
KANGOO ZE/STOPSTART/PH2	ABS	●	●	●	●

KANGOO ZE/STOPSTART/PH2	Airbag/Pretensioners	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Instrument Panel	●	●	●	●
KANGOO ZE/STOPSTART/PH2	UCH	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Variable P. A. S	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Communications Unit	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Parking Prox CAN	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Parking Assistance	●	●	●	●
KANGOO ZE/STOPSTART/PH2	UPC	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Air Conditioning	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Adaptation Unit	●	●	●	●
KANGOO ZE/STOPSTART/PH2	LBC	●	●	●	●
KANGOO ZE/STOPSTART/PH2	EVC	●	●	●	●
KANGOO ZE/STOPSTART/PH2	PEB	●	●	●	●
KANGOO ZE/STOPSTART/PH2	LBC2	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Telematic Control Unit	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Radio	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Multimedia Connection	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Multimedia Interface	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Heater	●	●	●	○
KAPTUR	Injection	●	●	●	●
KAPTUR	Transmission Control Module	●	●	●	●
KAPTUR	ABS	●	●	●	●
KAPTUR	Airbag/Pretensioners	●	●	●	●
KAPTUR	Instrument Panel	●	●	●	●
KAPTUR	UCH	●	●	●	●
KAPTUR	4 Wheels Drive	●	●	●	●
KAPTUR	Variable P. A. S	●	●	●	●
KAPTUR	UPC	●	●	●	●
KAPTUR	Air Conditioning	●	●	●	●
KAPTUR	Radio	●	●	●	●
KAPTUR	Multimedia Interface	●	●	●	●
KAPTUR	Telematic Control Unit	●	●	●	●
KAPTUR	Hands Free Kit	●	●	●	●
KOLEOS	Injection	●	●	●	●
KOLEOS	Transmission Control Module	●	●	●	●
KOLEOS	ABS	●	●	●	●
KOLEOS	Airbag/Pretensioners	●	●	●	●
KOLEOS	Instrument Panel	●	●	●	●
KOLEOS	UCH	●	●	●	●
KOLEOS	Communications Unit	●	●	●	※
KOLEOS	4 Wheels Drive	●	●	●	●
KOLEOS	Variable P. A. S	●	●	●	●
KOLEOS	Parking Brake	●	●	●	●
KOLEOS	Parking Prox CAN	●	●	●	●
KOLEOS	Tire Pressure Monitoring System	●	●	●	●
KOLEOS	UPC	●	●	●	●
KOLEOS	Multimedia Interface	●	●	●	●
KOLEOS	Multimedia Connection	●	●	●	●
KOLEOS	Radio	●	●	●	●
KOLEOS	Amplifier	●	●	●	●
KOLEOS	Telematic Control Unit	●	●	●	●
KOLEOS	Auto Front Lighting	●	●	●	●

KOLEOS	Discharge Lamp	●	○	○	●
KOLEOS II	Injection	●	●	●	●
KOLEOS II	Transmission Control Module	●	●	●	●
KOLEOS II	ABS	●	●	●	●
KOLEOS II	Airbag/Pretensioners	●	●	●	●
KOLEOS II	Instrument Panel	●	●	●	●
KOLEOS II	UCH	●	●	●	●
KOLEOS II	4 Wheels Drive	●	●	●	●
KOLEOS II	Variable P. A. S	●	●	●	●
KOLEOS II	Parking Brake	●	●	●	●
KOLEOS II	Parking Prox CAN	●	●	●	●
KOLEOS II	UPC	●	●	●	●
KOLEOS II	Air Conditioning	●	●	●	●
KOLEOS II	Power Back Door	●	●	●	●
KOLEOS II	Seat Management	●	●	●	●
KOLEOS II	Front Camera	●	●	●	●
KOLEOS II	Radio	●	●	●	●
KOLEOS II	Multimedia Interface	●	●	●	●
KOLEOS II	Telematic Control Unit	●	●	●	●
KOLEOS II	Amplifier	●	●	●	●
KOLEOS II	Distance Regulator	●	●	●	●
KOLEOS II CN	Injection	●	●	●	●
KOLEOS II CN	Transmission Control Module	●	●	●	●
KOLEOS II CN	ABS	●	●	●	●
KOLEOS II CN	Airbag/Pretensioners	●	●	●	●
KOLEOS II CN	Instrument Panel	●	●	●	●
KOLEOS II CN	UCH	●	●	●	●
KOLEOS II CN	4 Wheels Drive	●	●	●	●
KOLEOS II CN	Variable P. A. S	●	●	●	●
KOLEOS II CN	Parking Brake	●	●	●	●
KOLEOS II CN	Parking Prox CAN	●	●	●	●
KOLEOS II CN	UPC	●	●	●	●
KOLEOS II CN	Air Conditioning	●	●	●	●
KOLEOS II CN	Power Back Door	●	●	●	●
KOLEOS II CN	Seat Management	●	●	●	●
KOLEOS II CN	Front Camera	●	●	●	●
KOLEOS II CN	Radio	●	●	●	●
KOLEOS II CN	Multimedia Interface	●	●	●	●
KOLEOS II CN	Telematic Control Unit	●	●	●	●
KOLEOS II CN	Amplifier	●	●	●	●
KOLEOS II CN	Distance Regulator	●	●	●	●
KOLEOS II CN	Left-Hand Door	●	●	●	●
KWID	Injection	●	●	●	●
KWID	Airbag/Pretensioners	●	●	●	●
KWID	Instrument Panel	●	●	●	●
KWID	UCH	●	●	●	●
KWID	Variable P. A. S	●	●	●	●
KWID	Radio	●	●	●	●
LAGUNA	Injection	●	●	●	●
LAGUNA	Transmission Control Module	●	●	●	●
LAGUNA	ABS	●	●	●	●
LAGUNA	Airbag/Pretensioners	●	●	●	●

LAGUNA	Instrument Panel	●	●	●	●
LAGUNA	Variable P.A.S	●	●	●	●
LAGUNA	Engine Immobiliser	●	●	●	●
LAGUNA	Air Conditioning	●	●	●	●
LAGUNA II	Injection	●	●	●	●
LAGUNA II	Transmission Control Module	●	●	●	●
LAGUNA II	ABS	●	●	●	●
LAGUNA II	Airbag/Pretensioners	●	●	●	●
LAGUNA II	Instrument Panel	●	●	●	●
LAGUNA II	UCH	●	●	●	●
LAGUNA II	Air Conditioning	●	●	●	●
LAGUNA II	Parking Assistance	●	●	●	●
LAGUNA II	Discharge Lamp	●	●	●	●
LAGUNA II	Heater	●	●	●	●
LAGUNA II	Lighting	●	●	●	●
LAGUNA II PH2	Injection	●	●	●	●
LAGUNA II PH2	Transmission Control Module	●	●	●	●
LAGUNA II PH2	ABS	●	●	●	●
LAGUNA II PH2	Airbag/Pretensioners	●	●	●	●
LAGUNA II PH2	Instrument Panel	●	●	●	●
LAGUNA II PH2	Communications Unit	●	●	●	●
LAGUNA II PH2	UCH	●	●	●	●
LAGUNA II PH2	Parking Brake	●	●	●	●
LAGUNA II PH2	Air Conditioning	●	●	●	●
LAGUNA II PH2	Lighting	●	●	●	●
LAGUNA II PH2	Parking Assistance	●	●	●	●
LAGUNA II PH2	Heater	●	●	●	●
LAGUNA II PH2	Hands Free Kit	●	●	●	●
LAGUNA III	Injection	●	●	●	●
LAGUNA III	Transmission Control Module	●	●	●	●
LAGUNA III	ABS	●	●	●	●
LAGUNA III	Airbag/Pretensioners	●	●	●	●
LAGUNA III	Instrument Panel	●	●	●	●
LAGUNA III	UCH	●	●	●	●
LAGUNA III	Communications Unit	●	●	●	●
LAGUNA III	UPC	●	●	●	●
LAGUNA III	Variable P.A.S	●	●	●	●
LAGUNA III	Parking Prox CAN	●	●	●	●
LAGUNA III	Parking Brake	●	●	●	●
LAGUNA III	4 Wheels Steering	●	●	●	●
LAGUNA III	Air Conditioning	●	●	●	●
LAGUNA III	Amplifier	●	●	●	●
LAGUNA III	Lighting	●	●	●	●
LAGUNA III	Radio	●	※	※	※
LAGUNA III	Multimedia Interface	●	●	●	●
LAGUNA III	Multimedia Connection	●	●	●	●
LAGUNA III	Driver's Door	●	●	●	●
LAGUNA III	Passenger's Door	●	●	●	●
LAGUNA III	Seat Management	●	●	●	●
LAGUNA III	Telematic Control Unit	●	●	●	●
LAGUNA III	Left-Hand Door	●	○	●	○
LAGUNA III	Right-Hand Door	●	○	●	○



LAGUNA PHASE 2	Injection	●	●	●	●
LAGUNA PHASE 2	Transmission Control Module	●	●	●	●
LAGUNA PHASE 2	ABS	●	●	●	●
LAGUNA PHASE 2	Airbag/Pretensioners	●	●	●	●
LAGUNA PHASE 2	Instrument Panel	●	●	●	●
LAGUNA PHASE 2	Variable P. A. S	●	●	●	●
LAGUNA PHASE 2	Gasoline Injection	●	●	●	●
LAGUNA PHASE 2	Air Conditioning	●	●	●	●
LATITUDE/SM5	Injection	●	●	●	●
LATITUDE/SM5	Transmission Control Module	●	●	●	●
LATITUDE/SM5	ABS	●	●	●	●
LATITUDE/SM5	Airbag/Pretensioners	●	●	●	●
LATITUDE/SM5	Instrument Panel	●	●	●	●
LATITUDE/SM5	UCH	●	●	●	●
LATITUDE/SM5	Communications Unit	●	●	●	●
LATITUDE/SM5	Variable P. A. S	●	●	●	●
LATITUDE/SM5	UPC	●	●	●	●
LATITUDE/SM5	Parking Brake	●	●	●	●
LATITUDE/SM5	Parking Prox CAN	●	●	●	●
LATITUDE/SM5	Air Conditioning	●	●	●	●
LATITUDE/SM5	Lighting	●	●	●	●
LATITUDE/SM5	Seat Management	●	●	●	●
LATITUDE/SM5	Radio	●	●	●	●
LATITUDE/SM5	Multimedia Interface	●	●	●	●
LATITUDE/SM5	Multimedia Connection	●	●	●	●
LATITUDE/SM5	Amplifier	●	●	●	●
LATITUDE/SM5	Driver's Door	●	●	●	●
LATITUDE/SM5	Passenger's Door	●	●	●	●
LATITUDE/SM5	Left-Hand Door	●	○	○	●
LATITUDE/SM5	Right-Hand Door	●	○	○	●
LATITUDE/SM5	Telematic Control Unit	●	●	●	●
LODGY	Injection	●	●	●	●
LODGY	Transmission Control Module	●	●	●	●
LODGY	ABS	●	●	●	●
LODGY	Airbag/Pretensioners	●	●	●	●
LODGY	Instrument Panel	●	●	●	●
LODGY	UCH	●	●	●	●
LODGY	Variable P. A. S	●	●	●	●
LODGY	Radio	●	●	●	●
LOGAN	Injection	●	●	●	●
LOGAN	Transmission Control Module	●	●	●	●
LOGAN	ABS	●	●	●	●
LOGAN	Airbag/Pretensioners	●	●	●	●
LOGAN	UCH	●	●	●	●
LOGAN	Variable P. A. S	●	●	●	●
LOGAN	Gasoline Injection	●	●	●	●
LOGAN	Tracker	●	●	●	●
LOGAN	Radio	●	●	●	●
LOGAN II/SANDERO II	Injection	●	●	●	●
LOGAN II/SANDERO II	Transmission Control Module	●	●	●	●
LOGAN II/SANDERO II	ABS	●	●	●	●
LOGAN II/SANDERO II	Airbag/Pretensioners	●	●	●	●

LOGAN II/SANDERO II	Instrument Panel	●	●	●	●
LOGAN II/SANDERO II	UCH	●	●	●	●
LOGAN II/SANDERO II	Variable P.A.S	●	●	●	●
LOGAN II/SANDERO II	Air Conditioning	●	●	●	●
LOGAN II/SANDERO II	Radio	●	●	●	●
LOGAN II/SANDERO II	Multimedia Interface	●	●	●	●
LOGAN II/SANDERO II	Tracker	●	●	●	●
MASTER	Injection	●	●	●	●
MASTER	ABS	●	●	●	●
MASTER	Airbag/Pretensioners	●	●	●	●
MASTER	Engine Immobiliser	●	●	●	●
MASTER	Piloted Suspension	●	●	●	●
MASTER III	Injection	●	●	●	●
MASTER III	Transmission Control Module	●	●	●	●
MASTER III	ABS	●	●	●	●
MASTER III	Airbag/Pretensioners	●	●	●	●
MASTER III	Instrument Panel	●	●	●	●
MASTER III	UCH	●	●	●	●
MASTER III	Communications Unit	●	●	●	●
MASTER III	Variable P.A.S	●	●	●	●
MASTER III	UPC	●	●	●	●
MASTER III	Tire Pressure Monitoring System	●	●	●	●
MASTER III	Adaptation Unit	●	●	●	※
MASTER III	Parking Assistance	●	●	●	●
MASTER III	Air Conditioning	●	●	●	●
MASTER III	Radio	●	●	●	●
MASTER III	Multimedia Connection	●	●	●	●
MASTER III	Multimedia Interface	●	●	●	●
MASTER III	Lighting	●	○	○	●
MASTER III	Telematic Control Unit	●	●	●	●
MASTER III	Tracker	●	●	●	●
MASTER PH 2	Diesel Injection	●	●	●	●
MASTER PH 2	ABS	●	●	●	●
MASTER PH 2	Airbag/Pretensioners	●	●	●	●
MASTER PH 2	Interconnection Unit	●	●	●	●
MASTER PH 2	Engine Immobiliser	●	●	●	●
MASTER PH 2	Parking Brake	●	●	●	●
MASTER PH 3	Injection	●	●	●	●
MASTER PH 3	Transmission Control Module	●	●	●	●
MASTER PH 3	ABS	●	●	●	●
MASTER PH 3	Airbag/Pretensioners	●	●	●	●
MASTER PH 3	UCH	●	●	●	●
MASTER PH 3	Communications Unit	●	●	●	●
MASTER PH 3	Parking Assistance	●	●	●	●
MASTER PH 3	Adaptation Unit	●	●	●	●
MASTER PH 3	Piloted Suspension	●	●	●	●
MASTER PH 3	Tracker	●	●	●	●
MASTER RWD PH2	Injection	●	●	●	●
MASTER RWD PH2	Airbag/Pretensioners	●	●	●	●
MASTER RWD PH2	Communications Unit	●	●	●	●
MASTER RWD PH2	Adaptation Unit	●	●	●	●
MASTER RWD PH2	Engine Immobiliser	●	●	●	●

MASTER RWD PH3	Injection	●	●	●	●
MASTER RWD PH3	ABS	●	●	●	●
MASTER RWD PH3	Airbag/Pretensioners	●	●	●	●
MASTER RWD PH3	UCH	●	●	●	●
MASTER RWD PH3	Communications Unit	●	●	●	●
MASTER RWD PH3	Adaptation Unit	●	●	●	●
MEGANE II	Injection	●	●	●	●
MEGANE II	Transmission Control Module	●	●	●	●
MEGANE II	ABS	●	●	●	●
MEGANE II	Airbag/Pretensioners	●	●	●	●
MEGANE II	Instrument Panel	●	●	●	●
MEGANE II	UCH	●	●	●	●
MEGANE II	Communications Unit	●	●	●	●
MEGANE II	Variable P.A.S	●	●	●	●
MEGANE II	UPC	●	●	●	●
MEGANE II	Air Conditioning	●	●	●	●
MEGANE II	Lighting	●	●	●	●
MEGANE II	Sunroof	●	●	●	●
MEGANE II	Parking Brake	●	●	●	●
MEGANE II	Discharge Lamp	●	●	●	●
MEGANE II	Left-Hand Door	●	●	●	●
MEGANE II	Right-Hand Door	●	●	●	●
MEGANE IV	Injection	●	●	●	●
MEGANE IV	Transmission Control Module	●	●	●	●
MEGANE IV	ABS	●	●	●	●
MEGANE IV	Airbag/Pretensioners	●	●	●	●
MEGANE IV	Instrument Panel	●	●	●	●
MEGANE IV	UCH	●	●	●	●
MEGANE IV	4 Wheels Steering	●	●	●	●
MEGANE IV	Variable P.A.S	●	●	●	●
MEGANE IV	Parking Brake	●	●	●	●
MEGANE IV	Parking Prox CAN	●	●	●	●
MEGANE IV	UPC	●	●	●	●
MEGANE IV	Air Conditioning	●	●	●	●
MEGANE IV	Seat Management	●	●	●	●
MEGANE IV	Front Camera	●	●	●	●
MEGANE IV	Radio	●	●	●	●
MEGANE IV	Multimedia Interface	●	●	●	●
MEGANE IV	Amplifier	●	●	●	○
MEGANE IV	Telematic Control Unit	●	●	●	●
MEGANE IV	Left-Hand Door	●	●	●	○
MEGANE IV	LBC2	●	●	●	○
MEGANE IV	LBC	●	●	●	●
MEGANE IV	PEB	●	●	●	●
MEGANE IV	Distance Regulator	●	●	●	●
MEGANE IV	Supervisor	●	●	●	●
MEGANE IV SEDAN	Injection	●	●	●	●
MEGANE IV SEDAN	Transmission Control Module	●	●	●	●
MEGANE IV SEDAN	ABS	●	●	●	●
MEGANE IV SEDAN	Airbag/Pretensioners	●	●	●	●
MEGANE IV SEDAN	Instrument Panel	●	●	●	●
MEGANE IV SEDAN	UCH	●	●	●	●

MEGANE IV SEDAN	Variable P.A.S	●	●	●	●
MEGANE IV SEDAN	Parking Brake	●	●	●	●
MEGANE IV SEDAN	Parking Prox CAN	●	●	●	●
MEGANE IV SEDAN	UPC	●	●	●	●
MEGANE IV SEDAN	Air Conditioning	●	●	●	●
MEGANE IV SEDAN	Seat Management	●	●	●	●
MEGANE IV SEDAN	Front Camera	●	●	●	●
MEGANE IV SEDAN	Radio	●	●	●	●
MEGANE IV SEDAN	Multimedia Interface	●	●	●	●
MEGANE IV SEDAN	Amplifier	●	●	●	●
MEGANE IV SEDAN	Telematic Control Unit	●	●	●	●
MEGANE IV SEDAN	Left-Hand Door	●	●	●	●
MEGANE IV SEDAN	Distance Regulator	●	●	●	●
MEGANE/SCENIC	Injection	●	●	●	●
MEGANE/SCENIC	Transmission Control Module	●	●	●	●
MEGANE/SCENIC	ABS	●	●	●	●
MEGANE/SCENIC	Airbag/Pretensioners	●	●	●	●
MEGANE/SCENIC	Gasoline Injection	●	●	●	●
MEGANE/SCENIC	Engine Immobiliser	●	●	●	●
MEGANE/SCENIC	Air Conditioning	●	●	●	●
MEGANE/SCENIC	Hood Control	●	●	●	●
MODUS	Injection	●	●	●	●
MODUS	Transmission Control Module	●	●	●	●
MODUS	ABS	●	●	●	●
MODUS	Airbag/Pretensioners	●	●	●	●
MODUS	Instrument Panel	●	●	●	●
MODUS	UCH	●	●	●	●
MODUS	Variable P.A.S	●	●	●	●
MODUS	UPC	●	●	●	●
MODUS	Air Conditioning	●	●	●	●
MODUS	Tire Pressure Monitoring System	●	●	●	●
MODUS	Lighting	●	●	●	●
MODUS	Hands Free Kit	●	●	●	●
MODUS	Parking Assistance	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Injection	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Transmission Control Module	●	●	●	●
NEW SM3/FLUENCE/MEGANE	ABS	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Airbag/Pretensioners	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Instrument Panel	●	●	●	●
NEW SM3/FLUENCE/MEGANE	UCH	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Communications Unit	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Variable P.A.S	●	●	●	●
NEW SM3/FLUENCE/MEGANE	UPC	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Parking Prox CAN	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Parking Brake	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Air Conditioning	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Sunroof	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Lighting	●	●	●	○
NEW SM3/FLUENCE/MEGANE	Radio	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Multimedia Interface	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Amplifier	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Multimedia Connection	●	●	●	●

NEW SM3/FLUENCE/MEGANE	LBC	●	●	●	●
NEW SM3/FLUENCE/MEGANE	LBC2	●	●	●	●
NEW SM3/FLUENCE/MEGANE	EVC	●	●	●	●
NEW SM3/FLUENCE/MEGANE	PEB	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Driver's Door	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Telematic Control Unit	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Tracker	●	●	●	●
SANDERO	Injection	●	●	●	●
SANDERO	Transmission Control Module	●	●	●	●
SANDERO	ABS	●	●	●	●
SANDERO	Airbag/Pretensioners	●	●	●	●
SANDERO	UCH	●	●	●	●
SANDERO	Variable P.A.S	●	●	●	●
SANDERO	Tracker	●	●	●	●
SANDERO	Radio	●	●	●	●
SCENIC II	Injection	●	●	●	●
SCENIC II	Transmission Control Module	●	●	●	●
SCENIC II	ABS	●	●	●	●
SCENIC II	Airbag/Pretensioners	●	●	●	●
SCENIC II	Instrument Panel	●	●	●	●
SCENIC II	UCH	●	●	●	●
SCENIC II	Communications Unit	●	●	●	●
SCENIC II	Parking Brake	●	●	●	●
SCENIC II	Parking Prox CAN	●	●	●	●
SCENIC II	Variable P.A.S	●	●	●	●
SCENIC II	UPC	●	●	●	●
SCENIC II	Air Conditioning	●	●	●	●
SCENIC II	Radio	●	●	●	●
SCENIC II	Multimedia Interface	●	●	●	●
SCENIC II	Parking Assistance	●	●	●	●
SCENIC II	Engine Immobiliser	●	●	●	●
SCENIC II	Discharge Lamp	●	●	●	●
SCENIC III	Injection	●	●	●	●
SCENIC III	Transmission Control Module	●	●	●	●
SCENIC III	ABS	●	●	●	●
SCENIC III	Airbag/Pretensioners	●	●	●	●
SCENIC III	Instrument Panel	●	●	●	●
SCENIC III	UCH	●	●	●	●
SCENIC III	Communications Unit	●	●	●	●
SCENIC III	Parking Brake	●	●	●	●
SCENIC III	Variable P.A.S	●	●	●	●
SCENIC III	UPC	●	●	●	●
SCENIC III	Air Conditioning	●	●	●	●
SCENIC III	Radio	●	●	●	●
SCENIC III	Sunroof	●	●	●	●
SCENIC III	Multimedia Connection	●	●	●	●
SCENIC III	Multimedia Interface	●	●	●	●
SCENIC III	Driver's Door	●	●	●	●
SCENIC III	Passenger's Door	●	●	●	●
SCENIC III	Seat Management	●	●	●	●
SCENIC III	Telematic Control Unit	●	●	●	●
SCENIC III	Front Camera	●	●	●	●

SCENIC IV	Injection	●	●	●	●
SCENIC IV	Transmission Control Module	●	●	●	●
SCENIC IV	ABS	●	●	●	●
SCENIC IV	Airbag/Pretensioners	●	●	●	●
SCENIC IV	Instrument Panel	●	●	●	●
SCENIC IV	UCH	●	●	●	●
SCENIC IV	Variable P.A.S	●	●	●	●
SCENIC IV	Parking Brake	●	●	●	●
SCENIC IV	Parking Prox CAN	●	●	●	●
SCENIC IV	UPC	●	●	●	●
SCENIC IV	Air Conditioning	●	●	●	●
SCENIC IV	Seat Management	●	●	●	●
SCENIC IV	Front Camera	●	●	●	●
SCENIC IV	Radio	●	●	●	●
SCENIC IV	Multimedia Interface	●	●	●	●
SCENIC IV	Amplifier	●	●	●	●
SCENIC IV	Telematic Control Unit	●	●	●	●
SCENIC IV	Left-Hand Door	●	●	●	●
SCENIC IV	Right-Hand Door	●	●	●	●
SCENIC IV	Supervisor	●	●	●	●
SCENIC IV	LBC	●	●	●	●
SCENIC IV	PEB	●	●	●	●
SCENIC IV	LBC2	●	●	●	●
SCENIC IV	Distance Regulator	●	●	●	●
SM7-L47	Injection	●	●	●	●
SM7-L47	Transmission Control Module	●	●	●	●
SM7-L47	ABS	●	●	●	●
SM7-L47	Airbag/Pretensioners	●	●	●	●
SM7-L47	Instrument Panel	●	●	●	●
SM7-L47	UCH	●	●	●	●
SM7-L47	Communications Unit	●	●	●	●
SM7-L47	Parking Brake	●	●	●	●
SM7-L47	Parking Prox CAN	●	●	●	●
SM7-L47	UPC	●	●	●	●
SM7-L47	Air Conditioning	●	●	●	●
SM7-L47	Driver's Door	●	●	●	●
SM7-L47	Passenger's Door	●	●	●	●
SM7-L47	Lighting	●	●	●	●
SM7-L47	Radio	●	●	●	●
SM7-L47	Multimedia Connection	●	●	●	●
SM7-L47	Multimedia Interface	●	●	●	●
SM7-L47	Amplifier	●	●	●	●
TALISMAN SM6	Injection	●	●	●	●
TALISMAN SM6	Transmission Control Module	●	●	●	●
TALISMAN SM6	ABS	●	●	●	●
TALISMAN SM6	Airbag/Pretensioners	●	●	●	●
TALISMAN SM6	Instrument Panel	●	●	●	●
TALISMAN SM6	UCH	●	●	●	●
TALISMAN SM6	4 Wheels Steering	●	●	●	●
TALISMAN SM6	Variable P.A.S	●	●	●	●
TALISMAN SM6	Parking Brake	●	●	●	●
TALISMAN SM6	Parking Prox CAN	●	●	●	●

TALISMAN SM6	UPC	●	●	●	●
TALISMAN SM6	Air Conditioning	●	●	●	●
TALISMAN SM6	Seat Management	●	●	●	●
TALISMAN SM6	Front Camera	●	●	●	●
TALISMAN SM6	Radio	●	●	●	●
TALISMAN SM6	Multimedia Interface	●	●	●	●
TALISMAN SM6	Amplifier	●	●	●	●
TALISMAN SM6	Telematic Control Unit	●	●	●	●
TALISMAN SM6	Left-Hand Door	●	●	●	●
TALISMAN SM6	Distance Regulator	●	●	●	●
TALISMAN SM6	Power Back Door	●	●	●	●
TALISMAN SM6	Piloted Suspension	●	●	●	●
THALIA/SYMBL	Injection	●	●	●	●
THALIA/SYMBL	Transmission Control Module	●	●	●	●
THALIA/SYMBL	ABS	●	●	●	●
THALIA/SYMBL	Airbag/Pretensioners	●	●	●	●
THALIA/SYMBL	Engine Immobiliser	●	●	●	●
THALIA/SYMBL	Air Conditioning	●	●	●	●
THALIA/SYMBL. 2	Injection	●	●	●	●
THALIA/SYMBL. 2	Transmission Control Module	●	●	●	●
THALIA/SYMBL. 2	ABS	●	●	●	●
THALIA/SYMBL. 2	Airbag/Pretensioners	●	●	●	●
THALIA/SYMBL. 2	Variable P.A.S	●	●	●	●
THALIA/SYMBL. 2	Air Conditioning	●	●	●	●
THALIA/SYMBL. 2	UCH	●	●	●	●
THALIA/SYMBL. 2	Tracker	●	●	●	●
TRAFIC II	Injection	●	●	●	●
TRAFIC II	Transmission Control Module	●	●	●	●
TRAFIC II	ABS	●	●	●	●
TRAFIC II	Airbag/Pretensioners	●	●	●	●
TRAFIC II	Interconnection Unit	●	●	●	●
TRAFIC II	Adaptation Unit	●	●	●	●
TRAFIC II	Heater	●	●	●	●
TRAFIC II PH2	Injection	●	●	●	●
TRAFIC II PH2	Transmission Control Module	●	●	●	●
TRAFIC II PH2	ABS	●	●	●	●
TRAFIC II PH2	Airbag/Pretensioners	●	●	●	●
TRAFIC II PH2	Instrument Panel	●	●	●	●
TRAFIC II PH2	UCH	●	●	●	●
TRAFIC II PH2	Communications Unit	●	●	●	●
TRAFIC II PH2	Air Conditioning	●	●	●	●
TRAFIC II PH2	Parking Assistance	●	●	●	●
TRAFIC II PH2	Radio	●	●	●	●
TRAFIC II PH2	Multimedia Interface	●	●	●	●
TRAFIC II PH2	Multimedia Connection	●	●	●	●
TRAFIC II PH2	Heater	●	●	●	●
TRAFIC II PH2	Adaptation Unit	●	●	●	●
TRAFIC III	Injection	●	●	●	●
TRAFIC III	ABS	●	●	●	●
TRAFIC III	Airbag/Pretensioners	●	●	●	●
TRAFIC III	Instrument Panel	●	●	●	●
TRAFIC III	UCH	●	●	●	●

TRAFIC III	Communications Unit	●	●	●	●
TRAFIC III	Variable P.A.S	●	●	●	●
TRAFIC III	Parking Prox CAN	●	●	●	●
TRAFIC III	UPC	●	●	●	●
TRAFIC III	Air Conditioning	●	●	●	●
TRAFIC III	Adaptation Unit	●	●	●	●
TRAFIC III	Radio	●	●	●	●
TRAFIC III	Multimedia Interface	●	●	●	●
TRAFIC III	Telematic Control Unit	●	●	●	●
TRAFIC III	Hands Free Kit	●	●	●	●
TRAFIC III	Heater	●	●	●	○
TWINGO II	Injection	●	●	●	●
TWINGO II	Transmission Control Module	●	●	●	●
TWINGO II	ABS	●	●	●	●
TWINGO II	Airbag/Pretensioners	●	●	●	●
TWINGO II	Instrument Panel	●	●	●	●
TWINGO II	UCH	●	●	●	●
TWINGO II	Variable P.A.S	●	●	●	●
TWINGO II	Parking Assistance	●	●	●	●
TWINGO II	UPC	●	●	●	●
TWINGO II	Rev Counter/Symbol	●	※	※	●
TWINGO II	Air Conditioning	●	●	●	●
TWINGO II	Radio	●	●	●	●
TWINGO II	Multimedia Interface	●	●	●	●
TWINGO II	Multimedia Connection	●	●	●	●
TWINGO III	Injection	●	●	●	●
TWINGO III	Transmission Control Module	●	●	●	●
TWINGO III	ABS	●	●	●	●
TWINGO III	Airbag/Pretensioners	●	●	●	●
TWINGO III	Instrument Panel	●	●	●	●
TWINGO III	UCH	●	●	●	●
TWINGO III	Communications Unit	●	●	●	●
TWINGO III	Variable P.A.S	●	●	●	●
TWINGO III	UPC	●	●	●	●
TWINGO III	Air Conditioning	●	●	●	●
TWINGO III	Radio	●	●	●	●
TWINGO III	Multimedia Interface	●	●	●	●
TWINGO III	Telematic Control Unit	●	●	●	●
TWINGO PHASE 2	Injection	●	●	●	●
TWINGO PHASE 2	Transmission Control Module	●	●	●	●
TWINGO PHASE 2	ABS	●	●	●	●
TWINGO PHASE 2	Airbag/Pretensioners	●	●	●	●
TWINGO PHASE 2	Gasoline Injection	●	●	●	●
TWINGO PHASE 2	Engine Immobiliser	●	●	●	●
TWINGO PHASE 2	Interconnection Unit	●	●	●	●
TWIZY	LBC	●	●	●	●
TWIZY	Airbag/Pretensioners	●	●	●	●
TWIZY	UCH	●	●	●	●
TWIZY	Instrument Panel	●	●	●	●
TWIZY	Adaptation Unit	●	●	●	●
VEL SATIS	Injection	●	●	●	●
VEL SATIS	Transmission Control Module	●	●	●	●



VEL SATIS	ABS	●	●	●	●
VEL SATIS	Airbag/Pretensioners	●	●	●	●
VEL SATIS	Instrument Panel	●	●	●	●
VEL SATIS	UCH	●	●	●	●
VEL SATIS	Parking Brake	●	●	●	●
VEL SATIS	Parking Assistance	●	●	●	●
VEL SATIS	Tire Pressure Monitoring System	●	●	●	●
VEL SATIS	Air Conditioning	●	●	●	●
VEL SATIS	Distance Regulator	●	●	●	●
VEL SATIS	Heater	●	●	●	●
VEL SATIS	Hands Free Kit	●	●	●	●
VEL SATIS PH2	Injection	●	●	●	●
VEL SATIS PH2	Transmission Control Module	●	●	●	●
VEL SATIS PH2	ABS	●	●	●	●
VEL SATIS PH2	Airbag/Pretensioners	●	●	●	●
VEL SATIS PH2	Instrument Panel	●	●	●	●
VEL SATIS PH2	UCH	●	●	●	●
VEL SATIS PH2	Communications Unit	●	●	●	●
VEL SATIS PH2	Parking Prox CAN	●	●	●	●
VEL SATIS PH2	Parking Brake	●	●	●	●
VEL SATIS PH2	Parking Assistance	●	●	●	●
VEL SATIS PH2	Air Conditioning	●	●	●	●
VEL SATIS PH2	Lighting	●	●	●	●
VEL SATIS PH2	Hands Free Kit	●	●	●	●
VEL SATIS PH2	Heater	●	●	●	●
WIND	Injection	●	●	●	●
WIND	ABS	●	●	●	●
WIND	Airbag/Pretensioners	●	●	●	●
WIND	Instrument Panel	●	●	●	●
WIND	UCH	●	●	●	●
WIND	Variable P.A.S	●	●	●	●
WIND	Air Conditioning	●	●	●	●
WIND	Sunroof	●	●	●	●
WIND	Radio	●	●	●	●
WIND	Multimedia Interface	●	●	●	●
WIND	Multimedia Connection	●	●	●	●
ZOE	LBC	●	●	●	●
ZOE	ABS	●	●	●	●
ZOE	Airbag/Pretensioners	●	●	●	●
ZOE	Instrument Panel	●	●	●	●
ZOE	UCH	●	●	●	●
ZOE	Communications Unit	●	●	●	●
ZOE	Variable P.A.S	●	●	●	●
ZOE	Parking Prox CAN	●	●	●	●
ZOE	UPC	●	●	●	●
ZOE	Air Conditioning	●	●	●	●
ZOE	Telematic Control Unit	●	●	●	●
ZOE	Adaptation Unit	●	●	●	●
ZOE	EVC	●	●	●	●
ZOE	PEB	●	●	●	●
ZOE	Radio	●	●	●	●
ESPACE V	Seat Management	●	●	●	●

ESPACE V	Gasoline Injection	●	●	●	●
ESPACE V	PEB	●	●	●	●
ESPACE V	LBC2	●	●	●	●
ESPACE V	Telematic Control Unit	●	●	●	●
ESPACE V	EVC	●	●	●	●
ESPACE V	Left-Hand Door	●	●	●	●
ESPACE V	Right-Hand Door	●	●	●	●
ESPACE V	4 Wheels Steering	●	●	●	●
ESPACE V	Front Camera	●	●	●	●
ESPACE V	Distance Regulator	●	●	●	●
ESPACE V	Power Back Door	●	●	●	●
KADJAR	Petrol Injection	●	●	●	●
KADJAR	ABS	●	●	●	●
KADJAR	Airbag/Pretensioners	●	●	●	●
KADJAR	Interconnection Unit	●	●	●	●
KADJAR	Variable P.A.S	●	●	●	●
KADJAR	Transmission Control Module	●	●	●	●
KADJAR	Engine Immobiliser	●	●	●	●
KADJAR	Air Conditioning	●	●	●	●
KADJAR	Diesel Injection	●	●	●	●
KADJAR	Hood Control	●	●	●	●
KADJAR	Tire Pressure Monitoring System	●	●	●	●
KADJAR	Instrument Panel	●	●	●	●
KADJAR	Discharge Lamp	●	●	●	●
KADJAR	Heater	●	●	●	●
KADJAR	Supervisor	●	●	●	●
KADJAR	Piloted Suspension	●	●	●	●
KADJAR	Parking Assistance	●	●	●	●
KADJAR	Parking Brake	●	●	●	●
KADJAR	UPC	●	●	●	●
KADJAR	UCH	●	●	●	●
KADJAR	Lighting	●	●	●	●
KADJAR	Injection	●	●	●	●
KADJAR	Sunroof	●	●	●	●
KADJAR	Hands Free Kit	●	●	●	●
KADJAR	Parking Prox CAN	●	●	●	●
KADJAR	Rev Counter/Symbol	●	●	●	●
KADJAR	Parking Brake	●	●	●	●
KADJAR	Adaptation Unit	●	●	●	●
KADJAR	4 Wheels Drive	●	●	●	●
KADJAR	Tracker	●	●	●	●
KADJAR	LBC	●	●	●	●
KADJAR	Radio	●	●	●	●
KADJAR	Multimedia Interface	●	●	●	●
KADJAR	Multimedia Connection	●	●	●	●
KADJAR	Auto Front Lighting	●	●	●	●
KADJAR	Parking Prox CAN	●	●	●	●
KADJAR	Communications Unit	●	●	●	●
KADJAR	Amplifier	●	●	●	●
KADJAR	Driver's Door	●	●	●	●
KADJAR	Passenger's Door	●	●	●	●
KADJAR	Seat Management	●	●	●	●

KADJAR	Gasoline Injection	●	●	●	●
KADJAR	PEB	●	●	●	●
KADJAR	LBC2	●	●	●	●
KADJAR	Telematic Control Unit	●	●	●	●
KADJAR	EVC	●	●	●	●
KADJAR	Left-Hand Door	●	●	●	●
KADJAR	Right-Hand Door	●	●	●	●
KADJAR	4 Wheels Steering	●	●	●	●
KADJAR	Front Camera	●	●	●	●
KADJAR	Distance Regulator	●	●	●	●
KADJAR	Power Back Door	●	●	●	●
KADJAR CN	Petrol Injection	●	●	●	●
KADJAR CN	ABS	●	●	●	●
KADJAR CN	Airbag/Pretensioners	●	●	●	●
KADJAR CN	Interconnection Unit	●	●	●	●
KADJAR CN	Variable P.A.S	●	●	●	●
KADJAR CN	Transmission Control Module	●	●	●	●
KADJAR CN	Engine Immobiliser	●	●	●	●
KADJAR CN	Air Conditioning	●	●	●	●
KADJAR CN	Diesel Injection	●	●	●	●
KADJAR CN	Hood Control	●	●	●	●
KADJAR CN	Tire Pressure Monitoring System	●	●	●	●
KADJAR CN	Instrument Panel	●	●	●	●
KADJAR CN	Discharge Lamp	●	●	●	●
KADJAR CN	Heater	●	●	●	●
KADJAR CN	Supervisor	●	●	●	●
KADJAR CN	Piloted Suspension	●	●	●	●
KADJAR CN	Parking Assistance	●	●	●	●
KADJAR CN	Parking Brake	●	●	●	●
KADJAR CN	UPC	●	●	●	●
KADJAR CN	UCH	●	●	●	●
KADJAR CN	Lighting	●	●	●	●
KADJAR CN	Injection	●	●	●	●
KADJAR CN	Sunroof	●	●	●	●
KADJAR CN	Hands Free Kit	●	●	●	●
KADJAR CN	Parking Prox CAN	●	●	●	●
KADJAR CN	Rev Counter/Symbol	●	●	●	●
KADJAR CN	Parking Brake	●	●	●	●
KADJAR CN	Adaptation Unit	●	●	●	●
KADJAR CN	4 Wheels Drive	●	●	●	●
KADJAR CN	Tracker	●	●	●	●
KADJAR CN	LBC	●	●	●	●
KADJAR CN	Radio	●	●	●	●
KADJAR CN	Multimedia Interface	●	●	●	●
KADJAR CN	Multimedia Connection	●	●	●	●
KADJAR CN	Auto Front Lighting	●	●	●	●
KADJAR CN	Parking Prox CAN	●	●	●	●
KADJAR CN	Communications Unit	●	●	●	●
KADJAR CN	Amplifier	●	●	●	●
KADJAR CN	Driver's Door	●	●	●	●
KADJAR CN	Passenger's Door	●	●	●	●
KADJAR CN	Seat Management	●	●	●	●

KADJAR CN	Gasoline Injection	●	●	●	●
KADJAR CN	PEB	●	●	●	●
KADJAR CN	LBC2	●	●	●	●
KADJAR CN	Telematic Control Unit	●	●	●	●
KADJAR CN	EVC	●	●	●	●
KADJAR CN	Left-Hand Door	●	●	●	●
KADJAR CN	Right-Hand Door	●	●	●	●
KADJAR CN	4 Wheels Steering	●	●	●	●
KADJAR CN	Front Camera	●	●	●	●
KADJAR CN	Distance Regulator	●	●	●	●
KADJAR CN	Power Back Door	●	●	●	●
KANGOO	Petrol Injection	●	●	●	●
KANGOO	ABS	●	●	●	●
KANGOO	Airbag/Pretensioners	●	●	●	●
KANGOO	Interconnection Unit	●	●	●	●
KANGOO	Variable P.A.S	●	●	●	●
KANGOO	Transmission Control Module	●	●	●	●
KANGOO	Engine Immobiliser	●	●	●	●
KANGOO	Air Conditioning	●	●	●	●
KANGOO	Diesel Injection	●	●	●	●
KANGOO	Hood Control	●	●	●	●
KANGOO	Tire Pressure Monitoring System	●	●	●	●
KANGOO	Instrument Panel	●	●	●	●
KANGOO	Discharge Lamp	●	●	●	●
KANGOO	Heater	●	●	●	●
KANGOO	Supervisor	●	●	●	●
KANGOO	Piloted Suspension	●	●	●	●
KANGOO	Parking Assistance	●	●	●	●
KANGOO	Parking Brake	●	●	●	●
KANGOO	UPC	●	●	●	●
KANGOO	UCH	●	●	●	●
KANGOO	Lighting	●	●	●	●
KANGOO	Injection	●	●	●	●
KANGOO	Sunroof	●	●	●	●
KANGOO	Hands Free Kit	●	●	●	●
KANGOO	Parking Prox CAN	●	●	●	●
KANGOO	Rev Counter/Symbol	●	●	●	●
KANGOO	Parking Brake	●	●	●	●
KANGOO	Adaptation Unit	●	●	●	●
KANGOO	4 Wheels Drive	●	●	●	●
KANGOO	Tracker	●	●	●	●
KANGOO	LBC	●	●	●	●
KANGOO	Radio	●	●	●	●
KANGOO	Multimedia Interface	●	●	●	●
KANGOO	Multimedia Connection	●	●	●	●
KANGOO	Auto Front Lighting	●	●	●	●
KANGOO	Parking Prox CAN	●	●	●	●
KANGOO	Communications Unit	●	●	●	●
KANGOO	Amplifier	●	●	●	●
KANGOO	Driver's Door	●	●	●	●
KANGOO	Passenger's Door	●	●	●	●
KANGOO	Seat Management	●	●	●	●

KANGOO	Gasoline Injection	●	●	●	●
KANGOO	PEB	●	●	●	●
KANGOO	LBC2	●	●	●	●
KANGOO	Telematic Control Unit	●	●	●	●
KANGOO	EVC	●	●	●	●
KANGOO	Left-Hand Door	●	●	●	●
KANGOO	Right-Hand Door	●	●	●	●
KANGOO	4 Wheels Steering	●	●	●	●
KANGOO	Front Camera	●	●	●	●
KANGOO	Distance Regulator	●	●	●	●
KANGOO	Power Back Door	●	●	●	●
KANGOO II	Petrol Injection	●	●	●	●
KANGOO II	ABS	●	●	●	●
KANGOO II	Airbag/Pretensioners	●	●	●	●
KANGOO II	Interconnection Unit	●	●	●	●
KANGOO II	Variable P.A.S	●	●	●	●
KANGOO II	Transmission Control Module	●	●	●	●
KANGOO II	Engine Immobiliser	●	●	●	●
KANGOO II	Air Conditioning	●	●	●	●
KANGOO II	Diesel Injection	●	●	●	●
KANGOO II	Hood Control	●	●	●	●
KANGOO II	Tire Pressure Monitoring System	●	●	●	●
KANGOO II	Instrument Panel	●	●	●	●
KANGOO II	Discharge Lamp	●	●	●	●
KANGOO II	Heater	●	●	●	●
KANGOO II	Supervisor	●	●	●	●
KANGOO II	Piloted Suspension	●	●	●	●
KANGOO II	Parking Assistance	●	●	●	●
KANGOO II	Parking Brake	●	●	●	●
KANGOO II	UPC	●	●	●	●
KANGOO II	UCH	●	●	●	●
KANGOO II	Lighting	●	●	●	●
KANGOO II	Injection	●	●	●	●
KANGOO II	Sunroof	●	●	●	●
KANGOO II	Hands Free Kit	●	●	●	●
KANGOO II	Parking Prox CAN	●	●	●	●
KANGOO II	Rev Counter/Symbol	●	●	●	●
KANGOO II	Parking Brake	●	●	●	●
KANGOO II	Adaptation Unit	●	●	●	●
KANGOO II	4 Wheels Drive	●	●	●	●
KANGOO II	Tracker	●	●	●	●
KANGOO II	LBC	●	●	●	●
KANGOO II	Radio	●	●	●	●
KANGOO II	Multimedia Interface	●	●	●	●
KANGOO II	Multimedia Connection	●	●	●	●
KANGOO II	Auto Front Lighting	●	●	●	●
KANGOO II	Parking Prox CAN	●	●	●	●
KANGOO II	Communications Unit	●	●	●	●
KANGOO II	Amplifier	●	●	●	●
KANGOO II	Driver's Door	●	●	●	●
KANGOO II	Passenger's Door	●	●	●	●
KANGOO II	Seat Management	●	●	●	●

KANGOO II	Gasoline Injection	●	●	●	●
KANGOO II	PEB	●	●	●	●
KANGOO II	LBC2	●	●	●	●
KANGOO II	Telematic Control Unit	●	●	●	●
KANGOO II	EVC	●	●	●	●
KANGOO II	Left-Hand Door	●	●	●	●
KANGOO II	Right-Hand Door	●	●	●	●
KANGOO II	4 Wheels Steering	●	●	●	●
KANGOO II	Front Camera	●	●	●	●
KANGOO II	Distance Regulator	●	●	●	●
KANGOO II	Power Back Door	●	●	●	●

Renault\_V01.10 ETC Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	ETC
Renault	※

## Renault\_V01.10 OIL Function List (Note:For reference only)

**NOTES:**

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	OIL
Captur	●
Clio	●
Clio II	●
Clio III	●
Clio IV	●
Espace IV	●
Espace IV Ph2	●
Espace/Grand Espace IV	●
Fluence	●
Kangoo II	●
Kangoo Ze/Stopstart/Ph2	●
Koleos	●
Koleos/QM5	●
Laguna	●
Laguna II	●
Laguna II Ph2	●
Laguna III	●
Latitude/Sm5	●
Master III	●
Megane Scenic	●
Megane II	●
Megane III	●
Megane III/Scenic III	●
Modus	●
New Sm3/Fluence/Megane	●
Opel Vivaro	●
Safrane	●
Scenic	●
Scenic II	●
Scenic III	●
Sm7-147	●



## Renault\_V01.10 SAS Function List (Note:For reference only)

**NOTES:**

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	SAS
AvantIme	●
Captur	●
Clio II p 2/3/4	●
Clio III	●
Clio IV	●
Dokker	●
Duster Ph2	●
Espace IV	●
Espace IV Ph2	●
Kangoo II	●
Kangoo Ze/Stopstart/Ph2	●
Koleos/Qm5	●
Laguna III	●
Laguna II Ph2	●
Latitude/Sm5	●
Lodgy	●
Logan II/Sandero II	●
Megane Scenic	●
Master ph3	●
Megane II	●
Master III	●
Megane III/Scenic III	●
Modus	●
New Sm3/Fluence/Megane	●
Scenic II	●
Sm7-147	●
Trafic II/p/2/3	●
Twingo II	●
Twingo III	●
Vel Satis	●
Vel Satis Ph2	●
Wind	●
Zoe	●

## Renault\_V01.10 EPB Function List (Note:For reference only)

**NOTES:**

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	EPB
Espace IV	●
Espace IV Ph2	●
Koleos/Qm5	●
Laguna II Ph2	●
Laguna III	●
Latitude/Sm5	●
Megane III/Scenic III	●
New Sm3/Fluence/Megane	●
Scenic II	●
Sm7-147	●
Vel Satis	●
Vel Satis Ph2	●