

BMW Diagnostic Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

BMW Car List

Series	Development code	Sales designation
1'	E81	116d
1'	E81	116i
1'	E81	118d
1'	E81	118i
1'	E81	120d
1'	E81	120i
1'	E81	123d
1'	E81	130i
1'	E82	118d
1'	E82	120d
1'	E82	120i
1'	E82	123d
1'	E82	125i
1'	E82	128i
1'	E82	135i
1'	E82	135is
1'	E82	ActiveE
1'	E82	M Coupe
1'	E87	116d
1'	E87	116i
1'	E87	118d
1'	E87	118i
1'	E87	120d
1'	E87	120i
1'	E87	123d
1'	E87	130i
1'	E88	118d
1'	E88	118i
1'	E88	120d
1'	E88	120i
1'	E88	123d
1'	E88	125i
1'	E88	128d
1'	E88	135i
1'	F20	114d
1'	F20	114i
1'	F20	116d
1'	F20	116d EffDyn Edition
1'	F20	116i
1'	F20	118d
1'	F20	120d
1'	F20	120d xDrive
1'	F20	120i
1'	F20	125d

1'	F20	125i
1'	F20	M135i
1'	F20	M135i xDrive
1'	F20	M140i
1'	F20	M140i xDrive
1'	F21	114d
1'	F21	114i
1'	F21	116d
1'	F21	116d EffDyn Edition
1'	F21	116i
1'	F21	118d
1'	F21	120d
1'	F21	120d xDrive
1'	F21	120i
1'	F21	125d
1'	F21	125i
1'	F21	M135i
1'	F21	M135i xDrive
1'	F21	M140i
1'	F21	M140i xDrive
1'	F52	118i
1'	F52	120i
1'	F52	125i
2'	F22	218d
2'	F22	218i
2'	F22	220d
2'	F22	220d xDrive
2'	F22	220i
2'	F22	225d
2'	F22	228i
2'	F22	228i xDrive
2'	F22	230i
2'	F22	230i xDrive
2'	F22	M235i
2'	F22	M235i xDrive
2'	F22	M240i
2'	F22	M240i xDrive
2'	F23	218d
2'	F23	218i
2'	F23	220d
2'	F23	220i
2'	F23	225d
2'	F23	228i
2'	F23	228i xDrive
2'	F23	230i
2'	F23	230i xDrive
2'	F23	M235i
2'	F23	M235i xDrive
2'	F23	M240i
2'	F23	M240i xDrive
2'	F45	214d
2'	F45	216d
2'	F45	216i
2'	F45	218d

2'	F45	218d xDrive
2'	F45	218i
2'	F45	220d
2'	F45	220d xDrive
2'	F45	220i
2'	F45	225i
2'	F45	225i xDrive
2'	F46	214d
2'	F46	216d
2'	F46	216i
2'	F46	218d
2'	F46	218d xDrive
2'	F46	218i
2'	F46	220d
2'	F46	220d xDrive
2'	F46	220i
2'	F87	M2
2'	F87	M2 Competition
3'	E30	316
3'	E30	316i
3'	E30	318i
3'	E30	318is
3'	E30	320i
3'	E30	320is
3'	E30	323i
3'	E30	324d
3'	E30	324td
3'	E30	325e
3'	E30	325i
3'	E30	325ix
3'	E30	M3
3'	E30	318i
3'	E30	320i
3'	E30	325i
3'	E30	M3
3'	E30	316i
3'	E30	318i
3'	E30	320i
3'	E30	324td
3'	E30	325i
3'	E30	325ix
3'	E36	316i
3'	E36	318is
3'	E36	320i
3'	E36	323i
3'	E36	325i
3'	E36	325is
3'	E36	328i
3'	E36	M3
3'	E36	316i
3'	E36	318i
3'	E36	318is
3'	E36	318tds
3'	E36	320i

3'	E36	323i
3'	E36	325i
3'	E36	325td
3'	E36	325tds
3'	E36	328i
3'	E36	M3
3'	E36	318i
3'	E36	318is
3'	E36	320i
3'	E36	323i
3'	E36	325i
3'	E36	328i
3'	E36	M3
3'	E36	316i
3'	E36	318i
3'	E36	318tds
3'	E36	320i
3'	E36	323i
3'	E36	325tds
3'	E36	328i
3'	E36	316g
3'	E36	316i
3'	E36	318tds
3'	E36	318ti
3'	E36	323ti
3'	E46	316Ci
3'	E46	318Ci
3'	E46	320Cd
3'	E46	320Ci
3'	E46	323Ci
3'	E46	325Ci
3'	E46	328Ci
3'	E46	330Cd
3'	E46	330Ci
3'	E46	M3
3'	E46	M3 CSL
3'	E46	316i
3'	E46	318d
3'	E46	318i
3'	E46	320d
3'	E46	320i
3'	E46	323i
3'	E46	325i
3'	E46	325xi
3'	E46	328i
3'	E46	330d
3'	E46	330i
3'	E46	330xd
3'	E46	330xi
3'	E46	318Ci
3'	E46	320Cd
3'	E46	320Ci
3'	E46	323Ci
3'	E46	325Ci

3'	E46	330Cd
3'	E46	330Ci
3'	E46	M3
3'	E46	316i
3'	E46	318d
3'	E46	318i
3'	E46	320d
3'	E46	320i
3'	E46	323i
3'	E46	325i
3'	E46	325xi
3'	E46	328i
3'	E46	330d
3'	E46	330i
3'	E46	330xd
3'	E46	330xi
3'	E46	316ti
3'	E46	318td
3'	E46	318ti
3'	E46	320td
3'	E46	325ti
3'	E90	316d
3'	E90	316i
3'	E90	318d
3'	E90	318i
3'	E90	320d
3'	E90	320d EffDyn Edition
3'	E90	320dX
3'	E90	320i
3'	E90	320si
3'	E90	323i
3'	E90	325d
3'	E90	325i
3'	E90	325xi
3'	E90	328i
3'	E90	328xi
3'	E90	330d
3'	E90	330i
3'	E90	330xd
3'	E90	330xi
3'	E90	335d
3'	E90	335i
3'	E90	335xi
3'	E90	M3
3'	E90	M3 GT
3'	E91	316d
3'	E91	316i
3'	E91	318d
3'	E91	318i
3'	E91	320d
3'	E91	320d EffDyn Edition
3'	E91	320dX
3'	E91	320i
3'	E91	323i

3'	E91	325d
3'	E91	325i
3'	E91	325xi
3'	E91	328i
3'	E91	328iX
3'	E91	328xi
3'	E91	330d
3'	E91	330i
3'	E91	330xd
3'	E91	330xi
3'	E91	335d
3'	E91	335i
3'	E91	335iX
3'	E91	335xi
3'	E92	316i
3'	E92	318i
3'	E92	320d
3'	E92	320d xDrive
3'	E92	320dX
3'	E92	320i
3'	E92	323i
3'	E92	325d
3'	E92	325i
3'	E92	325i xDrive
3'	E92	325xi
3'	E92	328i
3'	E92	328i xDrive
3'	E92	328xi
3'	E92	330d
3'	E92	330d xDrive
3'	E92	330i
3'	E92	330i xDrive
3'	E92	330xd
3'	E92	330xi
3'	E92	335d
3'	E92	335i
3'	E92	335i xDrive
3'	E92	335is
3'	E92	335xi
3'	E92	M3
3'	E93	318i
3'	E93	320d
3'	E93	320i
3'	E93	323i
3'	E93	325d
3'	E93	325i
3'	E93	328i
3'	E93	330d
3'	E93	330i
3'	E93	335i
3'	E93	335is
3'	E93	M3
3'	F30	316d
3'	F30	316i

3'	F30	318d
3'	F30	318d xDrive
3'	F30	318i
3'	F30	320d
3'	F30	320d EffDyn Edition
3'	F30	320d xDrive
3'	F30	320i
3'	F30	320i EffDyn Edition
3'	F30	320i xDrive
3'	F30	325d
3'	F30	328d
3'	F30	328d xDrive
3'	F30	328i
3'	F30	328i xDrive
3'	F30	330d
3'	F30	330d xDrive
3'	F30	330i
3'	F30	330i xDrive
3'	F30	335d xDrive
3'	F30	335i
3'	F30	335i xDrive
3'	F30	340i
3'	F30	340i xDrive
3'	F30	ActiveHybrid 3
3'	F31	316d
3'	F31	316i
3'	F31	318d
3'	F31	318d xDrive
3'	F31	318i
3'	F31	320d
3'	F31	320d EffDyn Edition
3'	F31	320d xDrive
3'	F31	320i
3'	F31	320i xDrive
3'	F31	325d
3'	F31	328d xDrive
3'	F31	328i
3'	F31	328i xDrive
3'	F31	330d
3'	F31	330d xDrive
3'	F31	330i
3'	F31	330i xDrive
3'	F31	335d xDrive
3'	F31	335i
3'	F31	335i xDrive
3'	F31	340i
3'	F31	340i xDrive
3'	F34	318d
3'	F34	320d
3'	F34	320d xDrive
3'	F34	320i
3'	F34	320i xDrive
3'	F34	325d
3'	F34	328i

3'	F34	328i xDrive
3'	F34	330d
3'	F34	330d xDrive
3'	F34	330i
3'	F34	330i xDrive
3'	F34	335d xDrive
3'	F34	335i
3'	F34	335i xDrive
3'	F34	340i
3'	F34	340i xDrive
3'	F35	316Li
3'	F35	318Li
3'	F35	320Li
3'	F35	320Li xDrive
3'	F35	328Li
3'	F35	328Li xDrive
3'	F35	330Li
3'	F35	330Li xDrive
3'	F35	335Li
3'	F80	ALL
3'	G20	318d
3'	G20	320d
3'	G20	320d xDrive
3'	G20	320i
3'	G20	325i
3'	G20	330d
3'	G20	330d xDrive
3'	G20	330i
3'	G20	330i xDrive
3'	G20	M340i
3'	G20	M340i xDrive
4'	F32	418d
4'	F32	418i
4'	F32	420d
4'	F32	420d xDrive
4'	F32	420i
4'	F32	420i xDrive
4'	F32	425d
4'	F32	428i
4'	F32	428i xDrive
4'	F32	430i
4'	F32	430i xDrive
4'	F32	435d xDrive
4'	F32	435i
4'	F32	435i xDrive
4'	F32	440i
4'	F32	440i xDrive
4'	F33	420d
4'	F33	420i
4'	F33	425d
4'	F33	428i
4'	F33	428i xDrive
4'	F33	430d
4'	F33	430i

4'	F33	430i xDrive
4'	F33	435d xDrive
4'	F33	435i
4'	F33	435i xDrive
4'	F33	440i
4'	F33	440i xDrive
4'	F36	418d
4'	F36	418i
4'	F36	420d
4'	F36	420d xDrive
4'	F36	420i
4'	F36	420i xDrive
4'	F36	425d
4'	F36	428i
4'	F36	428i xDrive
4'	F36	430d
4'	F36	430d xDrive
4'	F36	430i
4'	F36	430i xDrive
4'	F36	435d xDrive
4'	F36	435i
4'	F36	435i xDrive
4'	F36	440i
4'	F36	440i xDrive
4'	F82	M4
4'	F82	M4 CS
4'	F82	M4 GTS
4'	F83	ALL
5'	E34	518i
5'	E34	520i
5'	E34	524td
5'	E34	525i
5'	E34	525ix
5'	E34	525td
5'	E34	525tds
5'	E34	530i
5'	E34	535i
5'	E34	540i
5'	E34	M5
5'	E34	518g
5'	E34	518i
5'	E34	520i
5'	E34	525i
5'	E34	525ix
5'	E34	525td
5'	E34	525tds
5'	E34	530i
5'	E34	540i
5'	E34	M5
5'	E39	520d
5'	E39	520i
5'	E39	523i
5'	E39	525d
5'	E39	525i

5'	E39	525td
5'	E39	525tds
5'	E39	528i
5'	E39	530d
5'	E39	530i
5'	E39	535i
5'	E39	540i
5'	E39	M5
5'	E39	520d
5'	E39	520i
5'	E39	523i
5'	E39	525d
5'	E39	525i
5'	E39	525tds
5'	E39	528i
5'	E39	530d
5'	E39	530i
5'	E39	540i
5'	E60	520Li
5'	E60	520d
5'	E60	520i
5'	E60	523Li
5'	E60	523i
5'	E60	525Li
5'	E60	525d
5'	E60	525i
5'	E60	525xd
5'	E60	525xi
5'	E60	528i
5'	E60	528xi
5'	E60	530Li
5'	E60	530d
5'	E60	530i
5'	E60	530xd
5'	E60	530xi
5'	E60	535d
5'	E60	535i
5'	E60	535xi
5'	E60	540i
5'	E60	545i
5'	E60	550i
5'	E60	M5
5'	E61	520d
5'	E61	520i
5'	E61	523i
5'	E61	525d
5'	E61	525i
5'	E61	525xd
5'	E61	525xi
5'	E61	530d
5'	E61	530i
5'	E61	530xd
5'	E61	530xi
5'	E61	535d

5'	E61	535xi
5'	E61	545i
5'	E61	550i
5'	E61	M5
5'	F07	520d
5'	F07	528i
5'	F07	530d
5'	F07	530d xDrive
5'	F07	535d
5'	F07	535d xDrive
5'	F07	535i
5'	F07	535i xDrive
5'	F07	550i
5'	F07	550i xDrive
5'	F10	518d
5'	F10	520d
5'	F10	520d EffDyn Edition
5'	F10	520d xDrive
5'	F10	520i
5'	F10	523i
5'	F10	525d
5'	F10	525d xDrive
5'	F10	528i
5'	F10	528i xDrive
5'	F10	530d
5'	F10	530d xDrive
5'	F10	530i
5'	F10	535d
5'	F10	535d xDrive
5'	F10	535i
5'	F10	535i xDrive
5'	F10	550i
5'	F10	ActiveHybrid 5
5'	F10	M5
5'	F10	M550d xDrive
5'	F11	518d
5'	F11	520d
5'	F11	520d xDrive
5'	F11	520i
5'	F11	523i
5'	F11	525d
5'	F11	525d xDrive
5'	F11	528i
5'	F11	528i xDrive
5'	F11	530d
5'	F11	530d xDrive
5'	F11	530i
5'	F11	535d
5'	F11	535d xDrive
5'	F11	535i
5'	F11	535i xDrive
5'	F11	550i
5'	F11	M550d xDrive
5'	F18	520Li

5'	F18	523Li
5'	F18	525Li
5'	F18	528Li
5'	F18	528Li xDriver
5'	F18	530Le
5'	F18	530Li
5'	F18	535Li
5'	F90	ALL
5'	G30	518d
5'	G30	520d
5'	G30	520d EffDyn Edition
5'	G30	520d xDrive
5'	G30	520i
5'	G30	525d
5'	G30	530d
5'	G30	530d xDrive
5'	G30	530i
5'	G30	530i xDriver
5'	G30	540d xDriver
5'	G30	540i
5'	G30	540i xDriver
5'	G30	M550d xDriver
5'	G30	M550i xDriver
5'	G31	518d
5'	G31	520d
5'	G31	520d xDrive
5'	G31	520i
5'	G31	525d
5'	G31	530d
5'	G31	530d xDrive
5'	G31	530i
5'	G31	530i xDriver
5'	G31	540d xDriver
5'	G31	540i xDriver
5'	G31	M550d xDriver
5'	G38	525Li
5'	G38	528Li
5'	G38	530Li
5'	G38	530L xDriver
5'	G38	540Li
6'	E63	630i
6'	E63	635d
6'	E63	645Ci
6'	E63	650i
6'	E63	M6
6'	E64	630i
6'	E64	635d
6'	E64	645Ci
6'	E64	650i
6'	E64	M6
6'	F06	640d
6'	F06	640d xDriver
6'	F06	640i
6'	F06	640i xDriver

6'	F06	650i
6'	F06	650i xDriver
6'	F06	M6
6'	F12	640d
6'	F12	640d xDriver
6'	F12	640i
6'	F12	640i xDriver
6'	F12	650i
6'	F12	650i xDriver
6'	F12	M6
6'	F13	640d
6'	F13	640d xDriver
6'	F13	640i
6'	F13	640i xDriver
6'	F13	650i
6'	F13	650i xDriver
6'	F13	M6
6'	G32	620d
6'	G32	620d xDriver
6'	G32	630d
6'	G32	630d xDriver
6'	G32	630i
6'	G32	640d xDriver
6'	G32	640i
6'	G32	640i xDriver
7'	E32	730i
7'	E32	730iL
7'	E32	735i
7'	E32	735iL
7'	E32	740i
7'	E32	740iL
7'	E32	750i
7'	E32	750iL
7'	E32	750iLS
7'	E38	725tds
7'	E38	728i
7'	E38	728iL
7'	E38	730d
7'	E38	730i
7'	E38	730iL
7'	E38	735i
7'	E38	735iL
7'	E38	740d
7'	E38	740i
7'	E38	740iL
7'	E38	750i
7'	E38	750iL
7'	E38	750iLS
7'	E38	750ixL
7'	E65	730d
7'	E65	730i
7'	E65	735i
7'	E65	740d
7'	E65	740i

7'	E65	745d
7'	E65	745i
7'	E65	750i
7'	E65	750i Alpina B7
7'	E65	760i
7'	E66	730Ld
7'	E66	730Li
7'	E66	735Li
7'	E66	740Li
7'	E66	745Li
7'	E66	750Li
7'	E66	760Li
7'	E68	ALL
7'	F01	730d
7'	F01	730d xDriver
7'	F01	730i
7'	F01	740d
7'	F01	740d xDriver
7'	F01	740i
7'	F01	750d xDriver
7'	F01	750i
7'	F01	750i Alpina B7
7'	F01	750i xDriver
7'	F01	750i xDriver Alpina B7
7'	F01	760i
7'	F01	ActiveHybrid 7
7'	F02	730Ld
7'	F02	730Li
7'	F02	740Ld xDriver
7'	F02	740Li
7'	F02	740Li xDriver
7'	F02	750Ld xDriver
7'	F02	750Li
7'	F02	750Li Alpina B7
7'	F02	750Li xDriver
7'	F02	750Li xDriver Alpina B7
7'	F02	760Li
7'	F02	ActiveHybrid 7
7'	F04	750Li Hybrid
7'	F04	750i Hybrid
7'	G11	725d
7'	G11	730d
7'	G11	730d xDriver
7'	G11	730i
7'	G11	740d xDriver
7'	G11	740i
7'	G11	750d xDriver
7'	G11	750i
7'	G11	750i xDriver
7'	G12	725Ld
7'	G12	730Ld
7'	G12	730Ld xDriver
7'	G12	730Li
7'	G12	740Ld xDriver

7'	G12	740Li
7'	G12	740Li xDriver
7'	G12	750Ld xDriver
7'	G12	750Li
7'	G12	750Li xDriver
7'	G12	M760LixDriver
8'	E31	840Ci
8'	E31	850CSi
8'	E31	850Ci
8'	G14	840d xDriver
8'	G14	M850i xDriver
8'	G15	840d xDriver
8'	G15	M850i xDriver
I'	I01	i3
I'	I01	i3(+ REX)
I'	I01	i3 120
I'	I01	i3 94
I'	I01	i3 94(+ REX)
I'	I01	i3s 120
I'	I01	i3s 94
I'	I12	ALL
X'	E53	X5 3.0d
X'	E53	X5 3.0i
X'	E53	X5 4.4i
X'	E53	X5 4.6is
X'	E53	X5 4.8is
X'	E70	X5 3.0d
X'	E70	X5 3.0sd
X'	E70	X5 3.0si
X'	E70	X5 4.8i
X'	E70	X5 M
X'	E70	X5 M50d
X'	E70	X5 xDriver30d
X'	E70	X5 xDriver35d
X'	E70	X5 xDriver35i
X'	E70	X5 xDriver40d
X'	E70	X5 xDriver40i
X'	E70	X5 xDriver50i
X'	E71	X6 M
X'	E71	X6 M50dX
X'	E71	X6 xDriver30d
X'	E71	X6 xDriver35d
X'	E71	X6 xDriver35i
X'	E71	X6 xDriver40d
X'	E71	X6 xDriver40i
X'	E71	X6 xDriver50i
X'	E72	ALL
X'	E83	X3 2.0d
X'	E83	X3 2.1i
X'	E83	X3 2.5i
X'	E83	X3 2.5si
X'	E83	X3 3.0d
X'	E83	X3 3.0i
X'	E83	X3 3.0sd

X'	E83	X3 3.0si
X'	E83	X3 xDriver 18d
X'	E84	X1 sDriver 20d
X'	E84	X1 sDriver 16d
X'	E84	X1 sDriver 16i
X'	E84	X1 sDriver 18d
X'	E84	X1 sDriver 18i
X'	E84	X1 sDriver 20d
X'	E84	X1 sDriver 20d ED
X'	E84	X1 sDriver 20i
X'	E84	X1 sDriver 28i
X'	E84	X1 sDriver 18d
X'	E84	X1 sDriver 20d
X'	E84	X1 sDriver 20i
X'	E84	X1 sDriver 23d
X'	E84	X1 sDriver 25d
X'	E84	X1 sDriver 25i
X'	E84	X1 sDriver 28i
X'	E84	X1 sDriver 35i
X'	F15	X5 M50d
X'	F15	X5 sDriver25d
X'	F15	X5 sDriver35i
X'	F15	X5 xDriver25d
X'	F15	X5 xDriver28i
X'	F15	X5 xDriver30d
X'	F15	X5 xDriver35d
X'	F15	X5 xDriver35i
X'	F15	X5 xDriver40d
X'	F15	X5 xDriver40e iPerformance
X'	F15	X5 xDriver50i
X'	F16	X6 M50dX
X'	F16	X6 sDriver35i
X'	F16	X6 sDriver28i
X'	F16	X6 sDriver30d
X'	F16	X6 sDriver35i
X'	F16	X6 sDriver40d
X'	F16	X6 sDriver50i
X'	F25	X3 28iX
X'	F25	X3 sDriver18d
X'	F25	X3 sDriver20i
X'	F25	X3 sDriver28i
X'	F25	X3 xDriver28i
X'	F25	X3 xDriver20d
X'	F25	X3 xDriver20i
X'	F25	X3 xDriver28d
X'	F25	X3 xDriver28i
X'	F25	X3 xDriver30d
X'	F25	X3 xDriver35d
X'	F25	X3 xDriver35i
X'	F26	X4 m40i
X'	F26	X4 xDriver20d
X'	F26	X4 xDriver20i
X'	F26	X4 xDriver28i
X'	F26	X4 xDriver30d

X'	F26	X4 xDriver35d
X'	F26	X4 xDriver35i
X'	F39	X2 M35i
X'	F39	X2 sDriver16d
X'	F39	X2 sDriver18d
X'	F39	X2 sDriver18i
X'	F39	X2 sDriver20d
X'	F39	X2 sDriver20i
X'	F39	X2 sDriver28i
X'	F39	X2 xDriver18d
X'	F39	X2 xDriver20d
X'	F39	X2 xDriver20i
X'	F39	X2 xDriver25d
X'	F39	X2 xDriver28i
X'	F48	X1 sDriver16d
X'	F48	X1 sDriver18d
X'	F48	X1 sDriver18i
X'	F48	X1 sDriver20d
X'	F48	X1 sDriver20i
X'	F48	X1 sDriver28i
X'	F48	X1 xDriver18d
X'	F48	X1 xDriver20d
X'	F48	X1 xDriver20i
X'	F48	X1 xDriver25d
X'	F48	X1 xDriver25i
X'	F48	X1 xDriver28i
X'	F49	X1 sDriver18Li
X'	F49	X1 sDriver20Li
X'	F49	X1 xDriver20Li
X'	F49	X1 xDriver25Li
X'	F85	ALL
X'	F86	ALL
X'	G01	X3 M40d
X'	G01	X3 M40i
X'	G01	X3 sDriver18d
X'	G01	X3 sDriver20i
X'	G01	X3 sDriver30i
X'	G01	X3 xDriver20d
X'	G01	X3 xDriver20i
X'	G01	X3 xDriver25d
X'	G01	X3 xDriver30d
X'	G01	X3 xDriver30i
X'	G02	X4 M40d
X'	G02	X4 m40i
X'	G02	X4 xDriver20d
X'	G02	X4 xDriver21i
X'	G02	X4 xDriver25d
X'	G02	X4 xDriver30d
X'	G02	X4 xDriver30i
X'	G05	X5 M50d
X'	G05	X5 xDriver30d
X'	G05	X5 xDriver40i
X'	G05	X5 xDriver50i
X'	G07	X7 M50d

X'	G07	X7 xDriver30d
X'	G07	X7 xDriver40i
X'	G07	X7 xDriver50i
X'	G08	X3 xDriver25i
X'	G08	X3 xDriver28i
X'	G08	X3 xDriver30i
Z'	E30	ALL
Z'	E36	Z3 1.8
Z'	E36	Z3 1.9
Z'	E36	Z3 2.0
Z'	E36	Z3 2.2
Z'	E36	Z3 2.3
Z'	E36	Z3 2.5
Z'	E36	Z3 2.8
Z'	E36	Z3 3.0i
Z'	E36	Z3 M 3.2
Z'	E36	Z3 2.8
Z'	E36	Z3 3.0i
Z'	E36	Z3 M 3.2
Z'	E52	ALL
Z'	E85	Z4 2.0i
Z'	E85	Z4 2.2i
Z'	E85	Z4 2.5i
Z'	E85	Z4 2.5si
Z'	E85	Z4 3.0i
Z'	E85	Z4 3.0si
Z'	E85	Z4 M 3.2
Z'	E86	Z4 3.0si
Z'	E86	Z4 M 3.2
Z'	E89	Z4 sDriver18i
Z'	E89	Z4 sDriver20i
Z'	E89	Z4 sDriver23i
Z'	E89	Z4 sDriver28i
Z'	E89	Z4 sDriver30i
Z'	E89	Z4 sDriver35i
Z'	E89	Z4 sDriver35is
Z'	G29	Z4 M40i
Z'	G29	Z4 sDriver20i
Z'	G29	Z4 sDriver30i

BMW Ecu List

System Name	Ecu Info	Read Codes	Erase Codes	Live Data	Act
AB [Airbag]	●	●	●	●	●
ABS [Antilock brake system FTE]	●	●	●	●	●
ABS [Antilock brake system Integral-ABS FTE]	●	●	●	●	●
ABS [Antilock braking systemABS1]	●	●	●	●	●
ABS [Antilock braking systemABS2]	●	●	●	●	●
ABS [Antilock braking systemABS5]	●	●	●	●	●
ABS [Antilock braking systemMK4G]	●	●	●	●	●
ABS [Bosch antilock brake system]	●	●	●	●	●
ABS [Conti antilock brake system]	●	●	●	●	●
ABS [Stability controlMK20]	●	●	●	●	●
ABS-DSC [Stability system EBC_450]	●	●	●	●	●

ABS-DSC [Stability system MK60]	●	●	●	●	●
ACC [Active cruise control]	●	●	●	●	●
ACP [Audio Control Panel]	●	●	●	●	●
ACSM [Crash safety module]	●	●	●	●	●
ACSM-MRS [Crash safety module/multiple restraint system]	●	●	●	●	●
ADP [Audio Display Panel]	●	●	●	●	●
ADS	●	●	●	●	●
AEP	●	●	●	●	●
AGS [Transmission control]	●	●	●	●	●
AHL [Adaptive Headlights/headlight beam throw adjustment]	●	●	●	●	●
AHL [Adaptive headlight/headlight beam throw adjustment]	●	●	●	●	●
AHM [Trailer module]	●	●	●	●	●
AIC [Automatic Interval Control]	●	●	●	●	●
AL [Active steering]	●	●	●	●	●
ALBBF [Active backrest width, front passenger]	●	●	●	●	●
ALBFA [Active backrest width, driver]	●	●	●	●	●
AMP [Hi-Fi amplifier]	●	●	●	●	●
AMP [Top HiFi amplifier]	●	●	●	●	●
AMPH [Hi-Fi amplifier]	●	●	●	●	●
AMPT [Top HiFi amplifier]	●	●	●	●	●
ANT [Aerial tuner]	●	●	●	●	●
APM [Hybrid DC/DC converter]	●	●	●	●	●
ARS [Dynamic drive]	●	●	●	●	●
ASC [Stability controlABD5]	●	●	●	●	●
ASC [Stability controlASC57]	●	●	●	●	●
ASC [Stability controlASC5D]	●	●	●	●	●
ASC [Stability controlASC5]	●	●	●	●	●
ASC [Stability controlMK20]	●	●	●	●	●
ASC [Stability controlMK4US]	●	●	●	●	●
ASC [Stability controlMK4]	●	●	●	●	●
ASC [Stability control]	●	●	●	●	●
ASD [Active sound design]	●	●	●	●	●
ASK [Audio system controller]	●	●	●	●	●
AUDIO [Audio system]	●	●	●	●	●
Automatic climate control	●	●	●	●	●
BATT48 [Battery electronics 48 volt]	●	●	●	●	●
BC [On-board computer]	●	●	●	●	●
BCM [Battery monitoring module]	●	●	●	●	●
BCO [On-board computer]	●	●	●	●	●
BCO/MID [On-board computer/MID]	●	●	●	●	●
BDC [Body Domain Controller]	●	●	●	●	●
BIT [Basic interface telephone]	●	●	●	●	●
BM [On-board monitor control panel]	●	●	●	●	●
BM [On-board monitor, Top navigation]	●	●	●	●	●
BM [On-board monitor, widescreen]	●	●	●	●	●
BM [On-board monitor]	●	●	●	●	●
BZM [Centre console control panel]	●	●	●	●	●
BZMF [Control centre, rear compartment centre armrest]	●	●	●	●	●
CA [Comfort Access]	●	●	●	●	●
CANALLG	●	●	●	●	●
CANWAY	●	●	●	●	●

CAN PL2	●	●	●	●	●
CAS [Car Access System]	●	●	●	●	●
CBX-ECALL [Combox emergency call]	●	●	●	●	●
CBX-MEDIA [Combox Multimedia]	●	●	●	●	●
CCC-A [Applications]	●	●	●	●	●
CCC-ANT [Aerial tuner]	●	●	●	●	●
CCC-ASK [Audio system controller]	●	●	●	●	●
CCC-BO [User interface]	●	●	●	●	●
CCC-GW [Gateway]	●	●	●	●	●
CCM [Check control module]	●	●	●	●	●
CD [Control display]	●	●	●	●	●
CD-GW [Control Display (Gateway)]	●	●	●	●	●
CDC [CD changer]	●	●	●	●	●
CDM [Coach door module]	●	●	●	●	●
CDML [coach door module, left]	●	●	●	●	●
CDMR [coach door module, right]	●	●	●	●	●
CEM [Clean Energy Module]	●	●	●	●	●
CHAMP [Central head unit and multimedia platform]	●	●	●	●	●
CHAMP-BO [User interface]	●	●	●	●	●
CHAMP-GW [Gateway]	●	●	●	●	●
CHRONO [Chronometer]	●	●	●	●	●
CIC [Car Information Computer]	●	●	●	●	●
CIC-GW [Gateway]	●	●	●	●	●
CID [Central Information Display]	●	●	●	●	●
CID [Central information display]	●	●	●	●	●
CIM [Chassis integration module]	●	●	●	●	●
CNAV [Navigation system China]	●	●	●	●	●
CON [Controller]	●	●	●	●	●
CPM [CPM]	●	●	●	●	●
CSM [Car sharing module]	●	●	●	●	●
CTM [Convertible-top module]	●	●	●	●	●
CVM [Convertible-top module]	●	●	●	●	●
CVM2 [Convertible top module 2]	●	●	●	●	●
Carb	●	●	●	●	●
Complete vehicle	●	●	●	●	●
Convenience charging electronics	●	●	●	●	●
DAB [DAB tuner]	●	●	●	●	●
DCS [Driver Camera System]	●	●	●	●	●
DDC [Electronic suspension adjustment]	●	●	●	●	●
DDE [Diesel electronics US]	●	●	●	●	●
DDE [Diesel electronics master]	●	●	●	●	●
DDE [Diesel electronics slave]	●	●	●	●	●
DDE [Diesel fuel electronics]	●	●	●	●	●
DDE [Digital diesel electronics]	●	●	●	●	●
DDE2 [Diesel electronics slave]	●	●	●	●	●
DIA_DOSE	●	●	●	●	●
DKG [Electronic transmission control]	●	●	●	●	●
DKG [Transmission control]	●	●	●	●	●
DME [Digital Motor Electronics]	●	●	●	●	●
DME [Digital engine electronics, cylinder bank 1]	●	●	●	●	●
DME [Engine control]	●	●	●	●	●
DME [Engine electronics H2, cylinder bank 1]	●	●	●	●	●

DME [Engine electronics, cylinder bank 1]	●	●	●	●	●
DME [Engine electronics]	●	●	●	●	●
DME2 [Digital Engine Electronics, bank 2]	●	●	●	●	●
DME2 [Digital Motor Electronics, cylinder bank 2]	●	●	●	●	●
DME2 [Engine electronics H2, cylinder bank 2]	●	●	●	●	●
DME2 [Engine electronics, cylinder bank 2]	●	●	●	●	●
DSC [Dynamic Stability Control DSC8 Plus]	●	●	●	●	●
DSC [Dynamic Stability Control]	●	●	●	●	●
DSC [Dynamic stability control DSC5.7]	●	●	●	●	●
DSC [Dynamic stability control DSC8 PLUS]	●	●	●	●	●
DSC [Dynamic stability controlDSC8]	●	●	●	●	●
DSC [Dynamic stability controlEHB3]	●	●	●	●	●
DSC [Dynamic stability controlMK60 E5]	●	●	●	●	●
DSC [Dynamic stability controlMK60]	●	●	●	●	●
DSC [Stability controlDSC3]	●	●	●	●	●
DSC [Stability controlDSC57]	●	●	●	●	●
DSC [Stability controlDSC5]	●	●	●	●	●
DSC [Stability controlMK20]	●	●	●	●	●
DSM [Hybrid parking lock]	●	●	●	●	●
DSP [DSP control panel]	●	●	●	●	●
DSP [Digital sound processor]	●	●	●	●	●
DVDC [DVD changer]	●	●	●	●	●
DWA [Anti-theft alarm system]	●	●	●	●	●
DWA-RDC [Anti-theft alarm system/tyre pressure control]	●	●	●	●	●
EARSH [Rear electric active roll stabilisation]	●	●	●	●	●
EARSV [Front electric active roll stabilisation]	●	●	●	●	●
EDC [Electronic Damper Control K]	●	●	●	●	●
EDC [Electronic Damper Control]	●	●	●	●	●
EDC [Vertical Dynamics Management]	●	●	●	●	●
EDCSHL [Damper satellite, rear left]	●	●	●	●	●
EDCSHR [Damper satellite, rear right]	●	●	●	●	●
EDCSVL [Damper satellite, front left]	●	●	●	●	●
EDCSVR [Damper satellite, front right]	●	●	●	●	●
EDIC	●	●	●	●	●
EDME [Electrical Digital Motor Electronics]	●	●	●	●	●
EGS [Electronic transmission control]	●	●	●	●	●
EGS [Transmission control]	●	●	●	●	●
EHC [- 1-axle air suspension]	●	●	●	●	●
EHC [- Axle air suspension]	●	●	●	●	●
EHC [2-axle air suspension]	●	●	●	●	●
EHC [Electronic ride height control]	●	●	●	●	●
EHC2 [2-axle air suspension]	●	●	●	●	●
EHC2 [Electronic ride height control]	●	●	●	●	●
EHKS [Electro-hydraulic centre stand]	●	●	●	●	●
EHPS [Electro-hydraulic power steering]	●	●	●	●	●
EKK [Electric A/C compressor]	●	●	●	●	●
EKPS [Electronic fuel pump control module]	●	●	●	●	●

EKPS [Fuel pump control module]	●	●	●	●	●
ELV [Electric steering lock]	●	●	●	●	●
ELV [Electrical steering column adjustment]	●	●	●	●	●
EMALI [Electric motor-driven reel, left]	●	●	●	●	●
EMARE [Electric motor-driven reel, right]	●	●	●	●	●
EME [Electrical machine electronics]	●	●	●	●	●
EMF [Parking brake]	●	●	●	●	●
EML [Electronic engine power control]	●	●	●	●	●
EMPI [Hybrid oil pump control unit]	●	●	●	●	●
ENS [Ethernet switch]	●	●	●	●	●
EPS [Electronic Power Steering]	●	●	●	●	●
EPS [electromechanical power steering]	●	●	●	●	●
ESA [Electronic suspension adjustment]	●	●	●	●	●
EWS [Electronic immobiliser 2]	●	●	●	●	●
EWS [Electronic immobiliser 3D]	●	●	●	●	●
EWS [Electronic immobiliser 3]	●	●	●	●	●
EWS [Electronic immobiliser]	●	●	●	●	●
Electrical machine electronics	●	●	●	●	●
Engine electronics	●	●	●	●	●
F01BN2K	●	●	●	●	●
FADP [Rear compartment audio display panel]	●	●	●	●	●
FBI [Flexible Bus Interface]	●	●	●	●	●
FBZV [Radio remote control]	●	●	●	●	●
FCON [Rear-compartment controller]	●	●	●	●	●
FD [Rear monitor]	●	●	●	●	●
FD2 [Rear compartment display 2]	●	●	●	●	●
FD2 [Rear display 2]	●	●	●	●	●
FEM [Front electronic module]	●	●	●	●	●
FGB [Rear compartment blower]	●	●	●	●	●
FGR [Cruise control]	●	●	●	●	●
FID [Rear passenger compartment multi-information display]	●	●	●	●	●
FKA [Automatic rear air-conditioning system]	●	●	●	●	●
FKA [Rear compartment heating and air conditioning system]	●	●	●	●	●
FKA [Rear-compartment air conditioning]	●	●	●	●	●
FLA [High-beam assistant]	●	●	●	●	●
FLEL [Frontal Light Electronics Left]	●	●	●	●	●
FLER [Frontal Light Electronics Right]	●	●	●	●	●
FMBT [Rear-compartment monitor]	●	●	●	●	●
FRM [Driver's side footwell module]	●	●	●	●	●
FRM [Footwell module]	●	●	●	●	●
FRS [Front radar sensor]	●	●	●	●	●
FRSF [Long-distance range front radar sensor]	●	●	●	●	●
FZD [Roof function centre]	●	●	●	●	●
FZGIDENT	●	●	●	●	●
GHAS [Adjusted limited slip differential]	●	●	●	●	●
GHAS [regulated rear axle differential lock]	●	●	●	●	●
GM [Basic module (BCL)]	●	●	●	●	●
GM [Basic module (BCO)]	●	●	●	●	●
GM [Basic module control unit]	●	●	●	●	●

GM [General Module 5]	●	●	●	●	●
GM [General module III]	●	●	●	●	●
GMS [Basic module satellite]	●	●	●	●	●
GMSF [Basic module special vehicle]	●	●	●	●	●
GR [Cruise control]	●	●	●	●	●
GRPLIST	●	●	●	●	●
GWS [Gear selector switch]	●	●	●	●	●
GZAL [Targeted illumination, left]	●	●	●	●	●
GZAR [Targeted illumination, right]	●	●	●	●	●
HCP [Hybrid master control unit]	●	●	●	●	●
HIM [Hybrid Interface Module]	●	●	●	●	●
HKA [Rear automatic climate control]	●	●	●	●	●
HKFM [Tailgate function module]	●	●	●	●	●
HKL [Automatic luggage compartment lid actuation]	●	●	●	●	●
HKL [Luggage compartment lid module]	●	●	●	●	●
HRSNL [Rear radar sensor near range left]	●	●	●	●	●
HRSNR [Rear radar sensor near range right]	●	●	●	●	●
HSR [Rear axle slip angle control]	●	●	●	●	●
HU-B [HU-B]	●	●	●	●	●
HU-H [Headunit High]	●	●	●	●	●
HUD [Head-Up Display]	●	●	●	●	●
IBOC [Digital tuner US]	●	●	●	●	●
ICM [Integrated chassis management]	●	●	●	●	●
IFR	●	●	●	●	●
IHKA [Automatic climate control]	●	●	●	●	●
IHKA [Integrated automatic heating / air conditioning system]	●	●	●	●	●
IHKR [Heating/air conditioning control]	●	●	●	●	●
IHKS [Heating/air conditioning control]	●	●	●	●	●
IHR [Heating control]	●	●	●	●	●
IHS [Heating control]	●	●	●	●	●
IHS [Heating/air conditioning control]	●	●	●	●	●
IKE [Instrument panel]	●	●	●	●	●
ILM [Integrated charging module]	●	●	●	●	●
IPOD [iPod interface]	●	●	●	●	●
IR [Infrared compact locking system]	●	●	●	●	●
IR [Radio/infrared locking system]	●	●	●	●	●
IRIS [Integrated radio information system]	●	●	●	●	●
JBE [Junction Box Electronics]	●	●	●	●	●
JBIT [Japan basic interface telephone 2]	●	●	●	●	●
JBIT [Japan basic interface telephone]	●	●	●	●	●
JNAV [Navigation, Japan]	●	●	●	●	●
KAFAS [Camera-based driver assist system]	●	●	●	●	●
KBM [Body general module]	●	●	●	●	●
KFS [Radiator figure control]	●	●	●	●	●
KGM [Body Gateway Module]	●	●	●	●	●
KHI [Headphones interface]	●	●	●	●	●
KLE [Charging interface module]	●	●	●	●	●
KLE [Convenience charging electronics]	●	●	●	●	●
KNAV [Navigation system Korea]	●	●	●	●	●
KOMBI [Instrument cluster RR]	●	●	●	●	●

KOMBI [Instrument panel control unitRR 2]	●	●	●	●	●
KOMBI [Instrument panel]	●	●	●	●	●
KOMBI2 [Additional instruments]	●	●	●	●	●
LCM [Lights/check module A]	●	●	●	●	●
LCM [Lights/check module III]	●	●	●	●	●
LCM [Lights/check module II]	●	●	●	●	●
LCM [Lights/check module IV]	●	●	●	●	●
LCM [Lights/check module]	●	●	●	●	●
LDM [Longitudinal dynamics management]	●	●	●	●	●
LEM [Light effect manager]	●	●	●	●	●
LHML [LED main light module, left]	●	●	●	●	●
LHMR [LED main light module, right]	●	●	●	●	●
LIM [Charging interface module]	●	●	●	●	●
LM [Light module]	●	●	●	●	●
LMV [Longitudinal torque distribution]	●	●	●	●	●
LRA [Headlight beam throw adjustment]	●	●	●	●	●
LRR [Long range radar]	●	●	●	●	●
LSZ [Light switch cluster]	●	●	●	●	●
LWS [Steering angle sensor]	●	●	●	●	●
M-ASK-BO [User interface]	●	●	●	●	●
M-ASK-GW [Gateway]	●	●	●	●	●
M-ASK-NAV [Navigation system]	●	●	●	●	●
MCPA [Hybrid electric motor control unit 1]	●	●	●	●	●
MCPB [Hybrid electric motor control unit 2]	●	●	●	●	●
MESSEMOD	●	●	●	●	●
MFL [Multifunction steering wheelE38]	●	●	●	●	●
MFL [Multifunction steering wheel]	●	●	●	●	●
MID [Multi-information display]	●	●	●	●	●
MIR [Multi-information radio]	●	●	●	●	●
MJOY [MINI joystick]	●	●	●	●	●
MMB [Multimedia box]	●	●	●	●	●
MOST [Bus system analysis]	●	●	●	●	●
MPM [Micro-power module]	●	●	●	●	●
MRK24	●	●	●	●	●
MRKH2	●	●	●	●	●
MRS [Multiple restraint system]	●	●	●	●	●
NAR [Navigation radio]	●	●	●	●	●
NAV [Navigation system]	●	●	●	●	●
NVE [Night vision electronics]	●	●	●	●	●
NVK [Night Vision Camera]	●	●	●	●	●
OBD	●	●	●	●	●
OC3_FLSH	●	●	●	●	●
OC3_UPD	●	●	●	●	●
OPPS	●	●	●	●	●
PCU [Power Control Unit]	●	●	●	●	●
PCU48 [Power Control Unit 48 volt]	●	●	●	●	●
PCode [Reporting mit CARBPR (California Air Resources Board)]	●	●	●	●	●
PDC [Park distance control]	●	●	●	●	●
PM [Power module]	●	●	●	●	●
PMA [Parking manoeuvre assistant]	●	●	●	●	●
PMA [Parking manoeuvring assistant]	●	●	●	●	●

QMVH [Rear axle lateral torque distribution]	●	●	●	●	●
QMVH [Transmission control]	●	●	●	●	●
R56	●	●	●	●	●
RAD [Radio]	●	●	●	●	●
RAD2 [Radio 2]	●	●	●	●	●
RAD2-GW [Gateway]	●	●	●	●	●
RADIO [Radio-CD player]	●	●	●	●	●
RAM [Receiver audio module]	●	●	●	●	●
RBT [Radio operating unit]	●	●	●	●	●
RCC [Radio clock module]	●	●	●	●	●
RDC [Tyre Pressure Monitor]	●	●	●	●	●
RDC [Tyre pressure control]	●	●	●	●	●
RDME [Range extender digital engine electronics]	●	●	●	●	●
REM [Rear electronic module]	●	●	●	●	●
REMALI [Reversible electromotive automatic reel, left]	●	●	●	●	●
REMARE [Reversible electromotive automatic reel, right]	●	●	●	●	●
REME [Range extender electrical machine electronics]	●	●	●	●	●
RFH [Reverser]	●	●	●	●	●
RFK [Reversing camera]	●	●	●	●	●
RLMAL [Rear light module outer left]	●	●	●	●	●
RLMAR [Rear light module outer right]	●	●	●	●	●
RLMIL [Rear light module inner left]	●	●	●	●	●
RLMIR [Rear light module inner right]	●	●	●	●	●
RLS [Rain/light sensor]	●	●	●	●	●
RLS [Rain/light solar sensor]	●	●	●	●	●
RPA [Run Flat Indicator]	●	●	●	●	●
RR1_2020	●	●	●	●	●
RSE [Rear seat entertainment system]	●	●	●	●	●
SAS [Optional extra system]	●	●	●	●	●
SASL [A-pillar satellite]	●	●	●	●	●
SASR [A-pillar satellite, right]	●	●	●	●	●
SBA [Hybrid brake actuation changeover]	●	●	●	●	●
SBBF [Front passenger seat occupancy]	●	●	●	●	●
SBE [Seat occupancy detection]	●	●	●	●	●
SBSL [B-pillar satellite, left]	●	●	●	●	●
SBSR [B-pillar satellite, right]	●	●	●	●	●
SCR [Selective Catalytic Reduction]	●	●	●	●	●
SDARS [Satellite tuner (US)]	●	●	●	●	●
SEC [Auxiliary control unit]	●	●	●	●	●
SEC2 [Auxiliary control unit 2]	●	●	●	●	●
SES [Voice control]	●	●	●	●	●
SFZ [Satellite, vehicle centre]	●	●	●	●	●
SG-FD [Rear-compartment display control unit]	●	●	●	●	●
SG-FD-GW [Control unit for rear compartment display (gateway)]	●	●	●	●	●
SGM-SIM [Safety and gateway module (SIM)]	●	●	●	●	●
SGM-ZGM [Safety and gateway module]	●	●	●	●	●
SGR48 [Starter motor generator 48 volt]	●	●	●	●	●
SHD [Panorama glass roof]	●	●	●	●	●
SHD [Slide/tilt sunroof]	●	●	●	●	●

SHD [Sunroof module]	●	●	●	●	●
SHZH [Indep./aux. heater]	●	●	●	●	●
SIM [Safety and Information Module]	●	●	●	●	●
SINE [Anti-theft alarm system]	●	●	●	●	●
SINE [siren and tilt alarm sensor]	●	●	●	●	●
SLM [Seat/steering column memory]	●	●	●	●	●
SM/LSM [Mirror/sea/backrest memory, 4-channel]	●	●	●	●	●
SM/LSM [Mirror/sea/backrest memory, 6-channel]	●	●	●	●	●
SMB [Easy entry, front passenger]	●	●	●	●	●
SMB [Seat memory for front passenger]	●	●	●	●	●
SMB [Seat memory, front passenger]	●	●	●	●	●
SMBF [Front passenger seat module]	●	●	●	●	●
SMBFH [Rear passenger's side seat module]	●	●	●	●	●
SMBFH [rear passenger seat module]	●	●	●	●	●
SME [Battery management electronics]	●	●	●	●	●
SMES1 [Battery management electronics]	●	●	●	●	●
SMES2 [Battery management electronics]	●	●	●	●	●
SME 82	●	●	●	●	●
SMF [Easy entry, driver]	●	●	●	●	●
SMF [Seat memory, driver]	●	●	●	●	●
SMFA [Seat module, driver]	●	●	●	●	●
SMFAH [Seat module, rear driver's side]	●	●	●	●	●
SMFAH [driver's seat module]	●	●	●	●	●
SMG [Transmission control]	●	●	●	●	●
SPMBT [Mirror memory, front passenger]	●	●	●	●	●
SPMFT [Mirror memory, driver]	●	●	●	●	●
SPNMHL [Rear left seat inflator module]	●	●	●	●	●
SPNMHR [Rear right seat inflator module]	●	●	●	●	●
SPNMVL [Front left seat inflator module]	●	●	●	●	●
SPNMVR [Front right seat inflator module]	●	●	●	●	●
SRSNVL [Side radar sensor near range front left]	●	●	●	●	●
SRSNVR [Side radar sensor near range front right]	●	●	●	●	●
SSBF [Satellite, seat, passenger]	●	●	●	●	●
SSFA [Satellite, seat, driver]	●	●	●	●	●
SSH [Rear seat satellite]	●	●	●	●	●
STH [Indep./aux. heater]	●	●	●	●	●
STML [Headlight driver module, left]	●	●	●	●	●
STMR [Headlight driver module, right]	●	●	●	●	●
STVL [Door satellite, front left]	●	●	●	●	●
STVR [Door satellite, front right]	●	●	●	●	●
SVA [Side View Assist]	●	●	●	●	●
SVS [Speech processing]	●	●	●	●	●
SVT [Servotronic]	●	●	●	●	●
SWE [Headlight electronics]	●	●	●	●	●
SWTUDS	●	●	●	●	●
SWW [Lane Change Warning]	●	●	●	●	●
SZL [Steering column switch cluster]	●	●	●	●	●
SZM [Centre console control panel]	●	●	●	●	●
TBX [Touchbox]	●	●	●	●	●
TCB [Telematic Communication Box]	●	●	●	●	●

TCM [Hybrid gearbox control unit]	●	●	●	●	●
TCU [Telematics control unit (I-bus)]	●	●	●	●	●
TCU [Telematics control unit]	●	●	●	●	●
TEL [Eject box/Interface telephone]	●	●	●	●	●
TEL [Telephone ECE]	●	●	●	●	●
TEL [Telephone USA]	●	●	●	●	●
TFE [Hybrid pressure refuelling electronic control unit]	●	●	●	●	●
TFE [Pressurized fuel tank control module]	●	●	●	●	●
TLC [Lane departure warning]	●	●	●	●	●
TM [Telematics]	●	●	●	●	●
TMBF [Door module, front passenger door]	●	●	●	●	●
TMBF [Door module, passenger]	●	●	●	●	●
TMBFH [Door module, rear passenger's side]	●	●	●	●	●
TMFA [Door module, driver]	●	●	●	●	●
TMFA [Driver's door module]	●	●	●	●	●
TMFAH [Rear driver's side door module]	●	●	●	●	●
TMODE	●	●	●	●	●
TOENS [Thermal oil-level sensor]	●	●	●	●	●
TOP-DSP [Digital sound processor]	●	●	●	●	●
TOP-DSP2 [Digital sound processor]	●	●	●	●	●
TRS [Electronic battery isolating switch]	●	●	●	●	●
TR SVC [All-round vision camera]	●	●	●	●	●
T_AUSB	●	●	●	●	●
T_GRTB	●	●	●	●	●
T_MSA	●	●	●	●	●
T_PCOD	●	●	●	●	●
T_SCOD	●	●	●	●	●
ULF [Universal charger and hands-free unit]	●	●	●	●	●
ULF-SBX [Interface box]	●	●	●	●	●
ULF-SBX-H [Interface box High]	●	●	●	●	●
URS [Rollover sensor]	●	●	●	●	●
UTILITY	●	●	●	●	●
VDM [Vertical Dynamics Management]	●	●	●	●	●
VDP [Vertical dynamics platform]	●	●	●	●	●
VIP [Virtual integration system]	●	●	●	●	●
VIRTSG90	●	●	●	●	●
VIRTSG91	●	●	●	●	●
VIRTSG92	●	●	●	●	●
VIRTSG93	●	●	●	●	●
VIRTSG98	●	●	●	●	●
VIRTSG9B	●	●	●	●	●
VM [Video module TV]	●	●	●	●	●
VM [Video module hybrid]	●	●	●	●	●
VM [Video module]	●	●	●	●	●
VM [Video switch]	●	●	●	●	●
VM-GT [Video module, graphics stage]	●	●	●	●	●
VO	●	●	●	●	●
VS [Video switch]	●	●	●	●	●
VSG [Vehicle Sound Generator]	●	●	●	●	●
VSG2 [Vehicle Sound Generator 2]	●	●	●	●	●
VSW [Video switch]	●	●	●	●	●

VTC [Valvetronic, bank 1]	●	●	●	●	●
VTC2 [Valvetronic bank 2]	●	●	●	●	●
VTG [Transfer box]	●	●	●	●	●
W2V	●	●	●	●	●
WIM [Wiper module]	●	●	●	●	●
X_K001	●	●	●	●	●
X_KS01	●	●	●	●	●
ZBM [Two-battery management]	●	●	●	●	●
ZCS_ALL	●	●	●	●	●
ZFE [Central chassis electronics]	●	●	●	●	●
ZGM [Central gateway module]	●	●	●	●	●
ZGM2 [Central gateway module 2]	●	●	●	●	●

MINI Diagnostic Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

MINI Car List

Series	Development code	Sales designation
MINI	F54	Cooper
MINI	F54	Cooper ALL4
MINI	F54	Cooper D
MINI	F54	Cooper S
MINI	F54	Cooper S ALL4
MINI	F54	Cooper SD
MINI	F54	Cooper SD ALL4
MINI	F54	John Cooper Works ALL4
MINI	F54	One
MINI	F54	One D
MINI	F55	Cooper
MINI	F55	Cooper D
MINI	F55	Cooper S
MINI	F55	Cooper SD
MINI	F55	One
MINI	F55	One D
MINI	F56	Cooper
MINI	F56	Cooper D
MINI	F56	Cooper S
MINI	F56	Cooper SD
MINI	F56	John Cooper Works
MINI	F56	One
MINI	F56	One D
MINI	F57	Cooper
MINI	F57	Cooper D
MINI	F57	Cooper S
MINI	F57	Cooper SD
MINI	F57	John Cooper Works
MINI	F57	One
MINI	F57	One D
MINI	F60	Cooper
MINI	F60	Cooper ALL4
MINI	F60	Cooper D
MINI	F60	Cooper D ALL4
MINI	F60	Cooper S
MINI	F60	Cooper S ALL4
MINI	F60	Cooper SD
MINI	F60	Cooper SD ALL4
MINI	F60	John Cooper Works ALL4
MINI	F60	One
MINI	F60	One D
MINI	R50	Cooper
MINI	R50	One
MINI	R50	One D

MINI	R52	Cooper
MINI	R52	Cooper S
MINI	R52	One
MINI	R53	Cooper S
MINI	R53	John Cooper Works
MINI	R55	Cooper
MINI	R55	Cooper D
MINI	R55	Cooper S
MINI	R55	Cooper SD
MINI	R55	John Cooper Works
MINI	R55	One
MINI	R55	One D
MINI	R56	Cooper
MINI	R56	Cooper D
MINI	R56	Cooper S
MINI	R56	Cooper SD
MINI	R56	John Cooper Works
MINI	R56	MINI E
MINI	R56	One
MINI	R56	One D
MINI	R57	Cooper
MINI	R57	Cooper D
MINI	R57	Cooper S
MINI	R57	Cooper SD
MINI	R57	John Cooper Works
MINI	R57	One
MINI	R58	Cooper
MINI	R58	Cooper S
MINI	R58	Cooper SD
MINI	R58	John Cooper Works
MINI	R59	Cooper
MINI	R59	Cooper S
MINI	R59	Cooper SD
MINI	R59	John Cooper Works
MINI	R60	Cooper
MINI	R60	Cooper ALL4
MINI	R60	Cooper D
MINI	R60	Cooper D ALL4
MINI	R60	Cooper S
MINI	R60	Cooper S ALL4
MINI	R60	Cooper SD
MINI	R60	Cooper SD ALL4
MINI	R60	John Cooper Works
MINI	R60	One
MINI	R60	One D
MINI	R61	Cooper
MINI	R61	Cooper ALL4
MINI	R61	Cooper D
MINI	R61	Cooper D ALL4
MINI	R61	Cooper S
MINI	R61	Cooper S ALL4
MINI	R61	Cooper SD
MINI	R61	Cooper SD ALL4
MINI	R61	John Cooper Works

MINI Ecu List					
System Name	Ecu Info	Read Codes	Erase Codes	Live Data	Act
AB [Airbag]	●	●	●	●	●
ABS [Antilock brake system FTE]	●	●	●	●	●
ABS [Antilock brake system Integral-ABS FTE]	●	●	●	●	●
ABS [Antilock braking systemABS1]	●	●	●	●	●
ABS [Antilock braking systemABS2]	●	●	●	●	●
ABS [Antilock braking systemABS5]	●	●	●	●	●
ABS [Antilock braking systemMK4G]	●	●	●	●	●
ABS [Bosch antilock brake system]	●	●	●	●	●
ABS [Conti antilock brake system]	●	●	●	●	●
ABS [Stability controlMK20]	●	●	●	●	●
ABS-DSC [Stability system EBC_450]	●	●	●	●	●
ABS-DSC [Stability system MK60]	●	●	●	●	●
ACC [Active cruise control]	●	●	●	●	●
ACP [Audio Control Panel]	●	●	●	●	●
ACSM [Crash safety module]	●	●	●	●	●
ACSM-MRS [Crash safety module/multiple restraint system]	●	●	●	●	●
ADP [Audio Display Panel]	●	●	●	●	●
ADS	●	●	●	●	●
AEP	●	●	●	●	●
AGS [Transmission control]	●	●	●	●	●
AHL [Adaptive Headlights/headlight beam throw adjustment]	●	●	●	●	●
AHL [Adaptive headlight/headlight beam throw adjustment]	●	●	●	●	●
AHM [Trailer module]	●	●	●	●	●
AIC [Automatic Interval Control]	●	●	●	●	●
AL [Active steering]	●	●	●	●	●
ALBBF [Active backrest width, front passenger]	●	●	●	●	●
ALBFA [Active backrest width, driver]	●	●	●	●	●
AMP [Hi-Fi amplifier]	●	●	●	●	●
AMP [Top HiFi amplifier]	●	●	●	●	●
AMPH [Hi-Fi amplifier]	●	●	●	●	●
AMPT [Top HiFi amplifier]	●	●	●	●	●
ANT [Aerial tuner]	●	●	●	●	●
APM [Hybrid DC/DC converter]	●	●	●	●	●
ARS [Dynamic drive]	●	●	●	●	●
ASC [Stability controlABD5]	●	●	●	●	●
ASC [Stability controlASC57]	●	●	●	●	●
ASC [Stability controlASC5D]	●	●	●	●	●
ASC [Stability controlASC5]	●	●	●	●	●
ASC [Stability controlMK20]	●	●	●	●	●
ASC [Stability controlMK4US]	●	●	●	●	●
ASC [Stability controlMK4]	●	●	●	●	●
ASC [Stability control]	●	●	●	●	●
ASD [Active sound design]	●	●	●	●	●
ASK [Audio system controller]	●	●	●	●	●
AUDIO [Audio system]	●	●	●	●	●
Automatic climate control	●	●	●	●	●
BATT48 [Battery electronics 48 volt]	●	●	●	●	●
BC [On-board computer]	●	●	●	●	●

BCM [Battery monitoring module]	●	●	●	●	●
BCO [On-board computer]	●	●	●	●	●
BCO/MID [On-board computer/MID]	●	●	●	●	●
BDC [Body Domain Controller]	●	●	●	●	●
BIT [Basic interface telephone]	●	●	●	●	●
BM [On-board monitor control panel]	●	●	●	●	●
BM [On-board monitor, Top navigation]	●	●	●	●	●
BM [On-board monitor, widescreen]	●	●	●	●	●
BM [On-board monitor]	●	●	●	●	●
BZM [Centre console control panel]	●	●	●	●	●
BZMF [Control centre, rear compartment centre armrest]	●	●	●	●	●
CA [Comfort Access]	●	●	●	●	●
CANALLG	●	●	●	●	●
CANWAY	●	●	●	●	●
CAN_PL2	●	●	●	●	●
CAS [Car Access System]	●	●	●	●	●
CBX-ECALL [Combox emergency call]	●	●	●	●	●
CBX-MEDIA [Combox Multimedia]	●	●	●	●	●
CCC-A [Applications]	●	●	●	●	●
CCC-ANT [Aerial tuner]	●	●	●	●	●
CCC-ASK [Audio system controller]	●	●	●	●	●
CCC-BO [User interface]	●	●	●	●	●
CCC-GW [Gateway]	●	●	●	●	●
CCM [Check control module]	●	●	●	●	●
CD [Control display]	●	●	●	●	●
CD-GW [Control Display (Gateway)]	●	●	●	●	●
CDC [CD changer]	●	●	●	●	●
CDM [Coach door module]	●	●	●	●	●
CDML [coach door module, left]	●	●	●	●	●
CDMR [coach door module, right]	●	●	●	●	●
CEM [Clean Energy Module]	●	●	●	●	●
CHAMP [Central head unit and multimedia platform]	●	●	●	●	●
CHAMP-BO [User interface]	●	●	●	●	●
CHAMP-GW [Gateway]	●	●	●	●	●
CHRONO [Chronometer]	●	●	●	●	●
CIC [Car Information Computer]	●	●	●	●	●
CIC-GW [Gateway]	●	●	●	●	●
CID [Central Information Display]	●	●	●	●	●
CID [Central information display]	●	●	●	●	●
CIM [Chassis integration module]	●	●	●	●	●
CNAV [Navigation system China]	●	●	●	●	●
CON [Controller]	●	●	●	●	●
CPM [CPM]	●	●	●	●	●
CSM [Car sharing module]	●	●	●	●	●
CTM [Convertible-top module]	●	●	●	●	●
CVM [Convertible-top module]	●	●	●	●	●
CVM2 [Convertible top module 2]	●	●	●	●	●
Carb	●	●	●	●	●
Complete vehicle	●	●	●	●	●
Convenience charging electronics	●	●	●	●	●
DAB [DAB tuner]	●	●	●	●	●
DCS [Driver Camera System]	●	●	●	●	●

DDC [Electronic suspension adjustment]	●	●	●	●	●
DDE [Diesel electronics US]	●	●	●	●	●
DDE [Diesel electronics master]	●	●	●	●	●
DDE [Diesel electronics slave]	●	●	●	●	●
DDE [Diesel fuel electronics]	●	●	●	●	●
DDE [Digital diesel electronics]	●	●	●	●	●
DDE2 [Diesel electronics slave]	●	●	●	●	●
DIA DOSE	●	●	●	●	●
DKG [Electronic transmission control]	●	●	●	●	●
DKG [Transmission control]	●	●	●	●	●
DME [Digital Motor Electronics]	●	●	●	●	●
DME [Digital engine electronics, cylinder bank 1]	●	●	●	●	●
DME [Engine control]	●	●	●	●	●
DME [Engine electronics H2, cylinder bank 1]	●	●	●	●	●
DME [Engine electronics, cylinder bank 1]	●	●	●	●	●
DME [Engine electronics]	●	●	●	●	●
DME2 [Digital Engine Electronics, bank 2]	●	●	●	●	●
DME2 [Digital Motor Electronics, cylinder bank 2]	●	●	●	●	●
DME2 [Engine electronics H2, cylinder bank 2]	●	●	●	●	●
DME2 [Engine electronics, cylinder bank 2]	●	●	●	●	●
DSC [Dynamic Stability Control DSC8 Plus]	●	●	●	●	●
DSC [Dynamic Stability Control]	●	●	●	●	●
DSC [Dynamic stability control DSC5.7]	●	●	●	●	●
DSC [Dynamic stability control DSC8 PLUS]	●	●	●	●	●
DSC [Dynamic stability controlDSC8]	●	●	●	●	●
DSC [Dynamic stability controlEHB3]	●	●	●	●	●
DSC [Dynamic stability controlMK60 E5]	●	●	●	●	●
DSC [Dynamic stability controlMK60]	●	●	●	●	●
DSC [Stability controlDSC3]	●	●	●	●	●
DSC [Stability controlDSC57]	●	●	●	●	●
DSC [Stability controlDSC5]	●	●	●	●	●
DSC [Stability controlMK20]	●	●	●	●	●
DSM [Hybrid parking lock]	●	●	●	●	●
DSP [DSP control panel]	●	●	●	●	●
DSP [Digital sound processor]	●	●	●	●	●
DVDC [DVD changer]	●	●	●	●	●
DWA [Anti-theft alarm system]	●	●	●	●	●
DWA-RDC [Anti-theft alarm system/tyre pressure control]	●	●	●	●	●
EARSH [Rear electric active roll stabilisation]	●	●	●	●	●
EARSV [Front electric active roll stabilisation]	●	●	●	●	●
EDC [Electronic Damper Control K]	●	●	●	●	●
EDC [Electronic Damper Control]	●	●	●	●	●
EDC [Vertical Dynamics Management]	●	●	●	●	●
EDCSHL [Damper satellite, rear left]	●	●	●	●	●
EDCSHR [Damper satellite, rear right]	●	●	●	●	●
EDCSVL [Damper satellite, front left]	●	●	●	●	●
EDCSVR [Damper satellite, front right]	●	●	●	●	●

EDIC	●	●	●	●	●
EDME [Electrical Digital Motor Electronics]	●	●	●	●	●
EGS [Electronic transmission control]	●	●	●	●	●
EGS [Transmission control]	●	●	●	●	●
EHC [- 1-axle air suspension]	●	●	●	●	●
EHC [- Axle air suspension]	●	●	●	●	●
EHC [2-axle air suspension]	●	●	●	●	●
EHC [Electronic ride height control]	●	●	●	●	●
EHC2 [2-axle air suspension]	●	●	●	●	●
EHC2 [Electronic ride height control]	●	●	●	●	●
EHKS [Electro-hydraulic centre stand]	●	●	●	●	●
EHPS [Electro-hydraulic power steering]	●	●	●	●	●
EKK [Electric A/C compressor]	●	●	●	●	●
EKPS [Electronic fuel pump control module]	●	●	●	●	●
EKPS [Fuel pump control module]	●	●	●	●	●
ELV [Electric steering lock]	●	●	●	●	●
ELV [Electrical steering column adjustment]	●	●	●	●	●
EMALI [Electric motor-driven reel, left]	●	●	●	●	●
EMARE [Electric motor-driven reel, right]	●	●	●	●	●
EME [Electrical machine electronics]	●	●	●	●	●
EMF [Parking brake]	●	●	●	●	●
EML [Electronic engine power control]	●	●	●	●	●
EMPI [Hybrid oil pump control unit]	●	●	●	●	●
ENS [Ethernet switch]	●	●	●	●	●
EPS [Electronic Power Steering]	●	●	●	●	●
EPS [electromechanical power steering]	●	●	●	●	●
ESA [Electronic suspension adjustment]	●	●	●	●	●
EWS [Electronic immobiliser 2]	●	●	●	●	●
EWS [Electronic immobiliser 3D]	●	●	●	●	●
EWS [Electronic immobiliser 3]	●	●	●	●	●
EWS [Electronic immobiliser]	●	●	●	●	●
Electrical machine electronics	●	●	●	●	●
Engine electronics	●	●	●	●	●
F01BN2K	●	●	●	●	●
FADP [Rear compartment audio display panel]	●	●	●	●	●
FBI [Flexible Bus Interface]	●	●	●	●	●
FBZV [Radio remote control]	●	●	●	●	●
FCON [Rear-compartment controller]	●	●	●	●	●
FD [Rear monitor]	●	●	●	●	●
FD2 [Rear compartment display 2]	●	●	●	●	●
FD2 [Rear display 2]	●	●	●	●	●
FEM [Front electronic module]	●	●	●	●	●
FGB [Rear compartment blower]	●	●	●	●	●
FGR [Cruise control]	●	●	●	●	●
FID [Rear passenger compartment multi-information display]	●	●	●	●	●
FKA [Automatic rear air-conditioning system]	●	●	●	●	●
FKA [Rear compartment heating and air conditioning system]	●	●	●	●	●
FKA [Rear-compartment air conditioning]	●	●	●	●	●
FLA [High-beam assistant]	●	●	●	●	●

FLEL [Frontal Light Electronics Left]	●	●	●	●	●
FLER [Frontal Light Electronics Right]	●	●	●	●	●
FMBT [Rear-compartment monitor]	●	●	●	●	●
FRM [Driver's side footwell module]	●	●	●	●	●
FRM [Footwell module]	●	●	●	●	●
FRS [Front radar sensor]	●	●	●	●	●
FRSF [Long-distance range front radar sensor]	●	●	●	●	●
FZD [Roof function centre]	●	●	●	●	●
FZGIDENT	●	●	●	●	●
GHAS [Adjusted limited slip differential]	●	●	●	●	●
GHAS [regulated rear axle differential lock]	●	●	●	●	●
GM [Basic module (BCL)]	●	●	●	●	●
GM [Basic module (BCO)]	●	●	●	●	●
GM [Basic module control unit]	●	●	●	●	●
GM [General Module 5]	●	●	●	●	●
GM [General module III]	●	●	●	●	●
GMS [Basic module satellite]	●	●	●	●	●
GMSF [Basic module special vehicle]	●	●	●	●	●
GR [Cruise control]	●	●	●	●	●
GRPLIST	●	●	●	●	●
GWS [Gear selector switch]	●	●	●	●	●
GZAL [Targeted illumination, left]	●	●	●	●	●
GZAR [Targeted illumination, right]	●	●	●	●	●
HCP [Hybrid master control unit]	●	●	●	●	●
HIM [Hybrid Interface Module]	●	●	●	●	●
HKA [Rear automatic climate control]	●	●	●	●	●
HKFM [Tailgate function module]	●	●	●	●	●
HKL [Automatic luggage compartment lid actuation]	●	●	●	●	●
HKL [Luggage compartment lid module]	●	●	●	●	●
HRSNL [Rear radar sensor near range left]	●	●	●	●	●
HRSNR [Rear radar sensor near range right]	●	●	●	●	●
HSR [Rear axle slip angle control]	●	●	●	●	●
HU-B [HU-B]	●	●	●	●	●
HU-H [Headunit High]	●	●	●	●	●
HUD [Head-Up Display]	●	●	●	●	●
IBOC [Digital tuner US]	●	●	●	●	●
ICM [Integrated chassis management]	●	●	●	●	●
IFR	●	●	●	●	●
IHKA [Automatic climate control]	●	●	●	●	●
IHKA [Integrated automatic heating / air conditioning system]	●	●	●	●	●
IHKR [Heating/air conditioning control]	●	●	●	●	●
IHKS [Heating/air conditioning control]	●	●	●	●	●
IHR [Heating control]	●	●	●	●	●
IHS [Heating control]	●	●	●	●	●
IHS [Heating/air conditioning control]	●	●	●	●	●
IKE [Instrument panel]	●	●	●	●	●
ILM [Integrated charging module]	●	●	●	●	●
IPOD [iPod interface]	●	●	●	●	●
IR [Infrared compact locking system]	●	●	●	●	●
IR [Radio/infrared locking system]	●	●	●	●	●

IRIS [Integrated radio information system]	●	●	●	●	●
JBE [Junction Box Electronics]	●	●	●	●	●
JBIT [Japan basic interface telephone 2]	●	●	●	●	●
JBIT [Japan basic interface telephone]	●	●	●	●	●
JNAV [Navigation, Japan]	●	●	●	●	●
KAFAS [Camera-based driver assist system]	●	●	●	●	●
KBM [Body general module]	●	●	●	●	●
KFS [Radiator figure control]	●	●	●	●	●
KGM [Body Gateway Module]	●	●	●	●	●
KHI [Headphones interface]	●	●	●	●	●
KLE [Charging interface module]	●	●	●	●	●
KLE [Convenience charging electronics]	●	●	●	●	●
KNAV [Navigation system Korea]	●	●	●	●	●
KOMBI [Instrument cluster RR]	●	●	●	●	●
KOMBI [Instrument panel control unitRR 2]	●	●	●	●	●
KOMBI [Instrument panel]	●	●	●	●	●
KOMBI2 [Additional instruments]	●	●	●	●	●
LCM [Lights/check module A]	●	●	●	●	●
LCM [Lights/check module III]	●	●	●	●	●
LCM [Lights/check module II]	●	●	●	●	●
LCM [Lights/check module IV]	●	●	●	●	●
LCM [Lights/check module]	●	●	●	●	●
LDM [Longitudinal dynamics management]	●	●	●	●	●
LEM [Light effect manager]	●	●	●	●	●
LHML [LED main light module, left]	●	●	●	●	●
LHMR [LED main light module, right]	●	●	●	●	●
LIM [Charging interface module]	●	●	●	●	●
LM [Light module]	●	●	●	●	●
LMV [Longitudinal torque distribution]	●	●	●	●	●
LRA [Headlight beam throw adjustment]	●	●	●	●	●
LRR [Long range radar]	●	●	●	●	●
LSZ [Light switch cluster]	●	●	●	●	●
LWS [Steering angle sensor]	●	●	●	●	●
M-ASK-BO [User interface]	●	●	●	●	●
M-ASK-GW [Gateway]	●	●	●	●	●
M-ASK-NAV [Navigation system]	●	●	●	●	●
MCPA [Hybrid electric motor control unit 1]	●	●	●	●	●
MCPB [Hybrid electric motor control unit 2]	●	●	●	●	●
MESSEMOD	●	●	●	●	●
MFL [Multifunction steering wheelE38]	●	●	●	●	●
MFL [Multifunction steering wheel]	●	●	●	●	●
MID [Multi-information display]	●	●	●	●	●
MIR [Multi-information radio]	●	●	●	●	●
MJOY [MINI joystick]	●	●	●	●	●
MMB [Multimedia box]	●	●	●	●	●
MOST [Bus system analysis]	●	●	●	●	●
MPM [Micro-power module]	●	●	●	●	●
MRK24	●	●	●	●	●
MRKH2	●	●	●	●	●
MRS [Multiple restraint system]	●	●	●	●	●
NAR [Navigation radio]	●	●	●	●	●

NAV [Navigation system]	●	●	●	●	●
NVE [Night vision electronics]	●	●	●	●	●
NVK [Night Vision Camera]	●	●	●	●	●
OBD	●	●	●	●	●
OC3_FLSH	●	●	●	●	●
OC3_UPD	●	●	●	●	●
OPPS	●	●	●	●	●
PCU [Power Control Unit]	●	●	●	●	●
PCU48 [Power Control Unit 48 volt]	●	●	●	●	●
PCode [Reporting mit CARBPR (California Air Resources Board)]	●	●	●	●	●
PDC [Park distance control]	●	●	●	●	●
PM [Power module]	●	●	●	●	●
PMA [Parking manoeuvre assistant]	●	●	●	●	●
PMA [Parking manoeuvring assistant]	●	●	●	●	●
QMVH [Rear axle lateral torque distribution]	●	●	●	●	●
QMVH [Transmission control]	●	●	●	●	●
R56	●	●	●	●	●
RAD [Radio]	●	●	●	●	●
RAD2 [Radio 2]	●	●	●	●	●
RAD2-GW [Gateway]	●	●	●	●	●
RADIO [Radio-CD player]	●	●	●	●	●
RAM [Receiver audio module]	●	●	●	●	●
RBT [Radio operating unit]	●	●	●	●	●
RCC [Radio clock module]	●	●	●	●	●
RDC [Tyre Pressure Monitor]	●	●	●	●	●
RDC [Tyre pressure control]	●	●	●	●	●
RDME [Range extender digital engine electronics]	●	●	●	●	●
REM [Rear electronic module]	●	●	●	●	●
REMALI [Reversible electromotive automatic reel, left]	●	●	●	●	●
REMARE [Reversible electromotive automatic reel, right]	●	●	●	●	●
REME [Range extender electrical machine electronics]	●	●	●	●	●
RFH [Reverser]	●	●	●	●	●
RFK [Reversing camera]	●	●	●	●	●
RLMAL [Rear light module outer left]	●	●	●	●	●
RLMAR [Rear light module outer right]	●	●	●	●	●
RLMIL [Rear light module inner left]	●	●	●	●	●
RLMIR [Rear light module inner right]	●	●	●	●	●
RLS [Rain/light sensor]	●	●	●	●	●
RLS [Rain/light solar sensor]	●	●	●	●	●
RPA [Run Flat Indicator]	●	●	●	●	●
RR1_2020	●	●	●	●	●
RSE [Rear seat entertainment system]	●	●	●	●	●
SAS [Optional extra system]	●	●	●	●	●
SASL [A-pillar satellite]	●	●	●	●	●
SASR [A-pillar satellite, right]	●	●	●	●	●
SBA [Hybrid brake actuation changeover]	●	●	●	●	●
SBBF [Front passenger seat occupancy]	●	●	●	●	●
SBE [Seat occupancy detection]	●	●	●	●	●
SBSL [B-pillar satellite, left]	●	●	●	●	●
SBSR [B-pillar satellite, right]	●	●	●	●	●

SCR [Selective Catalytic Reduction]	●	●	●	●	●
SDARS [Satellite tuner (US)]	●	●	●	●	●
SEC [Auxiliary control unit]	●	●	●	●	●
SEC2 [Auxiliary control unit 2]	●	●	●	●	●
SES [Voice control]	●	●	●	●	●
SFZ [Satellite, vehicle centre]	●	●	●	●	●
SG-FD [Rear-compartment display control unit]	●	●	●	●	●
SG-FD-GW [Control unit for rear compartment display (gateway)]	●	●	●	●	●
SGM-SIM [Safety and gateway module (SIM)]	●	●	●	●	●
SGM-ZGM [Safety and gateway module]	●	●	●	●	●
SGR48 [Starter motor generator 48 volt]	●	●	●	●	●
SHD [Panorama glass roof]	●	●	●	●	●
SHD [Slide/tilt sunroof]	●	●	●	●	●
SHD [Sunroof module]	●	●	●	●	●
SHZH [Indep./aux. heater]	●	●	●	●	●
SIM [Safety and Information Module]	●	●	●	●	●
SINE [Anti-theft alarm system]	●	●	●	●	●
SINE [siren and tilt alarm sensor]	●	●	●	●	●
SLM [Seat/steering column memory]	●	●	●	●	●
SM/LSM [Mirror/sea/backrest memory, 4-channel]	●	●	●	●	●
SM/LSM [Mirror/sea/backrest memory, 6-channel]	●	●	●	●	●
SMB [Easy entry, front passenger]	●	●	●	●	●
SMB [Seat memory for front passenger]	●	●	●	●	●
SMB [Seat memory, front passenger]	●	●	●	●	●
SMBF [Front passenger seat module]	●	●	●	●	●
SMBFH [Rear passenger's side seat module]	●	●	●	●	●
SMBFH [rear passenger seat module]	●	●	●	●	●
SME [Battery management electronics]	●	●	●	●	●
SMES1 [Battery management electronics]	●	●	●	●	●
SMES2 [Battery management electronics]	●	●	●	●	●
SME_82	●	●	●	●	●
SMF [Easy entry, driver]	●	●	●	●	●
SMF [Seat memory, driver]	●	●	●	●	●
SMFA [Seat module, driver]	●	●	●	●	●
SMFAH [Seat module, rear driver's side]	●	●	●	●	●
SMFAH [driver's seat module]	●	●	●	●	●
SMG [Transmission control]	●	●	●	●	●
SPMBT [Mirror memory, front passenger]	●	●	●	●	●
SPMFT [Mirror memory, driver]	●	●	●	●	●
SPNMHL [Rear left seat inflator module]	●	●	●	●	●
SPNMHR [Rear right seat inflator module]	●	●	●	●	●
SPNMVL [Front left seat inflator module]	●	●	●	●	●
SPNMVR [Front right seat inflator module]	●	●	●	●	●
SRSNVL [Side radar sensor near range front left]	●	●	●	●	●
SRSNVR [Side radar sensor near range front right]	●	●	●	●	●
SSBF [Satellite, seat, passenger]	●	●	●	●	●
SSFA [Satellite, seat, driver]	●	●	●	●	●
SSH [Rear seat satellite]	●	●	●	●	●
STH [Indep./aux. heater]	●	●	●	●	●

STML [Headlight driver module, left]	●	●	●	●	●
STMR [Headlight driver module, right]	●	●	●	●	●
STVL [Door satellite, front left]	●	●	●	●	●
STVR [Door satellite, front right]	●	●	●	●	●
SVA [Side View Assist]	●	●	●	●	●
SVS [Speech processing]	●	●	●	●	●
SVT [Servotronic]	●	●	●	●	●
SWE [Headlight electronics]	●	●	●	●	●
SWTUDS	●	●	●	●	●
SWW [Lane Change Warning]	●	●	●	●	●
SZL [Steering column switch cluster]	●	●	●	●	●
SZM [Centre console control panel]	●	●	●	●	●
TBX [Touchbox]	●	●	●	●	●
TCB [Telematic Communication Box]	●	●	●	●	●
TCM [Hybrid gearbox control unit]	●	●	●	●	●
TCU [Telematics control unit (I-bus)]	●	●	●	●	●
TCU [Telematics control unit]	●	●	●	●	●
TEL [Eject box/Interface telephone]	●	●	●	●	●
TEL [Telephone ECE]	●	●	●	●	●
TEL [Telephone USA]	●	●	●	●	●
TFE [Hybrid pressure refuelling electronic control unit]	●	●	●	●	●
TFE [Pressurized fuel tank control module]	●	●	●	●	●
TLC [Lane departure warning]	●	●	●	●	●
TM [Telematics]	●	●	●	●	●
TMBF [Door module, front passenger door]	●	●	●	●	●
TMBF [Door module, passenger]	●	●	●	●	●
TMBFH [Door module, rear passenger's side]	●	●	●	●	●
TMFA [Door module, driver]	●	●	●	●	●
TMFA [Driver's door module]	●	●	●	●	●
TMFAH [Rear driver's side door module]	●	●	●	●	●
TMODE	●	●	●	●	●
TOENS [Thermal oil-level sensor]	●	●	●	●	●
TOP-DSP [Digital sound processor]	●	●	●	●	●
TOP-DSP2 [Digital sound processor]	●	●	●	●	●
TRS [Electronic battery isolating switch]	●	●	●	●	●
TR SVC [All-round vision camera]	●	●	●	●	●
T_AUSB	●	●	●	●	●
T_GRTB	●	●	●	●	●
T_MSA	●	●	●	●	●
T_PCOD	●	●	●	●	●
T_SCOD	●	●	●	●	●
ULF [Universal charger and hands-free unit]	●	●	●	●	●
ULF-SBX [Interface box]	●	●	●	●	●
ULF-SBX-H [Interface box High]	●	●	●	●	●
URS [Rollover sensor]	●	●	●	●	●
UTILITY	●	●	●	●	●
VDM [Vertical Dynamics Management]	●	●	●	●	●
VDP [Vertical dynamics platform]	●	●	●	●	●
VIP [Virtual integration system]	●	●	●	●	●
VIRTSG90	●	●	●	●	●
VIRTSG91	●	●	●	●	●

VIRTSG92	●	●	●	●	●
VIRTSG93	●	●	●	●	●
VIRTSG98	●	●	●	●	●
VIRTSG9B	●	●	●	●	●
VM [Video module TV]	●	●	●	●	●
VM [Video module hybrid]	●	●	●	●	●
VM [Video module]	●	●	●	●	●
VM [Video switch]	●	●	●	●	●
VM-GT [Video module, graphics stage]	●	●	●	●	●
V0	●	●	●	●	●
VS [Video switch]	●	●	●	●	●
VSG [Vehicle Sound Generator]	●	●	●	●	●
VSG2 [Vehicle Sound Generator 2]	●	●	●	●	●
VSX [Video switch]	●	●	●	●	●
VTC [Valvetronic, bank 1]	●	●	●	●	●
VTC2 [Valvetronic bank 2]	●	●	●	●	●
VTG [Transfer box]	●	●	●	●	●
W2V	●	●	●	●	●
WIM [Wiper module]	●	●	●	●	●
X_K001	●	●	●	●	●
X_KS01	●	●	●	●	●
ZBM [Two-battery management]	●	●	●	●	●
ZCS_ALL	●	●	●	●	●
ZFE [Central chassis electronics]	●	●	●	●	●
ZGM [Central gateway module]	●	●	●	●	●
ZGM2 [Central gateway module 2]	●	●	●	●	●

RollsRoyce Diagnostic Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

RollsRoyce Car List

Series	Development code	Sales designation
Rolls-Royce	RR1	Phantom
Rolls-Royce	RR1	Phantom Extended Wheelbase
Rolls-Royce	RR11	ALL
Rolls-Royce	RR12	ALL
Rolls-Royce	RR2	ALL
Rolls-Royce	RR3	ALL
Rolls-Royce	RR31	ALL
Rolls-Royce	RR4	GHOST
Rolls-Royce	RR4	Ghost Extended Wheelbase
Rolls-Royce	RR5	ALL
Rolls-Royce	RR6	ALL

RollsRoyce Ecu List

System Name	Ecu Info	Read Codes	Erase Codes	Live Data	Act
AB [Airbag]	●	●	●	●	●
ABS [Antilock brake system FTE]	●	●	●	●	●
ABS [Antilock brake system Integral-ABS FTE]	●	●	●	●	●
ABS [Antilock braking systemABS1]	●	●	●	●	●
ABS [Antilock braking systemABS2]	●	●	●	●	●
ABS [Antilock braking systemABS5]	●	●	●	●	●
ABS [Antilock braking systemMK4G]	●	●	●	●	●
ABS [Bosch antilock brake system]	●	●	●	●	●
ABS [Conti antilock brake system]	●	●	●	●	●
ABS [Stability controlMK20]	●	●	●	●	●
ABS-DSC [Stability system EBC_450]	●	●	●	●	●
ABS-DSC [Stability system MK60]	●	●	●	●	●
ACC [Active cruise control]	●	●	●	●	●
ACP [Audio Control Panel]	●	●	●	●	●
ACSM [Crash safety module]	●	●	●	●	●
ACSM-MRS [Crash safety module/multiple restraint system]	●	●	●	●	●
ADP [Audio Display Panel]	●	●	●	●	●
ADS	●	●	●	●	●
AEP	●	●	●	●	●
AGS [Transmission control]	●	●	●	●	●
AHL [Adaptive Headlights/headlight beam throw adjustment]	●	●	●	●	●
AHL [Adaptive headlight/headlight beam throw adjustment]	●	●	●	●	●
AHM [Trailer module]	●	●	●	●	●
AIC [Automatic Interval Control]	●	●	●	●	●
AL [Active steering]	●	●	●	●	●
ALBBF [Active backrest width, front passenger]	●	●	●	●	●
ALBFA [Active backrest width, driver]	●	●	●	●	●

AMP [Hi-Fi amplifier]	●	●	●	●	●
AMP [Top HiFi amplifier]	●	●	●	●	●
AMPH [Hi-Fi amplifier]	●	●	●	●	●
AMPT [Top HiFi amplifier]	●	●	●	●	●
ANT [Aerial tuner]	●	●	●	●	●
APM [Hybrid DC/DC converter]	●	●	●	●	●
ARS [Dynamic drive]	●	●	●	●	●
ASC [Stability controlABD5]	●	●	●	●	●
ASC [Stability controlASC57]	●	●	●	●	●
ASC [Stability controlASC5D]	●	●	●	●	●
ASC [Stability controlASC5]	●	●	●	●	●
ASC [Stability controlMK20]	●	●	●	●	●
ASC [Stability controlMK4US]	●	●	●	●	●
ASC [Stability controlMK4]	●	●	●	●	●
ASC [Stability control]	●	●	●	●	●
ASD [Active sound design]	●	●	●	●	●
ASK [Audio system controller]	●	●	●	●	●
AUDIO [Audio system]	●	●	●	●	●
Automatic climate control	●	●	●	●	●
BATT48 [Battery electronics 48 volt]	●	●	●	●	●
BC [On-board computer]	●	●	●	●	●
BCM [Battery monitoring module]	●	●	●	●	●
BCO [On-board computer]	●	●	●	●	●
BCO/MID [On-board computer/MID]	●	●	●	●	●
BDC [Body Domain Controller]	●	●	●	●	●
BIT [Basic interface telephone]	●	●	●	●	●
BM [On-board monitor control panel]	●	●	●	●	●
BM [On-board monitor, Top navigation]	●	●	●	●	●
BM [On-board monitor, widescreen]	●	●	●	●	●
BM [On-board monitor]	●	●	●	●	●
BZM [Centre console control panel]	●	●	●	●	●
BZMF [Control centre, rear compartment centre armrest]	●	●	●	●	●
CA [Comfort Access]	●	●	●	●	●
CANALLG	●	●	●	●	●
CANWAY	●	●	●	●	●
CAN_PL2	●	●	●	●	●
CAS [Car Access System]	●	●	●	●	●
CBX-ECALL [Combox emergency call]	●	●	●	●	●
CBX-MEDIA [Combox Multimedia]	●	●	●	●	●
CCC-A [Applications]	●	●	●	●	●
CCC-ANT [Aerial tuner]	●	●	●	●	●
CCC-ASK [Audio system controller]	●	●	●	●	●
CCC-BO [User interface]	●	●	●	●	●
CCC-GW [Gateway]	●	●	●	●	●
CCM [Check control module]	●	●	●	●	●
CD [Control display]	●	●	●	●	●
CD-GW [Control Display (Gateway)]	●	●	●	●	●
CDC [CD changer]	●	●	●	●	●
CDM [Coach door module]	●	●	●	●	●
CDML [coach door module, left]	●	●	●	●	●
CDMR [coach door module, right]	●	●	●	●	●
CEM [Clean Energy Module]	●	●	●	●	●

CHAMP [Central head unit and multimedia platform]	●	●	●	●	●
CHAMP-BO [User interface]	●	●	●	●	●
CHAMP-GW [Gateway]	●	●	●	●	●
CHRONO [Chronometer]	●	●	●	●	●
CIC [Car Information Computer]	●	●	●	●	●
CIC-GW [Gateway]	●	●	●	●	●
CID [Central Information Display]	●	●	●	●	●
CID [Central information display]	●	●	●	●	●
CIM [Chassis integration module]	●	●	●	●	●
CNAV [Navigation system China]	●	●	●	●	●
CON [Controller]	●	●	●	●	●
CPM [CPM]	●	●	●	●	●
CSM [Car sharing module]	●	●	●	●	●
CTM [Convertible-top module]	●	●	●	●	●
CVM [Convertible-top module]	●	●	●	●	●
CVM2 [Convertible top module 2]	●	●	●	●	●
Carb	●	●	●	●	●
Complete vehicle	●	●	●	●	●
Convenience charging electronics	●	●	●	●	●
DAB [DAB tuner]	●	●	●	●	●
DCS [Driver Camera System]	●	●	●	●	●
DDC [Electronic suspension adjustment]	●	●	●	●	●
DDE [Diesel electronics US]	●	●	●	●	●
DDE [Diesel electronics master]	●	●	●	●	●
DDE [Diesel electronics slave]	●	●	●	●	●
DDE [Diesel fuel electronics]	●	●	●	●	●
DDE [Digital diesel electronics]	●	●	●	●	●
DDE2 [Diesel electronics slave]	●	●	●	●	●
DIA_DOSE	●	●	●	●	●
DKG [Electronic transmission control]	●	●	●	●	●
DKG [Transmission control]	●	●	●	●	●
DME [Digital Motor Electronics]	●	●	●	●	●
DME [Digital engine electronics, cylinder bank 1]	●	●	●	●	●
DME [Engine control]	●	●	●	●	●
DME [Engine electronics H2, cylinder bank 1]	●	●	●	●	●
DME [Engine electronics, cylinder bank 1]	●	●	●	●	●
DME [Engine electronics]	●	●	●	●	●
DME2 [Digital Engine Electronics, bank 2]	●	●	●	●	●
DME2 [Digital Motor Electronics, cylinder bank 2]	●	●	●	●	●
DME2 [Engine electronics H2, cylinder bank 2]	●	●	●	●	●
DME2 [Engine electronics, cylinder bank 2]	●	●	●	●	●
DSC [Dynamic Stability Control DSC8 Plus]	●	●	●	●	●
DSC [Dynamic Stability Control]	●	●	●	●	●
DSC [Dynamic stability control DSC5.7]	●	●	●	●	●
DSC [Dynamic stability control DSC8 PLUS]	●	●	●	●	●
DSC [Dynamic stability controlDSC8]	●	●	●	●	●
DSC [Dynamic stability controlEHB3]	●	●	●	●	●
DSC [Dynamic stability controlMK60 E5]	●	●	●	●	●

DSC [Dynamic stability controlMK60]	●	●	●	●	●
DSC [Stability controlDSC3]	●	●	●	●	●
DSC [Stability controlDSC57]	●	●	●	●	●
DSC [Stability controlDSC5]	●	●	●	●	●
DSC [Stability controlMK20]	●	●	●	●	●
DSM [Hybrid parking lock]	●	●	●	●	●
DSP [DSP control panel]	●	●	●	●	●
DSP [Digital sound processor]	●	●	●	●	●
DVDC [DVD changer]	●	●	●	●	●
DWA [Anti-theft alarm system]	●	●	●	●	●
DWA-RDC [Anti-theft alarm system/tyre pressure control]	●	●	●	●	●
EARSH [Rear electric active roll stabilisation]	●	●	●	●	●
EARSV [Front electric active roll stabilisation]	●	●	●	●	●
EDC [Electronic Damper Control K]	●	●	●	●	●
EDC [Electronic Damper Control]	●	●	●	●	●
EDC [Vertical Dynamics Management]	●	●	●	●	●
EDCSHL [Damper satellite, rear left]	●	●	●	●	●
EDCSHR [Damper satellite, rear right]	●	●	●	●	●
EDCSVL [Damper satellite, front left]	●	●	●	●	●
EDCSVR [Damper satellite, front right]	●	●	●	●	●
EDIC	●	●	●	●	●
EDME [Electrical Digital Motor Electronics]	●	●	●	●	●
EGS [Electronic transmission control]	●	●	●	●	●
EGS [Transmission control]	●	●	●	●	●
EHC [- 1-axle air suspension]	●	●	●	●	●
EHC [- Axle air suspension]	●	●	●	●	●
EHC [2-axle air suspension]	●	●	●	●	●
EHC [Electronic ride height control]	●	●	●	●	●
EHC2 [2-axle air suspension]	●	●	●	●	●
EHC2 [Electronic ride height control]	●	●	●	●	●
EHKS [Electro-hydraulic centre stand]	●	●	●	●	●
EHPS [Electro-hydraulic power steering]	●	●	●	●	●
EKK [Electric A/C compressor]	●	●	●	●	●
EKPS [Electronic fuel pump control module]	●	●	●	●	●
EKPS [Fuel pump control module]	●	●	●	●	●
ELV [Electric steering lock]	●	●	●	●	●
ELV [Electrical steering column adjustment]	●	●	●	●	●
EMALI [Electric motor-driven reel, left]	●	●	●	●	●
EMARE [Electric motor-driven reel, right]	●	●	●	●	●
EME [Electrical machine electronics]	●	●	●	●	●
EMF [Parking brake]	●	●	●	●	●
EML [Electronic engine power control]	●	●	●	●	●
EMPI [Hybrid oil pump control unit]	●	●	●	●	●
ENS [Ethernet switch]	●	●	●	●	●
EPS [Electronic Power Steering]	●	●	●	●	●
EPS [electromechanical power steering]	●	●	●	●	●
ESA [Electronic suspension adjustment]	●	●	●	●	●
EWS [Electronic immobiliser 2]	●	●	●	●	●
EWS [Electronic immobiliser 3D]	●	●	●	●	●
EWS [Electronic immobiliser 3]	●	●	●	●	●

EWS [Electronic immobiliser]	●	●	●	●	●
Electrical machine electronics	●	●	●	●	●
Engine electronics	●	●	●	●	●
F01BN2K	●	●	●	●	●
FADP [Rear compartment audio display panel]	●	●	●	●	●
FBI [Flexible Bus Interface]	●	●	●	●	●
FBZV [Radio remote control]	●	●	●	●	●
FCON [Rear-compartment controller]	●	●	●	●	●
FD [Rear monitor]	●	●	●	●	●
FD2 [Rear compartment display 2]	●	●	●	●	●
FD2 [Rear display 2]	●	●	●	●	●
FEM [Front electronic module]	●	●	●	●	●
FGB [Rear compartment blower]	●	●	●	●	●
FGR [Cruise control]	●	●	●	●	●
FID [Rear passenger compartment multi-information display]	●	●	●	●	●
FKA [Automatic rear air-conditioning system]	●	●	●	●	●
FKA [Rear compartment heating and air conditioning system]	●	●	●	●	●
FKA [Rear-compartment air conditioning]	●	●	●	●	●
FLA [High-beam assistant]	●	●	●	●	●
FLEL [Frontal Light Electronics Left]	●	●	●	●	●
FLER [Frontal Light Electronics Right]	●	●	●	●	●
FMBT [Rear-compartment monitor]	●	●	●	●	●
FRM [Driver's side footwell module]	●	●	●	●	●
FRM [Footwell module]	●	●	●	●	●
FRS [Front radar sensor]	●	●	●	●	●
FRSF [Long-distance range front radar sensor]	●	●	●	●	●
FZD [Roof function centre]	●	●	●	●	●
FZGIDENT	●	●	●	●	●
GHAS [Adjusted limited slip differential]	●	●	●	●	●
GHAS [regulated rear axle differential lock]	●	●	●	●	●
GM [Basic module (BCL)]	●	●	●	●	●
GM [Basic module (BCO)]	●	●	●	●	●
GM [Basic module control unit]	●	●	●	●	●
GM [General Module 5]	●	●	●	●	●
GM [General module III]	●	●	●	●	●
GMS [Basic module satellite]	●	●	●	●	●
GMSF [Basic module special vehicle]	●	●	●	●	●
GR [Cruise control]	●	●	●	●	●
GRPLIST	●	●	●	●	●
GWS [Gear selector switch]	●	●	●	●	●
GZAL [Targeted illumination, left]	●	●	●	●	●
GZAR [Targeted illumination, right]	●	●	●	●	●
HCP [Hybrid master control unit]	●	●	●	●	●
HIM [Hybrid Interface Module]	●	●	●	●	●
HKA [Rear automatic climate control]	●	●	●	●	●
HKFM [Tailgate function module]	●	●	●	●	●
HKL [Automatic luggage compartment lid actuation]	●	●	●	●	●
HKL [Luggage compartment lid module]	●	●	●	●	●
HRSNL [Rear radar sensor near range left]	●	●	●	●	●

HRSNR [Rear radar sensor near range right]	●	●	●	●	●
HSR [Rear axle slip angle control]	●	●	●	●	●
HU-B [HU-B]	●	●	●	●	●
HU-H [Headunit High]	●	●	●	●	●
HUD [Head-Up Display]	●	●	●	●	●
IBOC [Digital tuner US]	●	●	●	●	●
ICM [Integrated chassis management]	●	●	●	●	●
IFR	●	●	●	●	●
IHKA [Automatic climate control]	●	●	●	●	●
IHKA [Integrated automatic heating / air conditioning system]	●	●	●	●	●
IHKR [Heating/air conditioning control]	●	●	●	●	●
IHKS [Heating/air conditioning control]	●	●	●	●	●
IHR [Heating control]	●	●	●	●	●
IHS [Heating control]	●	●	●	●	●
IHS [Heating/air conditioning control]	●	●	●	●	●
IKE [Instrument panel]	●	●	●	●	●
ILM [Integrated charging module]	●	●	●	●	●
IPOD [iPod interface]	●	●	●	●	●
IR [Infrared compact locking system]	●	●	●	●	●
IR [Radio/infrared locking system]	●	●	●	●	●
IRIS [Integrated radio information system]	●	●	●	●	●
JBE [Junction Box Electronics]	●	●	●	●	●
JBIT [Japan basic interface telephone 2]	●	●	●	●	●
JBIT [Japan basic interface telephone]	●	●	●	●	●
JNAV [Navigation, Japan]	●	●	●	●	●
KAFAS [Camera-based driver assist system]	●	●	●	●	●
KBM [Body general module]	●	●	●	●	●
KFS [Radiator figure control]	●	●	●	●	●
KGM [Body Gateway Module]	●	●	●	●	●
KHI [Headphones interface]	●	●	●	●	●
KLE [Charging interface module]	●	●	●	●	●
KLE [Convenience charging electronics]	●	●	●	●	●
KNAV [Navigation system Korea]	●	●	●	●	●
KOMBI [Instrument cluster RR]	●	●	●	●	●
KOMBI [Instrument panel control unitRR 2]	●	●	●	●	●
KOMBI [Instrument panel]	●	●	●	●	●
KOMBI2 [Additional instruments]	●	●	●	●	●
LCM [Lights/check module A]	●	●	●	●	●
LCM [Lights/check module III]	●	●	●	●	●
LCM [Lights/check module II]	●	●	●	●	●
LCM [Lights/check module IV]	●	●	●	●	●
LCM [Lights/check module]	●	●	●	●	●
LDM [Longitudinal dynamics management]	●	●	●	●	●
LEM [Light effect manager]	●	●	●	●	●
LHML [LED main light module, left]	●	●	●	●	●
LHMR [LED main light module, right]	●	●	●	●	●
LIM [Charging interface module]	●	●	●	●	●
LM [Light module]	●	●	●	●	●
LMV [Longitudinal torque distribution]	●	●	●	●	●
LRA [Headlight beam throw adjustment]	●	●	●	●	●
LRR [Long range radar]	●	●	●	●	●

LSZ [Light switch cluster]	●	●	●	●	●
LWS [Steering angle sensor]	●	●	●	●	●
M-ASK-B0 [User interface]	●	●	●	●	●
M-ASK-GW [Gateway]	●	●	●	●	●
M-ASK-NAV [Navigation system]	●	●	●	●	●
MCPA [Hybrid electric motor control unit 1]	●	●	●	●	●
MCPB [Hybrid electric motor control unit 2]	●	●	●	●	●
MESSEMOD	●	●	●	●	●
MFL [Multifunction steering wheelE38]	●	●	●	●	●
MFL [Multifunction steering wheel]	●	●	●	●	●
MID [Multi-information display]	●	●	●	●	●
MIR [Multi-information radio]	●	●	●	●	●
MJOY [MINI joystick]	●	●	●	●	●
MMB [Multimedia box]	●	●	●	●	●
MOST [Bus system analysis]	●	●	●	●	●
MPM [Micro-power module]	●	●	●	●	●
MRK24	●	●	●	●	●
MRKH2	●	●	●	●	●
MRS [Multiple restraint system]	●	●	●	●	●
NAR [Navigation radio]	●	●	●	●	●
NAV [Navigation system]	●	●	●	●	●
NVE [Night vision electronics]	●	●	●	●	●
NVK [Night Vision Camera]	●	●	●	●	●
OBD	●	●	●	●	●
OC3_FLSH	●	●	●	●	●
OC3_UPD	●	●	●	●	●
OPPS	●	●	●	●	●
PCU [Power Control Unit]	●	●	●	●	●
PCU48 [Power Control Unit 48 volt]	●	●	●	●	●
PCode [Reporting mit CARBPR (California Air Resources Board)]	●	●	●	●	●
PDC [Park distance control]	●	●	●	●	●
PM [Power module]	●	●	●	●	●
PMA [Parking manoeuvre assistant]	●	●	●	●	●
PMA [Parking manoeuvring assistant]	●	●	●	●	●
QMVH [Rear axle lateral torque distribution]	●	●	●	●	●
QMVH [Transmission control]	●	●	●	●	●
R56	●	●	●	●	●
RAD [Radio]	●	●	●	●	●
RAD2 [Radio 2]	●	●	●	●	●
RAD2-GW [Gateway]	●	●	●	●	●
RADIO [Radio-CD player]	●	●	●	●	●
RAM [Receiver audio module]	●	●	●	●	●
RBT [Radio operating unit]	●	●	●	●	●
RCC [Radio clock module]	●	●	●	●	●
RDC [Tyre Pressure Monitor]	●	●	●	●	●
RDC [Tyre pressure control]	●	●	●	●	●
RDME [Range extender digital engine electronics]	●	●	●	●	●
REM [Rear electronic module]	●	●	●	●	●
REMA LI [Reversible electromotive automatic reel, left]	●	●	●	●	●
REMARE [Reversible electromotive automatic reel, right]	●	●	●	●	●

REME [Range extender electrical machine electronics]	●	●	●	●	●
RFH [Reverser]	●	●	●	●	●
RFK [Reversing camera]	●	●	●	●	●
RLMAL [Rear light module outer left]	●	●	●	●	●
RLMAR [Rear light module outer right]	●	●	●	●	●
RLMIL [Rear light module inner left]	●	●	●	●	●
RLMIR [Rear light module inner right]	●	●	●	●	●
RLS [Rain/light sensor]	●	●	●	●	●
RLS [Rain/light solar sensor]	●	●	●	●	●
RPA [Run Flat Indicator]	●	●	●	●	●
RR1_2020	●	●	●	●	●
RSE [Rear seat entertainment system]	●	●	●	●	●
SAS [Optional extra system]	●	●	●	●	●
SASL [A-pillar satellite]	●	●	●	●	●
SASR [A-pillar satellite, right]	●	●	●	●	●
SBA [Hybrid brake actuation changeover]	●	●	●	●	●
SBBF [Front passenger seat occupancy]	●	●	●	●	●
SBE [Seat occupancy detection]	●	●	●	●	●
SBSL [B-pillar satellite, left]	●	●	●	●	●
SBSR [B-pillar satellite, right]	●	●	●	●	●
SCR [Selective Catalytic Reduction]	●	●	●	●	●
SDARS [Satellite tuner (US)]	●	●	●	●	●
SEC [Auxiliary control unit]	●	●	●	●	●
SEC2 [Auxiliary control unit 2]	●	●	●	●	●
SES [Voice control]	●	●	●	●	●
SFZ [Satellite, vehicle centre]	●	●	●	●	●
SG-FD [Rear-compartment display control unit]	●	●	●	●	●
SG-FD-GW [Control unit for rear compartment display (gateway)]	●	●	●	●	●
SGM-SIM [Safety and gateway module (SIM)]	●	●	●	●	●
SGM-ZGM [Safety and gateway module]	●	●	●	●	●
SGR48 [Starter motor generator 48 volt]	●	●	●	●	●
SHD [Panorama glass roof]	●	●	●	●	●
SHD [Slide/tilt sunroof]	●	●	●	●	●
SHD [Sunroof module]	●	●	●	●	●
SHZH [Indep./aux. heater]	●	●	●	●	●
SIM [Safety and Information Module]	●	●	●	●	●
SINE [Anti-theft alarm system]	●	●	●	●	●
SINE [siren and tilt alarm sensor]	●	●	●	●	●
SLM [Seat/steering column memory]	●	●	●	●	●
SM/LSM [Mirror/sea/backrest memory, 4-channel]	●	●	●	●	●
SM/LSM [Mirror/sea/backrest memory, 6-channel]	●	●	●	●	●
SMB [Easy entry, front passenger]	●	●	●	●	●
SMB [Seat memory for front passenger]	●	●	●	●	●
SMB [Seat memory, front passenger]	●	●	●	●	●
SMBF [Front passenger seat module]	●	●	●	●	●
SMBFH [Rear passenger's side seat module]	●	●	●	●	●
SMBFH [rear passenger seat module]	●	●	●	●	●
SME [Battery management electronics]	●	●	●	●	●
SMES1 [Battery management electronics]	●	●	●	●	●
SMES2 [Battery management electronics]	●	●	●	●	●

SME 82	●	●	●	●	●
SMF [Easy entry, driver]	●	●	●	●	●
SMF [Seat memory, driver]	●	●	●	●	●
SMFA [Seat module, driver]	●	●	●	●	●
SMFAH [Seat module, rear driver's side]	●	●	●	●	●
SMFAH [driver's seat module]	●	●	●	●	●
SMG [Transmission control]	●	●	●	●	●
SPMBT [Mirror memory, front passenger]	●	●	●	●	●
SPMFT [Mirror memory, driver]	●	●	●	●	●
SPNMHL [Rear left seat inflator module]	●	●	●	●	●
SPNMHR [Rear right seat inflator module]	●	●	●	●	●
SPNMVL [Front left seat inflator module]	●	●	●	●	●
SPNMVR [Front right seat inflator module]	●	●	●	●	●
SRSNVL [Side radar sensor near range front left]	●	●	●	●	●
SRSNVR [Side radar sensor near range front right]	●	●	●	●	●
SSBF [Satellite, seat, passenger]	●	●	●	●	●
SSFA [Satellite, seat, driver]	●	●	●	●	●
SSH [Rear seat satellite]	●	●	●	●	●
STH [Indep./aux. heater]	●	●	●	●	●
STML [Headlight driver module, left]	●	●	●	●	●
STMR [Headlight driver module, right]	●	●	●	●	●
STVL [Door satellite, front left]	●	●	●	●	●
STVR [Door satellite, front right]	●	●	●	●	●
SVA [Side View Assist]	●	●	●	●	●
SVS [Speech processing]	●	●	●	●	●
SVT [Servotronic]	●	●	●	●	●
SWE [Headlight electronics]	●	●	●	●	●
SWTUDS	●	●	●	●	●
SWW [Lane Change Warning]	●	●	●	●	●
SZL [Steering column switch cluster]	●	●	●	●	●
SZM [Centre console control panel]	●	●	●	●	●
TBX [Touchbox]	●	●	●	●	●
TCB [Telematic Communication Box]	●	●	●	●	●
TCM [Hybrid gearbox control unit]	●	●	●	●	●
TCU [Telematics control unit (I-bus)]	●	●	●	●	●
TCU [Telematics control unit]	●	●	●	●	●
TEL [Eject box/Interface telephone]	●	●	●	●	●
TEL [Telephone ECE]	●	●	●	●	●
TEL [Telephone USA]	●	●	●	●	●
TFE [Hybrid pressure refuelling electronic control unit]	●	●	●	●	●
TFE [Pressurized fuel tank control module]	●	●	●	●	●
TLC [Lane departure warning]	●	●	●	●	●
TM [Telematics]	●	●	●	●	●
TMBF [Door module, front passenger door]	●	●	●	●	●
TMBF [Door module, passenger]	●	●	●	●	●
TMBFH [Door module, rear passenger's side]	●	●	●	●	●
TMFA [Door module, driver]	●	●	●	●	●
TMFA [Driver's door module]	●	●	●	●	●
TMFAH [Rear driver's side door module]	●	●	●	●	●
TMODE	●	●	●	●	●

TOENS [Thermal oil-level sensor]	●	●	●	●	●
TOP-DSP [Digital sound processor]	●	●	●	●	●
TOP-DSP2 [Digital sound processor]	●	●	●	●	●
TRS [Electronic battery isolating switch]	●	●	●	●	●
TR SVC [All-round vision camera]	●	●	●	●	●
T_AUSB	●	●	●	●	●
T_GRTB	●	●	●	●	●
T_MSA	●	●	●	●	●
T_PCOD	●	●	●	●	●
T_SCOD	●	●	●	●	●
ULF [Universal charger and hands-free unit]	●	●	●	●	●
ULF-SBX [Interface box]	●	●	●	●	●
ULF-SBX-H [Interface box High]	●	●	●	●	●
URS [Rollover sensor]	●	●	●	●	●
UTILITY	●	●	●	●	●
VDM [Vertical Dynamics Management]	●	●	●	●	●
VDP [Vertical dynamics platform]	●	●	●	●	●
VIP [Virtual integration system]	●	●	●	●	●
VIRTSG90	●	●	●	●	●
VIRTSG91	●	●	●	●	●
VIRTSG92	●	●	●	●	●
VIRTSG93	●	●	●	●	●
VIRTSG98	●	●	●	●	●
VIRTSG9B	●	●	●	●	●
VM [Video module TV]	●	●	●	●	●
VM [Video module hybrid]	●	●	●	●	●
VM [Video module]	●	●	●	●	●
VM [Video switch]	●	●	●	●	●
VM-GT [Video module, graphics stage]	●	●	●	●	●
VO	●	●	●	●	●
VS [Video switch]	●	●	●	●	●
VSG [Vehicle Sound Generator]	●	●	●	●	●
VSG2 [Vehicle Sound Generator 2]	●	●	●	●	●
VSW [Video switch]	●	●	●	●	●
VTC [Valvetronic, bank 1]	●	●	●	●	●
VTC2 [Valvetronic bank 2]	●	●	●	●	●
VTG [Transfer box]	●	●	●	●	●
W2V	●	●	●	●	●
WIM [Wiper module]	●	●	●	●	●
X_K001	●	●	●	●	●
X_KS01	●	●	●	●	●
ZBM [Two-battery management]	●	●	●	●	●
ZCS_ALL	●	●	●	●	●
ZFE [Central chassis electronics]	●	●	●	●	●
ZGM [Central gateway module]	●	●	●	●	●
ZGM2 [Central gateway module 2]	●	●	●	●	●